



General-Purpose AC Servo

MITSUBISHI SERVO AMPLIFIERS & MOTORS

MELSERVO-JE

General-Purpose Interface AC Servo

MODEL

MR-JE- A

SERVO AMPLIFIER

INSTRUCTION MANUAL

(POSITIONING MODE)

● Safety Instructions ●

Please read the instructions carefully before using the equipment.


To use the equipment correctly, do not attempt to install, operate, maintain, or inspect the equipment until you have read through this Instruction Manual, Installation guide, and appended documents carefully. Do not use the equipment until you have a full knowledge of the equipment, safety information and instructions. In this Instruction Manual, the safety instruction levels are classified into "WARNING" and "CAUTION".




Indicates that incorrect handling may cause hazardous conditions, resulting in death or severe injury.




Indicates that incorrect handling may cause hazardous conditions, resulting in medium or slight injury to personnel or may cause physical damage.

Note that the  CAUTION level may lead to a serious consequence depending on conditions. Please follow the instructions of both levels because they are important to personnel safety. What must not be done and what must be done are indicated by the following diagrammatic symbols.



Indicates what must not be done. For example, "No Fire" is indicated by .



Indicates what must be done. For example, grounding is indicated by .

In this Instruction Manual, instructions at a lower level than the above, instructions for other functions, and so on are classified into "POINT".

After reading this Instruction Manual, keep it accessible to the operator.

1. To prevent electric shock, note the following.

WARNING


- Before wiring and inspections, turn off the power and wait for 15 minutes or more until the charge lamp turns off. Otherwise, an electric shock may occur. In addition, when confirming whether the charge lamp is off or not, always confirm it from the front of the servo amplifier.
- Ground the servo amplifier and servo motor securely.
- Any person who is involved in wiring and inspection should be fully competent to do the work.
- Do not attempt to wire the servo amplifier and servo motor until they have been installed. Otherwise, it may cause an electric shock.
- Do not operate switches with wet hands. Otherwise, it may cause an electric shock.
- The cables should not be damaged, stressed, loaded, or pinched. Otherwise, it may cause an electric shock.
- To prevent an electric shock, always connect the protective earth (PE) terminal (marked \oplus) of the servo amplifier to the protective earth (PE) of the cabinet.
- To avoid an electric shock, insulate the connections of the power supply terminals.

2. To prevent fire, note the following.

CAUTION

- Install the servo amplifier, servo motor, and regenerative resistor on incombustible material. Installing them directly or close to combustibles will lead to smoke or a fire.
- Always connect a magnetic contactor between the power supply and the power supply (L1, L2, and L3) of the servo amplifier, in order to configure a circuit that shuts down the power supply on the side of the servo amplifier's power supply. If a magnetic contactor is not connected, continuous flow of a large current may cause smoke or a fire when the servo amplifier malfunctions.
- In order to configure a circuit that shuts down the power supply on the side of the servo amplifier's power supply, always connect one molded-case circuit breaker or fuse per servo amplifier between the power supply and the power supply (L1, L2, and L3) of a servo amplifier. If a molded-case circuit breaker or fuse is not connected, continuous flow of a large current may cause smoke or a fire when the servo amplifier malfunctions.
- When using a regenerative resistor, shut the power off with the alarm signal. Otherwise, a regenerative transistor malfunction or the like may overheat the regenerative resistor, causing smoke or a fire.
- When using a regenerative option with the MR-JE-40A to MR-JE-100A servo amplifier, remove the built-in regenerative resistor itself and wiring from the servo amplifier.
- Provide adequate protection to prevent screws and other conductive matter, oil and other combustible matter from entering the servo amplifier and servo motor.


3. To prevent injury, note the following.

 CAUTION	
<ul style="list-style-type: none"> ● Only the voltage specified in the Instruction Manual should be applied to each terminal. Otherwise, a burst, damage, etc. may occur. ● Connect cables to the correct terminals. Otherwise, a burst, damage, etc. may occur. ● Ensure that polarity (+/-) is correct. Otherwise, a burst, damage, etc. may occur. ● The servo amplifier heat sink, regenerative resistor, servo motor, etc. may be hot while the power is on, or for some time after power-off. Take safety measures, e.g. provide covers, to avoid accidentally touching the parts (cables, etc.) by hand. 	

4. Additional instructions

The following instructions should also be fully noted. Incorrect handling may cause a malfunction, injury, electric shock, fire, etc.


(1) Transportation and installation

 CAUTION																						
<ul style="list-style-type: none"> ● Transport the products correctly according to their mass. ● Stacking in excess of the specified number of product packages is not allowed. ● Do not hold the lead wire of the built-in regenerative resistor when transporting the servo amplifier. ● Install the servo amplifier and the servo motor in a load-bearing place in accordance with the Instruction Manual. ● Do not get on or put heavy load on the equipment. ● The equipment must be installed in the specified direction. ● Leave specified clearances between the servo amplifier and cabinet walls or other equipment. ● Do not install or operate the servo amplifier and servo motor which have been damaged or have any parts missing. ● Do not block the intake and exhaust areas of the servo amplifier. Otherwise, it may cause a malfunction. ● Do not drop or strike the servo amplifier and servo motor. Isolate them from all impact loads. ● When you keep or use the equipment, please fulfill the following environment. 																						
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 20%; text-align: center;">Item</th> <th style="width: 10%;"></th> <th style="width: 70%; text-align: center;">Environment</th> </tr> </thead> <tbody> <tr> <td rowspan="2" style="text-align: center; vertical-align: middle;">Ambient temperature</td> <td style="text-align: center;">Operation</td> <td style="text-align: center;">0 °C to 55 °C (non-freezing)</td> </tr> <tr> <td style="text-align: center;">Storage</td> <td style="text-align: center;">-20 °C to 65 °C (non-freezing)</td> </tr> <tr> <td rowspan="2" style="text-align: center; vertical-align: middle;">Ambient humidity</td> <td style="text-align: center;">Operation</td> <td rowspan="2" style="text-align: center;">90 %RH or less (non-condensing)</td> </tr> <tr> <td style="text-align: center;">Storage</td> </tr> <tr> <td colspan="2" style="text-align: center;">Ambience</td> <td style="text-align: center;">Indoors (no direct sunlight); no corrosive gas, inflammable gas, oil mist or dust</td> </tr> <tr> <td colspan="2" style="text-align: center;">Altitude</td> <td style="text-align: center;">1000 m or less above sea level</td> </tr> <tr> <td colspan="2" style="text-align: center;">Vibration resistance</td> <td style="text-align: center;">5.9 m/s², at 10 Hz to 55 Hz (directions of X, Y and Z axes)</td> </tr> </tbody> </table>		Item		Environment	Ambient temperature	Operation	0 °C to 55 °C (non-freezing)	Storage	-20 °C to 65 °C (non-freezing)	Ambient humidity	Operation	90 %RH or less (non-condensing)	Storage	Ambience		Indoors (no direct sunlight); no corrosive gas, inflammable gas, oil mist or dust	Altitude		1000 m or less above sea level	Vibration resistance		5.9 m/s ² , at 10 Hz to 55 Hz (directions of X, Y and Z axes)
Item		Environment																				
Ambient temperature	Operation	0 °C to 55 °C (non-freezing)																				
	Storage	-20 °C to 65 °C (non-freezing)																				
Ambient humidity	Operation	90 %RH or less (non-condensing)																				
	Storage																					
Ambience		Indoors (no direct sunlight); no corrosive gas, inflammable gas, oil mist or dust																				
Altitude		1000 m or less above sea level																				
Vibration resistance		5.9 m/s ² , at 10 Hz to 55 Hz (directions of X, Y and Z axes)																				
<ul style="list-style-type: none"> ● When the product has been stored for an extended period of time, contact your local sales office. ● When handling the servo amplifier, be careful about the edged parts such as corners of the servo amplifier. ● The servo amplifier must be installed in a metal cabinet. ● When fumigants that contain halogen materials, such as fluorine, chlorine, bromine, and iodine, are used for disinfecting and protecting wooden packaging from insects, they cause malfunction when entering our products. Please take necessary precautions to ensure that remaining materials from fumigant do not enter our products, or treat packaging with methods other than fumigation, such as heat treatment. Additionally, disinfect and protect wood from insects before packing the products. 																						


(2) Wiring

⚠ CAUTION

- When removing the CNP1 connector of the MR-JE-40A to MR-JE-100A servo amplifier, remove the lead wire of the built-in regenerative resistor from the CNP1 connector in advance.
- Wire the equipment correctly and securely. Otherwise, the servo motor may operate unexpectedly.
- Do not install a power capacitor, surge killer, or radio noise filter (optional FR-BIF) on the servo amplifier output side.
- To avoid a malfunction, connect the wires to the correct phase terminals (U, V, and W) of the servo amplifier and servo motor.
- Connect the servo amplifier power outputs (U, V, and W) to the servo motor power inputs (U, V, and W) directly. Do not let a magnetic contactor, etc. intervene. Otherwise, it may cause a malfunction.



- The connection diagrams in this Instruction Manual are shown for sink interfaces, unless stated otherwise.
- The surge absorbing diode installed to the DC relay for control output should be fitted in the specified direction. Otherwise, the emergency stop and other protective circuits may not operate.



- When the cable is not tightened enough to the terminal block, the cable or terminal block may generate heat because of the poor contact. Be sure to tighten the cable with specified torque.
- Connecting a servo motor of the wrong axis to U, V, W, or CN2 of the servo amplifier may cause a malfunction.

(3) Test run and adjustment

⚠ CAUTION

- Before operation, check and adjust the parameter settings. Improper settings may cause some machines to operate unexpectedly.
- Never make a drastic adjustment or change to the parameter values as doing so will make the operation unstable.
- Do not get close to moving parts during the servo-on status.

(4) Usage


⚠ CAUTION

- Provide an external emergency stop circuit to ensure that operation can be stopped and power switched off immediately.
- Do not disassemble, repair, or modify the equipment.
- Before resetting an alarm, make sure that the run signal of the servo amplifier is off in order to prevent a sudden restart. Otherwise, it may cause an accident.
- Use a noise filter, etc. to minimize the influence of electromagnetic interference. Electromagnetic interference may be given to the electronic equipment used near the servo amplifier.
- Burning or breaking a servo amplifier may cause a toxic gas. Do not burn or break it.
- Use the servo amplifier with the specified servo motor.
- The electromagnetic brake on the servo motor is designed to hold the motor shaft and should not be used for ordinary braking.
- For such reasons as service life and mechanical structure (e.g. where a ball screw and the servo motor are coupled via a timing belt), the electromagnetic brake may not hold the motor shaft. To ensure safety, install a stopper on the machine side.

(5) Corrective actions

⚠ CAUTION

- When a hazardous condition is assumed to occur due to a power failure or product malfunction, use a servo motor with an electromagnetic brake or an external brake to prevent the condition.
- Configure an electromagnetic brake circuit, which is activated by an external EMG stop switch.
Contacts must be opened when ALM (Malfunction) or MBR (Electromagnetic brake interlock) turns off.



- When an alarm occurs, eliminate its cause, ensure safety, and deactivate the alarm to restart operation.
- Provide an adequate protection to prevent unexpected restart after an instantaneous power failure.

(6) Maintenance, inspection and parts replacement

⚠ CAUTION

- With age, the electrolytic capacitor of the servo amplifier will deteriorate. To prevent a secondary accident due to a malfunction, it is recommended that the electrolytic capacitor be replaced every 10 years when it is used in general environment. For replacement, please contact your local sales office.
- When using the servo amplifier that has not been energized for an extended period of time, contact your local sales office.

(7) General instruction

- To illustrate details, the equipment in the diagrams of this Instruction Manual may have been drawn without covers and safety guards. When the equipment is operated, the covers and safety guards must be installed as specified. Operation must be performed in accordance with this Instruction Manual.

● DISPOSAL OF WASTE ●

Please dispose of this product in compliance with the following two applicable laws. The laws come into effect only in Japan. In a country other than Japan, local laws are prioritized. Please provide the following information by indicating it on the end product, etc. as necessary.

1. Requirements of the Act on the Promotion of Effective Utilization of Resources (so-called the Resource Recycling Promotion Law)

- (1) The product that is no longer needed should be recycled whenever possible.
- (2) Such a product is generally separated into iron scrap, electrical components, and others in the recycling process, and sold to scrap dealers. It is recommended that you separate the product as necessary and sell each separated item to appropriate dealers.

2. Requirements of the Waste Management and Public Cleansing Law (so-called the Waste Disposal Law)

- (1) It is recommended that you make efforts to reduce the amount of waste by recycling or selling the waste product as described in the preceding paragraph 1, etc.
- (2) When you cannot sell the waste product and therefore dispose of it, it must be treated as industrial waste specified in this law.
- (3) You need to subcontract the disposal of industrial waste to industrial waste disposal companies qualified by this law, and take proper actions including the waste manifest management.

Servo amplifier harmonic suppression measures

The servo amplifiers are subject to the "guidelines for harmonic suppression measures for customers who receive high voltage or extra high voltage electricity" (issued by the current Ministry of Economy, Trade and Industry). Customers to which the guidelines are applied need to check the necessity of harmonic suppression measures. When the threshold is exceeded, the measures are required.



EEP-ROM life

The number of write times to the EEP-ROM, which stores parameter settings, etc., is limited to 100,000. If the total number of the following operations exceeds 100,000, the servo amplifier may malfunction when the EEP-ROM reaches the end of its useful life.

- Write to the EEP-ROM due to parameter setting changes
- Write to the EEP-ROM due to device changes
- Write to the EEP-ROM due to point table setting changes
- Write to the EEP-ROM due to program setting changes

Compliance with global standards

Refer to appendix 2 for the compliance with global standards.

«About the manual»

You must have this Instruction Manual and the following manuals to use this servo. Ensure to prepare them to use the servo safely.

Relevant manuals

Manual name	Manual No.
MR-JE-_A Servo Amplifier Instruction Manual	SH(NA)030128
MR-JE-_A Servo Amplifier Instruction Manual (Modbus-RTU Protocol)	SH(NA)030177A
MELSERVO-JE Servo amplifier Instruction Manual (Troubleshooting)	SH(NA)030166
MELSERVO HG-KN_/HG-SN_ Servo Motor Instruction Manual	SH(NA)030135
EMC Installation Guidelines	IB(NA)67310

This Instruction Manual does not describe the following items. For the details of the items, refer to each chapter/section indicated in the detailed explanation field. "MR-JE-_A" means "MR-JE-_A Servo Amplifier Instruction Manual".

Item	Detailed explanation
Installation	MR-JE-_A Chapter 2
Normal gain adjustment	MR-JE-_A Chapter 6
Special adjustment functions	MR-JE-_A Chapter 7
Dimensions	MR-JE-_A Chapter 9
Characteristics	MR-JE-_A Chapter 10

«Cables used for wiring»

Wires mentioned in this Instruction Manual are selected based on the ambient temperature of 40 °C.

«U.S. customary units»

U.S. customary units are not shown in this manual. Convert the values if necessary according to the following table.

Quantity	SI (metric) unit	U.S. customary unit
Mass	1 [kg]	2.2046 [lb]
Length	1 [mm]	0.03937 [inch]
Torque	1 [N·m]	141.6 [oz·inch]
Moment of inertia	1 [$\times 10^{-4}$ kg·m ²]	5.4675 [oz·inch ²]
Load (thrust load/axial load)	1 [N]	0.2248 [lbf]
Temperature	N [°C] \times 9/5 + 32	N [°F]

CONTENTS

1. FUNCTIONS AND CONFIGURATION	1- 1 to 1- 8
1.1 For proper use of the positioning mode.....	1- 1
1.2 Positioning mode specification list.....	1- 2
1.3 Function list.....	1- 4
1.4 Configuration including peripheral equipment.....	1- 7
2. SIGNALS AND WIRING	2- 1 to 2-28
2.1 I/O signal connection example.....	2- 3
2.2 Connectors and pin assignment.....	2- 7
2.3 Signal (device) explanations.....	2-11
2.4 Analog override.....	2-24
2.5 Internal connection diagram.....	2-26
2.6 Power-on sequence.....	2-28
3. DISPLAY AND OPERATION SECTIONS	3- 1 to 3-24
3.1 MR-JE-_A.....	3- 1
3.1.1 Display flowchart.....	3- 1
3.1.2 Status display mode.....	3- 3
3.1.3 Diagnostic mode.....	3- 9
3.1.4 Alarm mode.....	3-12
3.1.5 Point table setting.....	3-14
3.1.6 Parameter mode.....	3-18
3.1.7 External I/O signal display.....	3-20
3.1.8 Output signal (DO) forced output.....	3-21
3.1.9 Single-step feed.....	3-22
3.1.10 Teaching function.....	3-24
4. HOW TO USE THE POINT TABLE	4- 1 to 4-70
4.1 Startup.....	4- 2
4.1.1 Power on and off procedures.....	4- 2
4.1.2 Stop.....	4- 2
4.1.3 Test operation.....	4- 3
4.1.4 Parameter setting.....	4- 4
4.1.5 Point table setting.....	4- 5
4.1.6 Actual operation.....	4- 5
4.1.7 Troubleshooting at start-up.....	4- 5
4.2 Automatic operation mode.....	4- 7
4.2.1 Automatic operation mode.....	4- 7
4.2.2 Automatic operation using point table.....	4-12
4.3 Manual operation mode.....	4-41
4.3.1 JOG operation.....	4-41
4.3.2 Manual pulse generator operation.....	4-43
4.4 Home position return mode.....	4-44
4.4.1 Outline of home position return.....	4-45

4.4.2	Dog type home position return	4-47
4.4.3	Count type home position return	4-49
4.4.4	Data set type home position return	4-51
4.4.5	Stopper type home position return	4-52
4.4.6	Home position ignorance (servo-on position as home position).....	4-54
4.4.7	Dog type rear end reference home position return	4-55
4.4.8	Count type front end reference home position return	4-57
4.4.9	Dog cradle type home position return	4-59
4.4.10	Dog type last Z-phase reference home position return	4-60
4.4.11	Dog type front end reference home position return type	4-62
4.4.12	Dogless Z-phase reference home position return type.....	4-64
4.4.13	Automatic retract function used for the home position return	4-65
4.4.14	Automatic positioning to home position function.....	4-66
4.5	Roll feed mode using the roll feed display function	4-67
4.6	Point table setting method	4-68
4.6.1	Setting procedure.....	4-68
4.6.2	Detailed setting window	4-70

5. HOW TO USE THE PROGRAM	5- 1 to 5-68
----------------------------------	---------------------

5.1	Startup	5- 1
5.1.1	Power on and off procedures	5- 1
5.1.2	Stop	5- 2
5.1.3	Test operation	5- 3
5.1.4	Parameter setting	5- 4
5.1.5	Actual operation	5- 5
5.1.6	Troubleshooting at start-up	5- 5
5.2	Program operation method	5- 6
5.2.1	Program operation method	5- 6
5.2.2	Program language.....	5- 7
5.2.3	Basic settings of signals and parameters	5-30
5.2.4	Timing chart of the program operation	5-32
5.3	Manual operation mode	5-34
5.3.1	JOG operation	5-34
5.3.2	Manual pulse generator operation	5-35
5.4	Home position return mode	5-37
5.4.1	Outline of home position return	5-37
5.4.2	Dog type home position return	5-40
5.4.3	Count type home position return	5-42
5.4.4	Data set type home position return	5-44
5.4.5	Stopper type home position return	5-45
5.4.6	Home position ignorance (servo-on position as home position).....	5-46
5.4.7	Dog type rear end reference home position return	5-47
5.4.8	Count type front end reference home position return	5-49
5.4.9	Dog cradle type home position return	5-51
5.4.10	Dog type last Z-phase reference home position return	5-53
5.4.11	Dog type front end reference home position return type	5-55
5.4.12	Dogless Z-phase reference home position return type.....	5-57
5.4.13	Automatic retract function used for the home position return	5-58
5.5	Serial communication operation	5-59
5.5.1	Positioning operation using the program	5-59

5.5.2 Multi-drop method (RS-422 communication)	5-60
5.5.3 Group specification	5-61
5.6 Incremental value command method	5-63
5.7 Roll feed mode using the roll feed display function	5-64
5.8 Program setting method	5-65
5.8.1 Setting procedure	5-65
5.8.2 Window for program edit	5-66
5.8.3 Indirect addressing window	5-67

6. APPLICATION OF FUNCTIONS	6- 1 to 6-22
------------------------------------	---------------------

6.1 Simple cam function.....	6- 1
6.1.1 Outline of simple cam function	6- 1
6.1.2 Simple cam function block	6- 2
6.1.3 Control of simple cam function.....	6- 3
6.1.4 Simple cam specification list	6- 4
6.1.5 What is able to do with the simple cam.....	6- 5
6.1.6 Setting list.....	6- 8
6.1.7 Data to be used with simple cam function	6- 9
6.1.8 Function block diagram for displaying state of simple cam control	6-12
6.1.9 Operation.....	6-12
6.2 Mark detection	6-13
6.2.1 Current position latch function	6-13
6.2.2 Interrupt positioning function	6-19

7. PARAMETERS	7- 1 to 7-72
----------------------	---------------------

7.1 Parameter list.....	7- 1
7.1.1 Basic setting parameters ([Pr. PA_ _]).....	7- 2
7.1.2 Gain/filter setting parameters ([Pr. PB_ _]).....	7- 3
7.1.3 Extension setting parameters ([Pr. PC_ _]).....	7- 5
7.1.4 I/O setting parameters ([Pr. PD_ _])	7- 7
7.1.5 Extension setting 2 parameters ([Pr. PE_ _]).....	7- 9
7.1.6 Extension setting 3 parameters ([Pr. PF_ _]).....	7-10
7.1.7 Positioning control parameters ([Pr. PT_ _]).....	7-12
7.2 Detailed list of parameters	7-14
7.2.1 Basic setting parameters ([Pr. PA_ _]).....	7-14
7.2.2 Gain/filter setting parameters ([Pr. PB_ _]).....	7-24
7.2.3 Extension setting parameters ([Pr. PC_ _]).....	7-36
7.2.4 I/O setting parameters ([Pr. PD_ _])	7-48
7.2.5 Extension setting 2 parameters ([Pr. PE_ _]).....	7-58
7.2.6 Extension setting 3 parameters ([Pr. PF_ _]).....	7-58
7.2.7 Positioning control parameters ([Pr. PT_ _]).....	7-60
7.3 How to set the electronic gear	7-69
7.4 Software limit	7-70
7.5 Stop method for LSP (Forward rotation stroke end) off or LSN (Reverse rotation stroke end) off	7-71
7.6 Stop method at software limit detection.....	7-72

8. TROUBLESHOOTING	8- 1 to 8- 6
---------------------------	---------------------

8.1 Explanations of the lists	8- 1
-------------------------------------	------

8.2 Alarm and warning list	8- 2
8.3 Alarm list	8- 2
8.4 Warning list	8- 6

9. OPTIONS AND PERIPHERAL EQUIPMENT	9- 1 to 9- 4
--	---------------------

9.1 MR-HDP01 manual pulse generator	9- 2
---	------

10. COMMUNICATION FUNCTION (MITSUBISHI GENERAL-PURPOSE AC SERVO PROTOCOL)	10- 1 to 10-32
--	-----------------------

10.1 Command and data No. list	10- 1
10.1.1 Reading command	10- 2
10.1.2 Writing commands	10-11
10.2 Detailed explanations of commands.....	10-15
10.2.1 External I/O signal status (DIO diagnosis).....	10-15
10.2.2 Input device on/off.....	10-20
10.2.3 Input device on/off (for test operation)	10-21
10.2.4 Test operation mode	10-22
10.2.5 Output signal pin on/off (output signal (DO) forced output).....	10-24
10.2.6 Point table	10-25

1. FUNCTIONS AND CONFIGURATION

1. FUNCTIONS AND CONFIGURATION

For the details of the items, refer to each chapter/section (in "MR-JE-_A Servo Amplifier Instruction Manual") indicated in the detailed explanation field.

Item	Detailed explanation
	MR-JE-_A
Combinations of servo amplifiers and servo motors	Section 1.4
Model designation	Section 1.6
Structure (parts identification)	Section 1.7

1.1 For proper use of the positioning mode

(1) Servo amplifier/MR Configurator2


The positioning mode is available with the servo amplifier and MR Configurator2 with the following software versions.

Product name	Model	Software version
Servo amplifier	MR-JE-_A	B7 or later
MR Configurator2	SW1DNC-MRC2-_	1.37P or later

(2) Parameter setting

(a) Selection of the positioning mode

Select a positioning mode with [Pr. PA01 Operation mode].



Control mode selection
 6: Positioning mode (point table method)
 7: Positioning mode (program method)

(b) Positioning control parameters ([Pr. PT__])

To enable read/write the positioning control parameters ([Pr. PT__]), set [Pr. PA19 Parameter writing inhibit] to "0 0 A B".

(c) Assigning recommended input/output devices

Assign recommended input/output devices to the pins of CN1 in accordance with each chapter of the point table/program method.

1. FUNCTIONS AND CONFIGURATION

1.2 Positioning mode specification list

Only the specifications of the positioning mode are listed here. For other specifications, refer to section 1.3 of "MR-JE-A Servo Amplifier Instruction Manual".

Item		Description			
Servo amplifier model		MR-JE-_A			
Positioning mode	Command method	Point table	Positioning by specifying the point table No. (31 points when using the communication function, and 15 points when assigning input signals) (Note 2)		
		Operational specifications	Set in the point table. Setting range of feed length per point: -999999 to 999999 [$\times 10^{\text{STM}}$ μm], -99.9999 to 99.9999 [$\times 10^{\text{STM}}$ inch], -999999 to 999999 [pulse], Setting range of rotation angle: -360.000 to 360.000 [degree]		
			Position command input (Note 1)	Set in the point table. Setting range of feed length per point: 0 to 999999 [$\times 10^{\text{STM}}$ μm], 0 to 99.9999 [$\times 10^{\text{STM}}$ inch], 0 to 999999 [pulse], Setting range of rotation angle: 0 to 999.999 [degree]	
		Absolute value command method			
		Incremental value command method			
		Speed command input	Set the acceleration/deceleration time constants in the point table. Set the S-pattern acceleration/deceleration time constants with [Pr. PC03].		
		System	Signed absolute value command method/incremental value command method		
		Analog override	0 V DC to ± 10 V DC/0% to 200%		
		Torque limit	Set with parameter or external analog input (0 V DC to +10 V DC/maximum torque)		
		Position command data input	RS-422/RS-485 communication	Position command input (Note 1)	Setting of position command data with RS-422/RS-485 communication Setting range of feed length per point: -999999 to 999999 [$\times 10^{\text{STM}}$ μm], -99.9999 to 99.9999 [$\times 10^{\text{STM}}$ inch], -999999 to 999999 [pulse], Setting range of rotation angle: -360.000 to 360.000 [degree]
				Incremental value command method	Setting of position command data with RS-422/RS-485 communication Setting range of feed length per point: 0 to 999999 [$\times 10^{\text{STM}}$ μm], 0 to 99.9999 [$\times 10^{\text{STM}}$ inch], 0 to 999999 [pulse], Setting range of rotation angle: 0 to 999.999 [degree]
			Speed command input	Selects the rotation speed and acceleration/deceleration time constant through RS-422/RS-485 communication. Set the S-pattern acceleration/deceleration time constants with [Pr. PC03].	
			System	Signed absolute value command method/incremental value command method	
			Operational specifications	Program language (program with MR Configurator2) Program capacity: 480 steps (16 programs)	
	Position command input (Note 1)		Absolute value command method	Set with program language. Setting range of feed length: -999999 to 999999 [$\times 10^{\text{STM}}$ μm], -99.9999 to 99.9999 [$\times 10^{\text{STM}}$ inch], -999999 to 999999 [pulse], Setting range of rotation angle: -360.000 to 360.000 [degree]	
		Incremental value command method	Set with program language. Setting range of feed length: -999999 to 999999 [$\times 10^{\text{STM}}$ μm], -99.9999 to 99.9999 [$\times 10^{\text{STM}}$ inch], -999999 to 999999 [pulse], Setting range of rotation angle: -999.999 to 999.999 [degree]		
	Speed command input	Set servo motor speed, acceleration/deceleration time constants, and S-pattern acceleration/deceleration time constants with program language. S-pattern acceleration/deceleration time constants are also settable with [Pr. PC03].			
	System	Signed absolute value command method/signed incremental value command method			
	Analog override	Set with external analog input (0 V DC to ± 10 V DC/0% to 200%)			
	Torque limit	Set with parameter or external analog input (0 V DC to +10 V DC/maximum torque)			

1. FUNCTIONS AND CONFIGURATION

Item			Description	
Positioning mode	Operation mode	Automatic operation mode	Each positioning operation	Point table No. input method/position data input method Operates each positioning based on position command and speed command.
			Point table	Varying-speed operation (2 to 31 speeds)/automatic continuous positioning operation (2 to 31 points)/ Automatic continuous operation to the point table selected at start/automatic continuous operation to point table No. 1.
		Program	Depends on settings of program language.	
	Manual operation mode	Point table/program	JOG operation	Executes a contact input or an inching operation with the RS-422/RS-485 communication function based on speed command set with parameters.
			Manual pulse generator operation	Manual feeding is executed with a manual pulse generator. Command pulse multiplication: select from ×1, ×10, and ×100 with a parameter.
	Home position return mode	Point table/program	Dog type	Returns to home position upon Z-phase pulse after passing through the proximity dog. home position address settable/home position shift amount settable/home position return direction selectable Automatic retract on dog back to home position/automatic stroke retract function
			Count type	Returns to home position upon the encoder pulse count after touching the proximity dog. Home position return direction selectable/home position shift amount settable/home position address settable Automatic retract on dog back to home position/automatic stroke retract function
			Data set type	Returns to home position without dog. Sets any position as a home position using manual operation, etc./home position address settable
			Stopper type	Returns to home position upon hitting the stroke end. Home position return direction selectable/home position address settable
			Home position ignorance (servo-on position as home position)	Sets a home position where SON (Servo-on) signal turns on. Home position address settable
Dog type rear end reference			Returns to home position based on the rear end of the proximity dog. Home position return direction selectable/home position shift amount settable/home position address settable Automatic retract on dog back to home position/automatic stroke retract function	
Count type front end reference			Returns to home position based on the front end of the proximity dog. Home position return direction selectable/home position shift amount settable/home position address settable Automatic retract on dog back to home position/automatic stroke retract function	
Dog cradle type			Returns to home position upon the first Z-phase pulse based on the front end of the proximity dog. Home position return direction selectable/home position shift amount settable/home position address settable Automatic retract on dog back to home position/automatic stroke retract function	
Dog type last Z-phase reference			Returns to home position upon the Z-phase pulse right before the proximity dog based on the front end of the proximity dog. Home position return direction selectable/home position shift amount settable/home position address settable Automatic retract on dog back to home position/automatic stroke retract function	
Dog type front end reference			Returns to home position to the front end of the dog based on the front end of the proximity dog. Home position return direction selectable/home position shift amount settable/home position address settable Automatic retract on dog back to home position/automatic stroke retract function	
Dogless Z-phase reference	Returns to home position to the Z-phase pulse with respect to the first Z-phase pulse. Home position return direction selectable/home position shift amount settable/home position address settable			
Automatic positioning to home position function		High-speed automatic positioning to a defined home position		
Other functions		Absolute position detection/backlash compensation/overtravel prevention with external limit switch (LSP/LSN)/software stroke limit/mark detection function/override		

- Note 1. STM is the ratio to the setting value of the position data. STM can be changed with [Pr. PT03 Feeding function selection].
- Note 2. Up to four points of DO are available; therefore, PT0 (Point table No. output 1) to PT4 (Point table No. output 5) cannot be outputted simultaneously.

1. FUNCTIONS AND CONFIGURATION

1.3 Function list

POINT
<p>● The symbols in the control mode column mean as follows.</p> <p>CP: Positioning mode (point table method)</p> <p>CL: Positioning mode (program method)</p>

The following table lists the functions of this servo. For details of the functions, refer to each section indicated in the detailed explanation field. "MR-JE-_A" means "MR-JE-_ A Servo Amplifier Instruction Manual".

Function	Description	Control mode		Detailed explanation
		C P	C L	
Model adaptive control	This function achieves a high response and stable control following the ideal model. The two-degrees-of-freedom model adaptive control enables you to set a response to the command and response to the disturbance separately. Additionally, this function can be disabled. To disable this function, refer to section 7.5 of "MR-JE-A_ Servo Amplifier Instruction Manual". This is available with servo amplifiers with software version B7 or later. Check the software version using MR Configurator2.	<input type="radio"/>	<input type="radio"/>	
Positioning mode (point table method)	Set 1 to 31 point tables in advance, and select any point table to perform operation in accordance with the set values. To select point tables, use external input signals or communication function.	<input type="radio"/>		Chapter 4
Positioning mode (program method)	Set 1 to 16 programs in advance and select any program to perform operation in accordance with the programs. To select programs, use external input signals or communication function.		<input type="radio"/>	Chapter 5
Roll feed display function	Positions based on specified travel distance from a status display "0" of current/command positions at start.	<input type="radio"/>	<input type="radio"/>	Section 4.5
Mark detection	Current position latch function When the mark detection signal turns on, the current position is latched. The latched data can be read with communication commands.	<input type="radio"/>	<input type="radio"/>	Section 6.6.2
	Interrupt positioning function When MSD (Mark detection) turns on, this function converts the remaining distance to the travel amount set in [Pr. PT30] and [Pr. PT31] (Mark sensor stop travel distance). This is available with servo amplifiers with software version B7 or later.	<input type="radio"/>	<input type="radio"/>	Section 6.2.3
Home position return	Dog type/count type/data setting type/stopper type/home position ignorance/dog type rear end reference/count type front end reference/dog cradle type/dog type last Z-phase reference/dog type Z-phase reference/dogless Z-phase reference	<input type="radio"/>	<input type="radio"/>	Section 4.4 Section 5.4
High-resolution encoder	Rotary servo motors compatible with MELSERVO-JE series are equipped with high-resolution encoder of 131072 pulses/rev.	<input type="radio"/>	<input type="radio"/>	
Gain switching function	You can switch gains during rotation/stop, and can use input devices to switch gains during operation.	<input type="radio"/>	<input type="radio"/>	MR-JE-_A Section 7.2
Advanced vibration suppression control II	This function suppresses vibration at an arm end or residual vibration.	<input type="radio"/>	<input type="radio"/>	MR-JE-_A Section 7.1.5
Machine resonance suppression filter	This filter function (notch filter) decreases the gain of the specific frequency to suppress the resonance of the mechanical system.	<input type="radio"/>	<input type="radio"/>	MR-JE-_A Section 7.1.1
Shaft resonance suppression filter	When a load is mounted to the servo motor shaft, resonance by shaft torsion during driving may generate a mechanical vibration at high frequency. The shaft resonance suppression filter suppresses the vibration.	<input type="radio"/>	<input type="radio"/>	MR-JE-_A Section 7.1.3
Adaptive filter II	The servo amplifier detects mechanical resonance and sets filter characteristics automatically to suppress mechanical vibration.	<input type="radio"/>	<input type="radio"/>	MR-JE-_A Section 7.1.2
Low-pass filter	Suppresses high-frequency resonance which occurs as the servo system response is increased.	<input type="radio"/>	<input type="radio"/>	MR-JE-_A Section 7.1.4

1. FUNCTIONS AND CONFIGURATION

Function	Description	Control mode		Detailed explanation
		C P	C L	
Machine analyzer function	Analyzes the frequency characteristic of the mechanical system by simply connecting an MR Configurator2 installed personal computer and the servo amplifier. MR Configurator2 is necessary for this function.	<input type="radio"/>	<input type="radio"/>	
Robust filter	For roll feed axis, etc. of which a response level cannot be increased because of the large load to motor inertia ratio, this function improves a disturbance response.	<input type="radio"/>	<input type="radio"/>	[Pr. PE41]
Slight vibration suppression control	Suppresses vibration of ± 1 pulse generated at a servo motor stop.	<input type="radio"/>	<input type="radio"/>	[Pr. PB24]
Electronic gear	Position commands can be multiplied by 1/864 to 33935.	<input type="radio"/>	<input type="radio"/>	[Pr. PA06] [Pr. PA07]
Auto tuning	Automatically adjusts the gain to optimum value if load applied to the servo motor shaft varies.	<input type="radio"/>	<input type="radio"/>	MR-JE-_A Section 6.3
Regenerative option	Use a regenerative option when the built-in regenerative resistor of the servo amplifier does not have sufficient regenerative capacity for a large regenerative power generated.	<input type="radio"/>	<input type="radio"/>	MR-JE-_A Section 11.2
Alarm history clear	Clears alarm histories.	<input type="radio"/>	<input type="radio"/>	[Pr. PC18]
Input signal selection (device settings)	ST1 (Forward rotation start), ST2 (Reverse rotation start), and SON (Servo-on) and other input device can be assigned to certain pins of the CN1 connector.	<input type="radio"/>	<input type="radio"/>	[Pr. PD04] [Pr. PD12] [Pr. PD14] [Pr. PD18] [Pr. PD20] [Pr. PD44] [Pr. PD46]
Output signal selection (device settings)	The output devices including MBR (Electromagnetic brake interlock) can be assigned to certain pins of the CN1 connector.	<input type="radio"/>	<input type="radio"/>	[Pr. PD24] to [Pr. PD26] [Pr. PD28] [Pr. PD47]
Output signal (DO) forced output	Turns on/off the output signals forcibly independently of the servo status. Use this function for checking output signal wiring, etc.	<input type="radio"/>	<input type="radio"/>	MR-JE-_A Section 4.5.8
Command pulse selection	Supports only A-phase/B-phase pulse trains.	<input type="radio"/>	<input type="radio"/>	[Pr. PA13]
Torque limit	Limits the servo motor torque.	<input type="radio"/>	<input type="radio"/>	[Pr. PA11] [Pr. PA12]
Status display	Shows servo status on the 5-digit, 7-segment LED display	<input type="radio"/>	<input type="radio"/>	Section 3.1.2
External I/O signal display	Shows on/off statuses of external I/O signals on the display.	<input type="radio"/>	<input type="radio"/>	Section 3.1.7
Alarm code output	If an alarm has occurred, the corresponding alarm number is outputted in 3-bit code.	<input type="radio"/>	<input type="radio"/>	Chapter 8
Test operation mode	Jog operation/positioning operation/motor-less operation/DO forced output/program operation/single-step feed Note that MR Configurator2 is necessary for positioning operation, program operation, and single-step feed.	<input type="radio"/>	<input type="radio"/>	Section 3.1.8 Section 3.1.9 MR-JE-_A Section 4.5.9
Analog monitor output	Outputs servo status with voltage in real time.	<input type="radio"/>	<input type="radio"/>	[Pr. PC14] [Pr. PC15]
MR Configurator2	Using a personal computer, you can perform the parameter setting, test operation, monitoring, and others.	<input type="radio"/>	<input type="radio"/>	MR-JE-_A Section 11.7
One-touch tuning	Adjusts gains just by pressing buttons on the servo amplifier or by clicking a button on MR Configurator2.	<input type="radio"/>	<input type="radio"/>	MR-JE-_A Section 6.2
Tough drive function	This function makes the equipment continue operating even under the condition that an alarm occurs. The tough drive function includes two types: the vibration tough drive and the instantaneous power failure tough drive.	<input type="radio"/>	<input type="radio"/>	MR-JE-_A Section 7.3

1. FUNCTIONS AND CONFIGURATION

Function	Description	Control mode		Detailed explanation
		C P	C L	
Drive recorder function	This function continuously monitors the servo status and records the status transition before and after an alarm for a fixed period of time. You can check the recorded data on the drive recorder window on MR Configurator2 by clicking the "Graph" button. However, the drive recorder is not available when: 1. The graph function of MR Configurator2 is being used. 2. The machine analyzer function is being used. 3. [Pr. PF21] is set to "-1".	<input type="radio"/>	<input type="radio"/>	[Pr. PA23]
Servo amplifier life diagnosis function	You can check the cumulative energization time and the number of on/off times of the inrush relay. This function gives an indication of the replacement time for parts of the servo amplifier including a capacitor and a relay before they malfunction. MR Configurator2 is necessary for this function.	<input type="radio"/>	<input type="radio"/>	
Power monitoring function	This function calculates the power running energy and the regenerative power from the data in the servo amplifier such as speed and current. Power consumption and others are displayed on MR Configurator2.	<input type="radio"/>	<input type="radio"/>	
Machine diagnosis function	From the data in the servo amplifier, this function estimates the friction and vibrational component of the drive system in the equipment and recognizes an error in the machine parts, including a ball screw and bearing. MR Configurator2 is necessary for this function.	<input type="radio"/>	<input type="radio"/>	
Limit switch	Limits travel intervals using LSP (Forward rotation stroke end) and LSN (Reverse rotation stroke end).	<input type="radio"/>	<input type="radio"/>	
S-pattern acceleration/deceleration	Enables smooth acceleration and deceleration. Set S-pattern acceleration/deceleration time constants with [Pr. PC03]. As compared with linear acceleration/deceleration, the acceleration/deceleration time will be longer for the S-pattern acceleration/deceleration time constants regardless of command speed.	<input type="radio"/>	<input type="radio"/>	[Pr. PC03] Section 5.2.2
Software limit	Limits travel intervals by address using parameters. Enables the same function with the limit switch by setting parameters.	<input type="radio"/>	<input type="radio"/>	Section 7.4
Analog override	Limits a servo motor speed with analog inputs. A value can be changed from 0% to 200% for a set speed.	<input type="radio"/>	<input type="radio"/>	Section 2.4
Teaching function	After an operation travels to a target position with a JOG operation or manual pulse generator operation, pushing the SET button of the operation part or turning on TCH (Teach) will import position data.	<input type="radio"/>		Section 3.1.10
Simple cam function	This function enables synchronous control by using software instead of controlling mechanically with cam. Synchronous operation and synchronous interpolation operation between two axes can be performed using the encoder following function, the mark sensor input compensation function, and the positioning data. This is available with servo amplifiers with software version B7 or later.	<input type="radio"/>	<input type="radio"/>	Section 6.1
Modbus-RTU communication function	The Modbus protocol uses dedicated message frames for the serial communication between a master and slaves. The dedicated message frames have functions for reading and writing data, and you can write parameters from servo amplifiers and check the operation status of the servo amplifiers by using this function.	<input type="radio"/>	<input type="radio"/>	MR-JE-_A Servo Amplifier Instruction Manual (Modbus-RTU Protocol)

1. FUNCTIONS AND CONFIGURATION


1.4 Configuration including peripheral equipment

CAUTION ● Connecting a servo motor of the wrong axis to U, V, W, or CN2 of the servo amplifier may cause a malfunction.

POINT
● Equipment other than the servo amplifier and servo motor are optional or recommended products.

(1) MR-JE-100A or less

The diagram shows MR-JE-40A.




- Note 1. A 1-phase 200 V AC to 240 V AC power supply may be used with the servo amplifier of MR-JE-70A or less. For 1-phase 200 V AC to 240 V AC, connect the power supply to L1 and L3. Leave L2 open. For power supply specifications, refer to section 1.3 of "MR-JE-_A Servo Amplifier Instruction Manual".
- Note 2. Depending on the power supply voltage and operation pattern, a bus voltage may drop, causing dynamic brake deceleration during forced stop deceleration. When dynamic brake deceleration is not required, delay the time to turn off the magnetic contactor.

1. FUNCTIONS AND CONFIGURATION

(2) MR-JE-200A or more

The diagram shows MR-JE-200A.



- Note 1. For power supply specifications, refer to section 1.3 of "MR-JE-_A Servo Amplifier Instruction Manual".
- Note 2. Depending on the power supply voltage and operation pattern, a bus voltage may drop, causing dynamic brake deceleration during forced stop deceleration. When dynamic brake deceleration is not required, delay the time to turn off the magnetic contactor.


2. SIGNALS AND WIRING

2. SIGNALS AND WIRING

⚠ WARNING


- A person who is involved in wiring should be fully competent to do the work.
- Before wiring, turn off the power and wait for 15 minutes or more until the charge lamp turns off. Otherwise, an electric shock may occur. In addition, when confirming whether the charge lamp is off or not, always confirm it from the front of the servo amplifier.
- Ground the servo amplifier and servo motor securely.
- Do not attempt to wire the servo amplifier and servo motor until they have been installed. Otherwise, it may cause an electric shock.
- The cables should not be damaged, stressed, loaded, or pinched. Otherwise, it may cause an electric shock.
- To avoid an electric shock, insulate the connections of the power supply terminals.

- Before removing the CNP1 connector from MR-JE-40A to MR-JE-100A, disconnect the lead wires of the regenerative resistor from the CNP1 connector.
- Wire the equipment correctly and securely. Otherwise, the servo motor may operate unexpectedly, resulting in injury.
- Connect cables to the correct terminals. Otherwise, a burst, damage, etc. may occur.
- Ensure that polarity (+/-) is correct. Otherwise, a burst, damage, etc. may occur.
- The surge absorbing diode installed to the DC relay for control output should be fitted in the specified direction. Otherwise, the emergency stop and other protective circuits may not operate.



⚠ CAUTION

- Use a noise filter, etc. to minimize the influence of electromagnetic interference. Electromagnetic interference may be given to the electronic equipment used near the servo amplifier.
- Do not install a power capacitor, surge killer or radio noise filter (optional FR-BIF) with the power line of the servo motor.
- When using a regenerative resistor, shut the power off with the alarm signal. Otherwise, a transistor fault or the like may overheat the regenerative resistor, causing a fire.
- Do not modify the equipment.
- Connect the servo amplifier power outputs (U, V, and W) to the servo motor power inputs (U, V, and W) directly. Do not let a magnetic contactor, etc. intervene. Otherwise, it may cause a malfunction.



- Connecting a servo motor of the wrong axis to U, V, W, or CN2 of the servo amplifier may cause a malfunction.

2. SIGNALS AND WIRING

For the details of the following items, refer to chapter/section (of "MR-JE-_A Servo Amplifier Instruction Manual") indicated in the table.


Item	Detailed explanation
	MR-JE-_A
Input power supply circuit	Section 3.1
Explanation of power supply system (except for section 2.6 Power-on sequence)	Section 3.3
Detailed explanation of signals	Section 3.6
Forced stop deceleration function	Section 3.7
Alarm occurrence timing chart	Section 3.8
Interface (except for section 2.5 Internal connection)	Section 3.9
Servo motor with an electromagnetic brake	Section 3.10
Grounding	Section 3.11

2. SIGNALS AND WIRING

2.1 I/O signal connection example

(1) Point table method

POINT
<p>● Assign the following output device to CN1-23 pin with [Pr. PD24]. CN1-23: ZP (Home position return completion)</p>




2. SIGNALS AND WIRING

- Note
1. To prevent an electric shock, always connect the protective earth (PE) terminal (marked \oplus) of the servo amplifier to the protective earth (PE) of the cabinet.
 2. Connect the diode in the correct direction. If it is connected reversely, the servo amplifier will malfunction and will not output signals, disabling EM2 (Forced stop 2) and other protective circuits.
 3. The forced stop switch (normally closed contact) must be installed.
 4. Supply 24 V DC \pm 10% to interfaces from outside. The total current capacity of these power supplies must be 300 mA or lower. 300 mA is the value applicable when all I/O signals are used. The current capacity can be decreased by reducing the number of I/O points. Refer to section 3.9.2 (1) that gives the current value necessary for the interface. The illustration of the 24 V DC power supply is divided between input signal and output signal for convenience. However, they can be configured by one.
 5. ALM (Malfunction) turns on in normal alarm-free condition (normally closed contact).
 6. The pins with the same signal name are connected in the servo amplifier.
 7. TLA will be available when TL (External torque limit selection) is enabled with [Pr. PD03], [Pr. PD11], [Pr. PD13], [Pr. PD17], and [Pr. PD19]. (Refer to section 3.6.1 (5).)
 8. Use SW1DNC MRC2-_. (Refer to section 11.4.)
 9. To prevent an unexpected restart of the servo amplifier, configure a circuit to turn off EM2 when the power is turned off.
 10. The USB communication function and RS-422/RS-485 communication function are mutually exclusive. They cannot be used together.
 11. Recommended device assignments are shown. The device can be changed by [Pr. PD24] to [Pr. PD25], and [Pr. PD28].
 12. DI2 and DI3 are assigned to the CN1-10 and CN1-35 pins by default. When connecting a manual pulse generator, change them with [Pr. PD44] and [Pr. PD46]. Refer to section 9.1 for details of the manual pulse generator.
 13. Supply + of 24 DC V to OPC (Power input for open-collector sink interface) when input devices are assigned to the CN1-10 pin and the CN-35 pin. They cannot be used with source input interface. For the positioning mode, input devices (DI2 and DI3) are assigned by default.

2. SIGNALS AND WIRING

(2) Program method

POINT
<ul style="list-style-type: none"> ● Assign the following output device to CN1-23 pin with [Pr. PD24]. CN1-23: ZP (Home position return completion)




2. SIGNALS AND WIRING

- Note
1. To prevent an electric shock, always connect the protective earth (PE) terminal (marked \oplus) of the servo amplifier to the protective earth (PE) of the cabinet.
 2. Connect the diode in the correct direction. If it is connected reversely, the servo amplifier will malfunction and will not output signals, disabling EM2 (Forced stop 2) and other protective circuits.
 3. The forced stop switch (normally closed contact) must be installed.
 4. Supply 24 V DC \pm 10% to interfaces from outside. The total current capacity of these power supplies must be 300 mA or lower. 300 mA is the value applicable when all I/O signals are used. The current capacity can be decreased by reducing the number of I/O points. Refer to section 3.9.2 (1) that gives the current value necessary for the interface. The illustration of the 24 V DC power supply is divided between input signal and output signal for convenience. However, they can be configured by one.
 5. ALM (Malfunction) turns on in normal alarm-free condition (normally closed contact).
 6. The pins with the same signal name are connected in the servo amplifier.
 7. TLA will be available when TL (External torque limit selection) is enabled with [Pr. PD03], [Pr. PD11], [Pr. PD13], [Pr. PD17], and [Pr. PD19]. (Refer to section 3.6.1 (5).)
 8. Use SW1DNC MRC2-_. (Refer to section 11.4.)
 9. To prevent an unexpected restart of the servo amplifier, configure a circuit to turn off EM2 when the power is turned off.
 10. The USB communication function and RS-422/RS-485 communication function are mutually exclusive. They cannot be used together.
 11. Recommended device assignments are shown. The device can be changed by [Pr. PD24] to [Pr. PD25], and [Pr. PD28].
 12. DI2 and DI3 are assigned to the CN1-10 and CN1-35 pins by default. When connecting a manual pulse generator, change them with [Pr. PD44] and [Pr. PD46]. Refer to section 9.1 for details of the manual pulse generator.
 13. Supply + of 24 DC V to OPC (Power input for open-collector sink interface) when input devices are assigned to the CN1-10 pin and the CN-35 pin. They cannot be used with source input interface. For the positioning mode, input devices (DI2 and DI3) are assigned by default.


2. SIGNALS AND WIRING

2.2 Connectors and pin assignment

POINT
<ul style="list-style-type: none">● The pin assignment of the connectors is as viewed from the cable connector wiring section.● For the CN1 connector, securely connect the external conductor of the shielded cable to the ground plate and fix it to the connector shell.  <ul style="list-style-type: none">● PP (CN1-10 pin) /NP (CN1-35 pin) and PP2 (CN1-37 pin) /NP2 (CN1-38 pin) are exclusive. They cannot be used together.

2. SIGNALS AND WIRING

The following is the front view of MR-JE-40A or less. For external appearance, connector arrangements, and details of other servo amplifiers, refer to chapter 9 of "MR-JE-_A Servo Amplifier Instruction Manual".



The device assignment of the CN1 connector pins changes depending on the control mode. For the pins which are given parameters in the related parameter column, their devices can be changed using those parameters.

2. SIGNALS AND WIRING

Pin No.	(Note 1) I/O	(Note 2) I/O signals in control modes		Related parameter
		CP	CL	
1				
2	I	VC	VC	
3		LG	LG	
4	O	LA	LA	
5	O	LAR	LAR	
6	O	LB	LB	
7	O	LBR	LBR	
8	O	LZ	LZ	
9	O	LZR	LZR	
10	I	(Note 5)	(Note 5)	Pr. PD44 (Note 4)
11	I	PG	PG	
12		OPC	OPC	
13	O	SDP	SDP	
14	O	SDN	SDN	
15	I	SON	SON	Pr. PD03/Pr. PD04
16				
17				
18				
19	I	DI0	DI0	Pr. PD12
20		DICOM	DICOM	
21		DICOM	DICOM	
22				
23	O	(Note 8) ZP	(Note 8) ZP	Pr. PD24
24	O	INP	INP	Pr. PD25
25				
26	O	MO1	MO1	Pr. PC14
27	I	(Note 3) TLA	(Note 3) TLA	
28		LG	LG	
29	O	MO2	MO2	Pr. PC15
30		LG	LG	
31	I	TRE	TRE	
32				
33	O	OP	OP	
34		LG	LG	
35	I	(Note 5)	(Note 5)	Pr. PD46 (Note 4)
36	I	NG	NG	
37 (Note 7)	I	(Note 6)	(Note 6)	Pr. PD44 (Note 4)
38 (Note 7)	I	(Note 6)	(Note 6)	Pr. PD46 (Note 4)
39	I	RDP	RDP	
40	I	RDN	RDN	
41	I	DI1	DI1	Pr. PD13/Pr. PD14
42	I	EM2	EM2	
43	I	LSP	LSP	Pr. PD17/Pr. PD18
44	I	LSN	LSN	Pr. PD19/Pr. PD20
45				
46		DOCOM	DOCOM	
47		DOCOM	DOCOM	
48	O	ALM	ALM	
49	O	RD	RD	Pr. PD28
50				

2. SIGNALS AND WIRING

- Note
1. I: input signal, O: output signal
 2. CP: Positioning mode (point table method)
CL: Positioning mode (program method)
 3. TLA will be available when TL (External torque limit selection) is enabled with [Pr. PD04], [Pr. PD12], [Pr. PD14], [Pr. PD18], [Pr. PD20], and [Pr. PD44].
 4. This is available with servo amplifiers with software version B7 or later.
 5. This is used with sink interface. Input devices are not assigned by default. Assign the input devices with [Pr. PD44] and [Pr. PD46] as necessary. In addition, supply + of 24 DC V to the CN1-12 pin of OPC (Power input for open-collector sink interface). This is available with servo amplifiers with software version B7 or later.
 6. This is used with source interface. Input devices are not assigned by default. Assign the input devices with [Pr. PD44] and [Pr. PD46] as necessary.
 7. These pins are available with servo amplifiers having software version B7 or later, and manufactured in May, 2015 or later.
 8. Assign the following output device to CN1-23 pin with [Pr. PD24].
CN1-23: ZP (Home position return completion)

2. SIGNALS AND WIRING

2.3 Signal (device) explanations

The connector pin No. column in the table lists the pin Nos. which devices are assigned to by default. For the I/O interfaces (symbols in I/O division column in the table), refer to section 2.5. The symbols in the control mode field of the table shows the followings.

CP: Positioning mode (point table method)

CL: Positioning mode (program method)

"○" and "△" of the table shows the followings.

○: Usable device by default.

△: Usable device by setting the following parameters.

[Pr. PD04], [Pr. PD12], [Pr. PD14], [Pr. PD18], [Pr. PD24] to [Pr. PD26], [Pr. PD28], [Pr. PD44], [Pr. PD46], and [Pr. PD47]

(1) I/O device

(a) Input device

Device	Symbol	Connect or pin No.	Function and application	I/O division	Control mode															
					C P	C L														
Forced stop 2	EM2	CN1-42	<p>Turn off EM2 (open between commons) to decelerate the servo motor to a stop with commands.</p> <p>Turn EM2 on (short between commons) in the forced stop state to reset that state.</p> <p>The following shows the setting of [Pr. PA04].</p> <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th rowspan="2">[Pr. PA04] setting</th> <th rowspan="2">EM2/EM1</th> <th colspan="2">Deceleration method</th> </tr> <tr> <th>EM2 or EM1 is off</th> <th>Alarm occurred</th> </tr> </thead> <tbody> <tr> <td>0 ___</td> <td>EM1</td> <td>MBR (Electromagnetic brake interlock) turns off without the forced stop deceleration.</td> <td>MBR (Electromagnetic brake interlock) turns off without the forced stop deceleration.</td> </tr> <tr> <td>2 ___</td> <td>EM2</td> <td>MBR (Electromagnetic brake interlock) turns off after the forced stop deceleration.</td> <td>MBR (Electromagnetic brake interlock) turns off after the forced stop deceleration.</td> </tr> </tbody> </table> <p>EM2 and EM1 are mutually exclusive.</p>	[Pr. PA04] setting	EM2/EM1	Deceleration method		EM2 or EM1 is off	Alarm occurred	0 ___	EM1	MBR (Electromagnetic brake interlock) turns off without the forced stop deceleration.	MBR (Electromagnetic brake interlock) turns off without the forced stop deceleration.	2 ___	EM2	MBR (Electromagnetic brake interlock) turns off after the forced stop deceleration.	MBR (Electromagnetic brake interlock) turns off after the forced stop deceleration.	DI-1	○	○
[Pr. PA04] setting	EM2/EM1	Deceleration method																		
		EM2 or EM1 is off	Alarm occurred																	
0 ___	EM1	MBR (Electromagnetic brake interlock) turns off without the forced stop deceleration.	MBR (Electromagnetic brake interlock) turns off without the forced stop deceleration.																	
2 ___	EM2	MBR (Electromagnetic brake interlock) turns off after the forced stop deceleration.	MBR (Electromagnetic brake interlock) turns off after the forced stop deceleration.																	
Forced stop 1	EM1	(CN1-42)	<p>When using EM1, set [Pr. PA04] to "0 ___" to enable EM1.</p> <p>Turn EM1 off (open between commons) to bring the servo motor to a forced stop state. The base circuit shuts off, and the dynamic brake is operated and decelerates the servo motor to a stop.</p> <p>Turn EM1 on (short between commons) in the forced stop state to reset that state.</p>	DI-1	△	△														
Servo-on	SON	CN1-15	<p>Turn SON on to power on the base circuit, and make the servo amplifier ready to operate. (servo-on status)</p> <p>Turn it off to shut off the base circuit, and coast the servo motor.</p> <p>Setting [Pr. PD01] to "___ 4" turns the signal on automatically (always connected) in the servo amplifier.</p>	DI-1	○	○														
Reset	RES	CN1-19	<p>Turn on RES for more than 50 ms to reset the alarm.</p> <p>Some alarms cannot be deactivated by RES (Reset). Refer to chapter 8.</p> <p>Turning RES on in an alarm-free status shuts off the base circuit. The base circuit is not shut off when [Pr. PD30] is set to "___ 1 ___".</p> <p>This device is not designed to make a stop. Do not turn it on during operation.</p>	DI-1	△	△														

2. SIGNALS AND WIRING

Device	Symbol	Connector pin No.	Function and application	I/O division	Control mode																																						
					C P	C L																																					
Forward rotation stroke end	LSP	CN1-43	To start the operation, turn on LSP and LSN. Turn it off to bring the servo motor to a sudden stop and make it servo-locked. Setting [Pr. PD30] to " ___ 1" will enable "Slow stop (home position erased)".	DI-1	○	○																																					
Reverse rotation stroke end	LSN	CN1-44	<table border="1" style="margin-bottom: 10px;"> <thead> <tr> <th colspan="2">(Note) Input device</th> <th colspan="2">Operation</th> </tr> <tr> <th>LSP</th> <th>LSN</th> <th>CCW direction</th> <th>CW direction</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>1</td> <td style="text-align: center;">○</td> <td style="text-align: center;">○</td> </tr> <tr> <td>0</td> <td>1</td> <td style="text-align: center;">/</td> <td style="text-align: center;">○</td> </tr> <tr> <td>1</td> <td>0</td> <td style="text-align: center;">○</td> <td style="text-align: center;">/</td> </tr> <tr> <td>0</td> <td>0</td> <td style="text-align: center;">/</td> <td style="text-align: center;">/</td> </tr> </tbody> </table> <p>Note. 0: Off 1: On</p> <p>The stop method can be changed with [Pr. PD30]. Setting [Pr. PD01] as follows turn the signals on automatically (always connected) in the servo amplifier.</p> <table border="1" style="margin-bottom: 10px;"> <thead> <tr> <th rowspan="2">[Pr. PD01]</th> <th colspan="2">Status</th> </tr> <tr> <th>LSP</th> <th>LSN</th> </tr> </thead> <tbody> <tr> <td>_ 4 _ _</td> <td>Automatic on</td> <td style="text-align: center;">/</td> </tr> <tr> <td>_ 8 _ _</td> <td style="text-align: center;">/</td> <td>Automatic on</td> </tr> <tr> <td>_ C _ _</td> <td>Automatic on</td> <td>Automatic on</td> </tr> </tbody> </table> <p>When LSP or LSN turns off, [AL. 99 Stroke limit warning] occurs, and WNG (Warning) turns on. When using WNG, enable it by setting [Pr. PD24], [Pr. PD25] and [Pr. PD28].</p>	(Note) Input device		Operation		LSP	LSN	CCW direction	CW direction	1	1	○	○	0	1	/	○	1	0	○	/	0	0	/	/	[Pr. PD01]	Status		LSP	LSN	_ 4 _ _	Automatic on	/	_ 8 _ _	/	Automatic on	_ C _ _	Automatic on	Automatic on		
(Note) Input device		Operation																																									
LSP	LSN	CCW direction	CW direction																																								
1	1	○	○																																								
0	1	/	○																																								
1	0	○	/																																								
0	0	/	/																																								
[Pr. PD01]	Status																																										
	LSP	LSN																																									
_ 4 _ _	Automatic on	/																																									
_ 8 _ _	/	Automatic on																																									
_ C _ _	Automatic on	Automatic on																																									
External torque limit selection	TL	/	Turning off TL will enable [Pr. PA11 Forward torque limit] and [Pr. PA12 Reverse torque limit], and turning on it will enable TLA (Analog torque limit). For details, refer to section 3.6.1 (5) of "MR-JE-_A Servo Amplifier Instruction Manual".	DI-1	△	△																																					
Internal torque limit selection	TL1	/	To select [Pr. PC35 Internal torque limit 2], enable TL1 with [Pr. PD03] to [Pr. PD20]. For details, refer to section 3.6.1 (5) of "MR-JE-_A Servo Amplifier Instruction Manual".	DI-1	△	△																																					
Operation mode selection 1	MD0	CN1-16	Point table method/program method Automatic operation mode is set by turning MD0 on, and manual operation mode by turning it off. Changing the operation mode during operation will clear the command remaining distance, and the servo motor will decelerate to stop.	DI-1	○	○																																					
Operation mode selection 2	MD1	/	MD1 cannot be used.	DI-1	/	/																																					

2. SIGNALS AND WIRING

Device	Symbol	Connector pin No.	Function and application	I/O division	Control mode	
					C P	C L
Forward rotation start	ST1	CN1-17	<p>Point table method</p> <p>1. Absolute value command method</p> <p>Turning on ST1 during automatic operation will execute one positioning based on the position data set in the point tables.</p> <p>Turning on ST1 during home position return will also start home position return.</p> <p>Turning on ST1 during JOG operation will rotate the servo motor in the forward rotation direction while it is on.</p> <p>The forward rotation means address increasing direction.</p> <p>Turning on both ST1 and ST2 during JOG operation will stop the servo motor.</p> <p>2. Incremental value command method</p> <p>Turning on ST1 during automatic operation will execute one positioning in the forward rotation direction based on the position data set in point tables.</p> <p>Turning on ST1 during home position return will also start home position return.</p> <p>Turning on ST1 during JOG operation will rotate the servo motor in the forward rotation direction while it is on.</p> <p>The forward rotation means address increasing direction.</p> <p>Turning on both ST1 and ST2 during JOG operation will stop the servo motor.</p>	DI-1	○	
			<p>Program method</p> <p>1. Automatic operation mode</p> <p>Turning on ST1 will execute a program operation selected with DI0 to DI3.</p> <p>The forward rotation means address increasing direction.</p> <p>Turning on both ST1 and ST2 during manual operation mode will stop the servo motor.</p> <p>2. Manual operation mode</p> <p>Turning on ST1 will rotate the servo motor in the forward rotation direction while it is on.</p> <p>The forward rotation means address increasing direction.</p> <p>Turning on both ST1 and ST2 during manual operation mode will stop the servo motor.</p>			○
Reverse rotation start	ST2	CN1-18	<p>Point table method</p> <p>Use this device with the incremental value command method. Turning on ST2 during automatic operation will execute one positioning in the reverse rotation direction based on the position data set in point tables. Turning on ST2 during JOG operation will rotate the servo motor in the reverse rotation direction while it is on. Turning on both ST1 and ST2 will stop the servo motor.</p> <p>Turning on ST2 during in the home position return mode will execute an automatic positioning to the home position.</p> <p>The reverse rotation means address decreasing direction.</p> <p>Turning on both ST1 and ST2 during JOG operation will stop the servo motor.</p>	DI-1	○	
			<p>Program method</p> <p>Turning on ST2 with JOG operation in the manual operation mode will rotate the servo motor in the reverse rotation direction while it is on.</p> <p>Turning on both ST1 and ST2 will stop the servo motor.</p> <p>The reverse rotation means address decreasing direction.</p> <p>Turning on both ST1 and ST2 during manual operation mode will stop the servo motor. ST2 will be disabled in the automatic operation mode.</p>			○

2. SIGNALS AND WIRING

Device	Symbol	Connector pin No.	Function and application	I/O division	Control mode																		
					C P	C L																	
Temporary stop/restart	TSTP		<p>Turning on TSTP during automatic operation will temporarily stop the servo motor.</p> <p>Turning on TSTP again will restart.</p> <p>Turning on ST1 (Forward rotation start)/ST2 (Reverse rotation start) during a temporary stop will not rotate the servo motor.</p> <p>Changing the automatic operation mode to manual operation mode during a temporary stop will erase a travel remaining distance.</p> <p>The temporary stop/restart input does not function during a home position return or JOG operation.</p>	DI-1	△	△																	
Proximity dog	DOG	CN1-45	<p>Turning off DOG will detect a proximity dog. The polarity for dog detection can be changed with [Pr. PT29].</p> <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th>[Pr. PT29]</th> <th>Polarity for proximity dog detection</th> </tr> </thead> <tbody> <tr> <td>___ 0</td> <td>Detection with off</td> </tr> <tr> <td>___ 1</td> <td>Detection with on</td> </tr> </tbody> </table>	[Pr. PT29]	Polarity for proximity dog detection	___ 0	Detection with off	___ 1	Detection with on	DI-1	○	○											
[Pr. PT29]	Polarity for proximity dog detection																						
___ 0	Detection with off																						
___ 1	Detection with on																						
Manual pulse generator multiplication 1	TP0		<p>Select a multiplication of the manual pulse generator.</p> <p>When a multiplication is not selected, the setting of [Pr. PT03] will be enabled.</p>	DI-1	△	△																	
Manual pulse generator multiplication 2	TP1		<table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th colspan="2">Device (Note)</th> <th rowspan="2">Manual pulse generator multiplication</th> </tr> <tr> <th>TP1</th> <th>TP0</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>[Pr. PT03] setting</td> </tr> <tr> <td>0</td> <td>1</td> <td>× 1</td> </tr> <tr> <td>1</td> <td>0</td> <td>× 10</td> </tr> <tr> <td>1</td> <td>1</td> <td>× 100</td> </tr> </tbody> </table> <p>Note. 0: Off 1: On</p>	Device (Note)		Manual pulse generator multiplication	TP1	TP0	0	0	[Pr. PT03] setting	0	1	× 1	1	0	× 10	1	1	× 100	DI-1	△	△
Device (Note)		Manual pulse generator multiplication																					
TP1	TP0																						
0	0	[Pr. PT03] setting																					
0	1	× 1																					
1	0	× 10																					
1	1	× 100																					
Analog override selection	OVR		Turning on OVR will enable VC (Analog override).	DI-1	△	△																	
Teach	TCH		Use this for teaching. Turning on TCH in the point table method will rewrite a position data of the selected point table No. to the current position.	DI-1	△	△																	

2. SIGNALS AND WIRING

Device	Symbol	Connector pin No.	Function and application	I/O division	Control mode																																																																		
					C P	C L																																																																	
Program input 1	PI1		Turning on PI1 will restart a step which was suspended with the SYNC (1) command during programming.	DI-1		△																																																																	
Program input 2	PI2		Turning on PI2 will restart a step which was suspended with the SYNC (2) command during programming.	DI-1		△																																																																	
Program input 3	PI3		Turning on PI3 will restart a step which was suspended with the SYNC (3) command during programming.	DI-1		△																																																																	
Current position latch input	LPS		Turning on LPS during execution of the LPOS command will latch a current position with its rising edge. The latched current position can be read with communication commands.	DI-1		△																																																																	
Point table No./program No. selection 1	DI0	CN1-19	Point table method Select point tables and home position return mode with DI0 to DI4.	DI-1	○	○																																																																	
Point table No./program No. selection 2	DI1	CN1-41	<table border="1"> <thead> <tr> <th colspan="5">Device (Note 1)</th> <th rowspan="2">Selection contents</th> </tr> <tr> <th>DI4 (Note 2)</th> <th>DI3</th> <th>DI2</th> <th>DI1</th> <th>DI0</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>Home position return mode</td> </tr> <tr> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>1</td> <td>Point table No. 1</td> </tr> <tr> <td>0</td> <td>0</td> <td>0</td> <td>1</td> <td>0</td> <td>Point table No. 2</td> </tr> <tr> <td>0</td> <td>0</td> <td>0</td> <td>1</td> <td>1</td> <td>Point table No. 3</td> </tr> <tr> <td>.</td> <td>.</td> <td>.</td> <td>.</td> <td>.</td> <td>.</td> </tr> <tr> <td>.</td> <td>.</td> <td>.</td> <td>.</td> <td>.</td> <td>.</td> </tr> <tr> <td>.</td> <td>.</td> <td>.</td> <td>.</td> <td>.</td> <td>.</td> </tr> <tr> <td>1</td> <td>1</td> <td>1</td> <td>1</td> <td>0</td> <td>Point table No. 30</td> </tr> <tr> <td>1</td> <td>1</td> <td>1</td> <td>1</td> <td>1</td> <td>Point table No. 31</td> </tr> </tbody> </table>		Device (Note 1)					Selection contents	DI4 (Note 2)	DI3	DI2	DI1	DI0	0	0	0	0	0	Home position return mode	0	0	0	0	1	Point table No. 1	0	0	0	1	0	Point table No. 2	0	0	0	1	1	Point table No. 3	1	1	1	1	0	Point table No. 30	1	1	1	1	1	Point table No. 31	○	○
Device (Note 1)					Selection contents																																																																		
DI4 (Note 2)	DI3	DI2	DI1			DI0																																																																	
0	0	0	0		0	Home position return mode																																																																	
0	0	0	0	1	Point table No. 1																																																																		
0	0	0	1	0	Point table No. 2																																																																		
0	0	0	1	1	Point table No. 3																																																																		
.																																																																		
.																																																																		
.																																																																		
1	1	1	1	0	Point table No. 30																																																																		
1	1	1	1	1	Point table No. 31																																																																		
Point table No./program No. selection 3	DI2	CN1-10		○	○																																																																		
Point table No./program No. selection 4	DI3	CN1-35		○	○																																																																		
Point table No. 5	DI4		<p>Note 1. 0: Off 1: On</p> <p>2. DI4 is available only with the communication function. This device cannot be assigned as an input signal.</p> <p>Program method Select program Nos. with DI0 to DI3.</p> <table border="1"> <thead> <tr> <th colspan="5">Device (Note)</th> <th rowspan="2">Selection contents</th> </tr> <tr> <th>DI4</th> <th>DI3</th> <th>DI2</th> <th>DI1</th> <th>DI0</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>Program No. 1</td> </tr> <tr> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>1</td> <td>Program No. 2</td> </tr> <tr> <td>0</td> <td>0</td> <td>0</td> <td>1</td> <td>0</td> <td>Program No. 3</td> </tr> <tr> <td>0</td> <td>0</td> <td>0</td> <td>1</td> <td>1</td> <td>Program No. 4</td> </tr> <tr> <td>.</td> <td>.</td> <td>.</td> <td>.</td> <td>.</td> <td>.</td> </tr> <tr> <td>.</td> <td>.</td> <td>.</td> <td>.</td> <td>.</td> <td>.</td> </tr> <tr> <td>.</td> <td>.</td> <td>.</td> <td>.</td> <td>.</td> <td>.</td> </tr> <tr> <td>1</td> <td>1</td> <td>1</td> <td>1</td> <td>0</td> <td>Program No. 15</td> </tr> <tr> <td>1</td> <td>1</td> <td>1</td> <td>1</td> <td>1</td> <td>Program No. 16</td> </tr> </tbody> </table> <p>Note. 0: Off 1: On</p>	Device (Note)					Selection contents	DI4	DI3	DI2	DI1	DI0	0	0	0	0	0	Program No. 1	0	0	0	0	1	Program No. 2	0	0	0	1	0	Program No. 3	0	0	0	1	1	Program No. 4	1	1	1	1	0	Program No. 15	1	1	1	1	1	Program No. 16	△		
Device (Note)					Selection contents																																																																		
DI4	DI3	DI2	DI1	DI0																																																																			
0	0	0	0	0	Program No. 1																																																																		
0	0	0	0	1	Program No. 2																																																																		
0	0	0	1	0	Program No. 3																																																																		
0	0	0	1	1	Program No. 4																																																																		
.																																																																		
.																																																																		
.																																																																		
1	1	1	1	0	Program No. 15																																																																		
1	1	1	1	1	Program No. 16																																																																		

2. SIGNALS AND WIRING

Device	Symbol	Connector pin No.	Function and application	I/O division	Control mode																																																															
					C P	C L																																																														
Mark detection	MSD		The current position latch function by sensor input can be used. For the current position latch function, refer to section 6.2.2. For the current position latch function, refer to section 6.2.3.	DI-1	△	△																																																														
Proportional control	PC		Turn PC on to switch the speed amplifier from the proportional integral type to the proportional type. If the servo motor at a stop is rotated even one pulse due to any external factor, it generates torque to compensate for a position shift. When the servo motor shaft is to be locked mechanically after positioning completion (stop), switching on the PC (Proportion control) upon positioning completion will suppress the unnecessary torque generated to compensate for a position shift. When the shaft is to be locked for a long time, switch on the PC (Proportion control) and TL (External torque limit selection) at the same time to make the torque less than the rated by TLA (Analog torque limit).	DI-1	△	△																																																														
Clear	CR		Turn CR on to clear the position control counter droop pulses on its leading edge. The pulse width should be 10 ms or longer. The delay amount set in [Pr. PB03 Position command acceleration/deceleration time constant] is also cleared. When " ___ 1 " is set to [Pr. PD32], the pulses are always cleared while CR is on.	DI-1	△	△																																																														
Gain switching	CDP		Turn on CDP to use the values of [Pr. PB29] to [Pr. PB36] and [Pr. PB56] to [Pr. PB60] as the load to motor inertia ratio and gain values.	DI-1	△	△																																																														
Cam control command	CAMC		When using CAMC, set [Pr. PT35] to " _ 1 _ " to enable it. Turning CAMC on switches the control from the normal positioning control to the cam control.	DI-1	△	△																																																														
Cam position compensation request	CPCD		Turning CPCD on compensates the cam axis one cycle current value to be in the position set in "Cam control data No. 60 - Cam position compensation target position".	DI-1	△	△																																																														
Clutch command	CLTC		This is used to turning on/off the main shaft clutch command. This is used when "Cam control data No. 36 - Main shaft clutch control setting" is set to " ___ 1".	DI-1	△	△																																																														
Cam No. selection 0	CI0		Select cam No. This is enabled when "Cam control data No. 49 - Cam No." is set to "0". Set the cam control data on the cam setting window of MR Configurator2.	DI-1	△	△																																																														
Cam No. selection 1	CI1		<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="4">Device (Note 1)</th> <th rowspan="2">Selection contents</th> </tr> <tr> <th>CI3</th> <th>CI2</th> <th>CI1</th> <th>CI0</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>Linear cam</td> </tr> <tr> <td>0</td> <td>0</td> <td>0</td> <td>1</td> <td>Cam No. 1</td> </tr> <tr> <td>0</td> <td>0</td> <td>1</td> <td>0</td> <td>Cam No. 2</td> </tr> <tr> <td>0</td> <td>0</td> <td>1</td> <td>1</td> <td>Cam No. 3</td> </tr> <tr> <td>.</td> <td>.</td> <td>.</td> <td>.</td> <td>.</td> </tr> <tr> <td>.</td> <td>.</td> <td>.</td> <td>.</td> <td>.</td> </tr> <tr> <td>1</td> <td>0</td> <td>0</td> <td>0</td> <td>Cam No. 8</td> </tr> <tr> <td>1</td> <td>0</td> <td>0</td> <td>1</td> <td rowspan="3">Setting prohibited (Note 2)</td> </tr> <tr> <td>.</td> <td>.</td> <td>.</td> <td>.</td> </tr> <tr> <td>.</td> <td>.</td> <td>.</td> <td>.</td> </tr> <tr> <td>1</td> <td>1</td> <td>1</td> <td>1</td> <td></td> </tr> </tbody> </table>		Device (Note 1)				Selection contents	CI3	CI2	CI1	CI0	0	0	0	0	Linear cam	0	0	0	1	Cam No. 1	0	0	1	0	Cam No. 2	0	0	1	1	Cam No. 3	1	0	0	0	Cam No. 8	1	0	0	1	Setting prohibited (Note 2)	1	1	1	1		△	△
Device (Note 1)					Selection contents																																																															
CI3	CI2	CI1				CI0																																																														
0	0	0		0	Linear cam																																																															
0	0	0	1	Cam No. 1																																																																
0	0	1	0	Cam No. 2																																																																
0	0	1	1	Cam No. 3																																																																
.																																																																
.																																																																
1	0	0	0	Cam No. 8																																																																
1	0	0	1	Setting prohibited (Note 2)																																																																
.	.	.	.																																																																	
.	.	.	.																																																																	
1	1	1	1																																																																	
Cam No. selection 2	CI2				△	△																																																														
Cam No. selection 3	CI3				△	△																																																														

Note1. 0: Off
1: On

2. [AL. F6.5 Cam No. external error] occurs.

2. SIGNALS AND WIRING

(b) Output device

Device	Symbol	Connector pin No.	Function and application	I/O division	Control mode	
					C P	C L
Malfunction	ALM	CN1-48	When an alarm occurs, ALM turns off. When an alarm is not occurring, turning on the power will turn on ALM after 4 s to 5 s. When [Pr. PD34] is set to "_ _ 1 _", an alarming or warning will turn off ALM.	DO-1	○	○
Alarm/warning	ALM WNG		When an alarm occurs, ALMWNG turns off. When a warning occurs (except for [AL. 9F Battery warning]), ALMWNG turns on and off repeatedly approximately every 1 s. When an alarm or a warning is not occurring, turning on the power will turn on ALMWNG after 4 s to 5 s.	DO-1	△	△
Warning	WNG		When a warning occurs, WNG turns on. When a warning is not occurring, turning on the power will turn off WNG after 4 s to 5 s.	DO-1	△	△
Ready	RD	CN1-49	When the servo-on is on and the servo amplifier is ready to operate, RD turns on.	DO-1	○	○
In-position	INP	CN1-24	When the number of droop pulses is in the preset in-position range, INP turns on. The in-position range can be changed with [Pr. PA10]. When the in-position range is increased, INP may be always on during low-speed rotation. INP turns on with servo-on.	DO-1	○	○
Limiting torque	TLC	CN1-25	TLC turns on when a generated torque reaches a value set with any of [Pr. PA11 Forward torque limit], [Pr. PA12 Reverse torque limit], or TLA (Analog torque limit).	DO-1	○	○
Under cam control	CAMS		It turns on when the control switches to the cam control. It turns off when the control switches to the normal positioning control.	DO-1	△	△
Cam position compensation execution completed	CPCC		It turns on when the cam position compensation execution is enabled. It turns on when the position compensation is not being executed during the cam control.	DO-1	△	△
Clutch on/off status	CLTS		It turns on with clutch-on. It is always off when "Cam control data No. 36 - Main shaft clutch control setting" is set to "_ _ _ 0".	DO-1	△	△
Clutch smoothing status	CLTSM		It outputs clutch smoothing status. The output depends on the setting in "Cam control data No. 42 - Main shaft clutch smoothing system" as follows: 0: Direct Always off 1: Time constant method (index) Always on in clutch-on status It turns off when the clutch is off and the smoothing is complete.	DO-1	△	△

2. SIGNALS AND WIRING

Device	Symbol	Connector pin No.	Function and application	I/O division	Control mode	
					C P	C L
Zero speed detection	ZSP	CN1-23	<p>ZSP turns on when the servo motor speed is at zero speed or less. Zero speed can be changed with [Pr. PC17].</p> <p>Forward rotation direction OFF level 70 r/min ON level 50 r/min</p> <p>Servo motor speed 0 r/min</p> <p>Reverse rotation direction ON level -50 r/min OFF level -70 r/min</p> <p>ZSP (Zero speed detection) ON OFF</p> <p>20 r/min (Hysteresis width) [Pr. PC17]</p> <p>20 r/min (Hysteresis width)</p> <p>1) 2) 3) 4)</p> <p>ZSP turns on when the servo motor is decelerated to 50 r/min (at 1)), and turns off when the servo motor is accelerated to 70 r/min again (at 2)). ZSP turns on when the servo motor is decelerated again to 50 r/min (at 3)), and turns off when the servo motor speed has reached -70 r/min (at 4)). The range from the point when the servo motor speed has reached the on-level, and ZSP turns on, to the point when it is accelerated again and has reached the off-level is called hysteresis width. Hysteresis width is 20 r/min for this servo amplifier.</p>	DO-1	○	○
Electromagnetic brake interlock	MBR		<p>When using the device, set an operation delay time of the electromagnetic brake in [Pr. PC16]. When a servo-off status or alarm occurs, MBR turns off.</p>	DO-1	△	△
Speed command reached	SA		<p>SA turns on when the command speed reaches the target speed in servo-on status. SA is always on when the command speed is 0 r/min in servo-on status. SA turns off in servo-off status or when the command speed is in acceleration/deceleration.</p>	DO-1	△	△
Home position return completion	ZP		<p>When a home position return completes normally, ZP (Home position return completion) turns on. It turns off with the following conditions in the incremental system.</p> <ol style="list-style-type: none"> 1) SON (Servo-on) is off. 2) EM2 (Forced stop 2) is off. 3) RES (Reset) is on. 4) At alarm occurrence 5) LSP (Forward rotation stroke end) or LSN (Reverse rotation stroke end) is off. 6) Home position return is not being executed. 7) Software limit is being detected. 8) Home position return is in progress. 	DO-1	△	△

2. SIGNALS AND WIRING

Device	Symbol	Connector pin No.	Function and application	I/O division	Control mode	
					C P	C L
Rough match	CPO		When a command remaining distance is lower than the rough match output range set with [Pr. PT12], CPO turns on. This is not outputted during base circuit shut-off. CPO turns on with servo-on.	DO-1	△	△
Position range output	POT		When an actual current position is within the range set with [Pr. PT21] and [Pr. PT22], POT turns on. This will be off when a home position return is not completed or base circuit shut-off is in progress.	DO-1	△	△
During a temporary stop	PUS		When a deceleration begins for a stop, PUS turns on by TSTP (Temporary stop/restart). When TSTP (Temporary stop/restart) is enabled again and an operation is restarted, PUS turns off.	DO-1	△	△
Travel completion	MEND		When the droop pulses are within the in-position output range set with [Pr. PA10] and the command remaining distance is "0", MEND turns on. MEND turns on with servo-on. MEND is off at servo-off status.	DO-1	△	△
Position end	PED		When the droop pulses are within the position end output range set with [Pr. PA10] and the command remaining distance is "0", PED turns on. When MEND (Travel completion) is on and ZP (Home position return completion) is on, PED (Position end) turns on. When ZP (Home position return completion) is on with servo-on status, PED turns on. PED is off at servo-off status.	DO-1	△	△
SYNC synchronous output	SOUT		When the status is waiting for input of the program SYNC (1 to 3), SOUT turns on. When PI1 (Program input 1) to PI3 (Program input 3) turn on, SOUT turns off.	DO-1		△
Program output 1	OUT1		OUT1 turns on with the OUTON (1) command during programming. The OUTOF (1) command turns off OUT1. You can also set time to turn off with [Pr. PT23].	DO-1		△
Program output 2	OUT2		OUT2 turns on with the OUTON (2) command during programming. The OUTOF (2) command turns off OUT2. You can also set time to turn off with [Pr. PT24].	DO-1		△
Program output 3	OUT3		OUT3 turns on with the OUTON (3) command during programming. The OUTOF (3) command turns off OUT3. You can also set time to turn off with [Pr. PT25].	DO-1		△

2. SIGNALS AND WIRING

Device	Symbol	Connector pin No.	Function and application	I/O division	Control mode																																																												
					C P	C L																																																											
Point table No. output 1	PT0	/	<p>The signals output point table Nos. in 5-bit code simultaneously with MEND (Travel completion) on.</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="5">Device (Note 1, 2)</th> <th rowspan="2">Description</th> </tr> <tr> <th>PT4</th> <th>PT3</th> <th>PT2</th> <th>PT1</th> <th>PT0</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>1</td> <td>Point table No. 1</td> </tr> <tr> <td>0</td> <td>0</td> <td>0</td> <td>1</td> <td>0</td> <td>Point table No. 2</td> </tr> <tr> <td>0</td> <td>0</td> <td>0</td> <td>1</td> <td>1</td> <td>Point table No. 3</td> </tr> <tr> <td>.</td> <td>.</td> <td>.</td> <td>.</td> <td>.</td> <td>.</td> </tr> <tr> <td>.</td> <td>.</td> <td>.</td> <td>.</td> <td>.</td> <td>.</td> </tr> <tr> <td>.</td> <td>.</td> <td>.</td> <td>.</td> <td>.</td> <td>.</td> </tr> <tr> <td>1</td> <td>1</td> <td>1</td> <td>1</td> <td>0</td> <td>Point table No. 30</td> </tr> <tr> <td>1</td> <td>1</td> <td>1</td> <td>1</td> <td>1</td> <td>Point table No. 31</td> </tr> </tbody> </table> <p>Note 1. 0: Off 1: On 2. Up to four points of DO are available; therefore, PT0 to PT4 cannot be outputted simultaneously.</p>	Device (Note 1, 2)					Description	PT4	PT3	PT2	PT1	PT0	0	0	0	0	1	Point table No. 1	0	0	0	1	0	Point table No. 2	0	0	0	1	1	Point table No. 3	1	1	1	1	0	Point table No. 30	1	1	1	1	1	Point table No. 31	DO-1	△	/
Device (Note 1, 2)					Description																																																												
PT4	PT3			PT2		PT1	PT0																																																										
0	0			0	0	1	Point table No. 1																																																										
0	0			0	1	0	Point table No. 2																																																										
0	0			0	1	1	Point table No. 3																																																										
.																																																												
.																																																												
.																																																												
1	1	1	1	0	Point table No. 30																																																												
1	1	1	1	1	Point table No. 31																																																												
Point table No. output 2	PT1	△	/																																																														
Point table No. output 3	PT2	△	/																																																														
Point table No. output 4	PT3	△	/																																																														
Point table No. output 5	PT4	△	/																																																														
Mark detection rising latch completed	MSDH	/	Turning on MSD (Mark detection) will turn on MSDH.	DO-1	△	△																																																											
Mark detection falling latch completed	MSDL	/	After MSD (Mark detection) is turned on, turning off MSD will turn on MSDL.	DO-1	△	△																																																											
Alarm code	ACD0	(CN1-24)	<p>To use these signals, set [Pr. PD34] to "___1". This signal is outputted when an alarm occurs. When an alarm is not occurring, respective ordinary signals are outputted. For details of the alarm codes, refer to chapter 8.</p>	DO-1	△	△																																																											
	ACD1	(CN1-23)																																																															
	ACD2	(CN1-22)																																																															
Variable gain selection	CDPS	/	CDPS turns on during gain switching.	DO-1	△	△																																																											
During tough drive	MTTR	/	When a tough drive is "Enabled" in [Pr. PA20], activating the instantaneous power failure tough drive will turn on MTTR.	DO-1	△	△																																																											

2. SIGNALS AND WIRING

Device	Symbol	Connector pin No.	Function and application	I/O division	Control mode																																																												
					C P	C L																																																											
M code 1 (bit 0)	MCD00		<p>This device can be used in the point table method.</p> <p>This device will be available in the future.</p> <p>These signals can be checked with output devices of the communication function. (Refer to section 10.2 (1).)</p> <p>To use these signals, set in [Pr. Po12] to " __ 1 _".</p> <p>The signals output M code simultaneously with CPO (Rough match) on. Set M code with point tables.</p>	DO-1	○	○																																																											
M code 2 (bit 1)	MCD01			DO-1	○	○																																																											
M code 3 (bit 2)	MCD02			DO-1	○	○																																																											
M code 4 (bit 3)	MCD03			DO-1	○	○																																																											
M code 5 (bit 4)	MCD10			DO-1	○	○																																																											
M code 6 (bit 5)	MCD11			DO-1	○	○																																																											
M code 7 (bit 6)	MCD12			DO-1	○	○																																																											
M code 8 (bit 7)	MCD13			DO-1	○	○																																																											
			<p>The code represents one digit of decimal using four digits of binary. The following shows correspondence of each digit and device.</p> <div style="text-align: center;"> </div> <table border="1" style="margin: 10px auto;"> <thead> <tr> <th>M code</th> <th colspan="4">Device (Note)</th> </tr> <tr> <th>First/second digit</th> <th>MCD03/ MCD13</th> <th>MCD02/ MCD12</th> <th>MCD01/ MCD11</th> <th>MCD00/ MCD10</th> </tr> </thead> <tbody> <tr><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td></tr> <tr><td>1</td><td>0</td><td>0</td><td>0</td><td>1</td></tr> <tr><td>2</td><td>0</td><td>0</td><td>1</td><td>0</td></tr> <tr><td>3</td><td>0</td><td>0</td><td>1</td><td>1</td></tr> <tr><td>4</td><td>0</td><td>1</td><td>0</td><td>0</td></tr> <tr><td>5</td><td>0</td><td>1</td><td>0</td><td>1</td></tr> <tr><td>6</td><td>0</td><td>1</td><td>1</td><td>0</td></tr> <tr><td>7</td><td>0</td><td>1</td><td>1</td><td>1</td></tr> <tr><td>8</td><td>1</td><td>0</td><td>0</td><td>0</td></tr> <tr><td>9</td><td>1</td><td>0</td><td>0</td><td>1</td></tr> </tbody> </table> <p>Note. 0: Off 1: On</p> <p>MCD00 to MCD03 and MCD10 to MCD13 turn off with the following status.</p> <ul style="list-style-type: none"> ▪ Power on ▪ Servo-off ▪ Manual operation mode ▪ At alarm occurrence 	M code	Device (Note)				First/second digit	MCD03/ MCD13	MCD02/ MCD12	MCD01/ MCD11	MCD00/ MCD10	0	0	0	0	0	1	0	0	0	1	2	0	0	1	0	3	0	0	1	1	4	0	1	0	0	5	0	1	0	1	6	0	1	1	0	7	0	1	1	1	8	1	0	0	0	9	1	0	0	1		
M code	Device (Note)																																																																
First/second digit	MCD03/ MCD13	MCD02/ MCD12	MCD01/ MCD11	MCD00/ MCD10																																																													
0	0	0	0	0																																																													
1	0	0	0	1																																																													
2	0	0	1	0																																																													
3	0	0	1	1																																																													
4	0	1	0	0																																																													
5	0	1	0	1																																																													
6	0	1	1	0																																																													
7	0	1	1	1																																																													
8	1	0	0	0																																																													
9	1	0	0	1																																																													

2. SIGNALS AND WIRING

(2) Input signal

Device	Symbol	Connector pin No.	Function and application	I/O division	Control mode	
					C P	C L
Manual pulse generator	PP	(CN1-10)	Connect the manual pulse generator (MR-HDP01). When using the signal, enable PP and NP with [Pr. PD44] and [Pr. PD46].	DI-2	△	△
	NP	(CN1-35)				
Analog torque limit	TLA	CN1-27	When using the signal, enable TL (External torque limit selection) with [Pr. PD04], [Pr. PD12], [Pr. PD14], [Pr. PD18], [Pr. PD20], [Pr. PD44], and [Pr. PD46]. When TLA is enabled, torque is limited in the full servo motor output torque range. Apply 0 V to +10 V DC between TLA and LG. Connect + of the power supply to TLA. The maximum torque is generated at +10 V. (Refer to section 3.6.1 (5) of "MR-JE-_A Servo Amplifier Instruction Manual".) If a value equal to or larger than the maximum torque is inputted to TLA, the value will be clamped at the maximum torque. Resolution: 10 bits	Analog input	△	△
Analog override	VC	CN1-2	The signal controls the servo motor setting speed by applying -10 V to +10 V to between VC and LG. The percentage will be 0% with -10 V, 100% with 0 V, and 200% with +10 V to the setting speed of the servo motor. Resolution: 14 bits or equivalent	Analog input	○	○

(3) Output signal

Device	Symbol	Connector pin No.	Function and application	I/O division	Control mode	
					C P	C L
Encoder A-phase pulse (differential line driver)	LA LAR	CN1-4 CN1-5	These devices output pulses of encoder output pulse set in [Pr. PA15] in the differential line driver type. In CCW rotation of the servo motor, the encoder B-phase pulse lags the encoder A-phase pulse by a phase angle of $\pi/2$.	DO-2	○	○
Encoder B-phase pulse (differential line driver)	LB LBR	CN1-6 CN1-7	The relation between rotation direction and phase difference of the A-phase and B-phase pulses can be changed with [Pr. PC19].			
Encoder Z-phase pulse (differential line driver)	LZ LZR	CN1-8 CN1-9	The encoder zero-point signal is outputted in the differential line driver type. One pulse is outputted per servo motor revolution. This turns on when the zero-point position is reached. (negative logic) The minimum pulse width is about 400 μ s. For home position return using this pulse, set the creep speed to 100 r/min or less.	DO-2	○	○
Encoder Z-phase pulse (open-collector)	OP	CN1-33	The encoder zero-point signal is outputted in the open-collector type.	DO-2	○	○
Analog monitor 1	MO1	CN6-3	This is used to output the data set in [Pr. PC14] to between MO1 and LG in terms of voltage. Output voltage: ± 10 V Resolution: 10 bits or equivalent	Analog output	○	○
Analog monitor 2	MO2	CN6-2	This signal outputs the data set in [Pr. PC15] to between MO2 and LG in terms of voltage. Output voltage: ± 10 V Resolution: 10 bits or equivalent	Analog output	○	○

2. SIGNALS AND WIRING

(4) Communication

Device	Symbol	Connector pin No.	Function and application	I/O division	Control mode	
					C P	C L
RS-422/RS-485 I/F	SDP SDN RDP RDN TRE	CN3-5 CN3-4 CN3-3 CN3-6 CN1-31	These are terminals for RS-422/RS-485 communication.	/	○	○

2. SIGNALS AND WIRING

2.4 Analog override


POINT
<ul style="list-style-type: none"> ● When using the analog override in the point table method or program method, enable OVR (Analog override selection). ● The following shows functions whether usable or not with the analog override. <ol style="list-style-type: none"> (1) Analog override usable <ul style="list-style-type: none"> ▪ Automatic operation mode (point table method/program method) ▪ JOG operation in the manual operation mode ▪ Automatic positioning to home position function in the point table method (2) Analog override unusable <ul style="list-style-type: none"> ▪ Manual pulse generator operation in the manual operation mode ▪ Home position return mode ▪ Test operation mode using MR Configurator2 (positioning operation/JOG operation)

You can change the servo motor speed by using VC (Analog override). The following table shows signals and parameters related to the analog override.

Item	Name	Remark
Analog input signal	VC (Analog override)	
Contact input signal	OVR (Analog override selection)	Turning on OVR enables VC (Analog override) setting value.
Parameter	[Pr. PC37 Analog override offset]	-9999 to 9999 [mV]

(1) VC (Analog override)


You can continuously set changed values from outside by applying voltage (-10 to +10 V) to VC (Analog override). The following shows percentage of the actual speed to input voltage and set speed.



Note. This diagram shows sink input interface.

2. SIGNALS AND WIRING

- (2) OVR (Analog override selection)
 Enable or disable VC (Analog override).



Select a changed value by using OVR (Analog override selection).

(Note) External input signal	Speed change value
0	No change
1	Setting of VC (Analog override) is enabled.

Note. 0: Off

1: On

- (3) Analog override offset ([Pr. PC37])

You can set an offset voltage to the input voltage of VC (Analog override) with [Pr. PC37]. The setting value ranges from -9999 to +9999 [mV].


2. SIGNALS AND WIRING

2.5 Internal connection diagram

POINT
● For details of interface and source I/O interface, refer to section 3.9 of "MR-JE- _A Servo Amplifier Instruction Manual".

The following shows an example of internal connection diagram of the point table method.

2. SIGNALS AND WIRING



- Note 1. Refer to section 9.1 for the connection of a manual pulse generator.
- Note 2. This diagram shows sink I/O interface. For source I/O interface, refer to section 3.9.3 of "MR-JE-_A Servo Amplifier Instruction Manual".
- Note 3. The illustration of the 24 V DC power supply is divided between input signal and output signal for convenience. However, they can be configured by one.
- Note 4. To use the RS-422/RS-485 communication function, connect between TRE and RDN of the final axis servo amplifier. (Refer to section 12.1.1.)

2. SIGNALS AND WIRING


2.6 Power-on sequence

POINT
<p>● The voltage of analog monitor output, output signal, etc. may be unstable at power-on.</p>

(1) Power-on procedure

- 1) Always use a magnetic contactor for the power supply wiring (L1, L2, and L3) as shown in section 3.1. Configure an external sequence to switch off the magnetic contactor as soon as an alarm occurs.
- 2) The servo amplifier receives the SON (Servo-on) in 4 s to 5 s after the power supply is switched on. Therefore, when SON (Servo-on) is switched on simultaneously with the power supply, the base circuit will switch on in about 4 s to 5 s, and the RD (Ready) will switch on in further about 5 ms, making the servo amplifier ready to operate. (Refer to (2) of this section.)
- 3) When RES (Reset) is switched on, the base circuit is shut off and the servo motor shaft coasts.

(2) Timing chart



3. DISPLAY AND OPERATION SECTIONS

3. DISPLAY AND OPERATION SECTIONS

For the details of the following items, refer to chapter/section (of "MR-JE-_A Servo Amplifier Instruction Manual") indicated in the table.

Item	Detailed explanation
	MR-JE-_A
Test operation mode	Section 4.5.9

3.1 MR-JE-_A

3.1.1 Display flowchart

Press the "MODE" button once to shift to the next display mode. Refer to section 3.1.2 and later for the description of the corresponding display mode.

3. DISPLAY AND OPERATION SECTIONS

Display mode transition	Initial display	Function	Reference
		Servo status display. For the point table and program, is displayed at power-on.	Section 3.1.2
		One-touch tuning Select this when performing the one-touch tuning.	MR-JE- _A Servo Amplifier Instruction Manual section 6.2
		Sequence display, drive recorder enabled/disabled display, external I/O signal display, output signal (DO) forced output, test operation, software version display, VC automatic offset, servo motor series ID display, servo motor type ID display, servo motor encoder ID display, teaching function	Section 3.1.3
		Current alarm display, alarm history display, and parameter error No./point table error No. display	Section 3.1.4
		Display and setting of point table data. This is displayed only in the point table method, not in other control modes.	Section 3.1.5
		Display and setting of basic setting parameters.	Section 3.1.6
		Display and setting of gain/filter parameters.	
		Display and setting of extension setting parameters.	
		Display and setting of I/O setting parameters.	
		Display and setting of extension setting 2 parameters.	
		Display and setting of extension setting 3 parameters.	
		Display and setting of positioning control parameters.	

Note. When the axis name is set to the servo amplifier using MR Configurator2, the servo status is displayed after the axis name is displayed.

3. DISPLAY AND OPERATION SECTIONS


3.1.2 Status display mode

The servo status during operation is shown on the 5-digit, 7-segment LED display. Press the "UP" or "DOWN" button to change the display data as desired. When a servo status is selected, the corresponding symbol is displayed. Press the "SET" button to display its data. However, only when the power is turned on, the data will be displayed after the status symbol selected with [Pr. PC36] is displayed for 2 s.

(1) Display transition

After selecting the status display mode with the "MODE" button, pressing the "UP" or "DOWN" button changes the display as follows:

3. DISPLAY AND OPERATION SECTIONS



3. DISPLAY AND OPERATION SECTIONS

(2) Status display list

The following table lists the servo statuses that may be shown.

Status display	Symbol	Unit	Description	Control mode (Note 1)	
				CP	CL
Cumulative feedback pulses	C	pulse	Feedback pulses from the servo motor encoder are counted and displayed. The values in excess of ± 99999 can be counted. However, the counter shows only the lower five digits of the actual value since the servo amplifier display is five digits. Press the "SET" button to reset the display value to "0". The decimal points in the upper four digits are lit for negative value.	○	○
Servo motor speed	r	r/min	The servo motor speed is displayed. It is displayed rounding off 0.1 r/min unit.	○	○
Droop pulses	E	pulse	The number of droop pulses in the deviation counter are displayed. The decimal points in the upper four digits are lit for reverse rotation pulses. The values in excess of ± 99999 can be counted. However, the counter shows only the lower five digits of the actual value since the servo amplifier display is five digits. The number of pulses displayed is in the encoder pulse unit.	○	○
Cumulative command pulses	P	pulse	Not used with the positioning mode. "0" is always displayed.		
Command pulse frequency	n	kpulse/s	Not used with the positioning mode. "0" is always displayed.		
Analog speed command voltage Analog speed limit voltage	F	V	Not used with the positioning mode. An applied voltage to the CN1 connector is displayed.		
Analog torque command voltage	U	V	Not used with the positioning mode. An applied voltage to the CN1 connector is displayed.		
Analog torque limit voltage			Voltage of TLA (Analog torque limit) is displayed.	○	○
Regenerative load ratio	L	%	The ratio of regenerative power to permissible regenerative power is displayed in %.	○	○
Effective load ratio	J	%	The continuous effective load current is displayed. The effective value in the past 15 s is displayed, with the rated current being 100 %.	○	○
Peak load ratio	b	%	The maximum torque generated is displayed. The highest value in the past 15 s is displayed, with the rated torque being 100 %.	○	○
Instantaneous torque	T	%	The instantaneous torque is displayed. The torque generated is displayed in real time, with the rated torque being 100%.	○	○
Within one-revolution position (1 pulse unit)	Cy1	pulse	Position within one revolution is displayed in encoder pulses. The values in excess of ± 99999 can be counted. However, the counter shows only the lower five digits of the actual value since the servo amplifier display is five digits. When the servo motor rotates in the CCW direction, the value is added.	○	○
Within one-revolution position (1000 pulse unit)	Cy2	1000 pulses	The within one-revolution position is displayed in 1000 pulse increments of the encoder. When the servo motor rotates in the CCW direction, the value is added.	○	○
ABS counter	LS	rev	Travel distance from power on is displayed by counter value.	○	○
Load to motor inertia ratio	dC	Multiplier	The estimated ratio of the load inertia moment to the servo motor shaft inertia moment is displayed.	○	○
Bus voltage	Pn	V	The voltage of main circuit converter (between P+ and N-) is displayed.	○	○
Encoder inside temperature	ETH	°C	Inside temperature of encoder detected by the encoder is displayed.	○	○
Settling time	ST	ms	Settling time is displayed. When it exceeds 1000 ms, "1000" will be displayed.	○	○
Oscillation detection frequency	oF	Hz	Frequency at the time of oscillation detection is displayed.	○	○
Number of tough drive operations	Td	times	The number of tough drive functions activated is displayed.	○	○

3. DISPLAY AND OPERATION SECTIONS

Status display	Symbol	Unit	Description	Control mode (Note 1)	
				CP	CL
Unit power consumption 1 (1 W unit)	PC1	W	Unit power consumption is displayed by increment of 1 W. Positive value indicates power running, and negative value indicates regeneration. The values in excess of ± 99999 can be counted. However, the counter shows only the lower five digits of the actual value since the servo amplifier display is five digits.	○	○
Unit power consumption 2 (1 kW unit)	PC2	kW	Unit power consumption is displayed by increment of 1 kW. Positive value indicates power running, and negative value indicates regeneration.	○	○
Unit total power consumption 1 (increment of 1 Wh)	TPC1	Wh	Unit total power consumption is displayed by increment of 1 Wh. Positive value is cumulated during power running and negative value during regeneration. The values in excess of ± 99999 can be counted. However, the counter shows only the lower five digits of the actual value since the servo amplifier display is five digits.	○	○
Unit total power consumption 2 (increment of 100 kWh)	TPC2	100 kWh	Unit total power consumption is displayed by increment of 100 kWh. Positive value is cumulated during power running and negative value during regeneration.	○	○
Current position	PoS	$10^{STM} \mu\text{m}$ $10^{(STM-4)} \text{inch}$ 10^{-3} degree pulse (Note 2)	When " _ _ 0 _ " (positioning display) is set in [Pr. PT26], the current position is displayed as machine home position is 0. When " _ _ 1 _ " (roll feed display) is set in [Pr. PT26], the actual current position is displayed as start position is 0. The values in excess of ± 99999 can be counted. However, the counter shows only the lower five digits of the actual value since the servo amplifier display is five digits.	○	○
Command position	CPoS	$10^{STM} \mu\text{m}$ $10^{(STM-4)} \text{inch}$ 10^{-3} degree pulse (Note 2)	When " _ _ 0 _ " (positioning display) is set in [Pr. PT26], the command current position is displayed as machine home position is 0. When " _ _ 1 _ " (roll feed display) is set in [Pr. PT26], turning on the start signal starts counting from 0 and a command current position to the target position is displayed in the automatic mode. The command positions of the selected point table are displayed at a stop. At the manual mode, the command positions of the selected point table are displayed. The values in excess of ± 99999 can be counted. However, the counter shows only the lower five digits of the actual value since the servo amplifier display is five digits.	○	○
Command remaining distance	rn	$10^{STM} \mu\text{m}$ $10^{(STM-4)} \text{inch}$ 10^{-3} degree pulse (Note 2)	The remaining distance to the command position of the currently selected point table/program is displayed. The values in excess of ± 99999 can be counted. However, the counter shows only the lower five digits of the actual value since the servo amplifier display is five digits.	○	○
Point table No./Program No.	Pno		The point table No./program No. currently being executed is displayed. The selected number is displayed during a temporary stop or manual operation.	○	○
Step No.	Sno		The step No. of the program currently being executed is displayed. At a stop, 0 is displayed.		○
Analog override voltage	oru	V	The analog override voltage is displayed.	○	○
Override level	or	%	The setting value of the override is displayed. When the override is disabled, 100% is displayed.	○	○

3. DISPLAY AND OPERATION SECTIONS

Status display	Symbol	Unit	Description	Control mode (Note 1)	
				CP	CL
Cam axis one cycle current value	CCyC	10^{STM} μm $10^{(\text{STM}-4)}$ inch $10^{(\text{STM}-3)}$ degree pulse (Note 3)	The current position in one cycle of CAM axis is displayed with the range of "0 to (cam axis one cycle length - 1)", the cam axis one cycle current value which is calculated from the travel distance inputted to the cam axis. The values in excess of ± 99999 can be counted. However, the counter shows only the lower five digits of the actual value since the servo amplifier display is five digits. When the simple cam function is disabled, 0 is always displayed. Refer to section 6.1.8 for detecting point.	○	○
Cam standard position	CbAS	10^{STM} μm $10^{(\text{STM}-4)}$ inch $10^{(\text{STM}-3)}$ degree pulse (Note 2)	A feed current value which is the standard position of the cam operation is displayed. The values in excess of ± 99999 can be counted. However, the counter shows only the lower five digits of the actual value since the servo amplifier display is five digits. When the simple cam function is disabled, 0 is always displayed. Refer to section 6.1.8 for detecting point.	○	○
Cam axis feed current value	CCMd	10^{STM} μm $10^{(\text{STM}-4)}$ inch $10^{(\text{STM}-3)}$ degree pulse (Note 2)	A feed current value during the cam axis control is displayed. The values in excess of ± 99999 can be counted. However, the counter shows only the lower five digits of the actual value since the servo amplifier display is five digits. When the simple cam function is disabled, 0 is always displayed. Refer to section 6.1.8 for detecting point.	○	○
Cam No. in execution	Cno	/	Cam No. in execution is displayed. When the simple cam function is disabled, 0 is always displayed. Refer to section 6.1.8 for detecting point.	○	○
Cam stroke amount in execution	CSTK	10^{STM} μm $10^{(\text{STM}-4)}$ inch $10^{(\text{STM}-3)}$ degree pulse (Note 2)	Cam stroke amount in execution is displayed. The values in excess of ± 99999 can be counted. However, the counter shows only the lower five digits of the actual value since the servo amplifier display is five digits. When the simple cam function is disabled, 0 is always displayed. Refer to section 6.1.8 for detecting point.	○	○
Main axis current value	MCMd	10^{STM} μm $10^{(\text{STM}-4)}$ inch $10^{(\text{STM}-3)}$ degree pulse (Note 3)	A current value of the input axis (synchronous encoder axis or servo input axis) is displayed. Unit is increment of input axis position. The values in excess of ± 99999 can be counted. However, the counter shows only the lower five digits of the actual value since the servo amplifier display is five digits. When the simple cam function is disabled, 0 is always displayed. Refer to section 6.1.8 for detecting point.	○	○
Main axis one cycle current value	MCyC	10^{STM} μm $10^{(\text{STM}-4)}$ inch $10^{(\text{STM}-3)}$ degree pulse (Note 3)	The input travel amount of the input axis in a range between 0 and (cam axis one cycle length setting - 1) is displayed. Unit is an increment of cam axis one cycle. When the simple cam function is disabled, 0 is always displayed. Refer to section 6.1.8 for detecting point.	○	○

Note 1. CP: Positioning mode (point table method)

CL: Positioning mode (program method)

2. The unit can be selected from μm /inch/degree/pulse with [Pr. PT01].

3. The unit can be changed with "Cam control data No. 14" to μm /inch/degree/pulse.

3. DISPLAY AND OPERATION SECTIONS

(3) Changing the status display screen

The status display on the servo amplifier at power-on can be changed with [Pr. PC36]. The status displayed by default varies depending on the control mode as follows:


Control mode	Status display
Position	Cumulative feedback pulses
Position/speed	Cumulative feedback pulses/servo motor speed
Speed	Servo motor speed
Speed/torque	Servo motor speed/analog torque command voltage
Torque	Analog torque command voltage
Torque/position	Analog torque command voltage/cumulative feedback pulses
Positioning (point table method/program method)	Current position

3. DISPLAY AND OPERATION SECTIONS

3.1.3 Diagnostic mode

Diagnosis contents can be displayed on the display. Press the "UP" or "DOWN" button to change the display data as desired.

(1) Display transition











3. DISPLAY AND OPERATION SECTIONS

(2) Diagnosis display list

Name		Display	Description
Sequence			Not ready Indicates that the servo amplifier is being initialized or an alarm has occurred.
			Ready Indicates that initialization is completed, and the servo amplifier is in servo-on state and ready to operate.
Drive recorder enabled/disabled display			Drive recorder enabled When an alarm occurs in this state, the drive recorder will operate and record the status of occurrence.
			Drive recorder disabled The drive recorder will not operate on the following conditions. 1. The graph function of MR Configurator2 is being used. 2. The machine analyzer function is being used. 3. [Pr. PF21] is set to "-1".
External I/O signal display		Refer to section 3.1.7.	This Indicates the on/off status of external I/O signal. The upper segments correspond to the input signals and the lower segments to the output signals.
Output signal (DO) forced output			This allows digital output signal to be switched on/off forcibly. Refer to section 3.1.8 for details.
Test operation mode	JOG operation		JOG operation can be performed when there is no command from an external controller. For details, refer to section 4.5.9 (2) of "MR-JE-_A Servo Amplifier Instruction Manual".
	Positioning operation		Positioning operation can be performed when there is no command from an external controller. MR Configurator2 is required to perform positioning operation. For details, refer to section 4.5.9 (3) of "MR-JE-_A Servo Amplifier Instruction Manual".
	Motor-less operation		Without connecting the servo motor, output signals or status display can be provided in response to the input device as if the servo motor is actually running. For details, refer to section 4.5.9 (4) of "MR-JE-_A Servo Amplifier Instruction Manual".
	Machine analyzer operation		Merely connecting the servo amplifier allows the resonance point of the mechanical system to be measured. MR Configurator2 is required to perform machine analyzer operation. For details, refer to section 11.4 of "MR-JE-_A Servo Amplifier Instruction Manual".
	For manufacturer adjustment		This is for manufacturer adjustment.
	Single-step feed		When the positioning operation is executed in accordance with the point table or program set by MR Configurator2, the diagnosis display changes to "d-06" during single-step feed. Refer to section 3.1.9 for details. The status will be displayed with the "MODE" button. The "UP" and "DOWN" buttons are disabled.

3. DISPLAY AND OPERATION SECTIONS

Name	Display	Description
Software version: lower		Indicates the version of the software.
Software version: upper		Indicates the system number of the software.
Automatic VC offset (Note)		<p>If offset voltages in the analog circuits inside and outside the servo amplifier cause the servo motor setting speed not to be the designated value at VC of 0 V, a zero-adjustment of offset voltages will be automatically performed. When using the VC automatic offset, enable it in the following procedures. When it is enabled, [Pr. PC37] value changes to the automatically adjusted offset voltage.</p> <ol style="list-style-type: none"> 1) Press the "SET" button once. 2) Set the number in the first digit to "1" with the "UP" button. 3) Press the "SET".button. <p>This function cannot be used if the input voltage of VC is -0.4 V or less, or +0.4 V or more.</p>
Servo motor series ID		<p>Push the "SET" button to show the series ID of the servo motor currently connected.</p> <p>For indication details, refer to appendix 1 of "HF-KN/HF-SN servo Motor Instruction Manual".</p>
Servo motor type ID		<p>Push the "SET" button to show the type ID of the servo motor currently connected.</p> <p>For indication details, refer to appendix 1 of "HF-KN/HF-SN servo Motor Instruction Manual".</p>
Servo motor encoder ID		<p>Push the "SET" button to show the encoder ID of the servo motor currently connected.</p> <p>For indication details, refer to appendix 1 of "HF-KN/HF-SN servo Motor Instruction Manual".</p>
For manufacturer adjustment		This is for manufacturer adjustment.
For manufacturer adjustment		This is for manufacturer adjustment.
Teaching function	Refer to section 3.1.10.	<p>After an operation travels to a target position (MEND (Travel completion) is turned on) with a JOG operation or manual pulse generator operation, pushing the "SET" button of the operation part or turning on TCH (Teach) will import position data. This function is available only in the point table method. In other control modes, the display remains the same.</p>

Note. Even if VC automatic offset is performed and 0 V is inputted, the speed may not completely be the set value.

3. DISPLAY AND OPERATION SECTIONS

3.1.4 Alarm mode

The current alarm, past alarm history and parameter error are displayed. The lower 2 digits on the display indicate the alarm No. that has occurred or the parameter No. in error.

Name	Display (Note 1)	Description
Current alarm		Indicates no occurrence of an alarm.
		Indicates the occurrence of [AL. 33.1 Main circuit voltage error]. Flickers at alarm occurrence.
Alarm history		Indicates that the last alarm is [AL. 50.1 Thermal overload error 1 during operation].
		Indicates the second last alarm is [AL. 33.1 Main circuit voltage error].
		Indicates the third last alarm is [AL. 10.1 Voltage drop in the control circuit power].
		Indicates that there is no tenth alarm in the past.
		Indicates that there is no eleventh alarm in the past.
		Indicates that there is no twelfth alarm in the past.
		Indicates that there is no sixteenth alarm in the past.
Parameter error No./point table error No. (Note 2)		This indicates no occurrence of [AL. 37 Parameter error].
		The data content error of [Pr. PA12 Reverse rotation torque limit].
		The value of the point table is over the setting range. The error point table No. (intermediate digit "2") and item (lower digit "d") are displayed. The following shows the items. P: position data, d: motor speed, A: acceleration time constant, b: deceleration time constant, n: dwell, H: sub function, M: M code

- Note 1. If a parameter error and point table error occur simultaneously, the display shows the parameter error.
2. The display shows only when the current alarm is [AL. 37 Parameter error].

3. DISPLAY AND OPERATION SECTIONS

The following is additional information of alarm occurrence:


- (1) The current alarm is displayed in any mode.
- (2) Even during an alarm occurrence, the other display can be viewed by pressing the button in the operation area. At this time, the decimal point in the fourth digit remains flickering.
- (3) Remove the cause of the alarm and clear it in any of the following methods. (Refer to chapter 8 for the alarms that can be cleared.)
 - (a) Cycle the power.
 - (b) Press the "SET" button on the current alarm display.
 - (c) Turn on RES (Reset).
- (4) Use [Pr. PC18] to clear the alarm history.
- (5) Press the "UP" or "DOWN" button to move to the next history.

3. DISPLAY AND OPERATION SECTIONS

3.1.5 Point table setting

You can set the target position, servo motor speed, acceleration time constant, deceleration time constant, dwell, sub function and M code.

(1) Display transition



3. DISPLAY AND OPERATION SECTIONS

(2) Setting list

The following point table setting can be displayed.

Status display	Symbol	Unit	Description	Indication range
Point table No.	Po001		Specify the point table to set the target position, servo motor speed, acceleration time constant, deceleration time constant, dwell, sub function and M code.	1 to 31
Target position	PoS	10 ^{STM} μm 10 ^(STM-4) inch 10 ⁻³ degree pulse (Note)	Set the travel distance.	-999999 to 999999
Servo motor speed	SPd	r/min	Set the command speed of the servo motor for execution of positioning. The setting value must be within the permissible speed of the servo motor used. If a value equal to or larger than the permissible speed is set, the value will be clamped at the permissible speed.	0 to Permissible speed
Acceleration time constant	STA	ms	Set a time for the servo motor to reach the rated speed.	0 to 20000
Deceleration time constant	STb	ms	Set a time for the servo motor to stop from the rated speed.	0 to 20000
Dwell	TLn	ms	This function is enabled when you select the point table by input signal. To disable the dwell, set "0" or "2" to the sub function. To perform a continuous operation, set "1", "3", "8", "9", "10", or "11" to the sub function and 0 to the dwell. When the dwell is set, the position command of the selected point table is completed. After the set dwell has elapsed, start the position command of the next point table.	0 to 20000
Sub function	H		This function is enabled when you select the point table by input signal. (1) When using the point table in the absolute value command method 0: Executes automatic operation for a selected point table. 1: Executes automatic continuous operation without stopping for the next point table. 8: Executes automatic continuous operation without stopping for the point table selected at the start. 9: Executes automatic continuous operation without stopping for the point table No. 1. (2) When using the point table in the incremental value command method 2: Executes automatic operation for a selected point table. 3: Executes automatic continuous operation without stopping for the next point table. 10: Executes automatic continuous operation without stopping for the point table selected at the start. 11: Executes automatic continuous operation without stopping for the point table No. 1. When a different rotation direction is set, smoothing zero (command output) is confirmed and then the rotation direction is reversed. When "1" or "3" is set to the point table No. 31, [AL. 61] will occur at the time of point table execution.	0 to 3, 8 to 11
M code	MCd		This is the code output at the completion of positioning. This code will be available in the future. Outputs the first digit and the second digit of the M code in 4-bit binary respectively.	0 to 99

Note. The unit can be selected from μm/inch/degree/pulse with [Pr. PT01].


3. DISPLAY AND OPERATION SECTIONS

(3) Operation method

POINT
<p>● After changing and defining the setting values of the specified point table, the defined setting values of the point table are displayed. To discard the changed setting, press the "MODE" button for 2 s or more. The setting before the change will be displayed. Keep pressing the "UP" or "DOWN" button to continuously change the most significant digit of the setting values.</p>

(a) Setting of 5 or less digits

The following example is the operation method at power-on to set "1" to the sub function of the point table No. 1.




Press the "UP" or "DOWN" button to switch to other item of the same point table No.

Press the "MODE" button to switch to the next point table No.

3. DISPLAY AND OPERATION SECTIONS

(b) Setting of 6 or more digits

The following example is the operation method to change the position data of the point table No. 1 to "123456".




3. DISPLAY AND OPERATION SECTIONS

3.1.6 Parameter mode

(1) Parameter mode transition


After selecting the corresponding parameter mode with the "MODE" button, pressing the "UP" or "DOWN" button changes the display as shown below.



(2) Operation method

(a) Parameters of 5 or less digits

The following example shows the operation procedure performed after power-on to change the control mode to the positioning mode (point table method) with [Pr. PA01 Operation mode]. Press "MODE" to switch to the basic setting parameter display.




To shift to the next parameter, press the "UP" or "DOWN" button.
After changing [Pr. PA01], cycle the power to enable the setting.

3. DISPLAY AND OPERATION SECTIONS

(b) Parameters of 6 or more digits

The following example gives the operation procedure to change the electronic gear numerator to "123456" with [Pr. PA06 Electronic gear numerator].



3. DISPLAY AND OPERATION SECTIONS


3.1.7 External I/O signal display

POINT	<p>● The I/O signal settings can be changed using I/O setting parameters [Pr. PD04] to [Pr. PD28].</p>
--------------	--

The on/off states of the digital I/O signals connected to the servo amplifier can be confirmed.


(1) Operation

The display at power-on. Switch to the diagnostic display with the "MODE" button.



(2) Display definition

The 7-segment LED segments and CN1 connector pins correspond as shown below.



The LED segment corresponding to the pin is lit to indicate on, and is extinguished to indicate off. For each pin signal in control modes, refer to section 2.2.

3. DISPLAY AND OPERATION SECTIONS


3.1.8 Output signal (DO) forced output

POINT

● When the servo system is used in a vertical lift application, turning on MBR (Electromagnetic brake interlock) by the DO forced output after assigning it to connector CN1 will release the electromagnetic brake, causing a drop. Take drop preventive measures on the machine side.

Output signals can be switched on/off forcibly independently of the servo status. This function can be used for output signal wiring check, etc. This operation must be performed in the servo off state by turning off SON (Servo-on).

The display screen at power-on. Switch to the diagnostic display with the "MODE" button.



3. DISPLAY AND OPERATION SECTIONS

3.1.9 Single-step feed



CAUTION


- The test operation mode is designed for checking servo operation. Do not use it for actual operation.
- If the servo motor operates unexpectedly, use EM2 (Forced stop 2) to stop it.

POINT


- MR Configurator2 is required to perform single-step feed.
- Test operation cannot be performed if SON (Servo-on) is not turned off.

The positioning operation can be performed in accordance with the point table No. or the program No. set by MR Configurator2.

Select the test operation/single-step feed from the menu of MR Configurator2. When the single-step feed window is displayed, input the following items and operate.



Point table operation



Program operation

(1) Point table No. or program No. setting

Enter a point table No. in the input box (a) "Point table No.", or a program No. in the input box (b) "Program No."

(2) Forward/reverse the servo motor

Click "Operation Start" button (c) to rotate the servo motor.

(3) Pause the servo motor

Click "Pause" button (d) to temporarily stop the servo motor.

While the servo motor is temporarily stopped, click the "Operation Start" button (c) to restart the rotation of the remaining travel distance.

While the servo motor is temporarily stopped, click the "Stop" button (e) to clear the remaining travel distance.

(4) Stop the servo motor

Click the "Stop" button (e) to stop the servo motor. At this time, the remaining travel distance will be cleared. Click the "Operation Start" (c) button to restart the rotation.

3. DISPLAY AND OPERATION SECTIONS

(5) Forced stop of the servo motor software

Click the "Forced Stop" (f) button to make an instantaneous stop. When the "Forced Stop" button is enabled, the "Operation Start" button cannot be used. Click the "Forced Stop" button again to enable the "Operation Start" button.

(6) Switch to the normal operation mode

Before switching from the test operation mode to the normal operation mode, turn off the servo amplifier.

3. DISPLAY AND OPERATION SECTIONS

3.1.10 Teaching function

After an operation travels to a target position (MEND (Travel completion) is turned on) with a JOG operation or manual pulse generator operation, pushing the "SET" button of the operation area or turning on TCH (Teach) will import the position data. This function is available only in the point table method. In other control modes, the display remains the same.

(1) Teaching preparation




Teaching setting initial display

Press the "SET" button for approximately 2 s to switch to the teaching setting mode.



When the lower three digits flicker, press the "UP" or "DOWN" button to select the point table.



When the lower three digits flicker, press the "SET" button to complete the teaching setting preparation. The upper two digits on the display will flicker on completion of proper preparation

(2) Position data setting method

After an operation travels to a target position (MEND (Travel completion) is turned on) with a JOG operation or manual pulse generator operation, pushing the "SET" button of the operation part or turning on TCH (Teach) will set the positioning address as position data.



When the upper two digits flicker, the current position is written to the selected point table by pressing the "SET" button.



When the upper two digits or the lower two digits flicker, the display returns to the teaching setting initial screen by pressing the "MODE" button.

The following shows the conditions for when the teaching function operates.

- (a) When the "positioning command method" of [Pr. PT01] is set to absolute value command method (___0)
- (b) Home position return completion (ZP (Home position return completion) is turned on)
- (c) While the servo motor is stopped (command output = 0, MEND (Travel completion) is turned on)

4. HOW TO USE THE POINT TABLE

4. HOW TO USE THE POINT TABLE

For the details of the following items, refer to chapter/section (of "MR-JE-_A Servo Amplifier Instruction Manual") indicated in the table.

Item	Detailed explanation
	MR-JE-_A
Switching power on for the first time	Section 4.1

POINT
● For the mark detection function (Current position latch), refer to section 6.2.2.
● For the mark detection function (Interrupt positioning), refer to section 6.2.3.

4. HOW TO USE THE POINT TABLE

4.1 Startup

4.1.1 Power on and off procedures

When the servo amplifier is powered on for the first time, the control mode is set to position control mode. (Refer to section 4.2.1 of "MR-JE-_A Servo Amplifier Instruction Manual".)

This section provides a case where the servo amplifier is powered on after setting the positioning mode.

(1) Power-on

Switch the power on in the following procedure. Always follow this procedure at power-on.

- 1) Switch off SON (Servo-on).
- 2) Make sure that ST1 (Forward rotation start) and ST2 (Reverse rotation start) are off.
- 3) Switch on the main circuit power supply and the control circuit power supply.
The display shows "Pos" and 2 s later shows data.



(2) Power-off

- 1) Switch off ST1 (Forward rotation start) and ST2 (Reverse rotation start).
- 2) Switch off SON (Servo-on).
- 3) Switch off the main circuit power supply and the control circuit power supply.

4.1.2 Stop

If any of the following situations occurs, the servo amplifier suspends and stops the operation of the servo motor.

Refer to section 3.10 of "MR-JE-_A Servo Amplifier Instruction Manual" for the servo motor with an electromagnetic brake.

Operation/command	Stopping condition
Switch off SON (Servo-on).	The base circuit is shut off, and the servo motor coasts.
Alarm occurrence	The servo motor decelerates to a stop. With some alarms; however, the dynamic brake operates to stop the servo motor. (Refer to chapter 8. (Note))
EM2 (Forced stop 2) off	The servo motor decelerates to a stop with the command. [AL. E6 Servo forced stop warning] occurs. Refer to section 2.3 for EM1.
LSP (Forward rotation stroke end) off or LSN (Reverse rotation stroke end) off	The servo motor stops immediately and will be servo locked. Operation in the opposite direction is possible.


Note. Only a list of alarms and warnings is listed in chapter 8. Refer to "MELSERVO-JE Servo Amplifier Instruction Manual (Troubleshooting)" for details of alarms and warnings.

4. HOW TO USE THE POINT TABLE

4.1.3 Test operation

Before starting an actual operation, perform a test operation to make sure that the machine operates normally.

Refer to section 4.1 for how to power on and off the servo amplifier.



4. HOW TO USE THE POINT TABLE

4.1.4 Parameter setting

POINT
<p>●The following encoder cables are of four-wire type. When using any of these encoder cables, set [Pr. PC22] to "1 ___" to select the four-wire type. Incorrect setting will result in [AL. 16 Encoder initial communication error 1].</p> <p>MR-EKCBL30M-L MR-EKCBL30M-H MR-EKCBL40M-H MR-EKCBL50M-H</p>

When you use the servo in the point table method, set [Pr. PA01] to "___6" (Positioning mode (point table method)). In the point table method, the servo can be used by merely changing the basic setting parameters ([Pr. PA __]) and the positioning control parameters ([Pr. PT __]) mainly.

As necessary, set other parameters.

The following table shows the necessary setting of [Pr. PA __] and [Pr. PT __] in the point table method.

Operation mode selection item		Parameter setting		Input device setting		
		[Pr. PA01]	[Pr. PT04]	MD0 (Note 1)	DI0 to DI4 (Note 1, 2)	
Automatic operation mode in point table method	Each positioning operation		___6	/	On	Set the point table No. (Refer to section 4.2.1 (2) (b).)
	Automatic continuous operation	Varying-speed operation				
		Automatic continuous positioning operation				
Manual operation mode	JOG operation		/	Off	/	
	Manual pulse generator operation					
Home position return mode	Dog type		___6	/	On	All off
	Count type					
	Data set type					
	Stopper type					
	Home position ignorance (servo-on position as home position)					
	Dog type rear end reference					
	Count type front end reference					
	Dog cradle type					
	Dog type last Z-phase reference					
	Dog type front end reference					
Dogless Z-phase reference						

Note 1. MD0: Operation mode selection 1, DI0 to DI4: Point table No. selection 1 to Point table No. selection 5

2. DI4 is available only with the communication function. This device cannot be assigned as an input signal.

4. HOW TO USE THE POINT TABLE

4.1.5 Point table setting

Set the data for operation to the point table. The following shows the items to be set.


Item	Main description
Position data	Set the position data for movement.
Servo motor speed	Set the command speed of the servo motor for execution of positioning.
Acceleration time constant	Set the acceleration time constant.
Deceleration time constant	Set the deceleration time constant.
Dwell	Set the waiting time when performing automatic continuous operation.
Sub function	Set when performing automatic continuous operation.
M code	The first digit and the second digit of the M code are outputted in 4-bit binary respectively. M code will be available in the future.

Refer to section 4.2.2 for details of the point table.

4.1.6 Actual operation

Start actual operation after confirmation of normal operation by test operation and completion of the corresponding parameter settings.

4.1.7 Troubleshooting at start-up

 CAUTION	<ul style="list-style-type: none"> ● Never make a drastic adjustment or change to the parameter values as doing so will make the operation unstable.
--	---

POINT	<ul style="list-style-type: none"> ● Using MR Configurator2, you can refer to the reason for rotation failure, etc.
--------------	--

The following faults may occur at start-up. If any of such faults occurs, take the corresponding action. "MR-JE-_A" means "MR-JE-_A Servo Amplifier Instruction Manual".

No.	Start-up sequence	Fault	Investigation	Possible cause	Reference
1	Power on	<ul style="list-style-type: none"> • The 7-segment LED display does not turn on. • The 7-segment LED display flickers. 	Not solved even if CN1, CN2, and CN3 connectors are disconnected.	1. Power supply voltage fault 2. The servo amplifier is malfunctioning.	/
			Solved when CN1 connector is disconnected.	Power supply of CN1 cabling is shorted.	
			Solved when CN2 connector is disconnected.	1. Power supply of encoder cabling is shorted. 2. Encoder is malfunctioning.	
			Solved when CN3 connector is disconnected.	Power supply of CN3 cabling is shorted.	
		Alarm occurs.	Refer to chapter 8 and remove the cause.		Chapter 8 (Note)
2	Switch on SON (Servo-on).	Alarm occurs.	Refer to chapter 8 and remove the cause.		Chapter 8 (Note)
		Servo motor shaft is not servo-locked. (Servo motor shaft is free.)	1. Check the display to see if the servo amplifier is ready to operate. 2. Check the external I/O signal indication (section 3.1.7) to see if SON (Servo-on) is on.	1. SON (Servo-on) is not input. (wiring mistake) 2. 24 V DC power is not supplied to DICOM.	Section 3.1.7

4. HOW TO USE THE POINT TABLE

No.	Start-up sequence	Fault	Investigation	Possible cause	Reference
3	Perform a home position return.	Servo motor does not rotate.	Check the on/off status of the input signal with the external I/O signal display. (Refer to section 3.1.7.)	LSP, LSN, and ST1 are off.	Section 3.1.7
			Check [Pr. PA11 Forward rotation torque limit] and [Pr. PA12 Reverse rotation torque limit].	Torque limit level is too low for the load torque.	Section 7.2.1
			When TLA (Analog torque limit) is usable, check the input voltage on the status display.	Torque limit level is too low for the load torque.	Section 3.1.2
		The home position return is not completed.	Check the on/off status of input signal DOG with the external I/O signal display. (Refer to section 3.1.7.)	The proximity dog is set incorrectly.	Section 3.1.7
4	Switch on ST1 (Forward rotation start) or ST2 (Reverse rotation start).	Servo motor does not rotate.	Check the on/off status of the input signal with the external I/O signal display (section 3.1.7).	LSP, LSN, and ST2 are off.	Section 3.1.7
			Check [Pr. PA11 Forward rotation torque limit] and [Pr. PA12 Reverse rotation torque limit].	Torque limit level is too low for the load torque.	Section 7.2.1
			When TLA (Analog torque limit) is usable, check the input voltage on the status display.	Torque limit level is too low for the load torque.	Section 3.1.2
5	Gain adjustment	Rotation ripples (speed fluctuations) are large at low speed.	Make gain adjustment in the following procedure. 1. Increase the auto tuning response level. 2. Repeat acceleration and deceleration several times to complete auto tuning.	Gain adjustment fault	MR-JE-_A Chapter 6
		Large load inertia moment causes the servo motor shaft to oscillate side to side.	If the servo motor may be driven with safety, repeat acceleration and deceleration three times or more to complete the auto tuning.	Gain adjustment fault	MR-JE-_A Chapter 6

Note. Only a list of alarms and warnings is listed in chapter 8. Refer to "MELSERVO-JE Servo Amplifier Instruction Manual (Troubleshooting)" for details of alarms and warnings.

4. HOW TO USE THE POINT TABLE

4.2 Automatic operation mode

4.2.1 Automatic operation mode

(1) Command method


Set point tables in advance, and select any point table by using an input signal or RS-422/RS-485 communication. Start the operation using ST1 (Forward rotation start) or ST2 (Reverse rotation start). Absolute value command method and incremental value command method are available in automatic operation mode.

(a) Absolute value command method

As position data, set the target address to be reached.

1) mm, inch, and pulse unit

Setting range: -999999 to 999999 [$\times 10^{\text{STM}}$ μm] (STM = Feed length multiplication [Pr. PT03])
 -999999 to 999999 [$\times 10^{(\text{STM}-4)}$ inch] (STM = Feed length multiplication [Pr. PT03])
 -999999 to 999999 [pulse]




2) Degree unit

Set the target position by indicating the CCW direction with a "+" sign and the CW direction with a "-" sign.

In the absolute value command method, the rotation direction can be specified with a "+" or "-" sign.

An example of setting is shown below.



Coordinate system in degrees

- The coordinate is determined by referring to the position of 0 degree.
 - + direction: 0 \rightarrow 90 \rightarrow 180 \rightarrow 270 \rightarrow 0
 - direction: 0 \rightarrow -90 \rightarrow -180 \rightarrow -270 \rightarrow -360
- The positions of 270 degrees and -90 degrees are the same.
- The positions of 0 degree, 360 degrees and -360 degrees are the same.


The travel direction to the target position is set with [Pr. PT03].

[Pr. PT03] setting	Servo motor rotation direction
_ 0 _ _	The servo motor rotates to the target position in a direction specified with a sign of the position data.
_ 1 _ _	The servo motor rotates from the current position to the target position in the shorter direction. If the distances from the current position to the target position are the same for CCW and CW, the servo motor rotates in the CCW direction.


4. HOW TO USE THE POINT TABLE

a) When using the Rotation direction specifying ([Pr. PT03] = "_ 0 _")

When the position data of 270.000 degrees is specified, the servo motor rotates in the CCW direction.




When the position data of -90.000 degrees is specified, the servo motor rotates in the CW direction.



When the position data of -360.000 degrees is specified, the servo motor rotates in the CW direction. (A)


When the position data of 360.000 degrees or 0 degree is specified, the servo motor rotates in the CCW direction. (B)




4. HOW TO USE THE POINT TABLE

b) When using the shortest rotation specification ([Pr. PT03] = _ 1 _)


When the position data of 270.000 degrees is specified, the servo motor rotates in the CCW direction.



When the position data of -90.000 degrees is specified, the servo motor rotates in the CCW direction.



If the position data of 270.000 degrees is specified when the current position is at 90, the distances in the CCW and CW are the same. In such a case, the servo motor rotates in the CCW direction.




4. HOW TO USE THE POINT TABLE

(b) Incremental value command method


As position data, set the travel distance from the current address to the target address.

1) mm, inch, and pulse unit

Setting range: 0 to 999999 [$\times 10^{\text{STM}}$ μm] (STM = Feed length multiplication [Pr. PT03])
-999999 to 999999 [$\times 10^{(\text{STM}-4)}$ inch] (STM = Feed length multiplication [Pr. PT03])
-999999 to 999999 [pulse]



2) Degree unit



4. HOW TO USE THE POINT TABLE

(2) Point table

(a) Point table setting

1 to 31 point tables can be set. To use point table No. 4 to 31, enable DI2 (Point table No. selection 3) to DI4 (Point table No. selection 5) with "Device Setting" on MR Configurator2.

Set point tables using MR Configurator2 or the operation section of the servo amplifier.

The following table lists what to set. Refer to section 4.2.2 for details of the settings.

Item	Main description
Position data	Set the position data for movement.
Servo motor speed	Set the command speed of the servo motor for execution of positioning.
Acceleration time constant	Set the acceleration time constant.
Deceleration time constant	Set the deceleration time constant.
Dwell	Set the waiting time when performing automatic continuous operation.
Sub function	Set when performing automatic continuous operation.
M code	The first digit and the second digit of the M code are outputted in 4-bit binary respectively. M code will be available in the future.

(b) Selection of point tables

Using the input signal or the communication function, select the point table No. with the communication command from the controller such as a personal computer.

The following table lists the point table No. selected in response to the input signal and the communication command.

However, when using the input signal to select the point table No., you can only use point table No. 1 to 3 in the initial status.

To use point table No. 4 to 31, enable DI2 (Point table No. selection 3) to DI4 (Point table No. selection 5) with "Device Setting" on MR Configurator2.

When using the communication function to select the point table No., refer to chapter 10.

Input signal (Note 1)					Selected point table No.
DI4 (Note 2)	DI3	DI2	DI1	DI0	
0	0	0	0	0	0 (for home position return)
0	0	0	0	1	1
0	0	0	1	0	2
0	0	0	1	1	3
0	0	1	0	0	4
.
.
.
1	1	1	1	0	30
1	1	1	1	1	31

Note 1. 0: Off

1: On

2. DI4 is available only with the communication function. This device cannot be assigned as an input signal.

4. HOW TO USE THE POINT TABLE

4.2.2 Automatic operation using point table

(1) Absolute value command method

This method allows to select absolute value command or incremental value command with the sub function of the point table.

(a) Point table

Set the point table values using MR Configurator2 or the operation section.

Set the position data, servo motor speed, acceleration time constant, deceleration time constant, dwell, sub function, and M code to the point table.

To use the point table with the absolute value command method, set "0", "1", "8", or "9" to the sub function. To use the point table with the incremental value command method, set "2", "3", "10", or "11" to the sub function.

When you set a value outside the setting range to the point table, the set value will be clamped with the maximum or minimum value. If the value becomes out of the range because of the changes in the command unit or the connected servo motor, [AL. 37] will occur.

Item	Setting range	Unit	Description
Position data	-999999 to 999999 (Note)	10 ^{STM} μm 10 ^(STM-4) inch 10 ⁻³ degree pulse (Note 2)	(1) When using this point table with the absolute value command method Set the target address (absolute value). The teaching function is also available for setting this value. (2) When using this point table with the incremental value command method Set the travel distance. A "-" sign indicates a reverse rotation command. The teaching function is not available. When teaching is executed, the setting will not be completed.
Servo motor speed	0 to permissible speed	r/min	Set the command speed of the servo motor for execution of positioning. The setting value must be the permissible instantaneous speed or less of the servo motor used.
Acceleration time constant	0 to 20000	ms	Set a time for the servo motor to reach the rated speed.
Deceleration time constant	0 to 20000	ms	Set a time for the servo motor to stop from the rated speed.
Dwell	0 to 20000	ms	Set the dwell. To disable the dwell, set "0" or "2" to the sub function. To perform a continuous operation, set "1", "3", "8", "9", "10", or "11" to the sub function and "0" to the dwell. When the dwell is set, a positioning of the next point table will be started after the positioning of the selected data is completed, and the set dwell has elapsed.
Sub function	0 to 3, 8 to 11		Set the sub function. (1) When using this point table with the absolute value command method 0: Executes automatic operation for a selected point table. 1: Executes automatic continuous operation without stopping for the next point table. 8: Executes automatic continuous operation without stopping for the point table selected at the start. 9: Executes automatic continuous operation without stopping for the point table No. 1. (2) When using this point table with the incremental value command method 2: Executes automatic operation for a selected point table. 3: Executes automatic continuous operation without stopping for the next point table. 10: Executes automatic continuous operation without stopping for the point table selected at the start. 11: Executes automatic continuous operation without stopping for the point table No. 1. When an opposite rotation direction is set, the servo motor rotates in the opposite direction after smoothing zero (command output) is confirmed. Setting "1" or "3" to point table No. 31 results in an error. For details, refer to (3) (b) of this section.
M code	0 to 99		Outputs the first digit and the second digit of the M code in 4-bit binary respectively. M code will be available in the future.

Note. The setting range of the position data in degrees is -360.000 to 360.000. When the unit of the position data is μm or inch, the location of the decimal point is changed according to the STM setting.


4. HOW TO USE THE POINT TABLE

(b) Parameter setting

Set the following parameters to perform automatic operation.

1) Command method selection ([Pr. PT01])


Select the absolute value command method as shown below.



2) Rotation direction selection ([Pr. PA14])

Select the servo motor rotation direction when ST1 (Forward rotation start) is switched on.

[Pr. PA14] setting	Servo motor rotation direction when ST1 (Forward rotation start) is switched on
0	CCW rotation with + position data CW rotation with - position data
1	CW rotation with + position data CCW rotation with - position data



3) Position data unit ([Pr. PT01])

Set the unit of the position data.

[Pr. PT01] setting	Position data unit
_ 0 _	mm
_ 1 _	inch
_ 2 _	degree
_ 3 _	pulse

4) Feed length multiplication ([Pr. PT03])

Set the feed length multiplication factor (STM) of the position data.

[Pr. PT03] setting	Position data input range			
	[mm]	[inch]	[degree] (Note 1)	[pulse] (Note 1)
_ _ _ 0	- 999.999 to + 999.999	- 99.9999 to + 99.9999	- 360.000 to + 360.000 (Note 2)	- 999999 to + 999999
_ _ _ 1	- 9999.99 to + 9999.99	- 999.999 to + 999.999		
_ _ _ 2	- 99999.9 to + 99999.9	- 9999.99 to + 9999.99		
_ _ _ 3	- 999999 to + 999999	- 99999.9 to + 99999.9		

Note 1. The feed length multiplication setting ([Pr. PT03]) is not applied to the unit multiplication factor.

Adjust the unit multiplication factor in the electronic gear setting ([Pr. PA06] and [Pr. PA07]).

- Note 2. The "-" sign has different meanings under the absolute value command method and the incremental value command method. Refer to section 4.2.1 for details.

4. HOW TO USE THE POINT TABLE

(c) Operation

Selecting DI0 to DI4 for the point table and switching on ST1 starts positioning to the position data at the set speed, acceleration time constant and deceleration time constant. At this time, ST2 (Reverse rotation start) is disabled.

Item	Device to be used	Setting
Automatic operation mode selection	MD0 (Operation mode selection 1)	Switch on MD0.
Point table selection	DI0 (Point table No. selection 1) DI1 (Point table No. selection 2) DI2 (Point table No. selection 3) DI3 (Point table No. selection 4) DI4 (Point table No. selection 5)	Refer to section 4.2.1 (2) (b).
Start	ST1 (Forward rotation start)	Switch on ST1 to start.

(2) Incremental value command method

(a) Point table

Set the point table values using MR Configurator2 or the operation section.

Set the position data, servo motor speed, acceleration time constant, deceleration time constant, dwell, sub function, and M code to the point table.

When you set a value outside the setting range to the point table, the set value will be clamped with the maximum or minimum value. If the value becomes out of the range because of the changes in the command unit or the connected servo motor, [AL. 37] will occur.

Item	Setting range	Unit	Description
Position data	0 to 999999 (Note)	$\times 10^{\text{STM}}$ μm $\times 10^{(\text{STM}-4)}$ inch $\times 10^{-3}$ degree pulse	Set the travel distance. The teaching function is not available. When teaching is executed, the setting will not be completed. The unit can be changed by [Pr. PT03] (Feed length multiplication).
Servo motor speed	0 to permissible speed	r/min	Set the command speed of the servo motor for execution of positioning. The setting value must be the permissible instantaneous speed or less of the servo motor used.
Acceleration time constant	0 to 20000	ms	Set a time for the servo motor to reach the rated speed.
Deceleration time constant	0 to 20000	ms	Set a time for the servo motor to stop from the rated speed.
Dwell	0 to 20000	ms	Set the dwell. To disable the dwell, set "0" to the sub function. To perform a continuous operation, set "1", "8" or "9" to the sub function and "0" to the dwell. When the dwell is set, a positioning of the next point table will be started after the positioning of the selected data is completed, and the set dwell has elapsed.
Sub function	0, 1, 8, 9		Set the sub function. 0: Executes automatic operation for a selected point table. 1: Executes automatic continuous operation without stopping for the next point table. 8: Executes automatic continuous operation without stopping for the point table selected at the start. 9: Executes automatic continuous operation without stopping for the point table No. 1. Setting "1" to point table No. 31 results in an error. For details, refer to (3) (b) of this section.
M code	0 to 99		Outputs the first digit and the second digit of the M code in 4-bit binary respectively. M code will be available in the future.

Note. The setting range of the position data in degrees is 0 to 999.999. When the unit of the position data is μm or inch, the location of the decimal point is changed according to the STM setting.


4. HOW TO USE THE POINT TABLE

(b) Parameter setting

Set the following parameters to perform automatic operation.

1) Command method selection ([Pr. PT01])



Select the incremental value command method as shown below.



2) Rotation direction selection ([Pr. PA14])

Select the servo motor rotation direction when ST1 (Forward rotation start) or ST2 (Reverse rotation start) is switched on.

[Pr. PA14] setting	Servo motor rotation direction	
	ST1 (Forward rotation start)	ST2 (Reverse rotation start)
0	CCW rotation (address increase)	CW rotation (address decrease)
1	CW rotation (address increase)	CCW rotation (address decrease)



3) Position data unit ([Pr. PT01])

Set the unit of the position data.

[Pr. PT01] setting	Position data unit
_ 0 _ _	mm
_ 1 _ _	inch
_ 2 _ _	degree
_ 3 _ _	pulse

4) Feed length multiplication ([Pr. PT03])

Set the feed length multiplication factor (STM) of the position data.

[Pr. PT03] setting	Position data input range			
	[mm]	[inch]	[degree] (Note)	[pulse] (Note)
___ 0	0 to + 999.999	0 to + 99.9999	0 to + 999.999	0 to + 999999
___ 1	0 to + 9999.99	0 to + 999.999		
___ 2	0 to + 99999.9	0 to + 9999.99		
___ 3	0 to + 999999	0 to + 99999.9		

Note. The feed length multiplication setting ([Pr. PT03]) is not applied to the unit multiplication factor.

Adjust the unit multiplication factor in the electronic gear setting ([Pr. PA06] and [Pr. PA07]).

4. HOW TO USE THE POINT TABLE

(c) Operation

Selecting DI0 to DI4 for the point table and switching on ST1 starts a forward rotation of the motor over the travel distance of the position data at the set speed, acceleration time constant and deceleration time constant.

Switching on ST2 starts a reverse rotation of the motor in accordance with the values set to the selected point table.

When the positioning operation is performed consecutively with the incremental value command method, the servo motor rotates in the same direction only.

To change the travel direction during the continuous operation, perform the operation with the absolute value command method.

Item	Device to be used	Setting
Automatic operation mode selection	MD0 (Operation mode selection 1)	Switch on MD0.
Point table selection	DI0 (Point table No. selection 1) DI1 (Point table No. selection 2) DI2 (Point table No. selection 3) DI3 (Point table No. selection 4) DI4 (Point table No. selection 5)	Refer to section 4.2.1 (2) (b).
Start	ST1 (Forward rotation start) ST2 (Reverse rotation start)	Switch on ST1 to start. Switch on ST2 to start.

4. HOW TO USE THE POINT TABLE


(3) Automatic operation timing chart

(a) Automatic individual positioning operation

1) Absolute value command method ([Pr. PT01] = ___ 0)

While the servo motor is stopped under servo-on state, switching on ST1 (Forward rotation start) starts the automatic positioning operation.

The following shows a timing chart.




- Note 1. The detection of external input signals is delayed by the set time in the input filter setting of [Pr. PD29]. Considering the output signal sequence from the controller and signal variations due to hardware, configure a sequence that changes the point table selection earlier.
- Note 2. For MR-JE-_A servo amplifiers, up to four points of DO are available; therefore, PT0 to PT4 cannot be outputted simultaneously.
- Note 3. M code will be available in the future.

4. HOW TO USE THE POINT TABLE

2) Absolute value command method ([Pr. PT01] = ___ 1)

While the servo motor is stopped under servo-on state, switching on ST1 (Forward rotation start) or ST2 (Reverse rotation start) starts the automatic positioning operation.

The following shows a timing chart.



- Note 1. The detection of external input signals is delayed by the set time in the input filter setting of [Pr. PD29]. Considering the output signal sequence from the controller and signal variations due to hardware, configure a sequence that changes the point table selection earlier.
- Note 2. For MR-JE-_A servo amplifiers, up to four points of DO are available; therefore, PT0 to PT4 cannot be outputted simultaneously.
- Note 3. M code will be available in the future.

4. HOW TO USE THE POINT TABLE

(b) Automatic continuous positioning operation

By merely selecting a point table and switching on ST1 (Forward rotation start) or ST2 (Reverse rotation start), the operation can be performed in accordance with the point tables having consecutive numbers.

1) Absolute value command method ([Pr. PT01] = ___ 0)

By specifying the absolute value command or the incremental value command in the sub function of the point table, the automatic continuous operation can be performed.

The following shows how to set.

Point table setting		
Dwell	Sub function	
	When the position data is absolute value	When the position data is incremental value
1 or more	1	3

a) Positioning in a single direction

The following shows an operation example with the set values listed in the table below.

In this example, point table No. 1 and No. 3 are set to the absolute value command method, and point table No. 2 the incremental value command method.


Point table No.	Position data [10 ^{STM} μm]	Servo motor speed [r/min]	Acceleration time constant [ms]	Deceleration time constant [ms]	Dwell [ms]	Sub function	M code (Note 2)
1	5.00	3000	100	150	100	1	05
2	5.00	2000	150	200	200	3	10
3	15.00	1000	300	100	Disabled	0 (Note 1)	15

Note 1. Always set "0" or "2" to the sub function of the last point table of the consecutive point tables.

0: When using the point table with the absolute value command method

2: When using the point table with the incremental value command method

2. M code will be available in the future.



Note 1. For MR-JE-_A servo amplifiers, up to four points of DO are available; therefore, PT0 to PT4 cannot be outputted simultaneously.

2. M code will be available in the future.

4. HOW TO USE THE POINT TABLE

b) Positioning in the reverse direction midway

The following shows an operation example with the set values listed in the table below.

In this example, point table No. 1 and No. 3 are set to the absolute value command method, and point table No. 2 the incremental value command method.


Point table No.	Position data [10 ⁵ μm]	Servo motor speed [r/min]	Acceleration time constant [ms]	Deceleration time constant [ms]	Dwell [ms]	Sub function	M code (Note 2)
1	5.00	3000	100	150	100	1	05
2	7.00	2000	150	200	200	3	10
3	8.00	1000	300	100	Disabled	0 (Note 1)	15

Note. 1. Always set "0" or "2" to the sub function of the last point table of the consecutive point tables.

0: When using the point table with the absolute value command method

2: When using the point table with the incremental value command method

2. M code will be available in the future.



Note 1. For MR-JE-_A servo amplifiers, up to four points of DO are available; therefore, PT0 to PT4 cannot be outputted simultaneously.

2. M code will be available in the future.

4. HOW TO USE THE POINT TABLE

c) Position data in degrees

The following shows an operation example with the set values listed in the table below.

In this example, point table No. 1, No. 2, and No. 4 are set to the absolute value command method, and point table No. 3 the incremental value command method.


Point table No.	Position data [degree]	Servo motor speed [r/min]	Acceleration time constant [ms]	Deceleration time constant [ms]	Dwell [ms]	Sub function	M code (Note 2)
1	120.000	1000	100	150	100	1	05
2	-320.000	500	150	100	200	1	10
3	-230.000	3000	200	300	150	3	15
4	70.000	1500	300	100	Disabled	0 (Note 1)	20

Note 1. Always set "0" or "2" to the sub function of the last point table of the consecutive point tables.

0: When using the point table with the absolute value command method

2: When using the point table with the incremental value command method

2. M code will be available in the future.



Note 1. For MR-JE-A servo amplifiers, up to four points of DO are available; therefore, PT0 to PT4 cannot be outputted simultaneously.

2. M code will be available in the future.

4. HOW TO USE THE POINT TABLE

2) Absolute value command method ([Pr. PT01] = ___ 1)

The position data of the incremental value command method is the sum of the position data of consecutive point tables.

The following shows how to set.

Point table setting	
Dwell	Sub function
1 or more	1


a) Positioning in a single direction

The following shows an operation example with the set values listed in the table below.

Point table No.	Position data [10 ^{STM} μm]	Servo motor speed [r/min]	Acceleration time constant [ms]	Deceleration time constant [ms]	Dwell [ms]	Sub function	M code (Note 2)
1	5.00	3000	100	150	100	1	05
2	6.00	2000	150	200	200	1	10
3	3.00	1000	300	100	Disabled	0 (Note 1)	15

Note 1. Always set "0" to the sub function of the last point table among the consecutive point tables.

2. M code will be available in the future.



Note 1. Switching on ST2 (Reverse rotation start) starts positioning in the reverse rotation direction.

2. For MR-JE-_A servo amplifiers, up to four points of DO are available; therefore, PT0 to PT4 cannot be outputted simultaneously.

3. M code will be available in the future.

4. HOW TO USE THE POINT TABLE

b) Position data in degrees

The following shows an operation example with the set values listed in the table below.



Point table No.	Position data [degree]	Servo motor speed [r/min]	Acceleration time constant [ms]	Deceleration time constant [ms]	Dwell [ms]	Sub function	M code (Note 2)
1	120.000	3000	100	150	0	1	05
2	60.000	1500	100	0	1	10	
3	90.000	1000	300	100	Disabled	0 (Note 1)	15

Note 1. Always set "0" or "2" to the sub function of the last point table of the consecutive point tables.

0: When using the point table with the absolute value command method

2: When using the point table with the incremental value command method

2. M code will be available in the future.



Note 1. For MR-JE-_A servo amplifiers, up to four points of DO are available; therefore, PT0 to PT4 cannot be outputted simultaneously.

2. M code will be available in the future.

4. HOW TO USE THE POINT TABLE

(c) Varying-speed operation

By setting the sub function of the point table, the servo motor speed during positioning can be changed. Point tables are used by the number of the set speed.

1) Absolute value command method ([Pr. PT01] = ___ 0)

Set "1" or "3" to the sub function to execute the positioning at the speed set in the following point table.

At this time, the position data selected at start is enabled, and the acceleration/deceleration time constant set in the next and subsequent point tables is disabled.

By setting "1" or "3" to sub functions until point table No. 30, the operation can be performed at maximum 31 speeds.

Always set "0" or "2" to the sub function of the last point table.

To perform varying-speed operation, always set "0" to the dwell.

Setting "1" or more enables the automatic continuous positioning operation.

The following table shows an example of setting.

Point table No.	Dwell [ms] (Note 1)	Sub function	Varying-speed operation
1	0	1	Consecutive point table data
2	0	3	
3	Disabled	0 (Note 2)	
4	0	3	Consecutive point table data
5	0	1	
6	Disabled	2 (Note 2)	

Note 1. Always set "0".

2 Always set "0" or "2" to the sub function of the last point table among the consecutive point tables.

4. HOW TO USE THE POINT TABLE

a) Positioning in a single direction

The following shows an operation example with the set values listed in the table below.

In this example, point table No. 1 and No. 3 are set to the absolute value command method, and point table No. 2 the incremental value command method.

Point table No.	Position data [10 ^{STM} μm]	Servo motor speed [r/min]	Acceleration time constant [ms]	Deceleration time constant [ms]	Dwell [ms] (Note 1)	Sub function	M code (Note 3)
1	5.00	3000	100	150	0	1	05
2	3.00	2000	Disabled	Disabled	0	3	10
3	10.00	1000	Disabled	Disabled	0	1	15
4	6.00	500	Disabled	Disabled	Disabled	2 (Note 2)	20


Note 1. Always set "0".

2. Always set "0" or "2" to the sub function of the last point table of the consecutive point tables.

0: When using the point table with the absolute value command method

2: When using the point table with the incremental value command method

3. M code will be available in the future.



Note 1. For MR-JE-_A servo amplifiers, up to four points of DO are available; therefore, PT0 to PT4 cannot be outputted simultaneously.

2. M code will be available in the future.

4. HOW TO USE THE POINT TABLE

b) Positioning in the reverse direction midway

The following shows an operation example with the set values listed in the table below.

In this example, point table No. 1 and No. 3 are set to the absolute value command method, and point table No. 2 the incremental value command method.

Point table No.	Position data [10 ⁵ μm]	Servo motor speed [r/min]	Acceleration time constant [ms]	Deceleration time constant [ms]	Dwell [ms] (Note 1)	Sub function	M code (Note 3)
1	5.00	3000	100	150	0	1	05
2	7.00	2000	Disabled	Disabled	0	3	10
3	8.00	1000	Disabled	Disabled	Disabled	0 (Note 2)	15


Note 1. Always set "0".

2. Always set "0" or "2" to the sub function of the last point table of the consecutive point tables.

0: When using the point table with the absolute value command method

2: When using the point table with the incremental value command method

3. M code will be available in the future.



Note 1. For MR-JE-_A servo amplifiers, up to four points of DO are available; therefore, PT0 to PT4 cannot be outputted simultaneously.

2. M code will be available in the future.

4. HOW TO USE THE POINT TABLE

2) Absolute value command method ([Pr. PT01] = ___ 1)

Setting "1" to the sub function executes positioning at the speed set in the following point table.

At this time, the position data selected at start is enabled, and the acceleration/deceleration time constant set in the next and subsequent point tables is disabled.

By setting "1" to sub functions until point table No. 30, the operation can be performed at maximum 31 speeds.

Always set "0" to the sub function of the last point table.

To perform varying-speed operation, always set "0" to the dwell.

Setting "1" or more enables the automatic continuous positioning operation.

The following table shows an example of setting.

Point table No.	Dwell [ms] (Note 1)	Sub function	Varying-speed operation
1	0	1	Consecutive point table data
2	0	1	
3	Disabled	0 (Note 2)	
4	0	1	Consecutive point table data
5	0	1	
6	Disabled	0 (Note 2)	

Note 1. Always set "0".

2. Always set "0" to the sub function of the last point table among the consecutive point tables.


The following shows an operation example with the set values listed in the table below.

Point table No.	Position data [10 ⁵ μm]	Servo motor speed [r/min]	Acceleration time constant [ms]	Deceleration time constant [ms]	Dwell [ms] (Note 1)	Sub function	M code (Note 3)
1	5.00	3000	100	150	0	1	05
2	3.00	2000	Disabled	Disabled	0	1	10
3	2.00	1000	Disabled	Disabled	0	1	15
4	6.00	500	Disabled	Disabled	Disabled	0 (Note 2)	20

Note 1. Always set "0".

2. Always set "0" to the sub function of the last point table among the consecutive point tables.

3. M code will be available in the future.



Note 1. For MR-JE-_A servo amplifiers, up to four points of DO are available; therefore, PT0 to PT4 cannot be outputted simultaneously.

2. M code will be available in the future.

4. HOW TO USE THE POINT TABLE

(d) Automatic repeat positioning operation

By setting the sub function of the point table, the operation pattern of the set point table No. can be returned to, and the positioning operation can be performed repeatedly.

1) Absolute value command method ([Pr. PT01] = ___ 0)

Setting "8" or "10" to the sub function performs an automatic continuous operation or a varying-speed operation until that point table, and after the completion of positioning, performs the operation again from the operation pattern of the point table No. used at start-up.

Setting "9" or "11" to the sub function performs an automatic continuous operation or a varying-speed operation until that point table, and after the completion of positioning, performs the operation again from the operation pattern of point table No. 1.

a) Automatic repeat positioning operation by absolute value command method


Example 1. Operations when "8" is set to the sub function of point table No. 4

Point table No.	Position data [10 ^{STM} μm]	Servo motor speed [r/min]	Acceleration time constant [ms]	Deceleration time constant [ms]	Dwell [ms]	Sub function	M code (Note)
1	4.00	1500	200	100	150	1	01
2	5.00	3000	100	150	100	1	05
3	5.00	2000	150	200	200	3	10
4	15.00	1000	300	100	150	8	15

Note. M code will be available in the future.

Operation sequence

- 1) Starting with point table No. 2
- 2) Executing point table No. 3
- 3) Executing point table No. 4
- 4) Executing again point table No.2 used at start-up when "8" is set to the sub function of point table No. 4
- 5) Repeating the above execution in the sequence of 2) to 3) to 4) to 2) to 3) to 4)



Note 1. PT0 to PT4 and M code are not outputted in automatic continuous operation.
 2. M code will be available in the future.

4. HOW TO USE THE POINT TABLE


Example 2. Operations when "9" is set to the sub function of point table No. 3

Point table No.	Position data [10 ^{STM} μm]	Servo motor speed [r/min]	Acceleration time constant [ms]	Deceleration time constant [ms]	Dwell [ms]	Sub function	M code (Note)
1	0.00	3000	100	150	100	1	05
2	5.00	2000	150	200	200	1	10
3	15.00	1000	300	100	150	9	15

Note. M code will be available in the future.

Operation sequence

- 1) Starting with point table No. 2
- 2) Executing point table No. 3
- 3) Executing point table No.1 when "9" is set to the sub function of point table No. 3
- 4) Repeating the above execution in the sequence of 1) to 2) to 3) to 1) to 2) to 3)



Note 1. PT0 to PT4 and M code are not outputted in automatic continuous operation.

Note 2. M code will be available in the future.

4. HOW TO USE THE POINT TABLE

b) Automatic repeat positioning operation by incremental value command method


Example 1. Operations when "10" is set to the sub function of point table No. 4

Point table No.	Position data [10 ^{STM} μm]	Servo motor speed [r/min]	Acceleration time constant [ms]	Deceleration time constant [ms]	Dwell [ms]	Sub function	M code (Note)
1	4.00	1500	200	100	150	1	01
2	5.00	3000	100	150	100	3	05
3	10.00	2000	150	200	200	1	10
4	5.00	1000	300	100	150	10	15

Note. M code will be available in the future.

Operation sequence

- 1) Starting with point table No. 2
- 2) Executing point table No. 3
- 3) Executing point table No. 4
- 4) Executing again point table No.2 used at start-up when "10" is set to the sub function of point table No. 4
- 5) Repeating the above execution in the sequence of 1) to 2) to 3) to 4) to 2) to 3) to 4)



Note 1. PT0 to PT4 and M code are not outputted in automatic continuous operation.

Note 2. M code will be available in the future.

4. HOW TO USE THE POINT TABLE


Example 2. Operations when "11" is set to the sub function of point table No. 3

Point table No.	Position data [10 ^{STM} μm]	Servo motor speed [r/min]	Acceleration time constant [ms]	Deceleration time constant [ms]	Dwell [ms]	Sub function	M code (Note)
1	5.00	3000	100	150	100	3	05
2	10.00	2000	150	200	200	1	10
3	5.00	1000	300	100	150	11	15

Note. M code will be available in the future.

Operation sequence

- 1) Starting with point table No. 2
- 2) Executing point table No. 3
- 3) Executing point table No.1 when "11" is set to the sub function of point table No. 3
- 4) Repeating the above execution in the sequence of 1) to 2) to 3) to 1) to 2) to 3)



- Note
1. PT0 to PT4 and M code are not outputted in automatic continuous operation.
 2. M code will be available in the future.

4. HOW TO USE THE POINT TABLE

c) Varying-speed operation by absolute value command method


Example. Operations when "8" is set to the sub function of point table No. 3

Point table No.	Position data [10 ^{STM} μm]	Servo motor speed [r/min]	Acceleration time constant [ms]	Deceleration time constant [ms]	Dwell [ms]	Sub function	M code (Note)
1	5.00	3000	100	150	0	1	05
2	5.00	2000	Disabled	Disabled	0	3	10
3	15.00	1000	Disabled	Disabled	0	8	15

Note. M code will be available in the future.

Operation sequence

- 1) Starting with point table No. 1
- 2) Varying the speed and executing point table No. 2
- 3) Varying the speed and executing point table No. 3
- 4) Executing point table No.1 used at start-up in CW direction when "8" is set to the sub function of point table No. 3
- 5) Repeating the above execution in the sequence of 1) to 2) to 3) to 4) to 2) to 3) to 4)



- Note
1. PT0 to PT4 and M code are not outputted in automatic continuous operation.
 2. M code will be available in the future.

4. HOW TO USE THE POINT TABLE

d) Varying-speed operation by incremental value command method


Example. Operations when "10" is set to the sub function of point table No. 3

Point table No.	Position data [10 ^{STM} μm]	Servo motor speed [r/min]	Acceleration time constant [ms]	Deceleration time constant [ms]	Dwell [ms]	Sub function	M code (Note)
1	5.00	3000	100	150	0	3	05
2	10.00	2000	150	200	0	1	10
3	5.00	1000	300	100	0	10	15

Note. M code will be available in the future.

Operation sequence

- 1) Starting with point table No. 1
- 2) Varying the speed and executing point table No. 2
- 3) Varying the speed and executing point table No. 3
- 4) Varying the speed, and executing point table No.1 when "10" is set to the sub function of point table No. 3
- 5) Repeating the above execution in the sequence of 1) to 2) to 3) to 4) to 2) to 3) to 4)



- Note 1. PT0 to PT4 and M code are not outputted in automatic continuous operation.
 2. M code will be available in the future.

4. HOW TO USE THE POINT TABLE

2) Absolute value command method ([Pr. PT01] = ___ 1)

Setting "8" to the sub function performs automatic continuous operation or varying-speed operation until that point table, and after the completion of positioning, performs the operation again from the operation pattern of the set point table.

Setting "9" to the sub function performs automatic continuous operation or varying-speed operation until that point table, and after the completion of positioning, performs the operation again from the operation pattern of point table No. 1.

b) Automatic repeat positioning operation by incremental value command method

Example 1. Operations when "8" is set to the sub function of point table No. 3

Point table No.	Position data [10 ^{STM} μm]	Servo motor speed [r/min]	Acceleration time constant [ms]	Deceleration time constant [ms]	Dwell [ms]	Sub function	M code (Note)
1	4.00	1500	200	100	150	1	01
2	5.00	3000	100	150	100	1	05
3	6.00	2000	150	200	200	8	10

Note. M code will be available in the future.


Operation sequence

1) Starting with point table No. 2

2) Executing point table No. 3

3) Executing again point table No.2 used at start-up when "8" is set to the sub function of point table No. 3

4) Repeating the above execution in the sequence of 1) to 2) to 3) to 2) to 3)



Note 1. PT0 to PT4 and M code are not outputted in automatic continuous operation.
 Note 2. M code will be available in the future.

4. HOW TO USE THE POINT TABLE


Example 2. Operations when "9" is set to the sub function of point table No. 2

Point table No.	Position data [10 ^{STM} μm]	Servo motor speed [r/min]	Acceleration time constant [ms]	Deceleration time constant [ms]	Dwell [ms]	Sub function	M code (Note)
1	5.00	3000	100	150	100	1	05
2	6.00	2000	150	200	200	9	10

Note. M code will be available in the future.

Operation sequence

- 1) Starting with point table No. 2
- 2) Executing point table No.1 when "9" is set to the sub function of point table No. 2
- 3) Repeating the above execution in the sequence of 1) to 2) to 1) to 2)



- Note 1. PT0 to PT4 and M code are not outputted in automatic continuous operation.
 Note 2. M code will be available in the future.

4. HOW TO USE THE POINT TABLE

b) Varying-speed operation by incremental value command method


Example. Operations when "8" is set to the sub function of point table No. 2

Point table No.	Position data [10 ^{STM} μm]	Servo motor speed [r/min]	Acceleration time constant [ms]	Deceleration time constant [ms]	Dwell [ms]	Sub function	M code (Note)
1	5.00	3000	100	150	0	1	05
2	6.00	2000	Disabled	Disabled	0	8	10

Note. M code will be available in the future.

Operation sequence

- 1) Starting with point table No. 1
- 2) Varying the speed and executing point table No. 2
- 3) Executing again point table No.1 used at start-up when "8" is set to the sub function of point table No. 2
- 4) Repeating the above execution in the sequence of 1) to 2) to 3) to 2) to 3)



- Note
1. PT0 to PT4 and M code are not outputted in automatic continuous operation.
 2. M code will be available in the future.

4. HOW TO USE THE POINT TABLE

(e) Temporary stop/restart

When TSTP (Temporary stop/restart) is switched on during automatic operation, the servo motor decelerates with the deceleration time constant of the point table being executed, and then stops temporarily.

Switching on TSTP (Temporary stop/restart) again restarts the servo motor rotation for the remaining distance.


During a temporary stop, ST1 (Forward rotation start) or ST2 (Reverse rotation start) does not function even if it is switched on.

When automatic operation mode is changed to manual operation mode during a temporary stop, the remaining travel distance is cleared at the time of servo-off or inputting the clear signal.

The temporary stop/restart input does not function during a home position return or JOG operation.

Operation status	Automatic operation	Manual operation	Home position return
During a stop			
During acceleration	Pause		
At a constant speed	Pause		
Deceleration			
During a temporary stop	Restart		


1) When the servo motor is rotating



Note. For MR-JE-_A servo amplifiers, up to four points of DO are available; therefore, PT0 to PT4 cannot be outputted simultaneously.

4. HOW TO USE THE POINT TABLE

2) During dwell




Note. For MR-JE-_A servo amplifiers, up to four points of DO are available; therefore, PT0 to PT4 cannot be outputted simultaneously.

(f) Suspension of automatic operation

Suspend the automatic operation or change the operation pattern in the following procedure.

To stop the operation in the middle of positioning, stop the servo motor with TSTP (Temporary stop/restart), switch off MD0 (Operation mode selection 1), and then set to the manual mode. At this time, the remaining travel distance is cleared.




4. HOW TO USE THE POINT TABLE

(g) Using a control unit of "degree"

1) Current position/command position address

The current position/command position address is of ring-address type.



2) Software limit activation/deactivation setting

POINT
<ul style="list-style-type: none"> ● After changing the "+" or "-" sign of an axis with the software limit activation setting, perform a home position return. ● When activating the software limit in an incremental system, perform a home position return after power-on.

a) Setting range

When the unit is set to "degree", the setting range of the software limit is from 0 degree (lower limit) to 359.999 degrees (upper limit).



When you set a value other than 0 degree to 359.999 degrees in [Pr. PT15] to [Pr. PT18], the set value is converted as follows. (It will be clamped between 0 degree and 359.999 degrees.)

Software limit value	After conversion
360.000 degrees to 999.999 degrees	The remainder of the set value divided by 360
-0.001 degrees to -359.999 degrees	The sum of the set value and 360
-360.000 degrees to -999.999 degrees	The sum of 360 and the quotient of the set value divided by 360

b) When the software limit is enabled

Set the software limit - ([Pr. PT17] and [Pr. PT18]) for the start position and the software limit + ([Pr. PT15] and [Pr. PT16]) for the end position.

The movable range is the section from - to + in the CCW direction.



Set the movable range of section A as follows:

- Software limit - ... 315.000 degrees
- Software limit + ... 90.000 degrees

Set the movable range of section B as follows:

- Software limit - ... 90.000 degrees
- Software limit + ... 315.000 degrees

4. HOW TO USE THE POINT TABLE

c) When the software limit is disabled

When deactivating the software limit, set the same values to the software limit - ([Pr. PT17] and [Pr. PT18]) and the software limit + ([Pr. PT15] and [Pr. PT16]).

Control can be performed independently of the software limit setting.

3) Position range output enabling/disabling setting

a) Setting range

When the unit is set to "degree", the setting range of the position range output is from 0 degree (lower limit) to 359.999 degrees (upper limit).



When you set a value other than 0 degree to 359.999 degrees in [Pr. PT19] to [Pr. PT22], the set value is converted as follows. (It will be clamped between 0 degree and 359.999 degrees.)

Position range output address	After conversion
360.000 degrees to 999.999 degrees	The remainder of the set value divided by 360
-0.001 degrees to -359.999 degrees	The sum of the set value and 360
-360.000 degrees to -999.999 degrees	The sum of 360 and the quotient of the set value divided by 360

b) Effective setting of position range output

Set the position range output address - ([Pr. PT21] and [Pr. PT22]) for the start position and the position range output address + ([Pr. PT19] and [Pr. PT20]) for the target position.

The movable range is the section from - to + in the CCW direction.



Set the movable range of section A as follows:

- Position range output address - ... 315.000 degrees
- Position range output address + ... 90.000 degrees

Set the movable range of section B as follows:

- Position range output address - ... 90.000 degrees
- Position range output address + ... 315.000 degrees

4. HOW TO USE THE POINT TABLE

4.3 Manual operation mode

For the machine adjustment, home position adjustment, and others, positioning to any point is possible using the JOG operation or the manual pulse generator.

4.3.1 JOG operation



(1) Setting

According to the purpose of use, set input devices and parameters as shown below. In this case, DI0 (Point table No. selection 1) to DI4 (Point table No. selection 5) are disabled.

Item	Device/parameter to be used	Setting
Manual operation mode selection	MD0 (Operation mode selection 1)	Switch off MD0.
Servo motor rotation direction	[Pr. PA14]	Refer to (2) of this section.
JOG speed	[Pr. PT13]	Set the servo motor speed.
Acceleration time constant/Deceleration time constant	Point table No. 1	The acceleration/deceleration time constant of point table No. 1 is used.

(2) Servo motor rotation direction

[Pr. PA14] setting	Servo motor rotation direction	
	ST1 (Forward rotation start) on	ST2 (Reverse rotation start) on
0	CCW rotation	CW rotation
1	CW rotation	CCW rotation




(3) Operation

Switching on ST1 (Forward rotation start) performs the operation at the JOG speed set by a parameter and the acceleration/deceleration constant of point table No. 1. For the rotation direction, refer to (2) of this section. Switching on ST2 (Reverse rotation start) starts the rotation in the reverse direction of ST1 (Forward rotation start).

Simultaneously switching on or off ST1 (Forward rotation start) and ST2 (Reverse rotation start) stops the operation.

4. HOW TO USE THE POINT TABLE

(4) Timing chart



4. HOW TO USE THE POINT TABLE

4.3.2 Manual pulse generator operation

(1) Setting


POINT
<p>● To enhance noise tolerance, set "_ 2 _" to [Pr. PA13] when the command pulse frequency is 500 kpulses/s or less, or set "_ 3 _" to [Pr. PA13] when the command pulse frequency is 200 kpulses/s or less.</p>

According to the purpose of use, set input devices and parameters as shown below. In this case, DI0 (Point table No. selection 1) to DI4 (Point table No. selection 5) are disabled.

Item	Device/parameter to be used	Setting
Manual operation mode selection	MD0 (Operation mode selection 1)	Switch off MD0.
Manual pulse generator multiplication	[Pr. PT03]	Set the multiplication factor for the pulses generated from the manual pulse generator. For details, refer to (3) of this section.
Servo motor rotation direction	[Pr. PA14]	Refer to (2) of this section.
Command input pulse train input form	[Pr. PA13]	Set "_ _ _ 2" (A/B-phase pulse train).
Pulse train filter selection	[Pr. PA13]	Set other than "0" and "1".

(2) Servo motor rotation direction

[Pr. PA14] setting	Servo motor rotation direction	
	Manual pulse generator operation: forward rotation	Manual pulse generator operation: reverse rotation
0	CCW rotation	CW rotation
1	CW rotation	CCW rotation



4. HOW TO USE THE POINT TABLE

(3) Manual pulse generator multiplication

(a) Using the input signals (devices) for setting

In "Device setting" of MR Configurator2, set TP0 (Pulse generator multiplication 1) and TP1 (Pulse generator multiplication 2) to input signals.

TP1 (Pulse generator multiplication 2) (Note)	TP0 (Pulse generator multiplication 1) (Note)	Servo motor rotation multiplication factor for manual pulse generator rotation amount	Travel distance			
			[mm]	[inch]	[degree]	[pulse]
0	0	[Pr. PT03] setting enabled				
0	1	1 time	0.001	0.0001	0.001	1
1	0	10 times	0.01	0.001	0.01	10
1	1	100 times	0.1	0.01	0.1	100

Note. 0: Off

1: On

(b) Using the parameter for setting

Using [Pr. PT03], set the servo motor rotation multiplication to the rotation amount of the manual pulse generator.

[Pr. PT03] setting	Servo motor rotation multiplication to manual pulse generator rotation amount	Travel distance			
		[mm]	[inch]	[degree]	[pulse]
__ 0 __	1 time	0.001	0.0001	0.001	1
__ 1 __	10 times	0.01	0.001	0.01	10
__ 2 __	100 times	0.1	0.01	0.1	100

(4) Operation

Turning the manual pulse generator rotates the servo motor. For the rotation direction of the servo motor, refer to (2) of this section. When you turn the manual pulse generator during a JOG operation, the commands inputted from the manual pulse generator are adjusted by the commands of JOG operation.

4.4 Home position return mode

POINT
<ul style="list-style-type: none"> ● Before performing the home position return, make sure that the limit switch operates. ● Check the home position return direction. An incorrect setting will cause a reverse running. ● Check the input polarity of the proximity dog. Otherwise, it may cause an unexpected operation.

4. HOW TO USE THE POINT TABLE

4.4.1 Outline of home position return

A home position return is performed to match the command coordinates with the machine coordinates. The home position return is required every time the input power is on.

This section shows the home position return methods of the servo amplifier. Select the optimum method according to the configuration and uses of the machine.

This servo amplifier has the home position return automatic retract function. When the machine stops beyond or on a proximity dog, this function automatically moves the machine back to the proper position to perform the home position return. Manual operation with JOG operation, etc. is unnecessary.

(1) Home position return types

Select the optimum home position return type according to the machine type or others.


Type	Home position return method	Feature
Dog type	Deceleration starts from the front end of the proximity dog. A position of the first Z-phase signal after the rear end is passed or a position moved by the home position shift amount from the Z-phase signal is set as the home position.	<ul style="list-style-type: none"> • Typical home position return method using a proximity dog • The repeatability of the home position return is high. • The machine is less loaded. • Use this when the width of the proximity dog can be set equal to or greater than the deceleration distance of the servo motor.
Count type	Deceleration starts from the front end of the proximity dog. After the proximity dog is passed, the motor travels the specified travel distance. Then, the position specified by the first Z-phase signal, or the position of the first Z-phase signal shifted by the home position shift distance is used as the home position.	<ul style="list-style-type: none"> • This is a home position return method using a proximity dog. • Use this to minimize the length of the proximity dog.
Data set type	An arbitrary position is set as the home position.	<ul style="list-style-type: none"> • No proximity dog is required.
Stopper type	A workpiece is pressed against a mechanical stopper, and the position where it is stopped is set as the home position.	<ul style="list-style-type: none"> • Since the workpiece collides with the mechanical stopper, the home position return speed must be low enough. • The strength of the machine and stopper must be increased.
Home position ignorance (servo-on position as home position)	Servo-on position is set as the home position.	
Dog type rear end reference	Deceleration starts from the front end of the proximity dog. After the rear end is passed, the position is shifted by the travel distance after proximity dog and the home position shift distance. The position after the shifts is set as the home position.	<ul style="list-style-type: none"> • The Z-phase signal is not required.
Count type front end reference	Deceleration starts from the front end of the proximity dog. A position moved by the moving amount after the proximity dog and the home position shift amount is set as the home position.	<ul style="list-style-type: none"> • The Z-phase signal is not required.
Dog cradle type	After the front end of the proximity dog is detected, the position specified by the first Z-phase signal is used as the home position.	
Dog type last Z-phase reference	After the front end of the proximity dog is detected, the position is shifted away from the proximity dog in the reverse direction. Then, the position specified by the first Z-phase signal or the position of the first Z-phase signal shifted by the home position shift distance is used as the home position.	
Dog type front end reference	Starting from the front end of the proximity dog, the position is shifted by the travel distance after proximity dog and the home position shift distance. The position after the shifts is used as the home position.	<ul style="list-style-type: none"> • The Z-phase signal is not required.
Dogless Z-phase reference	The position specified by the first Z-phase signal, or the position of the first Z-phase signal shifted by the home position shift distance is used as the home position.	

4. HOW TO USE THE POINT TABLE

(2) Parameters for home position return


To perform the home position return, set each parameter as follows.

(a) Select the home position return type with [Pr. PT04 Home position return type].




(b) Select the starting direction for the home position return with [Pr. PT04 Home position return type].

Setting "0" starts the home position return in a direction of increasing the address from the current position. Setting "1" starts the home position return in a direction of decreasing the address from the current position.



(c) Select the polarity where the proximity dog is detected with the DOG (Proximity dog) polarity selection of [Pr. PT29 Function selection T-3].

Setting "0" detects a proximity dog when DOG (Proximity dog) is switched off. Setting "1" detects a proximity dog when DOG (Proximity dog) is switched on.



4. HOW TO USE THE POINT TABLE

4.4.2 Dog type home position return

This is a home position return method using a proximity dog. Deceleration starts at the front end of the proximity dog. After the rear end is passed, the position specified by the first Z-phase signal, or the position of the first Z-phase signal shifted by the specified home position shift distance is used as the home position.

(1) Device/parameter

Set input devices and parameters as follows.

Item	Device/parameter to be used	Setting
Home position return mode selection	MD0 (Operation mode selection 1)	Switch on MD0.
	DI0 (Point table No. selection 1) to DI4 (Point table No. selection 5)	Switch off DI0 to DI4.
Dog type home position return	[Pr. PT04]	___ 0: Select the dog type.
Home position return direction	[Pr. PT04]	Refer to section 4.4.1 (2) to select the home position return direction.
Dog input polarity	[Pr. PT29]	Refer to section 4.4.1 (2) to select the proximity dog input polarity.
Home position return speed	[Pr. PT05]	Set the rotation speed specified until a dog is detected.
Creep speed	[Pr. PT06]	Set the rotation speed specified after a dog is detected.
Home position shift distance	[Pr. PT07]	Set this item to shift the home position, which is specified by the first Z-phase signal after the rear end of a proximity dog is passed.
Acceleration time constant/Deceleration time constant	Point table No. 1	The acceleration/deceleration time constant of point table No. 1 is used.
Home position return position data	[Pr. PT08]	Set the current position at the home position return completion.

(2) Length of the proximity dog

To generate the Z-phase signal of the servo motor during the detection of DOG (Proximity dog), set the length of the proximity dog that satisfies equations (4.1) and (4.2).

$$L_1 \geq \frac{V}{60} \cdot \frac{td}{2} \dots\dots\dots (4.1)$$


L_1 : Length of the proximity dog
 V : Home position return speed [mm/min]
 td : Deceleration time [s]

$$L_2 \geq 2 \cdot \Delta S \dots\dots\dots (4.2)$$

L_2 : Length of the proximity dog
 ΔS : Travel distance per servo motor revolution [mm]

4. HOW TO USE THE POINT TABLE

(3) Timing chart




The setting value of [Pr. PT08 Home position return position data] is used as the position address at the home position return completion.

(4) Adjustment

For the dog type home position return, adjust the setting so that the Z-phase signal is always generated during the detection of a dog. Make an adjustment so that the rear end of DOG (Proximity dog) is positioned almost at the center between the positions specified by a Z-phase signal and the next Z-phase signal.

The generation position of the Z-phase signal can be checked with "Position within one-revolution" of "Status display" on MR Configurator2.



4. HOW TO USE THE POINT TABLE

4.4.3 Count type home position return

For the count type home position return, after the front end of a proximity dog is detected, the position is shifted by the distance set in [Pr. PT09 Travel distance after proximity dog]. Then, the position specified by the first Z-phase signal is used as the home position. Therefore, when the on-time of DOG (Proximity dog) is 10 ms or more, the length of the proximity dog has no restrictions. When the required proximity dog length for using the dog type home position return cannot be reserved, or when DOG (Proximity dog) is entered electrically from the controller or the like, use the count type home position return.


(1) Device/parameter

Set input devices and parameters as follows.

Item	Device/parameter to be used	Setting
Home position return mode selection	MD0 (Operation mode selection 1)	Switch on MD0.
	DI0 (Point table No. selection 1) to DI4 (Point table No. selection 5)	Switch off DI0 to DI4.
Count type home position return	[Pr. PT04]	___ 0: Select the count type.
Home position return direction	[Pr. PT04]	Refer to section 4.4.1 (2) to select the home position return direction.
Dog input polarity	[Pr. PT29]	Refer to section 4.4.1 (2) to select the dog input polarity.
Home position return speed	[Pr. PT05]	Set the rotation speed specified until a dog is detected.
Creep speed	[Pr. PT06]	Set the rotation speed specified after a dog is detected.
Home position shift distance	[Pr. PT07]	After the front end of a proximity dog is passed, the position is shifted by the travel distance and then is specified by the first Z-phase signal. Set this item to shift the position of the first Z-phase signal.
Travel distance after proximity dog	[Pr. PT09]	Set the travel distance specified after the front end of the proximity dog is passed.
Acceleration time constant/Deceleration time constant	Point table No. 1	The acceleration/deceleration time constant of point table No. 1 is used.
Home position return position data	[Pr. PT08]	Set the current position at the home position return completion.

4. HOW TO USE THE POINT TABLE

(2) Timing chart



The setting value of [Pr. PT08 Home position return position data] is used as the position address at the home position return completion.

4. HOW TO USE THE POINT TABLE

4.4.4 Data set type home position return


To set an arbitrary position as the home position, use the data set type home position return. The JOG operation, the manual pulse generator operation, and others can be used for the travel. The data set type home position return can be performed at servo-on only.

(1) Device/parameter

Set input devices and parameters as follows.

Item	Device/parameter to be used	Setting
Home position return mode selection	MD0 (Operation mode selection 1)	Switch on MD0.
	DI0 (Point table No. selection 1) to DI4 (Point table No. selection 5)	Switch off DI0 to DI4.
Data set type home position return	[Pr. PT04]	___ 2: Select the data set type.
Home position return position data	[Pr. PT08]	Set the current position at the home position return completion.

(2) Timing chart



The setting value of [Pr. PT08 Home position return position data] is used as the position address at the home position return completion.

4. HOW TO USE THE POINT TABLE

4.4.5 Stopper type home position return

For the stopper type home position return, the home position is set where the workpiece is pressed against the stopper of the machine by using the JOG operation, the manual pulse generator operation, or others.


(1) Device/parameter

Set input devices and parameters as follows.

Item	Device/parameter to be used	Setting
Home position return mode selection	MD0 (Operation mode selection 1)	Switch on MD0.
	DI0 (Point table No. selection 1) to DI4 (Point table No. selection 5)	Switch off DI0 to DI4.
Stopper type home position return	[Pr. PT04]	___ 3: Select the stopper type.
Home position return direction	[Pr. PT04]	Refer to section 4.4.1 (2) to select the home position return direction.
Home position return speed	[Pr. PT05]	Set the rotation speed until the workpiece is pressed against the mechanical stopper.
Stopper time	[Pr. PT10]	Set the time from when the home position data is obtained after the workpiece is pressed against the stopper until when ZP (home position return completion) is outputted.
Stopper type home position return torque limit value	[Pr. PT11]	Set the servo motor torque limit value when executing the stopper type home position return.
Acceleration time constant of home position return	Point table No. 1	The acceleration/deceleration time constant of point table No. 1. is used.
Home position return position data	[Pr. PT08]	Set the current position when the home position return is complete.

4. HOW TO USE THE POINT TABLE

(2) Timing chart



Note 1. The following torque limits are enabled.

Input device (0: off, 1: on)		Limit value status			Enabled torque limit value
TL1	TL				
0	0				Pr. PT11
0	1	TLA	>	Pr. PT11	Pr. PT11
		TLA	<	Pr. PT11	TLA
1	0	Pr. PC35	>	Pr. PT11	Pr. PT11
		Pr. PC35	<	Pr. PT11	Pr. PC35
1	1	TLA	>	Pr. PT11	Pr. PT11
		TLA	<	Pr. PT11	TLA

2. TLC turns on when a generated torque reaches a value set with any of [Pr. PA11 Forward rotation torque limit], [Pr. PA12 Reverse rotation torque limit], or [Pr. PC35 Internal torque limit 2].

The setting value of [Pr. PT08 Home position return position data] is used as the position address at the home position return completion.

4. HOW TO USE THE POINT TABLE

4.4.6 Home position ignorance (servo-on position as home position)

POINT
<p>● When you perform this home position return, it is unnecessary to switch to the home position return mode.</p>


Servo-on position is set as the home position.

(1) Device/parameter

Set input devices and parameters as follows.

Item	Parameter to be used	Setting
Home position ignorance	[Pr. PT04]	___ 4: Select the home position ignorance.
Home position return position data	[Pr. PT08]	Set the current position when the home position return is complete.

(2) Timing chart



The setting value of [Pr. PT08 Home position return position data] is used as the position address at the home position return completion.

4. HOW TO USE THE POINT TABLE

4.4.7 Dog type rear end reference home position return

POINT
<p>● This home position return method depends on the timing of reading DOG (Proximity dog) that has detected the rear end of a proximity dog. Therefore, when a home position return is performed at a creep speed of 100 r/min, the home position has an error of 200 pulses (for HG series servo motor). The higher the creep speed, the greater the error of the home position.</p>

Deceleration starts from the front end of a proximity dog. After the rear end is passed, the position is shifted by the travel distance after proximity dog and the home position shift distance. The position after the shifts is set as the home position. The home position return is available independently of the Z-phase signal. Changing the creep speed may change the home position.


(1) Device/parameter

Set input devices and parameters as follows.

Item	Device/parameter to be used	Setting
Home position return mode selection	MD0 (Operation mode selection 1)	Switch on MD0.
	DI0 (Point table No. selection 1) to DI4 (Point table No. selection 5)	Switch off DI0 to DI4.
Dog type rear end reference home position return	[Pr. PT04]	___ 5: Select the dog type (rear end detection/rear end reference).
Home position return direction	[Pr. PT04]	Refer to section 4.4.1 (2) to select the home position return direction.
Dog input polarity	[Pr. PT29]	Refer to section 4.4.1 (2) to select the dog input polarity.
Home position return speed	[Pr. PT05]	Set the rotation speed specified until a dog is detected.
Creep speed	[Pr. PT06]	Set the rotation speed specified after a dog is detected.
Home position shift distance	[Pr. PT07]	Set this to shift the home position, which is specified after the rear end of a proximity dog is passed.
Travel distance after proximity dog	[Pr. PT09]	Set the travel distance after the rear end of a proximity dog is passed.
Acceleration time constant/deceleration time constant of home position return	Point table No. 1	The acceleration/deceleration time constant of point table No. 1 is used.
Home position return position data	[Pr. PT08]	Set the current position when the home position return is complete.

4. HOW TO USE THE POINT TABLE

(2) Timing chart



The setting value of [Pr. PT08 Home position return position data] is used as the position address at the home position return completion.

4. HOW TO USE THE POINT TABLE

4.4.8 Count type front end reference home position return

POINT
<ul style="list-style-type: none"> ● This home position return method depends on the timing of reading DOG (Proximity dog) that has detected the front end of a proximity dog. Therefore, when a home position return is performed with the creep speed of 100 r/min, the home position has an error of 200 pulses (for HG series servo motor). The higher the creep speed, the greater the error of the home position. ● After the front end of a proximity dog is detected, if a home position return ends without reaching the creep speed, [AL. 90.2] occurs. Set the travel distance after proximity dog and the home position shift distance enough for deceleration from the home position return speed to the creep speed.

Deceleration starts from the front end of a proximity dog. The position is shifted by the travel distance after proximity dog and the home position shift distance. The position after the shifts is set as the home position. The home position return is available independently of the Z-phase signal. Changing the creep speed may change the home position.


(1) Device/parameter

Set input devices and parameters as follows.

Item	Device/parameter to be used	Setting
Home position return mode selection	MD0 (Operation mode selection 1)	Switch on MD0.
	DI0 (Point table No. selection 1) to DI4 (Point table No. selection 5)	Switch off DI0 to DI4.
Count type front end reference home position return	[Pr. PT04]	___6: Select the count type (front end detection/front end reference).
Home position return direction	[Pr. PT04]	Refer to section 4.4.1 (2) to select the home position return direction.
Dog input polarity	[Pr. PT29]	Refer to section 4.4.1 (2) to select the dog input polarity.
Home position return speed	[Pr. PT05]	Set the rotation speed specified until a dog is detected.
Creep speed	[Pr. PT06]	Set the rotation speed specified after a dog is detected.
Home position shift distance	[Pr. PT07]	Set this to shift the home position, which is specified after the front end of a proximity dog is passed.
Travel distance after proximity dog	[Pr. PT09]	Set the travel distance after the rear end of a proximity dog is passed.
Acceleration time constant/deceleration time constant of home position return	Point table No. 1	The acceleration/deceleration time constant of point table No. 1 is used.
Home position return position data	[Pr. PT08]	Set the current position when the home position return is complete.

4. HOW TO USE THE POINT TABLE

(2) Timing chart



The setting value of [Pr. PT08 Home position return position data] is used as the position address at the home position return completion.

4. HOW TO USE THE POINT TABLE

4.4.9 Dog cradle type home position return


A position, which is specified by the first Z-phase signal after the front end of a proximity dog is detected, is set as the home position.

(1) Device/parameter

Set input devices and parameters as follows.

Item	Device/parameter to be used	Setting
Home position return mode selection	MD0 (Operation mode selection 1)	Switch on MD0.
	DI0 (Point table No. selection 1) to DI4 (Point table No. selection 5)	Switch off DI0 to DI4.
Dog cradle type home position return	[Pr. PT04]	___ 7: Select the dog cradle type.
Home position return direction	[Pr. PT04]	Refer to section 4.4.1 (2) to select the home position return direction.
Dog input polarity	[Pr. PT29]	Refer to section 4.4.1 (2) to select the dog input polarity.
Home position return speed	[Pr. PT05]	Set the rotation speed specified until a dog is detected.
Creep speed	[Pr. PT06]	Set the rotation speed specified after a dog is detected.
Home position shift distance	[Pr. PT07]	Set this to shift the home position, which is specified by the Z-phase signal.
Acceleration time constant/deceleration time constant of home position return	Point table No. 1	The acceleration/deceleration time constant of point table No. 1 is used.
Home position return position data	[Pr. PT08]	Set the current position when the home position return is complete.

(2) Timing chart



The setting value of [Pr. PT08 Home position return position data] is used as the position address at the home position return completion.

4. HOW TO USE THE POINT TABLE

4.4.10 Dog type last Z-phase reference home position return

After the front end of a proximity dog is detected, the position is shifted away from the proximity dog at the creep speed in the reverse direction and then specified by the first Z-phase signal. The position of the first Z-phase signal is set as the home position.


(1) Device/parameter

Set input devices and parameters as follows.

Item	Device/parameter to be used	Setting
Home position return mode selection	MD0 (Operation mode selection 1)	Switch on MD0.
	DI0 (Point table No. selection 1) to DI4 (Point table No. selection 5)	Switch off DI0 to DI4.
Dog type last Z-phase reference home position return	[Pr. PT04]	___8: Select the dog type last Z-phase reference.
Home position return direction	[Pr. PT04]	Refer to section 4.4.1 (2) to select the home position return direction.
Dog input polarity	[Pr. PT29]	Refer to section 4.4.1 (2) to select the dog input polarity.
Home position return speed	[Pr. PT05]	Set the rotation speed specified until a dog is detected.
Creep speed	[Pr. PT06]	Set the rotation speed specified after a dog is detected.
Home position shift distance	[Pr. PT07]	Set this item to shift the home position, which is specified by the Z-phase signal.
Acceleration time constant/deceleration time constant of home position return	Point table No. 1	The acceleration/deceleration time constant of point table No. 1 is used.
Home position return position data	[Pr. PT08]	Set the current position when the home position return is complete.

4. HOW TO USE THE POINT TABLE

(2) Timing chart



The setting value of [Pr. PT08 Home position return position data] is used as the position address at the home position return completion.

4. HOW TO USE THE POINT TABLE

4.4.11 Dog type front end reference home position return type

POINT
<p>● This home position return method depends on the timing of reading DOG (Proximity dog) that has detected the front end of a proximity dog. Therefore, when a home position return is performed at a creep speed of 100 r/min, the home position has an error of 200 pulses (for HG series servo motor). The higher the creep speed, the greater the error of the home position.</p>

A position, which is shifted by the travel distance after proximity dog and the home position shift distance from the front end of a proximity dog, is set as the home position.

The home position return is available independently of the Z-phase signal. Changing the creep speed may change the home position.


(1) Device/parameter

Set input devices and parameters as follows.

Item	Device/parameter to be used	Setting
Home position return mode selection	MD0 (Operation mode selection 1)	Switch on MD0.
	DI0 (Point table No. selection 1) to DI4 (Point table No. selection 5)	Switch off DI0 to DI4.
Dog type front end reference home position return	[Pr. PT04]	___ 9: Select the dog type front end reference.
Home position return direction	[Pr. PT04]	Refer to section 4.4.1 (2) to select the home position return direction.
Dog input polarity	[Pr. PT29]	Refer to section 4.4.1 (2) to select the dog input polarity.
Home position return speed	[Pr. PT05]	Set the rotation speed specified until a dog is detected.
Creep speed	[Pr. PT06]	Set the rotation speed specified after a dog is detected.
Home position shift distance	[Pr. PT07]	Set this to shift the home position, which is specified by the Z-phase signal.
Acceleration time constant/deceleration time constant of home position return	Point table No. 1	The acceleration/deceleration time constant of point table No. 1 is used.
Home position return position data	[Pr. PT08]	Set the current position when the home position return is complete.

4. HOW TO USE THE POINT TABLE

(2) Timing chart



The setting value of [Pr. PT08 Home position return position data] is used as the position address at the home position return completion.

4. HOW TO USE THE POINT TABLE

4.4.12 Dogless Z-phase reference home position return type


A position, which is shifted to by the home position shift distance from a position specified by the Z-phase pulse right after the start of the home position return, is set as the home position.

(1) Device/parameter

Set input devices and parameters as follows.

Item	Device/parameter to be used	Setting
Home position return mode selection	MD0 (Operation mode selection 1)	Switch on MD0.
	DI0 (Point table No. selection 1) to DI4 (Point table No. selection 5)	Switch off DI0 to DI4.
Dogless Z-phase reference home position return	[Pr. PT04]	___ A: Select the dogless type (Z-phase reference).
Home position return direction	[Pr. PT04]	Refer to section 4.4.1 (2) to select the home position return direction.
Home position return speed	[Pr. PT05]	Set the rotation speed specified until the Z-phase is detected.
Creep speed	[Pr. PT06]	Set the rotation speed specified after the Z-phase is detected.
Home position shift distance	[Pr. PT07]	Set this to shift the home position, which is specified by the Z-phase signal.
Acceleration time constant/deceleration time constant of home position return	Point table No. 1	The acceleration/deceleration time constant of point table No. 1 is used.
Home position return position data	[Pr. PT08]	Set the current position when the home position return is complete.

(2) Timing chart



The setting value of [Pr. PT08 Home position return position data] is used as the position address at the home position return completion.


4. HOW TO USE THE POINT TABLE

4.4.13 Automatic retract function used for the home position return

For a home position return using a proximity dog, if the home position return starts from or beyond the proximity dog, this function executes the home position return after the position is shifted back to where the home position return is possible.


(1) When the current position is on the proximity dog

When the current position is on the proximity dog, the position is shifted back automatically to execute the home position return.



(2) When the current position is beyond the proximity dog

The position is shifted in a direction of the home position return. When LSP (Forward rotation stroke end) or LSN (Reverse rotation stroke end) is detected, the position is shifted back automatically. The position will be shifted passing the proximity dog, and the travel will stop. The home position return will be restarted from that position. If the proximity dog is not detected, the travel stops at LSP or LSN on the opposite side, and [AL.90 Home position return incomplete warning] occurs.



Note. The software limit cannot be used instead of LSP (Forward stroke end) and LSN (Reverse stroke end).

4. HOW TO USE THE POINT TABLE

4.4.14 Automatic positioning to home position function

POINT
<p>● The automatic positioning to the home position cannot be performed from outside the setting range of position data. In this case, perform the home position return again using the home position return.</p>

If the home position is fixed by returning to the home position after the power-on, this function enables a high-speed automatic positioning to the home position. For the absolute position detection system, the home position return is unnecessary after the power-on.

If the automatic positioning to the home position is executed without completing the home position return, [AL. 90.1] will occur.

After the power-on, perform the home position return in advance.


Set input devices and parameters as follows.

Item	Device/parameter to be used	Setting
Home position return mode selection	MD0 (Operation mode selection 1)	Switch on MD0.
	DI0 (Point table No. selection 1) to DI4 (Point table No. selection 5)	Switch off DI0 to DI4.
Home position return speed	[Pr. PT05]	Set the servo motor speed to travel to the home position.
Acceleration time constant/deceleration time constant of home position return	Point table No. 1	The acceleration/deceleration time constant of point table No. 1 is used.
Home position return direction	[Pr. PT04]	Set the rotation direction in degrees.

Set the home position return speed of the automatic positioning to home position function with [Pr. PT05].

The data of point table No. 1 is used for acceleration/deceleration time constants. Switching on ST2 (Reverse rotation start) enables high-speed automatic return.

Set the rotation direction with home position return direction of [Pr. PT04] when the unit is set to degree.



4. HOW TO USE THE POINT TABLE

4.5 Roll feed mode using the roll feed display function

The roll feed display function changes the display method of the current position and the command position in the status monitor.


By using the roll feed display function, the servo amplifier can be used in the roll feed mode. The roll feed mode is compatible with the incremental system. Additionally, the feed speed can be changed by the override function during a operation. Refer to section 2.4 for details.

(1) Parameter setting

No.	Name	Setting digit	Setting item	Setting value	Setting
PT26	Current position/command position display selection	-- x _	Current position/command position display selection	-- 1 _	Select the roll feed display.
PT26	Electronic gear fraction clear selection	--- x	Electronic gear fraction clear selection	--- 1	Clear a fraction of the previous command by the electronic gear at start of the automatic operation. Always set "--_ 1" (enabled) in the electronic gear fraction clear.

(2) Roll feed display function

When the roll feed display function is used, the status display of the current position and the command position at start will be 0.



(3) Position data unit

The display unit is expressed in the unit set in [Pr. PT26], and the feed length multiplication is expressed in the unit set in [Pr. PT03].

When the unit is set in degrees, the roll feed display function is disabled.

Refer to section 4.2.2 for details.

(4) Operation method

Only the status display of the current position and command position changes. The operation method is the same as each operation mode.

Operation mode		Detailed explanation
Automatic operation	Automatic operation using the point table	Section 4.2.2
Manual operation	JOG operation	Section 4.3.1
	Manual pulse generator operation	Section 4.3.2
Home position return mode		Section 4.4


4. HOW TO USE THE POINT TABLE

4.6 Point table setting method

The following shows the setting method of point tables using MR Configurator2.

4.6.1 Setting procedure

Click "Positioning-data" in the menu bar, and click "Point Table" in the menu.



The following window will be displayed.

(i) Axis1 (l) Open (m) Save As (c) Read (d) Set to default (e) Verify (f) Detailed Setting (g) Single-step Feed (h) Copy (j) Paste (k) Insert (a) Delete (b) Restore (n) Redo

Point table positioning operation (Absolute value command system)

No.	Target position mm	Rotation speed r/min	Accel. time const. ms	Decel. time const. ms	Dwell time ms	Auxiliary func. 0-3,8-11	M code 0-99	For manufact. 1 0-65535	For manufact. 2 0-65535
1	0.000	0	0	0	0	0	0	0	0
2	0.000	0	0	0	0	0	0	0	0
3	0.000	0	0	0	0	0	0	0	0
4	0.000	0	0	0	0	0	0	0	0
5	0.000	0	0	0	0	0	0	0	0
6	0.000	0	0	0	0	0	0	0	0
7	0.000	0	0	0	0	0	0	0	0
8	0.000	0	0	0	0	0	0	0	0
9	0.000	0	0	0	0	0	0	0	0
10	0.000	0	0	0	0	0	0	0	0
11	0.000	0	0	0	0	0	0	0	0
12	0.000	0	0	0	0	0	0	0	0
13	0.000	0	0	0	0	0	0	0	0
14	0.000	0	0	0	0	0	0	0	0
15	0.000	0	0	0	0	0	0	0	0
16	0.000	0	0	0	0	0	0	0	0
17	0.000	0	0	0	0	0	0	0	0
18	0.000	0	0	0	0	0	0	0	0
19	0.000	0	0	0	0	0	0	0	0
20	0.000	0	0	0	0	0	0	0	0
21	0.000	0	0	0	0	0	0	0	0
22	0.000	0	0	0	0	0	0	0	0
23	0.000	0	0	0	0	0	0	0	0
24	0.000	0	0	0	0	0	0	0	0
25	0.000	0	0	0	0	0	0	0	0
26	0.000	0	0	0	0	0	0	0	0
27	0.000	0	0	0	0	0	0	0	0
28	0.000	0	0	0	0	0	0	0	0
29	0.000	0	0	0	0	0	0	0	0
30	0.000	0	0	0	0	0	0	0	0
31	0.000	0	0	0	0	0	0	0	0

Selected Items Write Write All Update Project

(1) Writing point table data (a)

Select changed point table data, and click "Selected Items Write" to write the changed point table data to the servo amplifier.

(2) Writing all point table data (b)

Click "Write All" to write all the point table data to the servo amplifier.

(3) Reading all point table data (c)

Click the "Read" button to read all the point table data from the servo amplifier and display them.


4. HOW TO USE THE POINT TABLE

- (4) Initial setting of point table data (d)
Click the "Set to default" button to initialize all the data of point table No. 1 to 31. This function also initializes data currently being edited.
- (5) Verifying point table data (e)
Click the "Verify" button to verify all the data displayed and data of the servo amplifier.
- (6) Detailed setting of point table data (f)
Click the "Detailed Setting" to change position data range and unit in the point table window. Refer to section 4.6.2 for details.
- (7) Single-step feed (g)
Click "Single-step Feed" to perform the single-step feed test operation. Refer to section 3.1.9 for details.
- (8) Copy and paste of point table data (h)
Click "Copy" to copy the point table data. Click "Paste" to paste the copied point table data.
- (9) Inserting point table data (i)
Click the "Insert" button to insert a block before the selected point table No. The selected block and later will be shifted down by one. The selected point table No. and lower rows will be shifted down one by one.
- (10) Deleting point table data (j)
Click the "Delete" button to delete the selected block of the point table No. The selected block and later will be shifted up by one.
- (11) Changing point table data (k)
After selecting the data to be changed, enter a new value, and click "Enter". You can change the displayed range and unit with "(6) Detailed setting of point table data" of this section.
- (12) Reading point table data (l)
Click "Open" to read the point table data.
- (13) Saving point table data (m)
Click "Save As" to save the point table data.
- (14) Updating project (n)
Click "Update Project" to update the point table data to a project.

4. HOW TO USE THE POINT TABLE

4.6.2 Detailed setting window

The position data range and unit can be changed with the detailed setting in the point table window. For the position data range and unit of [Pr. PT01] setting, refer to section 4.2.2. To reflect the setting for the corresponding parameter, click the "Update Project" button in the point table window.



(1) Command method selection (PT01 *CTY): 1)

Select either the absolute position command method or the incremental value command method.

(2) Others

(a) Feed length multiplication parameter setting STM (PT03 *FTY): 2)

Select a feed length multiplication from 1/10/100/1000.

(b) Position data unit setting (PT01 *CTY): 3)

Select a unit of position data from mm/inch/degree/pulse. When degree or pulse is selected for the unit, the setting of feed length multiplication will be disabled.

5. HOW TO USE THE PROGRAM

5. HOW TO USE THE PROGRAM

For the details of the following items, refer to chapter/section (of "MR-JE-_A Servo Amplifier Instruction Manual") indicated in the table.

Item	Detailed explanation
	MR-JE-_A
Switching power on for the first time	Section 4.1

POINT
● For the mark detection function (Current position latch), refer to section 6.2.2.
● For the mark detection function (Interrupt positioning), refer to section 6.2.3.

5.1 Startup

5.1.1 Power on and off procedures


When the servo amplifier is powered on for the first time, the control mode is set to position control mode. (Refer to section 4.2.1 of "MR-JE-_A Servo Amplifier Instruction Manual".)

This section provides a case where the servo amplifier is powered on after setting the positioning mode.

(1) Power-on

Switch the power on in the following procedure. Always follow this procedure at power-on.

- 1) Switch off SON (Servo-on).
- 2) Make sure that ST1 (Forward rotation start) is off.
- 3) Switch on the main circuit power supply and the control circuit power supply.
The display shows "Pos" and 2 s later shows data.



(2) Power-off

- 1) Switch off ST1 (Forward rotation start).
- 2) Switch off SON (Servo-on).
- 3) Switch off the main circuit power supply and the control circuit power supply.

5. HOW TO USE THE PROGRAM

5.1.2 Stop

If any of the following situations occurs, the servo amplifier suspends and stops the operation of the servo motor.

Refer to section 3.10 of "MR-JE-_A Servo Amplifier Instruction Manual" for the servo motor with an electromagnetic brake.

Operation/command	Stopping condition
Switch off SON (Servo-on).	The base circuit is shut off, and the servo motor coasts.
Alarm occurrence	The servo motor decelerates to a stop. With some alarms; however, the dynamic brake operates to stop the servo motor. (Refer to chapter 8. (Note))
EM2 (Forced stop 2) off	The servo motor decelerates to a stop. [AL. E6 Servo forced stop warning] occurs. Refer to section 2.3 for EM1.
LSP (Forward rotation stroke end) off or LSN (Reverse rotation stroke end) off	The servo motor stops immediately and will be servo locked. Operation in the opposite direction is possible.


Note. Only a list of alarms and warnings is listed in chapter 8. Refer to "MELSERVO-JE Servo Amplifier Instruction Manual (Troubleshooting)" for details of alarms and warnings.

5. HOW TO USE THE PROGRAM

5.1.3 Test operation

Before starting an actual operation, perform a test operation to make sure that the machine operates normally.

Refer to section 5.1.1 for how to power on and off the servo amplifier.



5. HOW TO USE THE PROGRAM

5.1.4 Parameter setting

POINT
<p>● The following encoder cables are of four-wire type. When using any of these encoder cables, set [Pr. PC22] to "1 ___" to select the four-wire type. Incorrect setting will result in [AL. 16 Encoder initial communication error 1].</p> <p>MR-EKCBL30M-L MR-EKCBL30M-H MR-EKCBL40M-H MR-EKCBL50M-H</p>

When you use the servo in the program method, set [Pr. PA01] to "___7" (Positioning mode (program method)). For the program method, the servo can be used by merely changing the basic setting parameters ([Pr. PA __]) and positioning control parameters ([Pr. PT __]) mainly.

As necessary, set other parameters.

The following table shows the necessary setting of [Pr. PA __] and [Pr. PT __] in the program method.

Operation mode selection item		Parameter setting		Input device setting	
		[Pr. PA01]	[Pr. PT04]	MD0 (Note 1)	DI0 to DI4 (Note 1)
Operation mode				On	Any
Automatic operation mode of the program method				Off	
Manual operation mode	JOG operation				
	Manual pulse generator operation				
Home position return	Dog type	___7	___0	On	Any (Note 2)
	Count type		___1		
	Data set type		___2		
	Stopper type		___3		
	Home position ignorance (servo-on position as home position)		___4		
	Dog type rear end reference		___5		
	Count type front end reference		___6		
	Dog cradle type		___7		
	Dog type last Z-phase reference		___8		
	Dog type front end reference		___9		
	Dogless Z-phase reference		___A		

Note 1. MD0: Operation mode selection 1, DI0 to DI3: Program No. selection 1 to Program No. selection 4

2. Select a program containing a "ZRT" command, which performs the home position return.

5. HOW TO USE THE PROGRAM

5.1.5 Actual operation

Start actual operation after confirmation of normal operation by test operation and completion of the corresponding parameter settings.

5.1.6 Troubleshooting at start-up



CAUTION ● Never make a drastic adjustment or change to the parameter values as doing so will make the operation unstable.

POINT

● Using MR Configurator2, you can refer to the reason for rotation failure, etc.

The following faults may occur at start-up. If any of such faults occurs, take the corresponding action. "MR-JE-_A" means "MR-JE-_A Servo Amplifier Instruction Manual".

No.	Start-up sequence	Fault	Investigation	Possible cause	Reference
1	Power on	<ul style="list-style-type: none"> • The 7-segment LED display does not turn on. • The 7-segment LED display flickers. 	Not solved even if CN1, CN2, and CN3 connectors are disconnected.	<ol style="list-style-type: none"> 1. Power supply voltage fault 2. The servo amplifier is malfunctioning. 	/
			Solved when CN1 connector is disconnected.	Power supply of CN1 cabling is shorted.	
			Solved when CN2 connector is disconnected.	<ol style="list-style-type: none"> 1. Power supply of encoder cabling is shorted. 2. Encoder is malfunctioning. 	
			Solved when CN3 connector is disconnected.	Power supply of CN3 cabling is shorted.	
		Alarm occurs.	Refer to chapter 8 and remove the cause.		Chapter 8 (Note)
2	Switch on SON (Servo-on).	Alarm occurs.	Refer to chapter 8 and remove the cause.		Chapter 8 (Note)
		Servo motor shaft is not servo-locked. (Servo motor shaft is free.)	<ol style="list-style-type: none"> 1. Check the display to see if the servo amplifier is ready to operate. 2. Check the external I/O signal indication (section 3.1.7) to see if SON (Servo-on) is on. 	<ol style="list-style-type: none"> 1. SON (Servo-on) is not input. (wiring mistake) 2. 24 V DC power is not supplied to DICOM. 	Section 3.1.7
3	Perform a home position return.	Servo motor does not rotate.	Check the on/off status of the input signal with the external I/O signal display. (Refer to section 3.1.7.)	LSP, LSN, and ST1 are off.	Section 3.1.7
			Check [Pr. PA11 Forward rotation torque limit] and [Pr. PA12 Reverse rotation torque limit].	Torque limit level is too low for the load torque.	Section 7.2.1
			When TLA (Analog torque limit) is usable, check the input voltage on the status display.	Torque limit level is too low for the load torque.	Section 3.1.2
		The home position return is not completed.	Check the on/off status of input signal DOG with the external I/O signal display. (Refer to section 3.1.7.)	The proximity dog is set incorrectly.	Section 3.1.7

5. HOW TO USE THE PROGRAM

No.	Start-up sequence	Fault	Investigation	Possible cause	Reference
4	Switch on ST1 (Forward rotation start).	Servo motor does not rotate.	Check the on/off status of the input signal with the external I/O signal display (section 3.1.7).	LSP, LSN, and ST1 are off.	Section 3.1.7
			Check [Pr. PA11 Forward rotation torque limit] and [Pr. PA12 Reverse rotation torque limit].	Torque limit level is too low for the load torque.	Section 7.2.1
			When TLA (Analog torque limit) is usable, check the input voltage on the status display.	Torque limit level is too low for the load torque.	Section 3.1.2
5	Gain adjustment	Rotation ripples (speed fluctuations) are large at low speed.	Make gain adjustment in the following procedure. 1. Increase the auto tuning response level. 2. Repeat acceleration and deceleration several times to complete auto tuning.	Gain adjustment fault	MR-JE-_A Chapter 6
		Large load inertia moment causes the servo motor shaft to oscillate side to side.	If the servo motor may be driven with safety, repeat acceleration and deceleration three times or more to complete the auto tuning.	Gain adjustment fault	MR-JE-_A Chapter 6

Note. Only a list of alarms and warnings is listed in chapter 8. Refer to "MELSERVO-JE Servo Amplifier Instruction Manual (Troubleshooting)" for details of alarms and warnings.

5.2 Program operation method

5.2.1 Program operation method

Select a program created in advance on MR Configurator2 by using an input signal or communication, and start an operation with ST1 (Forward rotation start).

This servo amplifier is set to the absolute value command method by factory setting.

For the position data, you can set the absolute value travel command ("MOV" command), which specifies the target address, and the incremental value travel command ("MOVI" command), which specifies the travel distance. Refer to section 4.2.1 (1) and 5.2.3 (1) (a) for the movable range and the setting unit.

5. HOW TO USE THE PROGRAM

5.2.2 Program language

The maximum number of steps of a program is 480. Up to 16 programs can be created; however, the total number of the steps of all programs must be 480 or less.

A set program is selectable by using DI0 (Program No. selection 1) to DI3 (Program No. selection 4).

(1) Command list

Command	Name	Setting	Setting range	Unit	Indirect specification (Note 7)	Description
SPN (Note 2)	Servo motor speed	SPN (Setting value)	0 to permissible instantaneous speed	3000 r/min	○	Set the servo motor command speed for positioning. The setting value must be the permissible instantaneous speed or less of the servo motor used. If the setting value is unspecified, the servo motor rotates at 50 r/min.
STA (Note 2)	Acceleration time constant	STA (Setting value)	0 to 20000	ms	○	Set the acceleration time constant. The setting value is a time period which the servo motor takes from a stop to the rated speed. The value cannot be changed during a command output. If the setting value is unspecified, 1000 ms is applied.
STB (Note 2)	Deceleration time constant	STB (Setting value)	0 to 20000	ms	○	Set the deceleration time constant. The setting value is a time period which the servo motor takes from the rated speed to a stop. The value cannot be changed during a command output. If the setting value is unspecified, 1000 ms is applied.
STC (Note 2)	Acceleration/ deceleration time constant	STC (setting value)	0 to 20000	ms	○	Set the acceleration/deceleration time constants. The setting value is a time period which the servo motor takes from a stop to the rated speed, and from the rated speed to a stop. When this command is used, the same value is applied for both the acceleration time constant and the deceleration time constant. To set the acceleration/deceleration time constants individually, use the "STA" and "STB" commands. The value cannot be changed during a command output. If the setting value is unspecified, 1000 ms is applied.
STD (Note 2, 5)	S-pattern acceleration/ deceleration time constant	STD (Setting value)	0 to 1000	ms	○	Set the S-pattern acceleration/deceleration time constants. Set this command to insert S-pattern acceleration/deceleration time constants to the acceleration/deceleration time constants of the program.
MOV	Absolute value travel command	MOV (setting value)	-999999 to 999999 (Note 6)	$\times 10^{\text{STM}} \mu\text{m}$ (Note 6)	○	The servo motor rotates using the set value as the absolute value.
MOVA	Absolute value continuous travel command	MOVA (setting value)	-999999 to 999999 (Note 6)	$\times 10^{\text{STM}} \mu\text{m}$ (Note 6)	○	The servo motor rotates continuously using the set value as the absolute value. Make sure to describe this command after the "MOV" command.

5. HOW TO USE THE PROGRAM

Command	Name	Setting	Setting range	Unit	Indirect specification (Note 7)	Description								
MOVI	Incremental value travel command	MOVA (setting value)	-999999 to 999999 (Note 6)	$\times 10^{\text{STM}} \mu\text{m}$ (Note 6)	○	The servo motor rotates using the set value as the incremental value. When a negative value is set, the servo motor rotates in the reverse rotation direction. For the reverse rotation, the servo motor rotates in a direction of decreasing the address.								
MOVIA	Incremental value continuous travel command	MOVIA (setting value)	-999999 to 999999 (Note 6)	$\times 10^{\text{STM}} \mu\text{m}$ (Note 6)	○	The servo motor rotates continuously using the set value as the incremental value. Make sure to describe this command after the "MOVI" command.								
SYNC (Note 1)	Waiting for external signal to switch on	SYNC (setting value)	1 to 3			After SOUT (SYNC synchronous output) is outputted, the following steps will be stopped until PI1 (Program input 1) to PI3 (Program input 3) are switched on. <table border="1"> <thead> <tr> <th>Setting value</th> <th>Input signal</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>PI1 (Program input 1)</td> </tr> <tr> <td>2</td> <td>PI2 (Program input 2)</td> </tr> <tr> <td>3</td> <td>PI3 (Program input 3)</td> </tr> </tbody> </table>	Setting value	Input signal	1	PI1 (Program input 1)	2	PI2 (Program input 2)	3	PI3 (Program input 3)
Setting value	Input signal													
1	PI1 (Program input 1)													
2	PI2 (Program input 2)													
3	PI3 (Program input 3)													
OUTON (Note 1, 3)	External signal on output	OUTON (setting value)	1 to 3			Switch on OUT1 (Program output 1) to OUT3 (Program output 3). By setting the on-time with [Pr. PT23] to [Pr. PT25], you can switch off the input signals after the set time elapses. <table border="1"> <thead> <tr> <th>Setting value</th> <th>Input signal</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>OUT1 (Program output 1)</td> </tr> <tr> <td>2</td> <td>OUT2 (Program output 2)</td> </tr> <tr> <td>3</td> <td>OUT3 (Program output 3)</td> </tr> </tbody> </table>	Setting value	Input signal	1	OUT1 (Program output 1)	2	OUT2 (Program output 2)	3	OUT3 (Program output 3)
Setting value	Input signal													
1	OUT1 (Program output 1)													
2	OUT2 (Program output 2)													
3	OUT3 (Program output 3)													
OUTON (Note 1)	External signal off output	OUTON (setting value)	1 to 3			Switch off OUT1 (Program output 1) to OUT3 (Program output 3), which have been on with the "OUTON" command. <table border="1"> <thead> <tr> <th>Setting value</th> <th>Input signal</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>OUT1 (Program output 1)</td> </tr> <tr> <td>2</td> <td>OUT2 (Program output 2)</td> </tr> <tr> <td>3</td> <td>OUT3 (Program output 3)</td> </tr> </tbody> </table>	Setting value	Input signal	1	OUT1 (Program output 1)	2	OUT2 (Program output 2)	3	OUT3 (Program output 3)
Setting value	Input signal													
1	OUT1 (Program output 1)													
2	OUT2 (Program output 2)													
3	OUT3 (Program output 3)													
TRIP (Note 1)	Absolute value Trip point specification	TRIP (setting value)	-999999 to 999999 (Note 6)	$\times 10^{\text{STM}} \mu\text{m}$ (Note 6)		When the servo motor rotates for the travel distance set by the "TRIP" command after the "MOV" or "MOVIA" command is initiated, the next step is executed. Make sure to describe this command after the "MOV" or "MOVIA" command.								
TRIP1 (Note 1)	Incremental value Trip point specification	TRIP1 (setting value)	-999999 to 999999 (Note 6)	$\times 10^{\text{STM}} \mu\text{m}$ (Note 6)		When the servo motor rotates for the travel distance set by the "TRIP1" command after the "MOVI" or "MOVIA" command is initiated, the next step is executed. Make sure to describe this command after the "MOVI" or "MOVIA" command.								
ITP (Note 1, 4)	Interrupt positioning	ITP (setting value)	0 to 999999 (Note 6)	$\times 10^{\text{STM}} \mu\text{m}$ (Note 6)		An interrupt signal stops the servo motor when the motor rotates the set travel distance. Make sure to describe this command after the "SYNC" command.								
COUNT (Note 1)	External pulse count	COUNT (setting value)	-999999 to 999999	pulse		When the pulse counter value becomes larger than the count value set for the "COUNT" command, the next step is executed. "COUNT (0)" clears the pulse counter to 0.								

5. HOW TO USE THE PROGRAM

Command	Name	Setting	Setting range	Unit	Indirect specification (Note 7)	Description
FOR NEXT	Step repeat command	FOR (setting value) NEXT	0, 1 to 10000	times		The servo motor repeats the operation of the steps, which are set between the "FOR (Setting value)" command and the "NEXT" command, for the set number of times. Setting "0" repeats the program endlessly. Do not describe another set of "FOR" and "NEXT" command between the "FOR" and "NEXT" commands. Otherwise, an error occurs.
LPOS (Note 1)	Current position Latch	LPOS				Latch the current position at the rising edge of LPS (Current position latch). The latched current position data can be read with communication commands. When the servo motor starts rotating, the latched position varies according to the motor speed and the sampling of input signals.
TIM	Dwell	TIM (setting value)	1 to 20000	ms	○	Waits for the next step until the set time elapses.
ZRT	Home position return	ZRT				Performs a manual home position return.
TIMES	Program count command	TIMES (setting value)	0, 1 to 10000	times	○	Set the number of program executions by writing "TIMES (setting value)" command at the start of the program. To execute the program only one time, no setting is required. Setting "0" repeats the program endlessly.
STOP	Program stop	STOP				Stop the running program. Make sure to describe this command in the final line.
TLP (Note 8)	Forward rotation torque limit	TLP (setting value)	0, 1 to 1000	0.1 %		Using the maximum torque as 100%, limit the generated torque of the servo motor in the CCW power running or CW regeneration. The setting value is enabled until the program stops. Specifying the setting value to "0" enables the [Pr. PA11] setting.
TLN (Note 8)	Reverse rotation torque limit	TLN (setting value)	0, 1 to 1000	0.1 %		Using the maximum torque as 100%, limit the generated torque of the servo motor in the CW power running or CCW regeneration. The setting value is enabled until the program stops. Specifying the setting value to "0" enables the [Pr. PA12] setting.
TQL (Note 8)	Torque limit	TQL (setting value)	0, 1 to 1000	0.1 %		Using the maximum torque as 100%, limit the generated torque of the servo motor. The setting value is enabled until the program stops. Specifying the setting value to "0" enables the [Pr. PA11] and [Pr. PA12] settings.

5. HOW TO USE THE PROGRAM

- Note
1. The "SYNC", "OUTON", "OUTOF", "TRIP", "TRIP1", "COUNT", "LPOS", and "ITP" commands are enabled even during a command output.
 2. The "SPN" command is enabled while the "MOV", "MOVA", "MOVI", or "MOVIA" command is executed. The "STA", "STB", "STC", and "STD" commands are enabled while the "MOV" or "MOVI" command is executed.
 3. When the on-time is set with [Pr. PT23] to [Pr. PT25], the next command is executed after the set time elapses.
 4. When the remaining distance is equal to or less than the set value, or while the servo motor is being stopped or decelerating, the program skips the "ITP" command and proceeds to the next step.
 5. The parameter value is enabled normally. However, the value set for the command is enabled after the command is executed until the program stops.
 6. The unit of the position command data input can be changed with [Pr. PT01]. For the setting range of each unit, refer to section 5.2.3 (1) (a).
 7. For the explanation of the indirect specification, refer to section 5.2.2 (2) (j).
 8. The parameter value is enabled normally. However, the value set for the command is enabled after the command is executed until the program stops.

(2) Detailed explanations of commands

(a) Positioning conditions (SPN/STA/STB/STC/STD)

POINT
<ul style="list-style-type: none">● Once values are set for the "SPN", "STA", "STB" and "STC" commands, the values are enabled without resetting them. (The values are not initialized at the program startup.) The settings are enabled in the other programs.● The value set for the "STD" command is enabled in the same program only. The value is initialized to the setting value of [Pr. PC03] at the program startup, and therefore the value is disabled in the other programs.


The "SPN", "STA", "STB", "STC", and "STD" commands are enabled while the "MOV" or "MOVIA" command is executed.

5. HOW TO USE THE PROGRAM

3) Program example 3

Using the S-pattern acceleration/deceleration time constants reduces abrupt movements at acceleration or deceleration. When the "STD" command is used, [Pr. PC03 S-pattern acceleration/deceleration time constant] does not function.

Command	Description
SPN (1000)	Servo motor speed 1000 [r/min] a)
STC (100)	Acceleration/deceleration time constant 1000 [ms] b)
STD (10)	S-pattern acceleration/deceleration time constant 10 [ms] c)
MOV (2000)	Absolute value travel command 2000 [$\times 10^{\text{STM}}$ μm] d)
STOP	Program stop



(b) Continuous travel commands (MOVA/MOVIA)

POINT
<ul style="list-style-type: none"> ● A combination of "MOV" and "MOVIA" commands, and a combination of "MOVI" and "MOVA" commands are not available.

The "MOVA" command is a continuous travel command for the "MOV" command. After the travel with the "MOV" command is executed, the travel with "MOVA" command will be executed continuously without a stop.

The speed specified by the "MOVA command" is enabled from the deceleration start point of the preceding "MOV" or "MOVA" command.

The acceleration/deceleration time constants for the preceding "MOV" command is also applied to those for the "MOVA" command.

The "MOVIA" command is a continuous travel command for the "MOVI" command. After the travel with the "MOVI" command is executed, the travel with "MOVIA" command will be executed continuously without a stop.

The speed specified by the "MOVIA command" is enabled from the deceleration start point of the preceding "MOVI" or "MOVIA" command.

5. HOW TO USE THE PROGRAM

The acceleration/deceleration time constants for the preceding "MOVI" command is also applied to those for the "MOVIA" command.


Command	Name	Setting	Unit	Description
MOV	Absolute value travel command	MOV (setting value)	$\times 10^{\text{STM}}$ μm	Absolute value travel command
MOVA	Absolute value continuous travel command	MOVA (setting value)	$\times 10^{\text{STM}}$ μm	Absolute value continuous travel command
MOVI	Incremental value travel command	MOVI (setting value)	$\times 10^{\text{STM}}$ μm	Incremental value travel command
MOVIA	Incremental value continuous travel command	MOVIA (setting value)	$\times 10^{\text{STM}}$ μm	Incremental value continuous travel command

5. HOW TO USE THE PROGRAM

1) Program example 1

When using the absolute value travel command under the absolute value command method


Command	Description		
SPN (500)	Servo motor speed	500 [r/min]	a)
STA (200)	Acceleration time constant	200 [ms]	b)
STB (300)	Deceleration time constant	300 [ms]	c)
MOV (500)	Absolute value travel command	$500 \times 10^{\text{STM}} \mu\text{m}$	d)
SPN (1000)	Servo motor speed	1000 [r/min]	e)
MOVA (1000)	Absolute value continuous travel command	$1000 \times 10^{\text{STM}} \mu\text{m}$	f)
MOVA (0)	Absolute value continuous travel command	$0 \times 10^{\text{STM}} \mu\text{m}$	g)
STOP	Program stop		



2) Program example 2 (Incorrect usage)

For continuous operations, the acceleration time constant and the deceleration time constant cannot be changed for each different speed. Therefore, even if the "STA", "STB", and "STD" commands are written at a speed change, the commands are invalid.

Command	Description		
SPN (500)	Servo motor speed	500 [r/min]	a)
STA (200)	Acceleration time constant	200 [ms]	b)
STB (300)	Deceleration time constant	300 [ms]	c)
MOV (500)	Absolute value travel command	$500 \times 10^{\text{STM}} \mu\text{m}$	d)
SPN (1000)	Servo motor speed	1000 [r/min]	e)
STC (500)	Acceleration/deceleration time constant	500 [ms]	f) Disabled
MOVA (1000)	Absolute value continuous travel command	$1000 \times 10^{\text{STM}} \mu\text{m}$	g)
SPN (1500)	Servo motor speed	1500 [r/min]	h)
STC (100)	Acceleration/deceleration time constant	100 [ms]	i) Disabled
MOVA (0)	Absolute value continuous travel command	$0 \times 10^{\text{STM}} \mu\text{m}$	j)
STOP	Program stop		



5. HOW TO USE THE PROGRAM


(c) Input/output commands (OUTON/OUTOF) and trip point commands (TRIP/TRIPI)

POINT
<ul style="list-style-type: none"> ● Using [Pr. PT23] to [Pr. PT25], you can set the time until OUT1 (Program output 1) to OUT3 (Program output 3) are switched off. The commands are switched off under the following conditions. <ul style="list-style-type: none"> ▪ The commands are switched off by the OUTOF command. ▪ The commands are switched off by a program stop. ● The "TRIP" and "TRIPI" commands have the following restrictions. <ul style="list-style-type: none"> ▪ The "MOV" or "MOVA" command cannot be used in combination with the "TRIPI" command. ▪ The "MOVI" or "MOVIA" command cannot be used in combination with the "TRIP" command. ▪ The "TRIP" and "TRIPI" commands do not execute the next step until the servo motor passes the set address or travel distance. Set the commands within the travel command range. ▪ Whether the servo motor has passed the set address or travel distance is determined by checking the actual position (for each command). It is also determined by checking both edges of the address increasing/decreasing directions.

1) Program example 1

OUT1 (Program output 1) is switched on upon a program execution. When the program ends, OUT1 (Program output 1) is switched off.

Command	Description
SPN (1000)	Servo motor speed 1000 [r/min]
STA (200)	Acceleration time constant 200 [ms]
STB (300)	Deceleration time constant 300 [ms]
MOV (500)	Absolute value travel command 500 [$\times 10^{\text{STM}}$ μm]
OUTON (1)	Switch on OUT1 (Program output 1). a)
TIM (100)	Dwell 100 [ms]
MOV (250)	Absolute value travel command 250 [$\times 10^{\text{STM}}$ μm]
TIM (50)	Dwell 50 [ms]
STOP	Program stop b)




5. HOW TO USE THE PROGRAM

2) Program example 2

Using [Pr. PT23] to [Pr. PT25], you can switch off OUT1 (Program output 1) to OUT3 (Program output 3) automatically.

Parameter	Name	Setting value	Description
Pr. PT23	OUT1 output setting time	20	Switch off OUT1 200 [ms] later. a)
Pr. PT24	OUT2 output setting time	10	Switch off OUT2 100 [ms] later. b)
Pr. PT25	OUT3 output setting time	50	Switch off OUT3 500 [ms] later. c)

Command	Description
SPN (500)	Servo motor speed 500 [r/min]
STA (200)	Acceleration time constant 200 [ms]
STB (300)	Deceleration time constant 300 [ms]
MOV (1000)	Absolute value travel command 1000 [$\times 10^5$ μ m]
OUTON (1)	Switch on OUT1 (Program output 1).
OUTON (2)	Switch on OUT2 (Program output 2).
OUTON (3)	Switch on OUT3 (Program output 3).
STOP	Program stop




5. HOW TO USE THE PROGRAM

3) Program example 3

When setting the position address where the "OUTON" or "OUTOF" command is executed by using the "TRIP" or "TRIP1" command


Command	Description	
SPN (1000)	Servo motor speed	1000 [r/min]
STA (200)	Acceleration time constant	200 [ms]
STB (300)	Deceleration time constant	1: 300 [ms]
MOV (500)	Absolute value travel command	$500 \times 10^{\text{STM}} \mu\text{m}$
TRIP (250)	Absolute value trip point specification	$250 \times 10^{\text{STM}} \mu\text{m}$ a)
OUTON (2)	Switch on OUT2 (Program output 2).	b)
TRIP (400)	Absolute value trip point specification	$400 \times 10^{\text{STM}} \mu\text{m}$ c)
OUTOF (2)	Switch off OUT2 (Program output 2).	d)
TIM (100)	Dwell	100 [ms]
MOVI (500)	Incremental value travel command	$500 \times 10^{\text{STM}} \mu\text{m}$
TRIP1 (300)	Incremental value trip point specification	$300 \times 10^{\text{STM}} \mu\text{m}$ e)
OUTON (2)	Switch on OUT2 (Program output 2).	f)
STOP	Program stop	g)



5. HOW TO USE THE PROGRAM

4) Program example 4

Command	Description
SPN (500)	Servo motor speed 500 [r/min]
STA (200)	Acceleration time constant 200 [ms]
STB (300)	Deceleration time constant 300 [ms]
MOVI (600)	Incremental value travel command $600 \times 10^{\text{STM}} \mu\text{m}$ a)
TRIP1 (300)	Incremental value trip point specification $300 \times 10^{\text{STM}} \mu\text{m}$ b)
OUTON (3)	Switch on OUT3 (Program output 3). c)
SPN (700)	Servo motor speed 700 [r/min]
MOVIA (700)	Incremental value continuous travel command $700 \times 10^{\text{STM}} \mu\text{m}$ d)
TRIP1 (300)	Incremental value trip point specification $300 \times 10^{\text{STM}} \mu\text{m}$ e)
OUTOF (3)	Switch off OUT3 (Program output 3). f)
STOP	Program stop




(d) Dwell (TIM)

Using the "TIM (setting value)" command, set the time from when the remaining distance under the command is "0" until when the next step is executed.

The following shows operation examples of using this command in combination with the other commands for reference.

1) Program example 1


Command	Description
TIM (200)	Dwell 200 [ms] a)
SPN (1000)	Servo motor speed 1000 [r/min]
STC (20)	Acceleration/deceleration time constant 20 [ms]
MOV (1000)	Absolute value travel command $1000 \times 10^{\text{STM}} \mu\text{m}$
STOP	Program stop



5. HOW TO USE THE PROGRAM


2) Program example 2

Command	Description	
SPN (1000)	Servo motor speed	1000 [r/min]
STC (20)	Acceleration/deceleration time constant	20 [ms]
MOVI (1000)	Incremental value travel command	1000 [$\times 10^{\text{STM}}$ μm]
TIM (200)	Dwell	1: 200 [ms] a)
OUTON (1)	Switch on OUT1 (Program output 1).	b)
MOVI (500)	Incremental value travel command	500 [$\times 10^{\text{STM}}$ μm]
STOP	Program stop	



3) Program example 3


Command	Description	
SPN (1000)	Servo motor speed	1000 [r/min]
STC (20)	Acceleration/deceleration time constant	20 [ms]
MOVI (1000)	Incremental value travel command	1000 [$\times 10^{\text{STM}}$ μm]
OUTON (1)	Switch on OUT1 (Program output 1).	a)
TIM (200)	Dwell	200 [ms] b)
MOVI (500)	Incremental value travel command	500 [$\times 10^{\text{STM}}$ μm]
STOP	Program stop	



5. HOW TO USE THE PROGRAM


4) Program example 4

Command	Description	
SPN (1000)	Servo motor speed	1000 [r/min]
STC (20)	Acceleration/deceleration time constant	20 [ms]
MOVI (1000)	Incremental value travel command	1000 [$\times 10^{\text{STM}}$ μm]
TIM (200)	Dwell	200 [ms] a)
OUTON (1)	Switch on OUT1 (Program output 1).	b)
TIM (300)	Dwell	300 [ms] c)
MOVI (500)	Incremental value travel command	500 [$\times 10^{\text{STM}}$ μm]
STOP	Program stop	



5) Program example 5


Command	Description	
SPN (1000)	Servo motor speed	1000 [r/min]
STC (20)	Acceleration/deceleration time constant	20 [ms]
MOVI (1000)	Incremental value travel command	1000 [$\times 10^{\text{STM}}$ μm]
TIM (200)	Dwell	200 [ms] a)
SYNC (1)	Suspend the step until PI1 (Program input) is switched on.	
MOVI (500)	Incremental value travel command	500 [$\times 10^{\text{STM}}$ μm]
STOP	Program stop	



5. HOW TO USE THE PROGRAM

6) Program example 6

Command	Description	
SPN (1000)	Servo motor speed	1000 [r/min]
STC (20)	Acceleration/deceleration time constant	20 [ms]
MOVI (1000)	Incremental value travel command	1000 [$\times 10^{\text{STM}}$ μm]
SYNC (1)	Suspend the step until PI1 (Program input) is switched on.	
TIM (200)	Dwell	200 [ms] a)
MOVI (500)	Incremental value travel command	500 [$\times 10^{\text{STM}}$ μm]
STOP	Program stop	



5. HOW TO USE THE PROGRAM

(e) Interrupt positioning (ITP)


POINT
<ul style="list-style-type: none"> ● For positioning with the ITP command, the stop position varies depending on the servo motor speed when the "ITP" command becomes enabled. ● In the following cases, the program does not execute the "ITP" command and proceeds to the next step. <ul style="list-style-type: none"> ▪ When the setting value of the "ITP" command is smaller than that of the travel command set by the "MOV", "MOVI", "MOVA" or "MOVIA" command ▪ When the remaining distance is equal to or less than the travel distance specified by the "ITP" command ▪ While the servo motor is decelerating

When an "ITP" command is used in the program, starting from the position where PI1 (Program input 1) to PI3 (Program input 3) are switched on, the servo motor rotates for a distance of the set value and stops.

When using the "ITP" command, make sure to describe the "SYNC" command right before the "ITP" command.

1) Program example 1

Command	Description
SPN (500)	Servo motor speed 500 [r/min]
STA (200)	Acceleration time constant 200 [ms]
STB (300)	Deceleration time constant 300 [ms]
MOV (600)	Absolute value travel command 600 [$\times 10^{\text{STM}}$ μm]
SPN (100)	Servo motor speed 100 [r/min]
MOVA (600)	Continuous travel command 600 [$\times 10^{\text{STM}}$ μm]
SYNC (1)	Suspend the step until PI1 (Program input) is switched on. a)
ITP (200)	Interrupt positioning 200 [$\times 10^{\text{STM}}$ μm] b)
STOP	Program stop




5. HOW TO USE THE PROGRAM

2) Program example 2

When the travel distance set by the "ITP" command is smaller than the travel distance required for deceleration, the actual deceleration time constant becomes smaller than the setting value of the "STB" command.


Command	Description	
SPN (500)	Servo motor speed	500 [r/min]
STA (200)	Acceleration time constant	200 [ms]
STB (300)	Deceleration time constant	300 [ms]
MOV (1000)	Absolute value travel command	1000 [$\times 10^{\text{STM}}$ μm]
SYNC (1)	Suspend the step until PI1 (Program input) is switched on.	a)
ITP (50)	Interrupt positioning	50 [$\times 10^{\text{STM}}$ μm] b)
STOP	Program stop	



(f) External pulse count (COUNT)

When the number of input pulses of the manual pulse generator becomes larger than the value set for the "COUNT" command, the next step is executed. Setting "0" clears the cumulative input pulses.

Command	Description	
COUNT (500)	Wait for the next step until the number of input pulses of the manual pulse generator reaches 500 [pulse].	a)
SPN (500)	Servo motor speed	500 [r/min]
STA (200)	Acceleration time constant	200 [ms]
STB (300)	Deceleration time constant	300 [ms]
MOV (1000)	Absolute value travel command	1000 [$\times 10^{\text{STM}}$ μm]
TRIP (500)	Trip point specification	500 [$\times 10^{\text{STM}}$ μm] b)
COUNT (0)	Clear cumulative input pulses.	c)
STOP	Program stop	



5. HOW TO USE THE PROGRAM


(g) Step repeat command (FOR...NEXT)

POINT
● You cannot insert "FOR...NEXT" commands between the "FOR" and "NEXT" commands.

The servo motor repeats the operation of the steps, which are set between the "FOR (Setting value)" and the "NEXT" commands. Setting "0" repeats the program endlessly.

For how to stop the program, which has been repeated endlessly, refer to section 5.2.4 (4).

Command	Description
SPN (1000)	Servo motor speed 1000 [r/min]
STC (20)	Acceleration/deceleration time constant 20 [ms]
MOV (1000)	Absolute value travel command 1000 [$\times 10^{\text{STM}}$ μm]
TIM (100)	Dwell 100 [ms]
FOR (3)	Start of step repeat command 3 [time] a)
MOVI (100)	Incremental value travel command 100 [$\times 10^{\text{STM}}$ μm] b)
TIM (100)	Dwell 100 [ms]
NEXT	End of step repeat command c)
FOR (2)	Start of step repeat command 2 [time] d)
MOVI (200)	Incremental value travel command 200 [$\times 10^{\text{STM}}$ μm] e)
TIM (100)	Dwell 100 [ms]
NEXT	End of step repeat command f)
STOP	Program stop




5. HOW TO USE THE PROGRAM

(h) Number of program executions command (TIMES)

A program can be executed repeatedly by setting the number of program executions in the "TIMES (setting value) command" placed at the start of the program. To execute the program one time, the "TIMES" command is not required. Setting "0" repeats the program endlessly. For how to stop the program, which has been repeated endlessly, refer to section 5.2.4 (4).

Command	Description
TIMES (2)	Number of program executions command 2 [time] a)
SPN (1000)	Servo motor speed 1000 [r/min]
STC (20)	Acceleration/deceleration time constant 20 [ms]
MOVI (1000)	Incremental value travel command 1000 [$\times 10^{\text{STM}}$ μm] b)
TIM (100)	Dwell 100 [ms]
STOP	Program stop



5. HOW TO USE THE PROGRAM


(i) Current position latch (LPOS)

POINT
<ul style="list-style-type: none"> ● When the current position is stored using LPS (Current position latch input), the value varies depending on the servo motor speed at switch-on of LPS. ● The program does not proceed to the next step until LPS (Current position latch input) is switched on. ● The stored data will not be cleared unless the servo amplifier is switched off. ● After the input of LPS (Current position latch input) becomes enabled by the "LPOS" command, the input is cleared in the following conditions. <ul style="list-style-type: none"> ▪ When the rising edge of LPS (Current position latch input) is detected ▪ When the program ends ▪ When the operation mode is changed ▪ When the servo motor forcibly stopped ▪ When an alarm occurs ▪ When the servo motor enters the servo-off status

The current position upon switch-on of LPS (Current position latch input) is stored. The stored position data can be read with the communication function.

The current position latch function, which is set during the execution of the program, will be canceled when the program ends. The function is also canceled with an operation mode change, forced stop, alarm occurrence, or servo-off. The function will not be canceled by only a temporary stop.

Command	Description
SPN (500)	Servo motor speed 500 [r/min]
STA (200)	Acceleration time constant 200 [ms]
STB (300)	Deceleration time constant 300 [ms]
MOV (1000)	Absolute value travel command 1000 [$\times 10^{\text{STM}}$ μm]
LPOS	Set a current position latch. a)
STOP	Program stop



5. HOW TO USE THE PROGRAM

(j) Indirect specification with general purpose registers (R1-R4, D1-D4)

You can indirectly specify the setting values of the "SPN", "STA", "STB", "STC", "STD", "MOV", "MOVI", "MOVA", "MOVIA", "TIM", and "TIMES" commands.

The value, which is stored in each general purpose register (R1-R4, D1-D4), is used as the setting value of each command.

Change the general purpose registers by using MR Configurator2 or a communication command while the program is not executed by a communication command


The data of the general purpose registers is erased at power-off of the servo amplifier. Note that the data of the general purpose registers (R1-R4) can be stored in EEPROM.

The setting range of each general purpose register is that of the command for which each register is used.

The following explains a case where the general purpose registers are set as shown below before the execution of the program.

General purpose register	Setting
R1	1000
R2	2000
D1	200
D2	300

Command	Description
SPN (1000)	Servo motor speed 1000 [r/min] a)
STA (D1)	Acceleration time constant D1 = 200 [ms] b)
STB (D2)	Deceleration time constant D2 = 300 [ms] c)
MOVI (R1)	Incremental value travel command R1 = 1000 [$\times 10^{\text{STM}}$ μm] d)
TIM (100)	Dwell 100 [ms] e)
MOVI (R2)	Incremental value travel command R2 = 2000 [$\times 10^{\text{STM}}$ μm] f)
STOP	Program stop



5. HOW TO USE THE PROGRAM

(k) Home position return command (ZRT)

Performs a home position return.


Set the home position with parameters. (Refer to section 5.4.)

With the "ZRT" command, the program proceeds to the next step after the home position return completion.

POINT
<p>● If the home position return has not completed successfully, [AL. 96 Home position return incomplete warning] occurs. In this case, the program proceeds to the next step without a stop. Since the home position return is incomplete, the travel command is disabled.</p>

Command	Description
SPN (500)	Servo motor speed 500 [r/min] a)
STA (200)	Acceleration time constant 200 [ms] b)
STB (300)	Deceleration time constant 300 [ms] c)
ZRT	Home position return d)
MOV (500)	Absolute value travel command 500 [$\times 10^{\text{STM}}$ μm] e)
STOP	Program stop

Item	Parameter to be used	Setting
Dog type home position return	[Pr. PT04]	"_ _ _ 0"
Home position return direction	[Pr. PT04]	"_ _ 0 _" (Address increasing direction)
Dog input polarity	[Pr. PT29]	"_ _ _ 1" (Detects dog when DOG (proximity dog) is on.)
Home position return speed	[Pr. PT05]	100 [r/min]
Creep speed	[Pr. PT06]	50 [r/min]
Home position shift distance	[Pr. PT07]	0 [$\times 10^{\text{STM}}$ μm]
Acceleration time constant of home position return	[Pr. PC30]	100 [ms]
Deceleration time constant of home position return	[Pr. PC31]	200 [ms]
Home position return position data	[Pr. PT08]	0




5. HOW TO USE THE PROGRAM

(I) Torque limit value switching (TLP/TLN/TQL)

Using the maximum torque as 100.0%, limit the generated torque of the servo motor.

1) Program example

Command	Description
SPN (1500)	Servo motor speed 1500 [r/min]
STA (100)	Acceleration time constant 100 [ms]
STB (200)	Deceleration time constant 1: 200 [ms]
MOV (1000)	Absolute value travel command $10^{\text{STM}} \mu\text{m}$
SYNC (1)	Suspend the step until PI1 (Program input) is switched on. a)
TLP (800)	Forward rotation torque limit 800 [0.1%] b)
SYNC (2)	Suspend the step until PI2 (Program input) is switched on. c)
TLN (500)	Reverse rotation torque limit 500 [0.1%] d)
TIM (100)	Dwell 100 [ms] e)
MOV (500)	Absolute value travel command $1000 [\times 10^{\text{STM}} \mu\text{m}]$
SYNC (3)	Suspend the step until PI3 (Program input) is switched on. f)
TQL (300)	Torque limit 300 [0.1%] g)
STOP	Program stop h)



5. HOW TO USE THE PROGRAM

5.2.3 Basic settings of signals and parameters

(1) Parameter

(a) Setting range of the position data


The following shows the setting of [Pr. PT01].

Command method	Travel command	[Pr. PT01]		Position data input range		
		Positioning command method	Position data unit			
Absolute value command method	Absolute value travel command ("MOV", "MOVA")	--- 0	_ 0 _ _	[mm]	-999999 to 999999 [$\times 10^{\text{STM}}$ μm]	
			_ 1 _ _	[inch]	-999999 to 999999 [$\times 10^{\text{STM-4}}$ inch]	
			_ 2 _ _	[degree]	-360.000 to 360.000	
	_ 3 _ _		[pulse]	-999999 to 999999		
	Incremental value travel command ("MOVI", "MOVIA")		Incremental value travel command ("MOVI", "MOVIA")	_ 0 _ _	[mm]	-999999 to 999999 [$\times 10^{\text{STM}}$ μm]
				_ 1 _ _	[inch]	-999999 to 999999 [$\times 10^{\text{STM-4}}$ inch]
_ 2 _ _		[degree]		-999.999 to 999.999		
Incremental value command method	Incremental value travel command ("MOVI", "MOVIA")	--- 1	_ 3 _ _	[pulse]	-999999 to 999999	
			_ 0 _ _	[mm]	-999999 to 999999 [$\times 10^{\text{STM}}$ μm]	
			_ 1 _ _	[inch]	-999999 to 999999 [$\times 10^{\text{STM-4}}$ inch]	
			_ 2 _ _	[degree]	-999.999 to 999.999	
			_ 3 _ _	[pulse]	-999999 to 999999	

(c) Rotation direction selection/travel direction selection ([Pr. PA14])

Select the servo motor rotation direction when ST1 (Forward rotation start) is switched on.

[Pr. PA14] setting	Servo motor rotation direction when ST1 (Forward rotation start) is switched on
0 (initial value)	CCW rotation with + position data CW rotation with - position data
1	CW rotation with + position data CCW rotation with - position data



5. HOW TO USE THE PROGRAM

(c) Feed length multiplication ([Pr. PT03])

Set the feed length multiplication factor (STM) of the position data.

[Pr. PT03] setting	Position data input range			
	[mm]	[inch]	[degree] (Note)	[pulse] (Note)
___0 (initial value)	-999.999 to 999.999	-99.9999 to 99.9999	-360.000 to 360.000	-999999 to 999999
___1	-9999.99 to 9999.99	-999.999 to 999.999		
___2	-99999.9 to 99999.9	-9999.99 to 9999.99		
___3	-999999 to 999999	-99999.9 to 99999.9		

Note. The feed length multiplication setting ([Pr. PT03]) is not applied to the unit multiplication factor. Adjust the unit multiplication factor in the electronic gear setting ([Pr. PA06] and [Pr. PA07]).

(2) Signal

Selecting a program with DI0 to DI3 and switching on ST1 perform the positioning operation according to the set program. At this time, ST2 (Reverse rotation start) is disabled.

Item	Device to be used	Setting
Program operation method selection	MD0 (Operation mode selection 1)	Switch on MD0.
Program selection	DI0 (Program No. selection 1) DI1 (Program No. selection 2) DI2 (Program No. selection 3) DI3 (Program No. selection 4)	Refer to section 2.3 (1).
Start	ST1 (Forward rotation start)	Switch on ST1 to execute the program operation.

5. HOW TO USE THE PROGRAM

5.2.4 Timing chart of the program operation


(1) Operation condition

The following shows a timing chart when the program below is executed after the home position return completion under the absolute value command method.

Program No.	Description		
SPN (1000)	Servo motor speed	1000 [r/min]	
STC (100)	Acceleration/deceleration time constant	100 [ms]	
MOV (5000)	Absolute value travel command	5000 [$\times 10^{\text{STM}}$ μm]	Travel command 1
SYNC (1)	Suspend the step until PI1 (Program input) is switched on.		
STC (50)	Acceleration/deceleration time constant	50 [ms]	
MOV (7500)	Absolute value travel command	7500 [$\times 10^{\text{STM}}$ μm]	Travel command 2
STOP	Program stop		

Program No.	Description		
SPN (1000)	Servo motor speed	1000 [r/min]	
STC (100)	Acceleration/deceleration time constant	100 [ms]	
MOV (2500)	Absolute value travel command	2500 [$\times 10^{\text{STM}}$ μm]	Travel command 3
SYNC (1)	Suspend the step until PI1 (Program input) is switched on.		
STC (50)	Acceleration/deceleration time constant	50 [ms]	
MOV (5000)	Absolute value travel command	5000 [$\times 10^{\text{STM}}$ μm]	Travel command 4
STOP	Program stop		

(2) Timing chart



Note. The detection of external input signals is delayed by the time set in the input filter setting of [Pr. PD29]. Considering the output signal sequence from the controller and signal variations due to hardware, configure a sequence that changes the program selection earlier.

5. HOW TO USE THE PROGRAM

(3) Temporary stop/restart

When TSTP is switched on during the automatic operation, deceleration is performed using the deceleration time constant under the executing travel command to make a temporary stop. An operation for the remaining distance will be started by switching TSTP off and on (on-edge detection).

ST1 (Forward rotation start) does not function even if it is switched on during the temporary stop. When the operation mode is switched from the automatic mode to the manual mode during the temporary stop, the remaining travel distance will be cleared, and the program will end. Switching on TSTP again will not restart the program. To start the program, switch on ST1 (Forward rotation start) again.

The temporary stop/restart input does not function during a home position return or JOG operation.

The timing chart is the same as that of the point table operation mode. Refer to section 4.2.2 (3) (e).

(4) How to stop the program

To stop the program in execution, switch on TSTP (Temporary stop/restart) to stop the positioning operation, and then switch on CR (Clear). At this time, the remaining distance will be cleared, and the program will end.

Switching on TSTP again will not restart the positioning operation.

To start the program, switch on ST1 (Forward rotation start) again.

(5) Program termination condition

The following shows the conditions for terminating the program in execution.

Termination condition	Restart condition
Execution of STOP (Program stop)	Switch on ST1 (Forward rotation start). The program starts from the beginning.
When the automatic operation mode is switched to the manual operation mode	After switching to the automatic operation mode, switch on ST1. The program starts from the beginning.
When the hardware stroke limit is detected	After LSP and LSN are switched on, switch on ST1. The program starts from the beginning.
When the software stroke limit is detected ([Pr. PT15] to [Pr. PT18])	After the machine travels to within the software stroke limit range, switch on ST1. The program starts from the beginning.
At base circuit shut-off	After resetting the base circuit shut-off, switch on ST1. The program starts from the beginning.

5. HOW TO USE THE PROGRAM

5.3 Manual operation mode

For the machine adjustment, home position adjustment, and others, you can shift the position to any position with a JOG operation or manual pulse generator.

5.3.1 JOG operation



(1) Setting

According to the purpose of use, set input signals and parameters as shown below. At this time, DI0 (Program No. selection 1) to DI3 (Program No. selection 4) are disabled.

Item	Device/parameter to be used	Setting
Manual operation mode selection	MD0 (Operation mode selection 1)	Switch off MD0.
Servo motor rotation direction	[Pr. PA14]	Refer to (2) of this section.
JOG speed	[Pr. PT13]	Set the servo motor speed.
Acceleration time constant	[Pr. PC01]	Set the acceleration time constant.
Deceleration time constant	[Pr. PC02]	Set the deceleration time constant.
S-pattern acceleration/deceleration time constant	[Pr. PC03]	Set the S-pattern acceleration/deceleration time constants.

(2) Servo motor rotation direction

[Pr. PA14] setting	Servo motor rotation direction	
	ST1 (Forward rotation start) on	ST2 (Reverse rotation start) on
0	CCW rotation	CW rotation
1	CW rotation	CCW rotation




(3) Operation

When ST1 is switched on, the servo motor rotates using the JOG speed set in [Pr. PT13] and the acceleration/deceleration constants set with [Pr. PC02] and [Pr. PC03]. For the rotation direction, refer to (2) of this section. Switching on ST2 rotates the servo motor opposite to the direction of ST1 (Forward rotation start).

5. HOW TO USE THE PROGRAM

(4) Timing chart



5.3.2 Manual pulse generator operation

(1) Setting

POINT
<ul style="list-style-type: none"> ● To enhance noise tolerance, set "_ 2 _" to [Pr. PA13] when the command pulse frequency is 500 kpulses/s or less, or set "_ 3 _" to [Pr. PA13] when the command pulse frequency is 200 kpulses/s or less.


According to the purpose of use, set input signals and parameters as shown below. At this time, DI0 (Program No. selection 1) to DI3 (Program No. selection 4) are disabled.

Item	Device/parameter to be used	Setting
Manual operation mode selection	MD0 (Operation mode selection 1)	Switch off MD0.
Manual pulse generator multiplication	[Pr. PT03]	Set the multiplication factor for the pulses generated from the manual pulse generator. For details, refer to (3) of this section.
Servo motor rotation direction	[Pr. PA14]	Refer to (2) of this section.
Command input pulse train input form	[Pr. PA13]	Set "_ _ _ 2" (A/B-phase pulse train).
Pulse train filter selection	[Pr. PA13]	Set other than "_ 0 _" and "_ 1 _".

5. HOW TO USE THE PROGRAM

(2) Servo motor rotation direction

[Pr. PA14] setting	Servo motor rotation direction	
	Manual pulse generator operation: forward rotation	Manual pulse generator operation: reverse rotation
0	CCW rotation	CW rotation
1	CW rotation	CCW rotation



(3) Manual pulse generator multiplication

(a) Setting with input signals

In "Device Setting" of MR Configurator2, set TP0 (Manual pulse generator multiplication 1) and TP1 (Manual pulse generator multiplication 2) for input signals.

TP1 (Pulse generator multiplication 2) (Note)	TP0 (Pulse generator multiplication 1) (Note)	Servo motor rotation multiplication factor for manual pulse generator rotation amount	Travel distance			
			[mm]	[inch]	[degree]	[pulse]
0	0	[Pr. PT03] setting enabled				
0	1	1 time	0.001	0.0001	0.001	1
1	0	10 times	0.01	0.001	0.01	10
1	1	100 times	0.1	0.01	0.1	100

Note. 0: Off

1: On

(b) Using the parameter for setting

Using [Pr. PT03], set the servo motor rotation multiplication factor for the rotation amount of the manual pulse generator.

[Pr. PT03] setting	Servo motor rotation multiplication to manual pulse generator rotation amount	Travel distance			
		[mm]	[inch]	[degree]	[pulse]
-- 0 --	1 time	0.001	0.0001	0.001	1
-- 1 --	10 times	0.01	0.001	0.01	10
-- 2 --	100 times	0.1	0.01	0.1	100

(4) Operation

Turning the manual pulse generator rotates the servo motor. For the rotation direction of the servo motor, refer to (2) of this section.

5. HOW TO USE THE PROGRAM

5.4 Home position return mode

POINT
<ul style="list-style-type: none">● Before performing the home position return, make sure that the limit switch operates.● Check the home position return direction. An incorrect setting will cause a reverse running.● Check the proximity dog input polarity. Otherwise, it may cause an unexpected operation.

5.4.1 Outline of home position return

A home position return is performed to match the command coordinates with the machine coordinates. The home position return is required every time the input power is on.

This section shows the home position return methods of the servo amplifier. Select the optimum method according to the configuration and uses of the machine.

This servo amplifier has the home position return automatic retract function. When the machine stops beyond or on a proximity dog, this function automatically moves the machine back to the proper position to perform the home position return. Manual operation with JOG operation, etc. is unnecessary.

5. HOW TO USE THE PROGRAM

(1) Home position return types

Select the optimum home position return type according to the machine type or others.

Type	Home position return method	Feature
Dog type	Deceleration starts from the front end of the proximity dog. After the rear end is passed, the position specified by the first Z-phase signal, or the position of the first Z-phase signal shifted by the specified home position shift distance is used as the home position. The servo amplifier internally recognizes the Z-phase signal one time per servo motor revolution. The Z-phase signal cannot be used as an output signal.	<ul style="list-style-type: none"> • Typical home position return method using a proximity dog • The repeatability of the home position return is high. • The machine is less loaded. • Use this when the width of the proximity dog can be set equal to or greater than the deceleration distance of the servo motor.
Count type	Deceleration starts from the front end of the proximity dog. After the front end is passed, the position specified by the first Z-phase signal after the set distance or the position of the Z-phase signal shifted by the set home position shift distance is set as a home position.	<ul style="list-style-type: none"> • This is a home position return method using a proximity dog. • Use this to minimize the length of the proximity dog.
Data set type	The position shifted by any distance manually is used as the home position.	<ul style="list-style-type: none"> • No proximity dog is required.
Stopper type	A workpiece is pressed against a mechanical stopper, and the position where it is stopped is set as the home position.	<ul style="list-style-type: none"> • Since the workpiece collides with the mechanical stopper, the home position return speed must be low enough. • The strength of the machine and stopper must be increased.
Home position ignorance (servo-on position as home position)	The position at servo-on is used as the home position.	
Dog type rear end reference	Deceleration starts from the front end of the proximity dog. After the rear end is passed, the position is shifted by the travel distance after proximity dog and the home position shift distance. The position after the shifts is used as the home position.	<ul style="list-style-type: none"> • The Z-phase signal is not required.
Count type front end reference	Deceleration starts from the front end of the proximity dog. The position is shifted by the travel distance after proximity dog and the home position shift distance. The position after the shifts is used as the home position.	<ul style="list-style-type: none"> • The Z-phase signal is not required.
Dog cradle type	After the front end of the proximity dog is detected, the position specified by the first Z-phase signal is used as the home position.	
Dog type last Z-phase reference	After the front end of the proximity dog is detected, the position is shifted away from the proximity dog in the reverse direction. Then, the position specified by the first Z-phase signal or the position of the first Z-phase signal shifted by the home position shift distance is used as the home position.	
Dog type front end reference	Starting from the front end of the proximity dog, the position is shifted by the travel distance after proximity dog and the home position shift distance. The position after the shifts is used as the home position.	<ul style="list-style-type: none"> • The Z-phase signal is not required.
Dogless Z-phase reference	The position specified by the first Z-phase signal, or the position of the first Z-phase signal shifted by the home position shift distance is used as the home position.	

5. HOW TO USE THE PROGRAM

(2) Parameters for home position return

To perform the home position return, set each parameter as follows.

(a) Select the home position return type with [Pr. PT04 Home position return type].

[Pr. PT04]

0	0	0	
---	---	---	--

Home position return method
 0: Dog type (rear-end detection Z-phase reference)
 1: Count type (front-end detection Z-phase reference)
 2: Data set type
 3: Stopper type
 4: Home position ignorance (servo-on position as home position)
 5: Dog type (rear-end detection, rear-end reference)
 6: Count type (front-end detection, front-end reference)
 7: Dog cradle type
 8: Dog type (front-end detection, Z-phase reference)
 9: Dog type (front-end detection, front-end reference)
 A: Dogless type (Z-phase reference)

(b) Select the starting direction for the home position return with [Pr. PT04 Home position return type].

Setting "0" starts the home position return in a direction of increasing the address from the current position. Setting "1" starts the home position return in a direction of decreasing the address from the current position.

[Pr. PT04]

0	0		0
---	---	--	---

Home position return direction
 0: Address increasing direction
 1: Address decreasing direction

(c) Select the polarity where the proximity dog is detected with the DOG (Proximity dog) polarity selection of [Pr. PT29 Function selection T-3].

Setting "0" detects a proximity dog when DOG (Proximity dog) is switched off. Setting "1" detects a proximity dog when DOG (Proximity dog) is switched on.

[Pr. PT29]

0	0	0	
---	---	---	--

--	--	--	--

DOG (Proximity dog) polarity selection
 0: Detection with off
 1: Detection with on

(3) Program example

Select a program containing a "ZRT" command, which performs the home position return.

5. HOW TO USE THE PROGRAM

5.4.2 Dog type home position return

This is a home position return method using a proximity dog. Deceleration starts at the front end of the proximity dog. After the rear end is passed, the position specified by the first Z-phase signal, or the position of the first Z-phase signal shifted by the specified home position shift distance is used as the home position.

(1) Device/parameter

Set input devices and parameters as follows:

Item	Device/parameter to be used	Setting
Automatic operation mode of the program method	MD0 (Operation mode selection 1)	Switch on MD0.
Dog type home position return	[Pr. PT04]	___0: Select dog type (rear end detection Z-phase reference)
Home position return direction	[Pr. PT04]	Refer to section 5.4.1 (2) to select the home position return direction.
Dog input polarity	[Pr. PT29]	Refer to section 5.4.1 (2) to select the dog input polarity.
Home position return speed	[Pr. PT05]	Set the rotation speed specified until a dog is detected.
Creep speed	[Pr. PT06]	Set the rotation speed specified after a dog is detected.
Home position shift distance	[Pr. PT07]	Set this to shift the home position, which is specified by the first Z-phase signal after the rear end of the proximity dog is passed.
Acceleration time constant of home position return	[Pr. PC30]	The acceleration time constant set for [Pr. PC30] is used.
Deceleration time constant of home position return	[Pr. PC31]	The deceleration time constant set for [Pr. PC31] is used.
Home position return position data	[Pr. PT08]	Set the current position when the home position return completed.
Program	D11 (Program No. selection 1) to D13 (Program No. selection 4)	Select a program containing a "ZRT" command, which performs the home position return.

(2) Length of the proximity dog

To generate the Z-phase signal of the servo motor during the detection of DOG (Proximity dog), set the length of the proximity dog that satisfies equations (5.1) and (5.2).

$$L_1 \geq \frac{V}{60} \cdot \frac{td}{2} \dots\dots\dots (5.1)$$

L₁: Length of the proximity dog [mm]
V: Home position return speed [mm/min]
td: Deceleration time [s]


$$L_2 \geq 2 \cdot \Delta S \dots\dots\dots (5.2)$$

L₂: Length of the proximity dog [mm]
ΔS: Travel distance per servo motor revolution [mm]

5. HOW TO USE THE PROGRAM

(3) Timing chart

The following shows a timing chart after a program containing a "ZRT" command is selected.




The setting value of [Pr. PT08 Home position return position data] is used as the position address at the home position return completion.

(4) Adjustment

For the dog type home position return, adjust the setting so that the Z-phase signal is always generated during the detection of a dog. Make an adjustment so that the rear end of DOG (Proximity dog) is positioned almost at the center between the positions specified by a Z-phase signal and the next Z-phase signal.

The generation position of the Z-phase signal can be checked with "Position within one-revolution" of "Status Display" on MR Configurator2.



5. HOW TO USE THE PROGRAM

5.4.3 Count type home position return

For the count type home position return, after the front end of the proximity dog is detected, the position is shifted by the distance set in [Pr. PT09 Travel distance after proximity dog]. Then, the position specified by the first Z-phase signal is used as the home position. Therefore, when the on-time of DOG (Proximity dog) is 10 ms or more, the length of the proximity dog has no restrictions. Use the count type home position return when you cannot use the dog type home position return because the length of the proximity dog cannot be reserved, when you input DOG (Proximity dog) electrically from the controller, or other cases.

(1) Device/parameter


Set input devices and parameters as follows:

Item	Device/parameter to be used	Setting
Automatic operation mode of the program method	MD0 (Operation mode selection 1)	Switch on MD0.
Count type home position return	[Pr. PT04]	__ _ 1: Select the count type (front end detection Z-phase reference).
Home position return direction	[Pr. PT04]	Refer to section 5.4.1 (2) to select the home position return direction.
Dog input polarity	[Pr. PT29]	Refer to section 5.4.1 (2) to select the dog input polarity.
Home position return speed	[Pr. PT05]	Set the rotation speed specified until a dog is detected.
Creep speed	[Pr. PT06]	Set the rotation speed specified after a dog is detected.
Home position shift distance	[Pr. PT07]	After the front end of the proximity dog is passed, the position is shifted by the travel distance and then is specified by the first Z-phase signal. Set this to shift the position of the first Z-phase signal.
Travel distance after proximity dog	[Pr. PT09]	Set the travel distance specified after the front end of the proximity dog is passed.
Acceleration time constant of home position return	[Pr. PC30]	The acceleration time constant set for [Pr. PC30] is used.
Deceleration time constant of home position return	[Pr. PC31]	The deceleration time constant set for [Pr. PC31] is used.
Home position return position data	[Pr. PT08]	Set the current position when the home position return completed.
Program	D10 (Program No. selection 1) to D13 (Program No. selection 4)	Select a program containing a "ZRT" command, which performs the home position return.

5. HOW TO USE THE PROGRAM

(2) Timing chart

The following shows a timing chart after a program containing a "ZRT" command is selected.



The setting value of [Pr. PT08 Home position return position data] is used as the position address at the home position return completion.

5. HOW TO USE THE PROGRAM

5.4.4 Data set type home position return


To set an arbitrary position as the home position, use the data set type home position return. The JOG operation, the manual pulse generator operation, and others can be used for the travel. The data set type home position return can be performed at servo-on only.

(1) Device/parameter

Set input devices and parameters as follows:

Item	Device/parameter to be used	Setting
Automatic operation mode of the program method	MD0 (Operation mode selection 1)	Switch on MD0.
Data set type home position return	[Pr. PT04]	___ 2: Select the data set type.
Home position return position data	[Pr. PT08]	Set the current position when the home position return completed.
Program	D10 (Program No. selection 1) to D13 (Program No. selection 4)	Select a program containing a "ZRT" command, which performs the home position return.

(2) Timing chart



The setting value of [Pr. PT08 Home position return position data] is used as the position address at the home position return completion.

5. HOW TO USE THE PROGRAM

5.4.5 Stopper type home position return

For the stopper type home position return, the home position is set where the workpiece pressed against the stopper of the machine by using the JOG operation, the manual pulse generator operation, or others.


(1) Device/parameter

Set input devices and parameters as follows:

Item	Device/parameter to be used	Setting
Automatic operation mode of the program method	MD0 (Operation mode selection 1)	Switch on MD0.
Stopper type home position return	[Pr. PT04]	___ 3: Select the stopper type.
Home position return direction	[Pr. PT04]	Refer to section 5.4.1 (2) to select the home position return direction.
Home position return speed	[Pr. PT05]	Set the rotation speed until the workpiece is pressed against the mechanical stopper.
Stopper time	[Pr. PT10]	Set the time from when the home position data is obtained after the workpiece pressed against the stopper until when ZP (Home position return completion) is outputted.
Stopper type home position return torque limit value	[Pr. PT11]	Set the servo motor torque limit value at the execution of the stopper type home position return.
Acceleration time constant of home position return	[Pr. PC30]	The acceleration time constant set for [Pr. PC30] is used.
Deceleration time constant of home position return	[Pr. PC31]	The deceleration time constant set for [Pr. PC31] is used.
Home position return position data	[Pr. PT08]	Set the current position when the home position return is complete.
Program	D10 (Program No. selection 1) to D13 (Program No. selection 4)	Select a program containing a "ZRT" command, which performs the home position return.

(2) Timing chart

The following shows a timing chart after a program containing a "ZRT" command is selected.



Note. The following torque limits are enabled.

5. HOW TO USE THE PROGRAM

Input device (0: off, 1: on)		Limit value status			Enabled torque limit value
TL1	TL				
0	0				Pr. PT11
0	1	TLA	>	Pr. PT11	Pr. PT11
		TLA	<	Pr. PT11	TLA
1	0	Pr. PC35	>	Pr. PT11	Pr. PT11
		Pr. PC35	<	Pr. PT11	Pr. PC35
1	1	TLA	>	Pr. PT11	Pr. PT11
		TLA	<	Pr. PT11	TLA

The setting value of [Pr. PT08 Home position return position data] is used as the position address at the home position return completion.

5.4.6 Home position ignorance (servo-on position as home position)

POINT
<ul style="list-style-type: none"> ● To perform a home position return by using the home position ignorance, selecting a program containing a "ZRT" command is not required.


The position at servo-on is used as the home position.

(1) Device/parameter

Set input devices and parameters as follows.

Item	Device/parameter to be used	Setting
Home position ignorance	[Pr. PT04]	___ 4: Select the home position ignorance (servo-on position as home position).
Home position return position data	[Pr. PT08]	Set the current position when the home position return completed.

(2) Timing chart



The setting value of [Pr. PT08 Home position return position data] is used as the position address at the home position return completion.

5. HOW TO USE THE PROGRAM

5.4.7 Dog type rear end reference home position return

POINT
<p>● This home position return method depends on the timing of reading DOG (Proximity dog) that has detected the rear end of the proximity dog. Therefore, when a home position return is performed at a creep speed of 100 r/min, the home position has an error of 200 pulses (for HG series servo motor). The higher the creep speed, the greater the error of the home position.</p>

Deceleration starts from the front end of the proximity dog. After the rear end is passed, the position is shifted by the travel distance after proximity dog and the home position shift distance. The position after the shifts is set as the home position. The home position return is available independently of the Z-phase signal.

(1) Device/parameter


Set input devices and parameters as follows:

Item	Device/parameter to be used	Setting
Automatic operation mode of the program method	MD0 (Operation mode selection 1)	Switch on MD0.
Dog type rear end reference home position return	[Pr. PT04]	___ 5: Select the dog type (rear end detection/rear end reference).
Home position return direction	[Pr. PT04]	Refer to section 5.4.1 (2) to select the home position return direction.
Dog input polarity	[Pr. PT29]	Refer to section 5.4.1 (2) to select the dog input polarity.
Home position return speed	[Pr. PT05]	Set the rotation speed specified until a dog is detected.
Creep speed	[Pr. PT06]	Set the rotation speed specified after a dog is detected.
Home position shift distance	[Pr. PT07]	Set this to shift the home position, which is specified after the rear end of the proximity dog is passed.
Travel distance after proximity dog	[Pr. PT09]	Set the travel distance after the rear end of the proximity dog is passed.
Acceleration time constant of home position return	[Pr. PC30]	The acceleration time constant set for [Pr. PC30] is used.
Deceleration time constant of home position return	[Pr. PC31]	The deceleration time constant set for [Pr. PC31] is used.
Home position return position data	[Pr. PT08]	Set the current position when the home position return completed.
Program	D10 (Program No. selection 1) to D13 (Program No. selection 4)	Select a program containing a "ZRT" command, which performs the home position return.

5. HOW TO USE THE PROGRAM

(2) Timing chart

The following shows a timing chart after a program containing a "ZRT" command is selected.



The setting value of [Pr. PT08 Home position return position data] is used as the position address at the home position return completion.

5. HOW TO USE THE PROGRAM

5.4.8 Count type front end reference home position return

POINT
<ul style="list-style-type: none"> ● This home position return method depends on the timing of reading DOG (Proximity dog) that has detected the front end of the proximity dog. Therefore, when a home position return is performed at a creep speed of 100 r/min, the home position has an error of 200 pulses (for HG series servo motor). The higher the creep speed, the greater the error of the home position. ● After the front end of the proximity dog is detected, if a home position return ends without reaching the creep speed, [AL. 90.2] occurs. Set the travel distance after proximity dog and the home position shift distance enough for deceleration from the home position return speed to the creep speed.

(1) Device/parameter


Set input devices and parameters as follows:

Item	Device/parameter to be used	Setting
Automatic operation mode of the program method	MD0 (Operation mode selection 1)	Switch on MD0.
Count type front end reference home position return	[Pr. PT04]	___ 6: Select the count type (front end detection/front end reference).
Home position return direction	[Pr. PT04]	Refer to section 5.4.1 (2) to select the home position return direction.
Dog input polarity	[Pr. PT29]	Refer to section 5.4.1 (2) to select the dog input polarity.
Home position return speed	[Pr. PT05]	Set the rotation speed specified until a dog is detected.
Creep speed	[Pr. PT06]	Set the rotation speed specified after a dog is detected.
Home position shift distance	[Pr. PT07]	Set this to shift the home position, which is specified after the rear end of the proximity dog is passed.
Travel distance after proximity dog	[Pr. PT09]	Set the travel distance after the rear end of the proximity dog is passed.
Acceleration time constant of home position return	[Pr. PC30]	The acceleration time constant set for [Pr. PC30] is used.
Deceleration time constant of home position return	[Pr. PC31]	The deceleration time constant set for [Pr. PC31] is used.
Home position return position data	[Pr. PT08]	Set the current position when the home position return completed.
Program	DI0 (Program No. selection 1) to DI3 (Program No. selection 4)	Select a program containing a "ZRT" command, which performs the home position return.

5. HOW TO USE THE PROGRAM

(2) Timing chart

The following shows a timing chart after a program containing a "ZRT" command is selected.



The setting value of [Pr. PT08 Home position return position data] is used as the position address at the home position return completion.

5. HOW TO USE THE PROGRAM

5.4.9 Dog cradle type home position return

A position, which is specified by the first Z-phase signal after the front end of the proximity dog is detected, is set as the home position.

(1) Device/parameter


Set input devices and parameters as follows:

Item	Device/parameter to be used	Setting
Automatic operation mode of the program method	MD0 (Operation mode selection 1)	Switch on MD0.
Dog cradle type home position return	[Pr. PT04]	___ 7: Select the dog cradle type.
Home position return direction	[Pr. PT04]	Refer to section 5.4.1 (2) to select the home position return direction.
Dog input polarity	[Pr. PT29]	Refer to section 5.4.1 (2) to select the dog input polarity.
Home position return speed	[Pr. PT05]	Set the rotation speed specified until a dog is detected.
Creep speed	[Pr. PT06]	Set the rotation speed specified after a dog is detected.
Home position shift distance	[Pr. PT07]	Set this to shift the home position, which is specified by the Z-phase signal.
Acceleration time constant of home position return	[Pr. PC30]	The acceleration time constant set for [Pr. PC30] is used.
Deceleration time constant of home position return	[Pr. PC31]	The deceleration time constant set for [Pr. PC31] is used.
Home position return position data	[Pr. PT08]	Set the current position when the home position return completed.
Program	D10 (Program No. selection 1) to D13 (Program No. selection 4)	Select a program containing a "ZRT" command, which performs the home position return.

5. HOW TO USE THE PROGRAM

(2) Timing chart

The following shows a timing chart after a program containing a "ZRT" command is selected.



The setting value of [Pr. PT08 Home position return position data] is used as the position address at the home position return completion.

5. HOW TO USE THE PROGRAM

5.4.10 Dog type last Z-phase reference home position return

After the front end of the proximity dog is detected, the position is shifted away from the proximity dog at the creep speed in the reverse direction and then specified by the first Z-phase signal. The position of the first Z-phase signal is set as the home position.

(1) Device/parameter


Set input devices and parameters as follows:

Item	Device/parameter to be used	Setting
Automatic operation mode of the program method	MD0 (Operation mode selection 1)	Switch on MD0.
Dog type last Z-phase reference home position return	[Pr. PT04]	__ _ 8: Select the dog type (rear end detection/Z-phase reference).
Home position return direction	[Pr. PT04]	Refer to section 5.4.1 (2) to select the home position return direction.
Dog input polarity	[Pr. PT29]	Refer to section 5.4.1 (2) to select the dog input polarity.
Home position return speed	[Pr. PT05]	Set the rotation speed specified until a dog is detected.
Creep speed	[Pr. PT06]	Set the rotation speed specified after a dog is detected.
Home position shift distance	[Pr. PT07]	Set this to shift the home position, which is specified by the Z-phase signal.
Acceleration time constant of home position return	[Pr. PC30]	The acceleration time constant set for [Pr. PC30] is used.
Deceleration time constant of home position return	[Pr. PC31]	The deceleration time constant set for [Pr. PC31] is used.
Home position return position data	[Pr. PT08]	Set the current position when the home position return completed.
Program	D11 (Program No. selection 1) to D13 (Program No. selection 4)	Select a program containing a "ZRT" command, which performs the home position return.

5. HOW TO USE THE PROGRAM

(2) Timing chart

The following shows a timing chart after a program containing a "ZRT" command is selected.



The setting value of [Pr. PT08 Home position return position data] is used as the position address at the home position return completion.

5. HOW TO USE THE PROGRAM

5.4.11 Dog type front end reference home position return type

POINT
<p>● This home position return method depends on the timing of reading DOG (Proximity dog) that has detected the front end of the proximity dog. Therefore, when a home position return is performed at a creep speed of 100 r/min, the home position has an error of 200 pulses (for HG series servo motor). The higher the creep speed, the greater the error of the home position.</p>

A position, which is shifted by the travel distance after proximity dog and the home position shift distance from the front end of the proximity dog, is set as the home position.

The home position return is available independently of the Z-phase signal. Changing the creep speed may change the home position.

(1) Device/parameter


Set input devices and parameters as follows:

Item	Device/parameter to be used	Setting
Automatic operation mode of the program method	MD0 (Operation mode selection 1)	Switch on MD0.
Dog type front end reference home position return	[Pr. PT04]	___ 9: Select the dog type (front end detection/front end reference).
Home position return direction	[Pr. PT04]	Refer to section 5.4.1 (2) to select the home position return direction.
Dog input polarity	[Pr. PT29]	Refer to section 5.4.1 (2) to select the dog input polarity.
Home position return speed	[Pr. PT05]	Set the rotation speed specified until a dog is detected.
Creep speed	[Pr. PT06]	Set the rotation speed specified after a dog is detected.
Home position shift distance	[Pr. PT07]	Set this to shift the home position, which is specified by the Z-phase signal.
Acceleration time constant of home position return	[Pr. PC30]	The acceleration time constant set for [Pr. PC30] is used.
Deceleration time constant of home position return	[Pr. PC31]	The deceleration time constant set for [Pr. PC31] is used.
Home position return position data	[Pr. PT08]	Set the current position when the home position return completed.
Program	D11 (Program No. selection 1) to D13 (Program No. selection 4)	Select a program containing a "ZRT" command, which performs the home position return.

5. HOW TO USE THE PROGRAM

(2) Timing chart

The following shows a timing chart after a program containing a "ZRT" command is selected.



The setting value of [Pr. PT08 Home position return position data] is used as the position address at the home position return completion.

5. HOW TO USE THE PROGRAM

5.4.12 Dogless Z-phase reference home position return type

A position, which is shifted to by the home position shift distance from a position specified by the Z-phase pulse right after the start of the home position return, is set as the home position.


(1) Device/parameter

Set input devices and parameters as follows:

Item	Device/parameter to be used	Setting
Automatic operation mode of the program method	MD0 (Operation mode selection 1)	Switch on MD0.
Dogless Z-phase reference home position return	[Pr. PT04]	___ A: Select the dogless type (Z-phase reference).
Home position return direction	[Pr. PT04]	Refer to section 5.4.1 (2) to select the home position return direction.
Dog input polarity	[Pr. PT29]	Refer to section 5.4.1 (2) to select the dog input polarity.
Home position return speed	[Pr. PT05]	Set the rotation speed specified until a dog is detected.
Creep speed	[Pr. PT06]	Set the rotation speed specified after a dog is detected.
Home position shift distance	[Pr. PT07]	Set this to shift the home position, which is specified by the Z-phase signal.
Acceleration time constant of home position return	[Pr. PC30]	The acceleration time constant set for [Pr. PC30] is used.
Deceleration time constant of home position return	[Pr. PC31]	The deceleration time constant set for [Pr. PC31] is used.
Home position return position data	[Pr. PT08]	Set the current position when the home position return completed.
Program	DI1 (Program No. selection 1) to DI3 (Program No. selection 4)	Select a program containing a "ZRT" command, which performs the home position return.

(2) Timing chart

The following shows a timing chart after a program containing a "ZRT" command is selected.



The setting value of [Pr. PT08 Home position return position data] is used as the position address at the home position return completion.


5. HOW TO USE THE PROGRAM

5.4.13 Automatic retract function used for the home position return

For a home position return using a proximity dog, if the home position return starts from or beyond the proximity dog, this function executes the home position return after the position is shifted back to where the home position return is possible.


(1) When the current position is on the proximity dog

When the current position is on the proximity dog, the position is shifted back automatically to execute the home position return.



(2) When the current position is beyond the proximity dog

The position is shifted in a direction of the home position return. When LSP (Forward rotation stroke end) or LSN (Reverse rotation stroke end) is detected, the position is shifted back automatically. The position will be shifted passing the proximity dog, and the travel will stop. The home position return will be restarted from that position. If the proximity dog is not detected, the travel stops at LSP or LSN on the opposite side, and [AL.90 Home position return incomplete warning] occurs.



Note. The software limit cannot be used instead of LSP (Forward stroke end) and LSN (Reverse stroke end).

5. HOW TO USE THE PROGRAM

5.5 Serial communication operation

Using the RS-422 communication function, the servo amplifier can be operated from a controller such as a personal computer.

This section explains the data communication procedure. Refer to chapter 10 for details of the connection between the controller and servo amplifier and of communication data.


5.5.1 Positioning operation using the program

The communication function enables to select program No., and positioning operation using program is possible by switching on ST1.

(1) Program selection

Select program No. 1 to 16 by using the forced output (command [9] [2] and data No. [6] [0]) of the device from the controller.

(2) Timing chart




No.	Transmission data description	Command	Data No.
1)	Select program No. 2.	[9] [2]	[6] [0]
2)	Select program No. 1.	[9] [2]	[6] [0]
3)	Select program No. 3.	[9] [2]	[6] [0]
4)	ST1 (Forward rotation start) on	[9] [2]	[6] [0]
5)	ST1 (Forward rotation start) off	[9] [2]	[6] [0]

5. HOW TO USE THE PROGRAM

5.5.2 Multi-drop method (RS-422 communication)

The RS-422 communication function enables to operate multiple servo amplifiers on the same bus. In this method, set station Nos. to the servo amplifiers so that the controller recognizes which servo amplifier is receiving the data currently being sent. Set the station Nos. with [Pr. PC20 Station number setting]. Be sure to set one station No. to one servo amplifier. Setting one station No. to multiple servo amplifiers will disable a normal communication. When operating multiple servo amplifiers with one command, use the group specification function mentioned in section 5.5.3. For the cable connection, refer to section 12.1.1 (2) of "MR-JE-_A Servo Amplifier Instruction Manual".



5. HOW TO USE THE PROGRAM

5.5.3 Group specification




CAUTION

● Set only one servo amplifier capable of returning data in a group. If multiple servo amplifiers return data simultaneously after receiving a command from the controller, the servo amplifiers may malfunction.

When using multiple servo amplifiers, you can set parameters with commands per group.

Up to six groups of a to f can be set. Set groups for each station with the communication commands of Mitsubishi general-purpose AC servo protocol.

(1) Group setting example




Servo amplifier station No.	Group setting
Station 0	a
Station 1	
Station 2	
Station 3	
Station 4	b
Station 5	c
Station 6	
Station 7	
Station 8	d
Station 9	

5. HOW TO USE THE PROGRAM

(2) Timing chart

The following shows a timing chart of operation for each group performed with setting values set in program No. 1.



No.	Transmission data description	Command	Data No.
1)	Select program No. 1 in group a.	[9] [2]	[6] [0]
2)	ST1 (Forward rotation start) on	[9] [2]	[6] [0]
3)	ST1 (Forward rotation start) off	[9] [2]	[6] [0]
4)	Select program No. 1 in group b.	[9] [2]	[6] [0]
5)	ST1 (Forward rotation start) on	[9] [2]	[6] [0]
6)	ST1 (Forward rotation start) off	[9] [2]	[6] [0]
7)	Select program No. 1 in group c.	[9] [2]	[6] [0]
8)	ST1 (Forward rotation start) on	[9] [2]	[6] [0]
9)	ST1 (Forward rotation start) off	[9] [2]	[6] [0]
10)	Select program No. 1 in group d.	[9] [2]	[6] [0]
11)	ST1 (Forward rotation start) on	[9] [2]	[6] [0]
12)	ST1 (Forward rotation start) off	[9] [2]	[6] [0]


Besides this, you can perform simultaneous writing of common parameters to stations of each group, reset alarms, etc.

5. HOW TO USE THE PROGRAM

5.6 Incremental value command method

When using this servo amplifier in incremental value command method, change the setting of [Pr. PT01]. As position data, set the travel distance from the current address to the target address. The incremental value command method enables infinitely long constant rate of feeding.


Setting range: -999999 to 999999 [$\times 10^{\text{STM}}$ μm] (STM = Feed length multiplication [Pr. PT03])
 -999999 to 999999 [$\times 10^{(\text{STM}-4)}$ inch] (STM = Feed length multiplication [Pr. PT03])
 -999999 to 999999 [pulse]



This section indicates contents different from the absolute value command method (factory setting) when this servo amplifier is used under the incremental value command method.

(1) Parameter setting

Set [Pr. PT01] to select the incremental value command method as shown below.



(2) Command


The command contents of "MOV" and "MOVA" are changed as follows. There is no change in other commands. Thus, the command contents are the same between "MOV" and "MOVI", and between "MOVA" and "MOVIA".

Command	Name	Setting	Setting range	Unit	Indirect specification	Description
MOV	Incremental value travel command	MOV (setting value)	-999999 to 999999	$\times 10^{\text{STM}}$ μm	○	The servo motor rotates using the set value as the incremental value. The same as "MOVI" command
MOVA	Incremental value continuous travel command	MOVA (setting value)	-999999 to 999999	$\times 10^{\text{STM}}$ μm	○	The servo motor rotates continuously as the set incremental value. Make sure to describe this command after the "MOV" command. If this command is described after other command, an error will occur. The same as "MOVIA" command

5. HOW TO USE THE PROGRAM

(3) Program example


Command	Description		
SPN (1000)	Servo motor speed	1000 [r/min]	a)
STA (200)	Acceleration time constant	200 [ms]	b)
STB (300)	Deceleration time constant	300 [ms]	c)
MOVI (1000)	Incremental value travel command	1000 [$\times 10^{STM} \mu\text{m}$]	d)
TIM (100)	Dwell	100 [ms]	e)
SPN (500)	Servo motor speed	500 [r/min]	f)
STA (200)	Acceleration time constant	200 [ms]	g)
STB (300)	Deceleration time constant	300 [ms]	h)
MOVI (1000)	Incremental value travel command	1000 [$\times 10^{STM} \mu\text{m}$]	i)
SPN (1000)	Servo motor speed	1000 [r/min]	j)
MOVIA (1000)	Incremental value continuous travel command	1000 [$\times 10^{STM} \mu\text{m}$]	k)
STOP	Program stop		



5.7 Roll feed mode using the roll feed display function

Refer to section 4.5 for parameter settings of roll feed display function, position data unit and operation method.

When the roll feed display function is used, the status display of the current position at start will be 0.




5. HOW TO USE THE PROGRAM

5.8 Program setting method


The following shows the setting method of programs using MR Configurator2.

5.8.1 Setting procedure

Click "Positioning-data" in the menu bar and "Program" in the menu.



The following window will be displayed.




- (1) Reading program (a)
Click the "Read" button to read and display programs from the servo amplifier.
- (2) Writing program (b)
Click the "Write" button to write the changed programs to the servo amplifier.
- (3) Verifying program (c)
Click the "Verify" button to verify the contents of programs in the personal computer and the servo amplifier.
- (4) Single-step feed (d)
Click "Single-step Feed" to perform the single-step feed test operation. Refer to section 3.1.9 for details.
- (5) Number of steps (e)
The numbers of steps used in all programs and the remained steps are displayed.
- (6) Editing program (f)
Selected programs can be edited. Click the "Edit" button to open the program editing window. For the editing window, refer to section 5.8.2.

5. HOW TO USE THE PROGRAM

- (7) Reading program file (g)
Click "Open" to read the program table data.
- (8) Saving program file (h)
Click "Save As" to save the program table data.
- (9) Indirect addressing (i)
Click "Indirect addressing" to open the indirect addressing window. Refer to section 5.8.3 for details.
- (10) Updating project (j)
Click "Update Project" to update the program to a project.

5.8.2 Window for program edit

Programs can be created on the program editing window.



- (1) Program edit (a)
Input commands to the program edit area (a) in text format.
- (2) Cutting text (b)
Select any text in the program edit area, and click the "Cut" button to cut the selected text.
- (3) Copying text (c)
Select any text in the program edit area, and click the "Copy" button to copy the selected text to the clipboard.

5. HOW TO USE THE PROGRAM

(4) Pasting text (d)

Click the "Paste" button to paste the copied text on the clipboard to a specified place in the program edit area.

(5) Ending program data window (e)

Click the "OK" button to execute the edit check. When no error is found in the program, the edit ends and the program data window will be closed. If an error is found in the program after the edit check, the error will be displayed.

(6) Canceling window for program edit (f)


Click the "Cancel" button to close the window for program edit without saving the program currently being edited.

(7) Displaying error (g)

When the edit check of (5) detects an error in the program, the line No. and content of the error will be displayed. Click the error content, the cursor will move to the line of the corresponding program.

5.8.3 Indirect addressing window

Set general purpose registers (D1 to D4 and R1 to R4) in this window.



(1) Register edit field (a)

Set general purpose register values of D1 to D4 and R1 to R4.

(2) Register reference field (b)

The last register value read from the servo amplifier is displayed.

(3) ROM writing button (c)

Write register values (D1 to D4 and R1 to R4) stored in the servo amplifier to the servo amplifier.

6. APPLICATION OF FUNCTIONS

6. APPLICATION OF FUNCTIONS

This chapter explains about application of using positioning function of servo amplifier.

CAUTION

● Note that the number of write times to the Flash-ROM where the cam data is stored is limited to approximately 1000. If the total number write times exceeds 1000, the servo amplifier may malfunction when the Flash-ROM reaches the end of its useful life.

6.1 Simple cam function


POINT

● The simple cam function is available with servo amplifiers with software version B7 or later.

6.1.1 Outline of simple cam function

Simple cam function enables synchronous control by using software instead of controlling mechanically with cam.

The following shows a movement trajectory when the cam below is used and the input axis is rotated once.




By setting cam data and cam control data, the simple cam function enables synchronous control with an input axis (external pulse command input, point table command, or program positioning command) with a start of positioning.

6. APPLICATION OF FUNCTIONS

6.1.2 Simple cam function block

The function block diagram of the simple cam is shown below. Set the cam data with MR Configurator2.



6. APPLICATION OF FUNCTIONS

6.1.3 Control of simple cam function

The following three cam controls are available by setting the cam data and the cam control data with MR Configurator2.

Cam control method	Description	Actual movement
To-and-fro control	Reciprocates within a specified cam stroke.	<p>Cam data and cam control data (Cam created by users)</p> <p>Cam conversion processing</p> <p>Cam axis one cycle current value (Input)</p> <p>Feed current value (Output)</p>
Feed control	Updates a cam standard position per cycle.	<p>Cam data and cam control data (Cam created by users)</p> <p>Cam conversion processing</p> <p>Cam axis one cycle current value (Input)</p> <p>Feed current value (Output)</p> <p>Cam standard position (First cycle)</p> <p>Cam standard position (Second cycle)</p> <p>Cam standard position (Third cycle)</p>
Linear control	Performs linear control to keep one-cycle ratio as 100%.	<p>Cam data and cam control data (Linear cam: Cam No. 0)</p> <p>Cam conversion processing</p> <p>Cam axis one cycle current value (Input)</p> <p>Feed current value (Output)</p> <p>Cam standard position (First cycle)</p> <p>Cam standard position (Second cycle)</p> <p>Cam standard position (Third cycle)</p> <p>Stroke amount × 100 %</p>

The feed current value of the cam axis is calculated as follows:

(1) Stroke ratio data type


Feed current value = Cam standard position + (Cam stroke amount × Stroke ratio to cam axis one cycle current value)

6. APPLICATION OF FUNCTIONS

(2) Coordinate data type

Feed current value = Cam standard position + Output value to cam axis one cycle current value

When the cam axis one cycle current value is in the middle of the specified stroke ratio data, the intermediate value is calculated from the anteroposterior cam data.



6.1.4 Simple cam specification list

(1) Specification list

Item		MR-JE-_A	
Memory capacity (Note 1)	Storage area for cam data	8 Kbytes (Flash-ROM)	
	Working area for cam data	8 Kbytes (RAM) (Note 2)	
Number of registration		Max. 8	
Comment		Max. 32 single-byte characters for each cam data	
Cam data	Stroke ratio data type	Cam resolution	256/512/1024/2048
		Stroke ratio	-100.000 to 100.000 [%]
	Coordinate data type	Number of coordinate	2 to 1024
		Coordinate data	Input value: 0 to 999999 Output value: -999999 to 999999
Cam curve		12 types (constant speed/constant acceleration/5th curve/single hypotenuse/cycloid/distorted trapezoid/distorted sine/distorted constant speed/trapezoid/reverse trapezoid/double hypotenuse/reverse double hypotenuse)	

Note 1. The memory capacity includes a use area (storage area for cam data) for storing in the servo amplifier and an actual operation area (working area for cam data).

2. This can be always changed by using Modbus-RTU communication during servo-off.

(2) Cam resolution

(a) Stroke ratio data type

Cam resolution	Max. number of registration
256	8
512	4
1024	2
2048	1

(b) Coordinate data type

Number of coordinate	Max. number of registration
128	8
256	4
512	2
1024	1


6. APPLICATION OF FUNCTIONS

6.1.5 What is able to do with the simple cam

(1) Encoder following function

The servo amplifier receives A/B-phase output signal from a synchronous encoder and drives the servo motor with the signal.


Up to 4 Mpulses/s of input from synchronous encoder is compatible with the servo amplifier.



6. APPLICATION OF FUNCTIONS

(2) Mark sensor input compensation function

The servo amplifier receives input signals from a mark sensor, calculates compensation amounts, and corrects position errors of the rotary knife axis.





Item	Specifications
Number of mark detection setting	One setting (one input)
Input signal detection direction	Detected by rising edge of an external input signal
Detection accuracy (compensation cycle)	Max. 888 μ s

6. APPLICATION OF FUNCTIONS

(3) Synchronous operation using positioning data

A synchronous operation is enabled by setting the same positioning data and starting the positioning simultaneously.

For example, to synchronize the vertical motion of the vertical axis (axis 2) with the position of the horizontal axis (axis 1), input the same positioning commands to axis 2 as those for axis 1.





Note. Input the same positioning commands to the driven shaft (axis 2) as those for the main shaft (axis 1).

6. APPLICATION OF FUNCTIONS

(4) Operation example of synchronous interpolation between two axes

To move a part from point P1 to P3 making a detour to avoid work A, axis 2 starts moving after the travel completion signal of axis 1 is checked at point P2. However, by using the cam control, checking of the travel completion signal is not necessary, shortening the positioning time.



(5) Cam data transmission through Modbus-RTU

Rewriting cam data is possible by transmitting the cam data through Modbus-RTU communication if over eight cam data exceeding the maximum number of registration need to be used. In this case, be sure to rewrite the cam data in servo-off state.

6.1.6 Setting list

(1) List of items set with MR Configurator2

Set the following on the cam setting window of MR Configurator2.

Setting item		Setting
Cam control data	Main shaft input axis selection	Select a command input method for cam axis. Select from "encoder following (external pulse input) and "internal point table".
	Cam No. selection	Select the number to create the cam control data.
	Resolution setting	Set the cam resolution. Select from 256/512/1024/2048.
	Cam axis one cycle length	Set a travel amount of cam one cycle. Command unit is used as an input unit.
	Cam stroke amount	Set a cam stroke amount for the stroke ratio of 100% when using the stroke ratio data type cam control.
Cam data		Create the cam data on the cam creating window of MR Configurator2. After the data is created, write the cam data to the servo amplifier.

(2) List of items set with parameters of the servo amplifier

Set the following with the parameters of the servo amplifier.

Setting item	Setting
Operation mode selection	Select "Positioning mode (point table method or program method)" with [Pr. PA01 Operation mode].
Cam function setting	Enable the cam function with [Pr. PT35 Function selection T-5]
Cam data selection	Select the cam data to be executed with C10 (Cam No. selection 0) to C13 (Cam No. selection 3). Selecting the cam data for execution is also possible with "Cam control data No. 49 Cam No.".
Device setting	Assign CAMC (Cam control command input) and CAMS (Output in cam control) with I/O setting parameters ([Pr. PD__]).

6. APPLICATION OF FUNCTIONS


6.1.7 Data to be used with simple cam function



● Note that the number of write times to the Flash-ROM is limited to approximately 100,000. Exceeding the limited number of write times causes the servo amplifier to malfunction. If setting values need to be changed frequently, write the setting values to the RAM, not to the Flash-ROM.

(1) Memory configuration of cam control data and cam data

The cam control data and the cam data used for the simple cam are stored in Flash-ROM inside the servo amplifier. When the power is turned on, the cam data and the cam control data are copied from the Flash-ROM to the RAM inside the servo amplifier, and then cam control will be executed.



Note. When the power is turned on, the cam data and the cam control data are copied from the Flash-ROM to the RAM inside the servo amplifier, and then cam control will be executed.

Use MR Configurator2 to write the cam data and the cam control data. Two writing methods are available.

Writing method	Description
Temporary writing	Write the cam control data and the cam data to the RAM of the servo amplifier. After writing, the cam control data and the cam data will be reflected. The written data will be disabled if the power is turned off. Use this when creating and adjusting the cam control data and the cam data.
Writing	Write the cam control data and the cam data to the Flash-ROM. The data will be enabled when the power is cycled after writing After cycling the power, control is performed based on the written data. Conduct this after the cam control data and the cam data are finalized.

6. APPLICATION OF FUNCTIONS

(2) Cam control data and cam data

The following two types are available for the cam control data and cam data.

Cam data type	Description
Stroke ratio data type	Cam curve of one cycle is divided equally by the number of cam resolution and defined. The cam curve will be created with the stroke ratio data of the number of cam resolution.
Coordinate data type	Data in which cam curve of one cycle is defined with two or more points. The coordinate data is defined as (input value and output value). The input value will be the cam axis one cycle current value, and the output value will be the stroke value from the cam standard position.


(a) Stroke ratio data type

The following are set in the stroke ratio data type.

Set these on the cam setting window of MR Configurator2.

Setting item	Setting	Setting range
Cam No.	Set a Cam No.	0: Linear cam 1 to 8: User-created cam
Cam control data and cam data type	Set "1: Stroke ratio data type".	
Cam resolution	Set the number of divisions for the cam curve of one cycle.	Select from 256/512/1024/2048.
Cam control data and cam data start position	Set the position of the cam control data and the cam data when "cam axis one cycle current value" is "0".	0 to "Cam resolution - 1"
Stroke ratio data	Set the stroke ratio from the first to the last point.	-100.000 to 100.000

The following is a setting example for "cam resolution = 512" in the stroke ratio data type.



6. APPLICATION OF FUNCTIONS


(b) Coordinate data type

The following are set in the coordinate data type.


Set these on the cam setting window of MR Configurator2.

Setting item	Setting	Setting range
Cam No.	Set a Cam No.	0: Linear cam 1 to 8: User-created cam
Cam control data and cam data type	Set "2: Coordinate data type".	
Number of coordinate	Set the number of coordinates for the cam curve of one cycle. The number of coordinates includes 0th point.	2 to 1024
Cam control data and cam data start position	Setting is not necessary.	
Coordinate data	Set the coordinate data (input value X_n and output value Y_n) for the number of coordinates. Set from the 0th coordinate data (X_0 and Y_0). Set an input value larger than that of the coordinate data.	-999.999 to 999.999

The following is a setting example for the coordinate data type.




If "input value = 0" and "input value = cam axis one cycle length" are not set in the coordinate data, a control is executed by the line created from the closest two points.



6. APPLICATION OF FUNCTIONS

6.1.8 Function block diagram for displaying state of simple cam control



6.1.9 Operation

For operation method, contact your local sales office.

6. APPLICATION OF FUNCTIONS

6.2 Mark detection

6.2.1 Current position latch function

POINT
<ul style="list-style-type: none"> ● The current position latch function can be used with the point table method and the program method. However, the current position latch function is disabled in the following condition. <ul style="list-style-type: none"> ▪ Home position return ▪ Manual operation (excluding home position return) ● The latched actual current position data can be read with communication commands. ● For the servo amplifiers with software version B6 or earlier, the latched position data is not compatible with the current position of the state monitor when the roll feed display function is enabled. Disable the roll feed display function to compare the current data of the state monitor and the latched position data. ● For the servo amplifiers with software version B7 or later, the read latched position data is equal to the travel distance as the starting point is set to "0" when the roll feed display function is enabled. The output value is the same as the current position of the state monitor.

When the mark detection signal turns on, the current position is latched. The latched data can be read with communication commands.

- (1) Communication command
Reads mark detection data.

Command	Data No.	Description	Control mode			Frame length
			CP/ BCD	C L	P S	
[1] [A]	[0] [0]	MSD (Mark detection) rising latch data (data part)	○	○	/	8
	[0] [1]	MSD (Mark detection) falling latch data (data part)	○	○	/	
	[0] [2]	MSD (Mark detection) rising latch data (data part + additional information)	○	○	/	12
	[0] [3]	MSD (Mark detection) falling latch data (data part + additional information)	○	○	/	

6. APPLICATION OF FUNCTIONS

(2) Reading data

(a) Rising latch data or falling latch data (data part)

Reads MSD (Mark detection) rising latch data or MSD (Mark detection) falling latch data.

1) Transmission

Transmit command [1] [A] and data No. [0] [0] or [0] [1] corresponding to the point tables to read.
Refer to section 10.1.1.

2) Return

The slave station returns the position data of point table requested.



↑
Data will be received in hexadecimal per set command.
Hexadecimal should be changed to decimal.

Example

Data "000186A0" will be 100.000 mm in the command-side unit.

A decimal point position depends on setting contents of [Pr. PT01] and [Pr. PT03].

(b) Rising latch data or falling latch data (data part + additional information)

Reads MSD (Mark detection) rising latch data or MSD (Mark detection) falling latch data.

1) Transmission

Transmit command [1] [A] and data No. [0] [2] or [0] [3] corresponding to the point tables to read.
Refer to section 10.1.1.

2) Return

The slave station returns the speed data of point table requested.



↑
Data will be received in hexadecimal per set command.
Hexadecimal should be changed to decimal.

Example

Data "000186A0" will be 100.000 mm in the command-side unit.

A decimal point position depends on setting contents of [Pr. PT01] and [Pr. PT03].

↑
Display type

0: Data must be converted into decimal

1: Data is used unchanged in hexadecimal

↑
Decimal point position

0: No decimal point

1: First least significant digit (not used normally)

2: Second least significant digit

3: Third least significant digit

4: Forth least significant digit

5: Fifth least significant digit

6. APPLICATION OF FUNCTIONS

(3) Parameter

Set the parameter as follows:

Item	Parameter to be used	Setting
Mark detection function selection	[Pr. PT26]	Set the mark detection function selection as follows: 0 _ _ _ : Current position latch function
Mark detection range + (lower three digits)	[Pr. PC66]	Set the upper limit of the latch data in the current position latch function. When the roll feed display is enabled, set a valid range with the travel distance from the starting position. Set a same sign for [Pr. PC66] and [Pr. PC67]. A different sign will be recognized as minus sign data.
Mark detection range + (upper three digits)	[Pr. PC67]	When changing the direction to address decreasing, change it from the - side of the mark detection ([Pr. PC68] and [Pr. PC69]). An incorrect order of the setting will trigger [AL. 37]. Therefore, cycling power may be required after [Pr. PC66] to [Pr. PC69] are all set. This parameter is supported with software version B7 or later.
Mark detection range - (lower three digits)	[Pr. PC68]	Set the lower limit of the latch data in the current position latch function. When the roll feed display is enabled, set a valid range with the travel distance from the starting position. Set a same sign for [Pr. PC68] and [Pr. PC69]. A different sign will be recognized as minus sign data.
Mark detection range - (upper three digits)	[Pr. PC69]	When changing the direction to address increasing, change it from the + side of the mark detection ([Pr. PC66] and [Pr. PC67]). An incorrect order of the setting will trigger [AL. 37]. Therefore, cycling power may be required after [Pr. PC66] to [Pr. PC69] are all set. This parameter is supported with software version B7 or later.

6. APPLICATION OF FUNCTIONS

(4) Latch data range setting


The current position is latched only within the range set in [Pr. PC66] to [Pr. PC69]

When a same value is set for the upper and lower limits, the current value will be latched for a whole range.

(a) mm, inch, and pulse unit

The current position latch function is enabled when Upper limit value > Lower limit value. The valid range is the same for the absolute value command ([Pr. PT01]: ___ 0) and the incremental value command ([Pr. PT01]: ___ 1).


[AL. 37 occurs] when Upper limit value < Lower limit value.



1) When the roll feed display is disabled ([Pr. PT26]: __ 0 _)

Set the valid range with the distance from the home position.

When the starting position is at 100000, [Pr. PC66] and [Pr. PC67] are set to 500000, and [Pr. PC68] and [Pr. PC69] are set to 300000, the valid range is between the actual current position of 300000 and 500000 as set in the parameters.




2) When the roll feed display is enabled ([Pr. PT26]: __ 1 _)

When the roll feed display is enabled, the valid range is calculated as the starting position is 0.

Set the valid range with the travel distance from the starting position.

When the starting position is at 100000, [Pr. PC66] and [Pr. PC67] are set to 500000, and [Pr. PC68] and [Pr. PC69] are set to 300000, the valid range is between the feed current position of 300000 and 500000 from the start position (between the actual current position of 400000 and 600000).



6. APPLICATION OF FUNCTIONS

(b) Degree unit


When the unit is set to "degree", the setting range of the current position latch is from 0 degree (upper limit) to 359.999 degrees (lower limit).

When you set a value other than 0 degree to 359.999 degrees in the current position latch +/- [Pr. PC66] to [Pr. PC69], the set value is converted as follows.

Current position latch range	After conversion
360.000 degrees to 999.999 degrees	(Setting value) % 360
-0.001 degrees to -359.999 degrees	360 + (setting value)
-360.000 degrees to -999.999 degrees	(setting value) % 360 + 360

The valid range of the current position latch varies depending on the setting of the upper and lower limits.

The valid range remains unchanged even if the rotation direction is reversed.



To enable the current position latch function of section A in the figure, set the parameters as follows:


Current position latch range -: 315.000 [degrees] ([Pr. PC68]: 0, [Pr. PC69]: 315)

Current position latch range +: 90.000 [degrees] ([Pr. PC66]: 0, [Pr. PC67]: 90)

To enable the current position latch function of section B in the figure, set the parameter as follows:


Current position latch range -: 90.000 [degrees] ([Pr. PC68]: 0, [Pr. PC69]: 90)

Current position latch range +: 315.000 [degrees] ([Pr. PC66]: 0, [Pr. PC67]: 315)




6. APPLICATION OF FUNCTIONS

(5) Timing chart



- Note 1. When MSD (Mark detection) is assigned to the CN1-10 pin with [Pr. PD44], a current position data can be obtained in high speed (within 0.4 ms). When assigning MSD (Mark detection) to the CN1-10 pin, set "Mark detection fast input signal filter selection" in [Pr. PD31].
- Note 2. The position data will not be changed from the previous value.
- Note 3. MSDH (Latch completed at rising edge of mark detection) turns off at the same time as MSDL (Latch completed at falling edge of mark detection) turns on. Set as MSDL turns on/off within the range of the latch data.

If MSD (Mark detection) was turned on again when the previous falling was out of the valid range, MSDH (Latch completed at rising edge of mark detection) will not change, but the position data will be updated. Refer to the following timing chart.



6. APPLICATION OF FUNCTIONS

6.2.2 Interrupt positioning function

The interrupt positioning function executes an operation by changing the remaining distance to the travel distance that is set with [Pr. PT31] (Mark sensor stop travel distance) when MSD (Mark detection) is turned on. The interrupt positioning function is enabled by setting [Pr. PT26] to "1 _ _ _".

POINT
<ul style="list-style-type: none"> ● The interrupt positioning function is available with servo amplifiers with software version B7 or later. ● The interrupt positioning function can be used with the point table method and the program method. However, the interrupt positioning function is disabled in the following condition. <ul style="list-style-type: none"> ▪ During home position return ▪ During manual operation ▪ During stop ▪ During deceleration or stop with TSTP (Temporary stop/restart) ● An error may occur depending on the droop pulses at the time of MSD (Mark detection) is turned on and a minimum stopping distance required for deceleration.

(1) Parameters

Set the parameters as follows:

Item	Parameter to be used	Setting
Control mode selection	[Pr. PA01]	Select a control mode. _ _ _ 6 (Positioning mode (point table method)) _ _ _ 7 (Positioning mode (program method))
Mark detection function selection	[Pr. PT26]	Set the mark detection function selection as follows: 1 _ _ _ : Interrupt positioning function Starts the interrupt positioning function at rising of MSD (Mark detection).
PI1 (Program input 1) Polarity selection to PI3 (Program input 3) Polarity selection	[Pr. PT29]	The polarity of MSD (Mark detection) can be changed with [Pr. PT29]. ▪ Starts the interrupt positioning function at rising of MSD (Mark detection) if "_ _ x_" bit 3 of [Pr. PT29] is off. ▪ Starts the interrupt positioning function at falling of MSD (Mark detection) if "_ _ x_" bit 3 of [Pr. PT29] is on.
Mark sensor stop travel distance (lower three digits)	[Pr. PT30]	Set the lower three digits of the travel distance after the mark detection. The travel distance starts from the current position regardless of the setting of absolute value command method or incremental value command method.
Mark sensor stop travel distance (upper three digits)	[Pr. PT31]	Set the upper three digits of the travel distance after the mark detection. The travel distance starts from the current position regardless of the setting of absolute value command method or incremental value command method.
Mark detection range + (lower three digits)	[Pr. PC66]	Set the upper and lower limits of the interrupt positioning function. If a sign for the upper and lower differ, [AL. 37] occurs. When the roll feed display is enabled, set a valid range with the travel distance from the starting position.
Mark detection range + (upper three digits)	[Pr. PC67]	
Mark detection range - (lower three digits)	[Pr. PC68]	
Mark detection range - (upper three digits)	[Pr. PC69]	

6. APPLICATION OF FUNCTIONS


(2) Rotation direction

[Pr. PA14] setting	Servo motor rotation direction ST1 (Forward rotation start) on
--- 0	CCW rotation with + position data CW rotation with - position data
--- 1	CW rotation with + position data CCW rotation with - position data

(3) Operation

Travels for the interrupt positioning travel distance ([Pr. PT30] and [Pr. PT31]) starting from the position where MSD (Mark detection) is turned on. The operation after a stop complies with the operation mode and the operation pattern.


(4) Timing chart



Note. Deceleration time constant of the point table at the time of start is applied for the point table method, and deceleration time constant set by the program in execution is applied for the program method.


The movement other than above is as follows:

- (a) The interrupt positioning travel distance is smaller than the travel distance required for the deceleration, the actual deceleration time constant will be shorter than the set time constant.




6. APPLICATION OF FUNCTIONS

- (b) If the interrupt travel distance is large during acceleration, the servo motor stops with the deceleration time constant after rotating with the command speed at which MSD (Mark detection) turned on.




Note. Deceleration time constant of the point table at the time of start is applied for the point table method, and deceleration time constant set by the program in execution is applied for the program method.

- (c) If the interrupt travel distance is large during deceleration, the servo motor stops with the deceleration time constant after rotating with the command speed at which MSD (Mark detection) turned on.



Note. Deceleration time constant of the point table at the time of start is applied for the point table method, and deceleration time constant set by the program in execution is applied for the program method.

- (d) Input will be disabled if MSD (Mark detection) is turned on again during the interrupt positioning.



Note. Deceleration time constant of the point table at the time of start is applied for the point table method, and deceleration time constant set by the program in execution is applied for the program method.

6. APPLICATION OF FUNCTIONS

(5) Using together with other functions

Availability of other functions during the interrupt positioning is as follows:

Function	Available (Note 1)
S-pattern acceleration/deceleration	○
Stroke limit	○
Software limit	○
Temporary stop/restart	×
Speed change value	×
Analog override	△(Note 2)
Backlash	×
Rough match	○
Electronic gear	○
Roll feed display function	×
Mark detection function (current position latch function)	×

Note 1. ○: enabled, ×: disabled, △: enabled with condition
2. Enabled only in a constant speed

ITP (Interrupt positioning) is available with the program function.

Because the interrupt positioning function with MSD (Mark detection) input signal is prioritized, the interrupt positioning function with MSD (Mark detection) can be used during the interrupt positioning function with ITP (Interrupt positioning). However, ITP (Interrupt positioning) cannot be used during the interrupt positioning with MSD (Mark detection).

7. PARAMETERS

7. PARAMETERS



CAUTION

- Never make a drastic adjustment or change to the parameter values as doing so will make the operation unstable.
- If fixed values are written in the digits of a parameter, do not change these values.
- Do not change parameters for manufacturer setting.
- Do not set any values other than the described setting values to each parameter.

7.1 Parameter list

POINT

- To enable a parameter whose symbol is preceded by *, turn off the power for 1 s or more after setting and turn it on again. However, the time will be longer depending on a setting value of [Pr. PF25 Instantaneous power failure tough drive - Detection time] when "instantaneous power failure tough drive selection" is enabled in [Pr. PA20].
- The symbols in the control mode column mean as follows:
 - CP: Positioning mode (point table method)
 - CL: Positioning mode (program method)
- Setting a value out of the setting range in each parameter will trigger [AL. 37 Parameter error].

7. PARAMETERS

7.1.1 Basic setting parameters ([Pr. PA_ _])

POINT
<ul style="list-style-type: none"> ● To enable the following parameters in the positioning mode, turn off the power for 1 s or more after setting and turn it on again. However, the time will be longer depending on a setting value of [Pr. PF25 Instantaneous power failure tough drive - Detection time] when "instantaneous power failure tough drive selection" is enabled in [Pr. PA20]. <ul style="list-style-type: none"> ▪ [Pr. PA06 Electronic gear numerator (command pulse multiplication numerator)/Number of gear teeth on machine side] ▪ [Pr. PA07 Electronic gear denominator (command pulse multiplication denominator)/Number of gear teeth on servo motor side] ● The following parameter cannot be used in the positioning mode. <ul style="list-style-type: none"> ▪ [Pr. PA05 Number of command input pulses per revolution]

No.	Symbol	Name	Initial value	Unit	Control mode	
					C P	C L
PA01	*STY	Operation mode	1000h		○	○
PA02	*REG	Regenerative option	0000h		○	○
PA03		For manufacturer setting	0000h		○	○
PA04	*AOP1	Function selection A-1	2000h		○	○
PA05	*FBP	Number of command input pulses per revolution	10000		○	○
PA06	*CMX	Electronic gear numerator (command pulse multiplication numerator)	1		○	○
PA07	*CDV	Electronic gear denominator (command pulse multiplication denominator)	1		○	○
PA08	ATU	Auto tuning mode	0001h		○	○
PA09	RSP	Auto tuning response	16		○	○
PA10	INP	In-position range	100	[μm]/ 10 ⁻⁴ [inch]/ 10 ⁻³ [degree]/ [pulse]	○	○
PA11	TLP	Forward rotation torque limit	100.0	[%]	○	○
PA12	TLN	Reverse rotation torque limit	100.0	[%]	○	○
PA13	*PLSS	Command pulse input form	0100h		○	○
PA14	*POL	Rotation direction selection	0		○	○
PA15	*ENR	Encoder output pulses	4000	[pulse/rev]	○	○
PA16	*ENR2	Encoder output pulses 2	1		○	○
PA17		For manufacturer setting	0000h		○	○
PA18			0000h		○	○
PA19	*BLK	Parameter writing inhibit	00AAh		○	○
PA20	*TDS	Tough drive setting	0000h		○	○
PA21	*AOP3	Function selection A-3	0001h		○	○
PA22		For manufacturer setting	0000h		○	○
PA23	DRAT	Drive recorder arbitrary alarm trigger setting	0000h		○	○
PA24	AOP4	Function selection A-4	0000h		○	○
PA25	OTHOV	One-touch tuning - Overshoot permissible level	0	[%]	○	○
PA26	*AOP5	Function selection A-5	0000h		○	○
PA27		For manufacturer setting	0000h		○	○
PA28			0000h		○	○
PA29			0000h		○	○
PA30			0000h		○	○
PA31			0000h		○	○
PA32			0000h		○	○

7. PARAMETERS

7.1.2 Gain/filter setting parameters ([Pr. PB_ _])

No.	Symbol	Name	Initial value	Unit	Control mode	
					C P	C L
PB01	FILT	Adaptive tuning mode (adaptive filter II)	0000h		○	○
PB02	VRFT	Vibration suppression control tuning mode (advanced vibration suppression control II)	0000h		○	○
PB03	PST	Position command acceleration/deceleration time constant (position smoothing)	0	[ms]	○	○
PB04	FFC	Feed forward gain	0	[%]	○	○
PB05		For manufacturer setting	500			
PB06	GD2	Load to motor inertia ratio	7.00	[Multiplier]	○	○
PB07	PG1	Model loop gain	15.0	[rad/s]	○	○
PB08	PG2	Position loop gain	37.0	[rad/s]	○	○
PB09	VG2	Speed loop gain	823	[rad/s]	○	○
PB10	VIC	Speed integral compensation	33.7	[ms]	○	○
PB11	VDC	Speed differential compensation	980		○	○
PB12	OVA	Overshoot amount compensation	0	[%]	○	○
PB13	NH1	Machine resonance suppression filter 1	4500	[Hz]	○	○
PB14	NHQ1	Notch shape selection 1	0000h		○	○
PB15	NH2	Machine resonance suppression filter 2	4500	[Hz]	○	○
PB16	NHQ2	Notch shape selection 2	0000h		○	○
PB17	NHF	Shaft resonance suppression filter	0000h		○	○
PB18	LPF	Low-pass filter setting	3141	[rad/s]	○	○
PB19	VRF11	Vibration suppression control 1 - Vibration frequency	100.0	[Hz]	○	○
PB20	VRF12	Vibration suppression control 1 - Resonance frequency	100.0	[Hz]	○	○
PB21	VRF13	Vibration suppression control 1 - Vibration frequency damping	0.00		○	○
PB22	VRF14	Vibration suppression control 1 - Resonance frequency damping	0.00		○	○
PB23	VFBF	Low-pass filter selection	0100h		○	○
PB24	*MVS	Slight vibration suppression control	0000h		○	○
PB25	*BOP1	Function selection B-1	0000h		○	○
PB26	*CDP	Gain switching function	0000h		○	○
PB27	CDL	Gain switching condition	10	[kpulse/s]/ [pulse]/ [r/min]	○	○
PB28	CDT	Gain switching time constant	1	[ms]	○	○
PB29	GD2B	Load to motor inertia ratio after gain switching	7.00	[Multiplier]	○	○
PB30	PG2B	Position loop gain after gain switching	0.0	[rad/s]	○	○
PB31	VG2B	Speed loop gain after gain switching	0	[rad/s]	○	○
PB32	VICB	Speed integral compensation after gain switching	0.0	[ms]	○	○
PB33	VRF1B	Vibration suppression control 1 - Vibration frequency after gain switching	0.0	[Hz]	○	○
PB34	VRF2B	Vibration suppression control 1 - Resonance frequency after gain switching	0.0	[Hz]	○	○
PB35	VRF3B	Vibration suppression control 1 - Vibration frequency damping after gain switching	0.00		○	○
PB36	VRF4B	Vibration suppression control 1 - Resonance frequency damping after gain switching	0.00		○	○
PB37		For manufacturer setting	1600			
PB38			0.00			
PB39			0.00			
PB40			0.00			
PB41			0000h			
PB42			0000h			
PB43			0000h			
PB44			0.00			
PB45	CNHF	Command notch filter	0000h		○	○
PB46	NH3	Machine resonance suppression filter 3	4500	[Hz]	○	○

7. PARAMETERS

No.	Symbol	Name	Initial value	Unit	Control mode	
					C P	C L
PB47	NHQ3	Notch shape selection 3	0000h		<input type="radio"/>	<input type="radio"/>
PB48	NH4	Machine resonance suppression filter 4	4500	[Hz]	<input type="radio"/>	<input type="radio"/>
PB49	NHQ4	Notch shape selection 4	0000h		<input type="radio"/>	<input type="radio"/>
PB50	NH5	Machine resonance suppression filter 5	4500	[Hz]	<input type="radio"/>	<input type="radio"/>
PB51	NHQ5	Notch shape selection 5	0000h		<input type="radio"/>	<input type="radio"/>
PB52	VRF21	Vibration suppression control 2 - Vibration frequency	100.0	[Hz]	<input type="radio"/>	<input type="radio"/>
PB53	VRF22	Vibration suppression control 2 - Resonance frequency	100.0	[Hz]	<input type="radio"/>	<input type="radio"/>
PB54	VRF23	Vibration suppression control 2 - Vibration frequency damping	0.00		<input type="radio"/>	<input type="radio"/>
PB55	VRF24	Vibration suppression control 2 - Resonance frequency damping	0.00		<input type="radio"/>	<input type="radio"/>
PB56	VRF21B	Vibration suppression control 2 - Vibration frequency after gain switching	0.0	[Hz]	<input type="radio"/>	<input type="radio"/>
PB57	VRF22B	Vibration suppression control 2 - Resonance frequency after gain switching	0.0	[Hz]	<input type="radio"/>	<input type="radio"/>
PB58	VRF23B	Vibration suppression control 2 - Vibration frequency damping after gain switching	0.00		<input type="radio"/>	<input type="radio"/>
PB59	VRF24B	Vibration suppression control 2 - Resonance frequency damping after gain switching	0.00		<input type="radio"/>	<input type="radio"/>
PB60	PG1B	Model loop gain after gain switching	0.0	[rad/s]	<input type="radio"/>	<input type="radio"/>
PB61		For manufacturer setting	0.0		<input type="radio"/>	<input type="radio"/>
PB62			0000h			
PB63			0000h			
PB64			0000h			

7. PARAMETERS

7.1.3 Extension setting parameters ([Pr. PC__])

POINT
<ul style="list-style-type: none"> ● To enable the following parameters in the positioning mode, turn off the power for 1 s or more after setting and turn it on again. However, the time will be longer depending on a setting value of [Pr. PF25 Instantaneous power failure tough drive - Detection time] when "instantaneous power failure tough drive selection" is enabled in [Pr. PA20]. <ul style="list-style-type: none"> ▪ [Pr. PC03 S-pattern acceleration/deceleration time constant] ● The following parameter cannot be used in the positioning mode. <ul style="list-style-type: none"> ▪ [Pr. PC04 Torque command time constant] ▪ [Pr. PC08 Internal speed command 4/internal speed limit 4] ▪ [Pr. PC09 Internal speed command 5/internal speed limit 5] ▪ [Pr. PC10 Internal speed command 6/internal speed limit 6] ▪ [Pr. PC11 Internal speed command 7/internal speed limit 7] ▪ [Pr. PC12 Analog speed command - Maximum speed/Analog speed limit - Maximum speed] ▪ [Pr. PC13 Analog torque/thrust command maximum output] ▪ [Pr. PC23 Function selection C-2] ▪ [Pr. PC32 Command input pulse multiplication numerator 2] ▪ [Pr. PC33 Command input pulse multiplication numerator 3] ▪ [Pr. PC34 Command input pulse multiplication numerator 4] ● The following parameters are used for Modbus-RTU communication. For details, refer to "MR-JE-_A Servo Amplifier Instruction Manual (Modbus-RTU communication)". <ul style="list-style-type: none"> ▪ [Pr. PC70 Modbus-RTU communication station number setting] ▪ [Pr. PC71 Function selection C-F] ▪ [Pr. PC72 Function selection C-G]

No.	Symbol	Name	Initial value	Unit	Control mode	
					C P	C L
PC01	STA	JOG operation acceleration time constant	0	[ms]	<input type="checkbox"/>	<input type="checkbox"/>
PC02	STB	JOG operation deceleration time constant	0	[ms]	<input type="checkbox"/>	<input type="checkbox"/>
PC03	*STC	S-pattern acceleration/deceleration time constant	0	[ms]	<input type="checkbox"/>	<input type="checkbox"/>
PC04	TQC	Torque command time constant	0		<input type="checkbox"/>	<input type="checkbox"/>
PC05		For manufacturer setting	100		<input type="checkbox"/>	<input type="checkbox"/>
PC06			500			
PC07			1000			
PC08	SC4	Internal speed command 4	200	[r/min]	<input type="checkbox"/>	<input type="checkbox"/>
		Internal speed limit 4				
PC09	SC5	Internal speed command 5	300	[r/min]	<input type="checkbox"/>	<input type="checkbox"/>
		Internal speed limit 5				
PC10	SC6	Internal speed command 6	500	[r/min]	<input type="checkbox"/>	<input type="checkbox"/>
		Internal speed limit 6				
PC11	SC7	Internal speed command 7	800	[r/min]	<input type="checkbox"/>	<input type="checkbox"/>
		Internal speed limit 7				
PC12	VCM	Analog speed command - Maximum speed	0	[r/min]	<input type="checkbox"/>	<input type="checkbox"/>
		Analog speed limit - Maximum speed				
PC13	TLC	Analog torque command maximum output	100.0	[%]	<input type="checkbox"/>	<input type="checkbox"/>
PC14	MOD1	Analog monitor 1 output	0000h		<input type="checkbox"/>	<input type="checkbox"/>
PC15	MOD2	Analog monitor 2 output	0001h		<input type="checkbox"/>	<input type="checkbox"/>
PC16	MBR	Electromagnetic brake sequence output	0	[ms]	<input type="checkbox"/>	<input type="checkbox"/>

7. PARAMETERS

No.	Symbol	Name	Initial value	Unit	Control mode	
					C P	C L
PC17	ZSP	Zero speed	50	[r/min]	<input type="radio"/>	<input type="radio"/>
PC18	*BPS	Alarm history clear	0000h		<input type="radio"/>	<input type="radio"/>
PC19	*ENRS	Encoder output pulse selection	0000h		<input type="radio"/>	<input type="radio"/>
PC20	*SNO	Station number setting	0	[station]	<input type="radio"/>	<input type="radio"/>
PC21	*SOP	RS-422 communication function selection	0000h		<input type="radio"/>	<input type="radio"/>
PC22	*COP1	Function selection C-1	0020h		<input type="radio"/>	<input type="radio"/>
PC23	*COP2	Function selection C-2	0000h		<input type="radio"/>	<input type="radio"/>
PC24	*COP3	Function selection C-3	0000h		<input type="radio"/>	<input type="radio"/>
PC25		For manufacturer setting	0000h		<input type="radio"/>	<input type="radio"/>
PC26	*COP5	Function selection C-5	0000h		<input type="radio"/>	<input type="radio"/>
PC27	*COP6	Function selection C-6	0000h		<input type="radio"/>	<input type="radio"/>
PC28	*COP7	Function selection C-7	0000h		<input type="radio"/>	<input type="radio"/>
PC29		For manufacturer setting	0000h		<input type="radio"/>	<input type="radio"/>
PC30	STA2	Home position return acceleration time constant	0	[ms]	<input type="radio"/>	<input type="radio"/>
PC31	STB2	Home position return deceleration time constant	0	[ms]	<input type="radio"/>	<input type="radio"/>
PC32	CMX2	Command input pulse multiplication numerator 2	1		<input type="radio"/>	<input type="radio"/>
PC33	CMX3	Command input pulse multiplication numerator 3	1		<input type="radio"/>	<input type="radio"/>
PC34	CMX4	Command input pulse multiplication numerator 4	1		<input type="radio"/>	<input type="radio"/>
PC35	TL2	Internal torque limit 2	100.0	[%]	<input type="radio"/>	<input type="radio"/>
PC36	*DMD	Status display selection	0000h		<input type="radio"/>	<input type="radio"/>
PC37	VCO	Analog override offset	0	[mV]	<input type="radio"/>	<input type="radio"/>
PC38	TPO	Analog torque limit offset	0	[mV]	<input type="radio"/>	<input type="radio"/>
PC39	MO1	Analog monitor 1 offset	0	[mV]	<input type="radio"/>	<input type="radio"/>
PC40	MO2	Analog monitor 2 offset	0	[mV]	<input type="radio"/>	<input type="radio"/>
PC41		For manufacturer setting	0		<input type="radio"/>	<input type="radio"/>
PC42			0		<input type="radio"/>	<input type="radio"/>
PC43	ERZ	Error excessive alarm detection level	0	[rev]	<input type="radio"/>	<input type="radio"/>
PC44		For manufacturer setting	0000h		<input type="radio"/>	<input type="radio"/>
PC45			0000h		<input type="radio"/>	<input type="radio"/>
PC46			0		<input type="radio"/>	<input type="radio"/>
PC47			0		<input type="radio"/>	<input type="radio"/>
PC48			0		<input type="radio"/>	<input type="radio"/>
PC49			0		<input type="radio"/>	<input type="radio"/>
PC50			0000h		<input type="radio"/>	<input type="radio"/>
PC51	RSBR	Forced stop deceleration time constant	100	[ms]	<input type="radio"/>	<input type="radio"/>
PC52		For manufacturer setting	0		<input type="radio"/>	<input type="radio"/>
PC53			0		<input type="radio"/>	<input type="radio"/>
PC54	RSUP1	Vertical axis freefall prevention compensation amount	0	[0.0001rev]	<input type="radio"/>	<input type="radio"/>
PC55		For manufacturer setting	0		<input type="radio"/>	<input type="radio"/>
PC56			100		<input type="radio"/>	<input type="radio"/>
PC57			0000h		<input type="radio"/>	<input type="radio"/>
PC58			0		<input type="radio"/>	<input type="radio"/>
PC59			0000h		<input type="radio"/>	<input type="radio"/>
PC60	*COPD	Function selection C-D	0000h		<input type="radio"/>	<input type="radio"/>
PC61		For manufacturer setting	0000h		<input type="radio"/>	<input type="radio"/>
PC62			0000h		<input type="radio"/>	<input type="radio"/>
PC63			0000h		<input type="radio"/>	<input type="radio"/>
PC64			0000h		<input type="radio"/>	<input type="radio"/>
PC65			0000h		<input type="radio"/>	<input type="radio"/>

7. PARAMETERS

No.	Symbol	Name	Initial value	Unit	Control mode	
					C P	C L
PC66	LPSPL	Mark detection range + (lower three digits)	0	10 ^{STM} [μm]/ 10 ^(STM-4) [inch]/ 10 ⁻³ [degree]/ [pulse]	○	○
PC67	LPSPH	Mark detection range + (upper three digits)	0	10 ^{STM} [μm]/ 10 ^(STM-4) [inch]/ 10 ⁻³ [degree]/ [pulse]	○	○
PC68	LPSNL	Mark detection range - (lower three digits)	0	10 ^{STM} [μm]/ 10 ^(STM-4) [inch]/ 10 ⁻³ [degree]/ [pulse]	○	○
PC69	LPSNH	Mark detection range - (upper three digits)	0	10 ^{STM} [μm]/ 10 ^(STM-4) [inch]/ 10 ⁻³ [degree]/ [pulse]	○	○
PC70	*SNOM	Modbus-RTU communication station number setting	0		○	○
PC71	*COPF	Function selection C-F	0040h		○	○
PC72	*COPG	Function selection C-G	0000h		○	○
PC73	ERW	Error excessive warning level	0	[rev]	○	○
PC74		For manufacturer setting	0000h			
PC75			0000h			
PC76			0000h			
PC77			0000h			
PC78			0000h			
PC79			0000h			
PC80			0000h			

7.1.4 I/O setting parameters ([Pr. PD_ _])

POINT
<p>● The following parameter cannot be used in the positioning mode.</p> <ul style="list-style-type: none"> ▪ [Pr. PD03 Input device selection 1L] ▪ [Pr. PD11 Input device selection 5L] ▪ [Pr. PD13 Input device selection 6L] ▪ [Pr. PD17 Input device selection 8L] ▪ [Pr. PD19 Input device selection 9L] ▪ [Pr. PD43 Input device selection 11L] ▪ [Pr. PD45 Input device selection 12L]

7. PARAMETERS

No.	Symbol	Name	Initial value	Unit	Control mode	
					C P	C L
PD01	*DIA1	Input signal automatic on selection 1	0000h		○	○
PD02		For manufacturer setting	0000h			
PD03	*DI1L	Input device selection 1L	0202h			
PD04	*DI1H	Input device selection 1H	0202h		○	○
PD05		For manufacturer setting	0000h			
PD06			0000h			
PD07			0000h			
PD08			0000h			
PD09			0000h			
PD10			0000h			
PD11	*DI5L	Input device selection 5L	0703h			
PD12	*DI5H	Input device selection 5H	3807h		○	○
PD13	*DI6L	Input device selection 6L	0806h			
PD14	*DI6H	Input device selection 6H	3908h		○	○
PD15		For manufacturer setting	0000h			
PD16			0000h			
PD17	*DI8L	Input device selection 8L	0A0Ah			
PD18	*DI8H	Input device selection 8H	0700h		○	○
PD19	*DI9L	Input device selection 9L	0B0Bh			
PD20	*DI9H	Input device selection 9H	0800h		○	○
PD21		For manufacturer setting	0000h			
PD22			0000h			
PD23			0000h			
PD24	*DO2	Output device selection 2	000Ch		○	○
PD25	*DO3	Output device selection 3	0004h		○	○
PD26	*DO4	Output device selection 4	0000h		○	○
PD27		For manufacturer setting	0003h			
PD28	*DO6	Output device selection 6	0002h		○	○
PD29	*DIF	Input filter setting	0004h		○	○
PD30	*DOP1	Function selection D-1	0000h		○	○
PD31	*DOP2	Function selection D-2	0000h		○	○
PD32	*DOP3	Function selection D-3	0000h		○	○
PD33	*DOP4	Function selection D-4	0000h		○	○
PD34	DOP5	Function selection D-5	0000h		○	○
PD35		For manufacturer setting	0000h			
PD36			0000h			
PD37			0000h			
PD38			0			
PD39			0			
PD40			0			
PD41	*DIA3	Input signal automatic on selection 3	0000h		○	○
PD42	*DIA4	Input signal automatic on selection 4	0000h		○	○
PD43	*DI11L	Input device selection 11L	0000h			
PD44	*DI11H	Input device selection 11H	2000h		○	○
PD45	*DI12L	Input device selection 12L	0000h			
PD46	*DI12H	Input device selection 12H	2B00h		○	○
PD47	*DO7	Output device selection 7	0000h		○	○
PD48		For manufacturer setting	0000h			

7. PARAMETERS

7.1.5 Extension setting 2 parameters ([Pr. PE_ _])

No.	Symbol	Name	Initial value	Unit	Control mode	
					C P	C L
PE01		For manufacturer setting	0000h			
PE02			0000h			
PE03			0000h			
PE04			0			
PE05			0			
PE06			0			
PE07			0			
PE08			0			
PE09			0000h			
PE10			0000h			
PE11			0000h			
PE12			0000h			
PE13			0000h			
PE14			0111h			
PE15			20			
PE16			0000h			
PE17			0000h			
PE18			0000h			
PE19			0000h			
PE20			0000h			
PE21			0000h			
PE22			0000h			
PE23			0000h			
PE24			0000h			
PE25			0000h			
PE26			0000h			
PE27			0000h			
PE28			0000h			
PE29			0000h			
PE30			0000h			
PE31			0000h			
PE32			0000h			
PE33			0000h			
PE34			0			
PE35			0			
PE36			0.0			
PE37			0.00			
PE38			0.00			
PE39			0			
PE40			0000h			
PE41	EOP3	Function selection E-3	0000h			○ ○

7. PARAMETERS

No.	Symbol	Name	Initial value	Unit	Control mode	
					C P	C L
PE42		For manufacturer setting	0			
PE43			0.0			
PE44			0000h			
PE45			0000h			
PE46			0000h			
PE47			0000h			
PE48			0000h			
PE49			0000h			
PE50			0000h			
PE51			0000h			
PE52			0000h			
PE53			0000h			
PE54			0000h			
PE55			0000h			
PE56			0000h			
PE57			0000h			
PE58			0000h			
PE59			0000h			
PE60			0000h			
PE61			0.00			
PE62			0.00			
PE63			0.00			
PE64			0.00			

7.1.6 Extension setting 3 parameters ([Pr. PF_ _])

POINT
<ul style="list-style-type: none"> ● The following parameters are used for Modbus-RTU communication. For details, refer to "MR-JE-_A Servo Amplifier Instruction Manual (Modbus-RTU communication)". <ul style="list-style-type: none"> ▪ [Pr. PF45 Function selection F-12] ▪ [Pr. PF46 Modbus-RTU communication time out selection]

No.	Symbol	Name	Initial value	Unit	Control mode	
					C P	C L
PF01		For manufacturer setting	0000h			
PF02			0000h			
PF03			0000h			
PF04			0			
PF05			0			
PF06			0000h			
PF07			1			
PF08			1			
PF09	*FOP5	Function selection F-5	0000h			○ ○
PF10		For manufacturer setting	0000h			
PF11			0000h			
PF12			10000			
PF13			100			
PF14			100			
PF15	DBT	Electronic dynamic brake operating time	2000	[ms]		○ ○

7. PARAMETERS

No.	Symbol	Name	Initial value	Unit	Control mode	
					C P	C L
PF16		For manufacturer setting	0000h			
PF17			10			
PF18			0000h			
PF19			0000h			
PF20			0000h			
PF21	DRT	Drive recorder switching time setting	0	[s]	<input type="radio"/>	<input type="radio"/>
PF22		For manufacturer setting	200			
PF23						
PF24	*OSCL2	Vibration tough drive function selection	0000h		<input type="radio"/>	<input type="radio"/>
PF25	CVAT	Instantaneous power failure tough drive - Detection time	200	[ms]	<input type="radio"/>	<input type="radio"/>
PF26		For manufacturer setting	0			
PF27			0			
PF28			0			
PF29			0000h			
PF30			0			
PF31	FRIC	Machine diagnosis function - Friction judgement speed	0	[r/min]	<input type="radio"/>	<input type="radio"/>
PF32		For manufacturer setting	50			
PF33			0000h			
PF34			0000h			
PF35			0000h			
PF36			0000h			
PF37			0000h			
PF38			0000h			
PF39			0000h			
PF40			0			
PF41			0			
PF42			0			
PF43			0			
PF44			0			
PF45	*FOP12	Function selection F-12	0000h		<input type="radio"/>	<input type="radio"/>
PF46	MIC	Modbus-RTU communication time out selection	0		<input type="radio"/>	<input type="radio"/>
PF47		For manufacturer setting	0000h			
PF48			0000h			

7. PARAMETERS

7.1.7 Positioning control parameters ([Pr. PT_ _])

POINT
<p>● The following parameters are used for Modbus-RTU communication. For details, refer to "MR-JE-_A Servo Amplifier Instruction Manual (Modbus-RTU communication)".</p> <p>▪ [Pr. PT45 Home position return type 2]</p>

No.	Symbol	Name	Initial value	Unit	Control mode	
					C	C
					P	L
PT01	*CTY	Command mode selection	0000h		○	○
PT02	*TOP1	Function selection T-1	0000h		○	○
PT03	*FTY	Feeding function selection	0000h		○	○
PT04	*ZTY	Home position return type	0010h		○	○
PT05	ZRF	Home position return speed	100	[r/min]	○	○
PT06	CRF	Creep speed	10	[r/min]	○	○
PT07	ZST	Home position shift distance	0	[μm]/ 10 ⁻⁴ [inch]/ 10 ⁻³ [degree]/ [pulse]	○	○
PT08	*ZPS	Home position return position data	0	10 ^{STM} [μm]/ 10 ^(STM-4) [inch]/ 10 ⁻³ [degree]/ [pulse]	○	○
PT09	DCT	Travel distance after proximity dog	1000	10 ^{STM} [μm]/ 10 ^(STM-4) [inch]/ 10 ⁻³ [degree]/ [pulse]	○	○
PT10	ZTM	Stopper type home position return stopper time	100	[ms]	○	○
PT11	ZTT	Stopper type home position return torque limit value	15.0	[%]	○	○
PT12	CRP	Rough match output range	0	10 ^{STM} [μm]/ 10 ^(STM-4) [inch]/ 10 ⁻³ [degree]/ [pulse]	○	○
PT13	JOG	JOG operation	100	[r/min]	○	○
PT14	*BKC	Backlash compensation	0	[pulse]	○	○
PT15	LMPL	Software limit +	0	10 ^{STM} [μm]/ 10 ^(STM-4) [inch]/ 10 ⁻³ [degree]/ [pulse]	○	○
PT16	LMPH					
PT17	LMNL	Software limit -	0	10 ^{STM} [μm]/ 10 ^(STM-4) [inch]/ 10 ⁻³ [degree]/ [pulse]	○	○
PT18	LMNH					
PT19	*LPPL	Position range output address +	0	10 ^{STM} [μm]/ 10 ^(STM-4) [inch]/ 10 ⁻³ [degree]/ [pulse]	○	○
PT20	*LPPH					
PT21	*LNPL	Position range output address -	0	10 ^{STM} [μm]/ 10 ^(STM-4) [inch]/ 10 ⁻³ [degree]/ [pulse]	○	○
PT22	*LNPH					
PT23	OUT1	OUT1 output setting time	0	[ms]	○	○
PT24	OUT2	OUT2 output setting time	0	[ms]	○	○
PT25	OUT3	OUT3 output setting time	0	[ms]	○	○
PT26	*TOP2	Function selection T-2	0000h		○	○

7. PARAMETERS

No.	Symbol	Name	Initial value	Unit	Control mode	
					C P	C L
PT27		For manufacturer setting	0000h			
PT28			0000h			
PT29	*TOP3	Function selection T-3	0000h			○ ○
PT30	MSTL	Mark sensor stop travel distance	0	10^{STM} [μm]/ $10^{-(\text{STM}-4)}$		○ ○
PT31	MSTH		0	[inch]/ 10^{-3} [degree]/ [pulse]		○ ○
PT32		For manufacturer setting	0000h			
PT33			0000h			
PT34	*PDEF	Point table/program default	0000h			○ ○
PT35	*TOP5	Function selection T-5	0000h			○ ○
PT36		For manufacturer setting	0000h			
PT37			0000h			
PT38			0000h			
PT39			0000h			
PT40			0000h			
PT41	ORP	Home position return inhibit function selection	0000h			○ ○
PT42		For manufacturer setting	0000h			
PT43			0000h			
PT44			0000h			
PT45	*CZTY	Home position return type 2	0000h			
PT46		For manufacturer setting	0000h			
PT47			0000h			
PT48			0000h			

7. PARAMETERS

7.2 Detailed list of parameters

POINT
● Set a value to each "x" in the "Setting digit" columns.

7.2.1 Basic setting parameters ([Pr. PA_ _])

No./symbol /name	Setting digit	Function	Initial value [unit]	Control mode	
				C P	C L
PA01 *STY Operation mode	___ x	Control mode selection Select a control mode. 0 to 5: Not used for positioning mode. 6: Positioning mode (point table method) 7: Positioning mode (program method)	0h	○	○
	_ _ x _	For manufacturer setting	0h	/	/
	_ x _ _		0h	/	/
	x _ _ _		1h	/	/
PA02 *REG Regenerative option	_ _ x x	Regenerative option Select a regenerative option. Incorrect setting may cause the regenerative option to burn. If a selected regenerative option is not for use with the servo amplifier, [AL. 37 Parameter error] occurs. 00: Regenerative option is not used. ▪ For a servo amplifier of 200 W or less, no regenerative resistor is used. ▪ For servo amplifier of 0.4 kW to 3 kW, built-in regenerative resistor is used. 02: MR-RB032 03: MR-RB12 04: MR-RB32 05: MR-RB30 06: MR-RB50 (Cooling fan is required.)	00h	○	○
	_ x _ _	For manufacturer setting	0h	/	/
	x _ _ _		0h	/	/

7. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode															
				C P	C L														
PA04 *AOP1 Function selection A-1	___x	For manufacturer setting	0h																
	__x_		0h																
	_x__		0h																
	x___	Forced stop deceleration function selection 0: Forced stop deceleration function disabled (EM1) 2: Forced stop deceleration function enabled (EM2) Refer to table 7.1 for details.	2h	○	○														
<p>Table 7.1 Deceleration method</p> <table border="1"> <thead> <tr> <th rowspan="2">Setting value</th> <th rowspan="2">EM2/EM1</th> <th colspan="2">Deceleration method</th> </tr> <tr> <th>EM2 or EM1 is off</th> <th>Alarm occurred</th> </tr> </thead> <tbody> <tr> <td>0___</td> <td>EM1</td> <td>MBR (Electromagnetic brake interlock) turns off without the forced stop deceleration.</td> <td>MBR (Electromagnetic brake interlock) turns off without the forced stop deceleration.</td> </tr> <tr> <td>2___</td> <td>EM2</td> <td>MBR (Electromagnetic brake interlock) turns off after the forced stop deceleration.</td> <td>MBR (Electromagnetic brake interlock) turns off after the forced stop deceleration.</td> </tr> </tbody> </table>						Setting value	EM2/EM1	Deceleration method		EM2 or EM1 is off	Alarm occurred	0___	EM1	MBR (Electromagnetic brake interlock) turns off without the forced stop deceleration.	MBR (Electromagnetic brake interlock) turns off without the forced stop deceleration.	2___	EM2	MBR (Electromagnetic brake interlock) turns off after the forced stop deceleration.	MBR (Electromagnetic brake interlock) turns off after the forced stop deceleration.
Setting value	EM2/EM1	Deceleration method																	
		EM2 or EM1 is off	Alarm occurred																
0___	EM1	MBR (Electromagnetic brake interlock) turns off without the forced stop deceleration.	MBR (Electromagnetic brake interlock) turns off without the forced stop deceleration.																
2___	EM2	MBR (Electromagnetic brake interlock) turns off after the forced stop deceleration.	MBR (Electromagnetic brake interlock) turns off after the forced stop deceleration.																
PA06 *CMX Electronic gear numerator (command pulse multiplication numerator)	<p>Set an electronic gear numerator. (Refer to section 7.3.1.)</p> <p>To enable the parameter value in the positioning mode, turn off the power for 1 s or more after setting and turn it on again. However, the time will be longer depending on a setting value of [Pr. PF25 Instantaneous power failure tough drive - Detection time] when "instantaneous power failure tough drive selection" is enabled in [Pr. PA20].</p> <p>To enable the parameter, select "Electronic gear (0 ___)" of "Electronic gear selection" in [Pr. PA21].</p> <p>Set the electronic gear within the following range. Setting out of the range will trigger [AL. 37 Parameter error].</p> <table border="1"> <thead> <tr> <th>Pr. PA21</th> <th>Electronic gear setting range</th> </tr> </thead> <tbody> <tr> <td>0___</td> <td>1/865 < CMX/CDV < 271471</td> </tr> <tr> <td>2___</td> <td>1/13825 < CMX/CDV < 16967</td> </tr> <tr> <td>3___</td> <td>1/27649 < CMX/CDV < 8484</td> </tr> </tbody> </table> <p>Setting range: 1 to 16777215</p>		Pr. PA21	Electronic gear setting range	0___	1/865 < CMX/CDV < 271471	2___	1/13825 < CMX/CDV < 16967	3___	1/27649 < CMX/CDV < 8484	1	○	○						
	Pr. PA21	Electronic gear setting range																	
0___	1/865 < CMX/CDV < 271471																		
2___	1/13825 < CMX/CDV < 16967																		
3___	1/27649 < CMX/CDV < 8484																		
PA07 *CDV Electronic gear denominator (command pulse multiplication denominator)	<p>Set an electronic gear denominator. (Refer to section 7.3.1.)</p> <p>To enable the parameter value in the positioning mode, turn off the power for 1 s or more after setting and turn it on again. However, the time will be longer depending on a setting value of [Pr. PF25 Instantaneous power failure tough drive - Detection time] when "instantaneous power failure tough drive selection" is enabled in [Pr. PA20].</p> <p>To enable the parameter, select "Electronic gear (0 ___)" of "Electronic gear selection" in [Pr. PA21].</p> <p>Set the electronic gear within the range of [Pr. PA06].</p> <p>Setting out of the range will trigger [AL. 37 Parameter error].</p> <p>Setting range: 1 to 16777215</p>		1	○	○														

7. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode																			
				CP	C L																		
PA08 ATU Auto tuning mode	___x	Gain adjustment mode selection Select the gain adjustment mode. 0: 2 gain adjustment mode 1 (interpolation mode) 1: Auto tuning mode 1 2: Auto tuning mode 2 3: Manual mode 4: 2 gain adjustment mode 2 Refer to table 7.2 for details.	1h	○	○																		
	__x_	For manufacturer setting	0h	▤	▤																		
	_x__		0h	▤	▤																		
	x___		0h	▤	▤																		
Table 7.2 Gain adjustment mode selection																							
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 10%;">Setting value</th> <th style="width: 30%;">Gain adjustment mode</th> <th style="width: 60%;">Automatically adjusted parameter</th> </tr> </thead> <tbody> <tr> <td>___0</td> <td>2 gain adjustment mode 1 (interpolation mode)</td> <td>[Pr. PB06 Load to motor inertia ratio] [Pr. PB08 Position loop gain] [Pr. PB09 Speed loop gain] [Pr. PB10 Speed integral compensation]</td> </tr> <tr> <td>___1</td> <td>Auto tuning mode 1</td> <td>[Pr. PB06 Load to motor inertia ratio] [Pr. PB07 Model loop gain] [Pr. PB08 Position loop gain] [Pr. PB09 Speed loop gain] [Pr. PB10 Speed integral compensation]</td> </tr> <tr> <td>___2</td> <td>Auto tuning mode 2</td> <td>[Pr. PB07 Model loop gain] [Pr. PB08 Position loop gain] [Pr. PB09 Speed loop gain] [Pr. PB10 Speed integral compensation]</td> </tr> <tr> <td>___3</td> <td>Manual mode</td> <td></td> </tr> <tr> <td>___4</td> <td>2 gain adjustment mode 2</td> <td>[Pr. PB08 Position loop gain] [Pr. PB09 Speed loop gain] [Pr. PB10 Speed integral compensation]</td> </tr> </tbody> </table>						Setting value	Gain adjustment mode	Automatically adjusted parameter	___0	2 gain adjustment mode 1 (interpolation mode)	[Pr. PB06 Load to motor inertia ratio] [Pr. PB08 Position loop gain] [Pr. PB09 Speed loop gain] [Pr. PB10 Speed integral compensation]	___1	Auto tuning mode 1	[Pr. PB06 Load to motor inertia ratio] [Pr. PB07 Model loop gain] [Pr. PB08 Position loop gain] [Pr. PB09 Speed loop gain] [Pr. PB10 Speed integral compensation]	___2	Auto tuning mode 2	[Pr. PB07 Model loop gain] [Pr. PB08 Position loop gain] [Pr. PB09 Speed loop gain] [Pr. PB10 Speed integral compensation]	___3	Manual mode		___4	2 gain adjustment mode 2	[Pr. PB08 Position loop gain] [Pr. PB09 Speed loop gain] [Pr. PB10 Speed integral compensation]
Setting value	Gain adjustment mode	Automatically adjusted parameter																					
___0	2 gain adjustment mode 1 (interpolation mode)	[Pr. PB06 Load to motor inertia ratio] [Pr. PB08 Position loop gain] [Pr. PB09 Speed loop gain] [Pr. PB10 Speed integral compensation]																					
___1	Auto tuning mode 1	[Pr. PB06 Load to motor inertia ratio] [Pr. PB07 Model loop gain] [Pr. PB08 Position loop gain] [Pr. PB09 Speed loop gain] [Pr. PB10 Speed integral compensation]																					
___2	Auto tuning mode 2	[Pr. PB07 Model loop gain] [Pr. PB08 Position loop gain] [Pr. PB09 Speed loop gain] [Pr. PB10 Speed integral compensation]																					
___3	Manual mode																						
___4	2 gain adjustment mode 2	[Pr. PB08 Position loop gain] [Pr. PB09 Speed loop gain] [Pr. PB10 Speed integral compensation]																					

7. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode																																																																																												
				C P	C L																																																																																											
PA09 RSP Auto tuning response		Set the auto tuning response.	16	<input type="radio"/>	<input type="radio"/>																																																																																											
		<table border="1"> <thead> <tr> <th rowspan="2">Setting value</th> <th colspan="2">Machine characteristic</th> <th rowspan="2">Setting value</th> <th colspan="2">Machine characteristic</th> </tr> <tr> <th>Response</th> <th>Guideline for machine resonance frequency [Hz]</th> <th>Response</th> <th>Guideline for machine resonance frequency [Hz]</th> </tr> </thead> <tbody> <tr> <td>1</td> <td rowspan="19">Low response ↑ ↓ Middle response</td> <td>2.7</td> <td>21</td> <td rowspan="20">Middle response ↑ ↓ High response</td> <td>67.1</td> </tr> <tr> <td>2</td> <td>3.6</td> <td>22</td> <td>75.6</td> </tr> <tr> <td>3</td> <td>4.9</td> <td>23</td> <td>85.2</td> </tr> <tr> <td>4</td> <td>6.6</td> <td>24</td> <td>95.9</td> </tr> <tr> <td>5</td> <td>10.0</td> <td>25</td> <td>108.0</td> </tr> <tr> <td>6</td> <td>11.3</td> <td>26</td> <td>121.7</td> </tr> <tr> <td>7</td> <td>12.7</td> <td>27</td> <td>137.1</td> </tr> <tr> <td>8</td> <td>14.3</td> <td>28</td> <td>154.4</td> </tr> <tr> <td>9</td> <td>16.1</td> <td>29</td> <td>173.9</td> </tr> <tr> <td>10</td> <td>18.1</td> <td>30</td> <td>195.9</td> </tr> <tr> <td>11</td> <td>20.4</td> <td>31</td> <td>220.6</td> </tr> <tr> <td>12</td> <td>23.0</td> <td>32</td> <td>248.5</td> </tr> <tr> <td>13</td> <td>25.9</td> <td>33</td> <td>279.9</td> </tr> <tr> <td>14</td> <td>29.2</td> <td>34</td> <td>315.3</td> </tr> <tr> <td>15</td> <td>32.9</td> <td>35</td> <td>355.1</td> </tr> <tr> <td>16</td> <td>37.0</td> <td>36</td> <td>400.0</td> </tr> <tr> <td>17</td> <td>41.7</td> <td>37</td> <td>446.6</td> </tr> <tr> <td>18</td> <td>47.0</td> <td>38</td> <td>501.2</td> </tr> <tr> <td>19</td> <td>52.9</td> <td>39</td> <td>571.5</td> </tr> <tr> <td>20</td> <td>59.6</td> <td>40</td> <td>642.7</td> </tr> </tbody> </table>	Setting value	Machine characteristic		Setting value	Machine characteristic		Response	Guideline for machine resonance frequency [Hz]	Response	Guideline for machine resonance frequency [Hz]	1	Low response ↑ ↓ Middle response	2.7	21	Middle response ↑ ↓ High response	67.1	2	3.6	22	75.6	3	4.9	23	85.2	4	6.6	24	95.9	5	10.0	25	108.0	6	11.3	26	121.7	7	12.7	27	137.1	8	14.3	28	154.4	9	16.1	29	173.9	10	18.1	30	195.9	11	20.4	31	220.6	12	23.0	32	248.5	13	25.9	33	279.9	14	29.2	34	315.3	15	32.9	35	355.1	16	37.0	36	400.0	17	41.7	37	446.6	18	47.0	38	501.2	19	52.9	39	571.5	20	59.6	40	642.7		
Setting value	Machine characteristic			Setting value	Machine characteristic																																																																																											
	Response	Guideline for machine resonance frequency [Hz]	Response		Guideline for machine resonance frequency [Hz]																																																																																											
1	Low response ↑ ↓ Middle response	2.7	21	Middle response ↑ ↓ High response	67.1																																																																																											
2		3.6	22		75.6																																																																																											
3		4.9	23		85.2																																																																																											
4		6.6	24		95.9																																																																																											
5		10.0	25		108.0																																																																																											
6		11.3	26		121.7																																																																																											
7		12.7	27		137.1																																																																																											
8		14.3	28		154.4																																																																																											
9		16.1	29		173.9																																																																																											
10		18.1	30		195.9																																																																																											
11		20.4	31		220.6																																																																																											
12		23.0	32		248.5																																																																																											
13		25.9	33		279.9																																																																																											
14		29.2	34		315.3																																																																																											
15		32.9	35		355.1																																																																																											
16		37.0	36		400.0																																																																																											
17		41.7	37		446.6																																																																																											
18		47.0	38		501.2																																																																																											
19		52.9	39		571.5																																																																																											
20	59.6	40	642.7																																																																																													
		Setting range: 1 to 40																																																																																														
PA10 INP In-position range		Set an in-position range in a command unit. To change it to the servo motor encoder pulse unit, set [Pr. PC24].	100 Refer to Function column for unit.	<input type="radio"/>	<input type="radio"/>																																																																																											
		<table border="1"> <thead> <tr> <th>Pr. PA01</th> <th>In-position setting range</th> </tr> </thead> <tbody> <tr> <td>___ 6 (Positioning mode (point table method))</td> <td rowspan="2">The range where MEND (Travel completion), PED (Position end) and INP (In-position) are outputted.</td> </tr> <tr> <td>___ 7 (Positioning mode (program method))</td> </tr> </tbody> </table>	Pr. PA01	In-position setting range	___ 6 (Positioning mode (point table method))	The range where MEND (Travel completion), PED (Position end) and INP (In-position) are outputted.	___ 7 (Positioning mode (program method))																																																																																									
Pr. PA01	In-position setting range																																																																																															
___ 6 (Positioning mode (point table method))	The range where MEND (Travel completion), PED (Position end) and INP (In-position) are outputted.																																																																																															
___ 7 (Positioning mode (program method))																																																																																																
		Select from [μm], 10^{-4} [inch], 10^{-3} [degree], or [pulse] with [Pr. PT01]																																																																																														
		Setting range: 0 to 65535																																																																																														

7. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode	
				C P	C L
PA11 TLP Forward rotation torque limit		<p>You can limit the torque generated by the servo motor. Set this parameter referring section 3.6.1 (5) of "MR-JE-_A Servo Amplifier Instruction Manual".</p> <p>When the torque is outputted with the analog monitor output, the setting of [Pr. PA11 Forward rotation torque limit] or [Pr. PA12 Reverse rotation torque limit], whichever is larger, will be the maximum output voltage (8 V).</p> <p>Set the parameter on the assumption that the maximum torque is 100 [%]. The parameter is for limiting the torque of the servo motor in the CCW power running or CW regeneration. No torque is generated when this parameter is set to "0.0".</p> <p>Setting range: 0.0 to 100.0</p>	100.0 [%]	○	○
PA12 TLN Reverse rotation torque limit		<p>You can limit the torque generated by the servo motor. Set this parameter referring section 3.6.1 (5) of "MR-JE-_A Servo Amplifier Instruction Manual".</p> <p>When the torque is outputted with the analog monitor output, the setting of [Pr. PA11 Forward rotation torque limit] or [Pr. PA12 Reverse rotation torque limit], whichever is larger, will be the maximum output voltage (8 V).</p> <p>Set the parameter on the assumption that the maximum torque is 100.0 [%]. The parameter is for limiting the torque of the servo motor in the CW power running or CCW regeneration. No torque is generated when this parameter is set to "0.0".</p> <p>Setting range: 0.0 to 100.0</p>	100.0 [%]	○	○
PA13 *PLSS Command pulse input form	___ x	<p>Command input pulse train form selection</p> <p>0: Forward/reverse rotation pulse train</p> <p>1: Signed pulse train</p> <p>2: A-phase/B-phase pulse train (The servo amplifier imports input pulses after multiplying by four.)</p> <p>When connecting the manual pulse generator MR-HDP01 in the positioning mode, set "2" to this digit.</p> <p>Refer to table 7.3 for settings.</p>	0h	○	○
	-- x _	<p>Pulse train logic selection</p> <p>0: Positive logic</p> <p>1: Negative logic</p> <p>Match the logic of the command pulse train received from a connected controller. Refer to POINT of section 3.6.1 of "MR-JE-_A Servo Amplifier Instruction Manual" for logic of MELSEC iQ-R series/MELSEC-Q series/MELSEC-L series/MELSEC-F series. When connecting the manual pulse generator MR-HDP01 in the positioning mode, set "0" to this digit.</p> <p>Refer to table 7.3 for settings.</p>	0h	○	○

7. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode	
				C P	C L
PA13 *PLSS Command pulse input form	_ x _ _	Command input pulse train filter selection Selecting proper filter enables to enhance noise tolerance. 0: Command input pulse train is 4 Mpulses/s or less. 1: Command input pulse train is 1 Mpulses/s or less. 2: Command input pulse train is 500 kpulses/s or less. 3: Command input pulse train is 200 kpulses/s or less. 1 Mpulse/s or lower commands are supported by "1". When inputting commands over 1 Mpulse/s and 4 Mpulses/s or lower, set "0". When connecting the manual pulse generator MR-HDP01 in the positioning mode, set "2" or "3" to this digit. Incorrect setting may cause the following malfunctions. - Setting a value higher than actual command will lower noise tolerance. - Setting a value lower than actual command will cause a position mismatch.	1h	<input type="radio"/>	<input type="radio"/>
	x _ _ _	For manufacturer setting	0h	<input type="checkbox"/>	<input type="checkbox"/>


Table 7.3 Command input pulse train form selection

Setting value		Pulse train form	Forward rotation command	Reverse rotation command
_ _ 10h	Negative logic	Forward rotation pulse train	PP	NP
		Reverse rotation pulse train		
_ _ 11h	Negative logic	Signed pulse train	PP	NP
_ _ 12h	Positive logic	A-phase pulse train	PP	NP
		B-phase pulse train		
_ _ 00h	Positive logic	Forward rotation pulse train	PP	NP
		Reverse rotation pulse train		
_ _ 01h	Positive logic	Signed pulse train	PP	NP
_ _ 02h	Positive logic	A-phase pulse train	PP	NP
		B-phase pulse train		

Arrows in the table indicate the timing of importing pulse trains. A-phase/B-phase pulse trains are imported after they have been multiplied by 4.

When connecting the manual pulse generator MR-HDP01 in the positioning mode, set "_ _ 02h".

7. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode												
				C P	C L											
PA14 *POL Rotation direction selection		<p>Select the servo motor rotation direction when ST1 (Forward rotation start) or ST2 (Reverse rotation start) is switched on.</p> <table border="1"> <thead> <tr> <th rowspan="2">Setting value</th> <th colspan="2">Servo motor rotation direction</th> </tr> <tr> <th>When positioning address increases</th> <th>When positioning address decreases</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>CCW</td> <td>CW</td> </tr> <tr> <td>1</td> <td>CW</td> <td>CCW</td> </tr> </tbody> </table> <p>The following shows the servo motor rotation directions.</p>  <p>Setting range: 0, 1</p>	Setting value	Servo motor rotation direction		When positioning address increases	When positioning address decreases	0	CCW	CW	1	CW	CCW	0	<input type="radio"/>	<input type="radio"/>
Setting value	Servo motor rotation direction															
	When positioning address increases	When positioning address decreases														
0	CCW	CW														
1	CW	CCW														
PA15 *ENR Encoder output pulses		<p>Set the encoder output pulses from the servo amplifier by using the number of output pulses per revolution, dividing ratio, or electronic gear ratio. (after multiplication by 4)</p> <p>Set a numerator of the electronic gear when selecting "A-phase/B-phase pulse electronic gear setting (_ _ 3 _)" of "Encoder output pulse setting selection" in [Pr. PC19].</p> <p>The maximum output frequency is 4.6 Mpulses/s. Set the parameter within this range.</p> <p>Setting range: 1 to 4194304</p>	4000 [pulse/ rev]	<input type="radio"/>	<input type="radio"/>											
PA16 *ENR2 Encoder output pulses 2		<p>Set a denominator of the electronic gear for the A/B-phase pulse output.</p> <p>Set a denominator of the electronic gear when selecting "A-phase/B-phase pulse electronic gear setting (_ _ 3 _)" of "Encoder output pulse setting selection" in [Pr. PC19].</p> <p>Setting range: 1 to 4194304</p>	1	<input type="radio"/>	<input type="radio"/>											

7. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode																																																																																																																																																																																				
				C P	C L																																																																																																																																																																																			
PA19 *BLK Parameter writing inhibit		Select a reference range and writing range of the parameter. For the positioning mode, set [Pr. PA19] to "0 0 A B" to enable read/write the positioning control parameters ([Pr. PT_ _]). Refer to table 7.4 for settings.	00AAh	<input type="radio"/>	<input type="radio"/>																																																																																																																																																																																			
<p>Table 7.4 [Pr. PA19] setting value and reading/writing range</p> <table border="1"> <thead> <tr> <th>PA19</th> <th>Setting operation</th> <th>PA</th> <th>PB</th> <th>PC</th> <th>PD</th> <th>PE</th> <th>PF</th> <th>PT</th> </tr> </thead> <tbody> <tr> <td rowspan="2">Other than below</td> <td>Reading</td> <td><input type="radio"/></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>Writing</td> <td><input type="radio"/></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td rowspan="2">000Ah</td> <td>Reading</td> <td>Only 19</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>Writing</td> <td>Only 19</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td rowspan="2">000Bh</td> <td>Reading</td> <td><input type="radio"/></td> <td><input type="radio"/></td> <td><input type="radio"/></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>Writing</td> <td><input type="radio"/></td> <td><input type="radio"/></td> <td><input type="radio"/></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td rowspan="2">000Ch</td> <td>Reading</td> <td><input type="radio"/></td> <td><input type="radio"/></td> <td><input type="radio"/></td> <td><input type="radio"/></td> <td></td> <td></td> <td></td> </tr> <tr> <td>Writing</td> <td><input type="radio"/></td> <td><input type="radio"/></td> <td><input type="radio"/></td> <td><input type="radio"/></td> <td></td> <td></td> <td></td> </tr> <tr> <td rowspan="2">00AAh (Initial value)</td> <td>Reading</td> <td><input type="radio"/></td> <td><input type="radio"/></td> <td><input type="radio"/></td> <td><input type="radio"/></td> <td><input type="radio"/></td> <td><input type="radio"/></td> <td></td> </tr> <tr> <td>Writing</td> <td><input type="radio"/></td> <td><input type="radio"/></td> <td><input type="radio"/></td> <td><input type="radio"/></td> <td><input type="radio"/></td> <td><input type="radio"/></td> <td></td> </tr> <tr> <td rowspan="2">00ABh</td> <td>Reading</td> <td><input type="radio"/></td> <td><input type="radio"/></td> <td><input type="radio"/></td> <td><input type="radio"/></td> <td><input type="radio"/></td> <td><input type="radio"/></td> <td><input type="radio"/></td> </tr> <tr> <td>Writing</td> <td><input type="radio"/></td> <td><input type="radio"/></td> <td><input type="radio"/></td> <td><input type="radio"/></td> <td><input type="radio"/></td> <td><input type="radio"/></td> <td><input type="radio"/></td> </tr> <tr> <td rowspan="2">100Bh</td> <td>Reading</td> <td><input type="radio"/></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>Writing</td> <td>Only 19</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td rowspan="2">100Ch</td> <td>Reading</td> <td><input type="radio"/></td> <td><input type="radio"/></td> <td><input type="radio"/></td> <td><input type="radio"/></td> <td></td> <td></td> <td></td> </tr> <tr> <td>Writing</td> <td>Only 19</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td rowspan="2">10AAh</td> <td>Reading</td> <td><input type="radio"/></td> <td><input type="radio"/></td> <td><input type="radio"/></td> <td><input type="radio"/></td> <td><input type="radio"/></td> <td><input type="radio"/></td> <td></td> </tr> <tr> <td>Writing</td> <td>Only 19</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td rowspan="2">10ABh</td> <td>Reading</td> <td><input type="radio"/></td> <td><input type="radio"/></td> <td><input type="radio"/></td> <td><input type="radio"/></td> <td><input type="radio"/></td> <td><input type="radio"/></td> <td><input type="radio"/></td> </tr> <tr> <td>Writing</td> <td>Only 19</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> </tbody> </table>						PA19	Setting operation	PA	PB	PC	PD	PE	PF	PT	Other than below	Reading	<input type="radio"/>							Writing	<input type="radio"/>							000Ah	Reading	Only 19							Writing	Only 19							000Bh	Reading	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>					Writing	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>					000Ch	Reading	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>				Writing	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>				00AAh (Initial value)	Reading	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		Writing	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		00ABh	Reading	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	Writing	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	100Bh	Reading	<input type="radio"/>							Writing	Only 19							100Ch	Reading	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>				Writing	Only 19							10AAh	Reading	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		Writing	Only 19							10ABh	Reading	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	Writing	Only 19						
PA19	Setting operation	PA	PB	PC	PD	PE	PF	PT																																																																																																																																																																																
Other than below	Reading	<input type="radio"/>																																																																																																																																																																																						
	Writing	<input type="radio"/>																																																																																																																																																																																						
000Ah	Reading	Only 19																																																																																																																																																																																						
	Writing	Only 19																																																																																																																																																																																						
000Bh	Reading	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>																																																																																																																																																																																				
	Writing	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>																																																																																																																																																																																				
000Ch	Reading	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>																																																																																																																																																																																			
	Writing	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>																																																																																																																																																																																			
00AAh (Initial value)	Reading	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>																																																																																																																																																																																	
	Writing	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>																																																																																																																																																																																	
00ABh	Reading	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>																																																																																																																																																																																
	Writing	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>																																																																																																																																																																																
100Bh	Reading	<input type="radio"/>																																																																																																																																																																																						
	Writing	Only 19																																																																																																																																																																																						
100Ch	Reading	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>																																																																																																																																																																																			
	Writing	Only 19																																																																																																																																																																																						
10AAh	Reading	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>																																																																																																																																																																																	
	Writing	Only 19																																																																																																																																																																																						
10ABh	Reading	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>																																																																																																																																																																																
	Writing	Only 19																																																																																																																																																																																						

7. PARAMETERS


No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode	
				C P	C L
PA20 *TDS Tough drive setting		Alarms may not be avoided with the tough drive function depending on the situations of the power supply and load fluctuation. You can assign MTTR (During tough drive) to pins CN1-13, CN1-14, CN1-22 to CN1-25, and CN1-49 with [Pr. PD24] to [Pr. PD26], [Pr. PD28], and [Pr. PD47].			
	___x	For manufacturer setting	0h		
	--x-	Vibration tough drive selection 0: Disabled 1: Enabled Selecting "1" enables to suppress vibrations by automatically changing the setting values of [Pr. PB13 Machine resonance suppression filter 1] and [Pr. PB15 Machine resonance suppression filter 2] in case that the vibration exceeds the value of the oscillation level set in [Pr. PF23]. To output the oscillation detection alarm as a warning, set [Pr. PF24 Vibration tough drive function selection]. For details, refer to section 7.3 of "MR-JE-_A Servo Amplifier Instruction Manual".	0h	○	○
	_x__	Instantaneous power failure tough drive selection 0: Disabled 1: Enabled Selecting "1" enables to avoid triggering [AL. 10 Undervoltage] by using the electrical energy charged in the capacitor in the servo amplifier in case that an instantaneous power failure occurs during operation. Set the time until the occurrence of [AL. 10.1 Voltage drop in the power] with [Pr. PF25 Instantaneous power failure tough drive - Detection time]. When the parameter is enabled, the power should be off for the setting value of [Pr. PF25] + 1 s or more before cycling the power to enable a parameter whose symbol is preceded by "**".	0h	○	○
	x___	For manufacturer setting	0h		
PA21 *AOP3 Function selection A-3	___x	One-touch tuning function selection 0: Disabled 1: Enabled When the digit is "0", the one-touch tuning is not available.	1h	○	○
	__x-	For manufacturer setting	0h		
	-x__	For manufacturer setting	0h		
	x___	Electronic gear selection When this digit is changed, the home position will be changed. Execute the home position return again. 0: Electronic gear ([Pr. PA06] and [Pr. PA07]) 1: Not used for positioning mode. Setting this will trigger [AL. 37 Parameter error].	0h	○	○

7. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode	
				C P	C L
PA23 DRAT Drive recorder arbitrary alarm trigger setting	-- x x	Alarm detail No. setting Set the digits when you execute the trigger with arbitrary alarm detail No. for the drive recorder function. When these digits are "0 0", only the arbitrary alarm No. setting will be enabled.	00h	<input type="radio"/>	<input type="radio"/>
	x x _ _	Alarm No. setting Set the digits when you execute the trigger with arbitrary alarm No. for the drive recorder function. When "0 0" are set, arbitrary alarm trigger of the drive recorder will be disabled.	00h	<input type="radio"/>	<input type="radio"/>
	Setting example: To activate the drive recorder when [AL. 50 Overload 1] occurs, set "5 0 0 0". To activate the drive recorder when [AL. 50.3 Thermal overload error 4 during operation] occurs, set "5 0 0 3".				
PA24 AOP4 Function selection A-4	___ x	Vibration suppression mode selection 0: Standard mode 1: 3 inertia mode 2: Low response mode When you select the standard mode or low response mode, "Vibration suppression control 2" is not available. When you select the 3 inertia mode, the feed forward gain is not available.	0h	<input type="radio"/>	<input type="radio"/>
	_ _ x _	For manufacturer setting	0h	<input type="checkbox"/>	<input type="checkbox"/>
	_ x _ _		0h	<input type="checkbox"/>	<input type="checkbox"/>
	x _ _ _		0h	<input type="checkbox"/>	<input type="checkbox"/>
PA25 OTHOV One-touch tuning - Overshoot permissible level	/	Set a permissible value of overshoot amount for one-touch tuning as a percentage of the in-position range. However, setting "0" will be 50%.	0 [%]	<input type="radio"/>	<input type="radio"/>
PA26 *AOP5 Function selection A-5	___ x	Torque limit function selection at instantaneous power failure 0: Disabled 1: Enabled Selecting "1" for this digit will limit torques to save electric energy when an instantaneous power failure occurs during operation and will make [AL. 10 Undervoltage] less likely to occur. The torque limit function at instantaneous power failure is enabled when "instantaneous power failure tough drive selection" in [Pr. PA20] is "Enabled (_ 1 _)".	0h	<input type="radio"/>	<input type="radio"/>
	_ _ x _	For manufacturer setting	0h	<input type="checkbox"/>	<input type="checkbox"/>
	_ x _ _		0h	<input type="checkbox"/>	<input type="checkbox"/>
	x _ _ _		0h	<input type="checkbox"/>	<input type="checkbox"/>

7. PARAMETERS

7.2.2 Gain/filter setting parameters ([Pr. PB_ _])

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode	
				C P	C L
PB01 FILT Adaptive tuning mode (adaptive filter II)	___x	Filter tuning mode selection Set the adaptive filter tuning. Select the adjustment mode of the machine resonance suppression filter 1. For details, refer to section 7.1.2 of "MR-JE-_A Servo Amplifier Instruction Manual". 0: Disabled 1: Automatic setting 2: Manual setting	0h	<input type="radio"/>	<input type="radio"/>
	__x_	For manufacturer setting	0h	<input type="checkbox"/>	<input type="checkbox"/>
	_x__		0h	<input type="checkbox"/>	<input type="checkbox"/>
	x___		0h	<input type="checkbox"/>	<input type="checkbox"/>
PB02 VRFT Vibration suppression control tuning mode (advanced vibration suppression control II)	___x	Vibration suppression control 1 tuning mode selection Select the tuning mode of the vibration suppression control 1. For details, refer to section 7.1.5 of "MR-JE-_A Servo Amplifier Instruction Manual". 0: Disabled 1: Automatic setting 2: Manual setting	0h	<input type="radio"/>	<input type="radio"/>
	__x_	Vibration suppression control 2 tuning mode selection Select the tuning mode of the vibration suppression control 2. To enable the digit, select "3 inertia mode (___1)" of "Vibration suppression mode selection" in [Pr. PA24]. For details, refer to section 7.1.5 of "MR-JE-_A Servo Amplifier Instruction Manual". 0: Disabled 1: Automatic setting 2: Manual setting	0h	<input type="radio"/>	<input type="radio"/>
	_x__	For manufacturer setting	0h	<input type="checkbox"/>	<input type="checkbox"/>
	x___		0h	<input type="checkbox"/>	<input type="checkbox"/>
PB03 PST Position command acceleration/d eceleration time constant (position smoothing)		Set the constant of a primary delay to the position command. You can select a control method from "Primary delay" or "Linear acceleration/deceleration" in [Pr. PB25 Function selection B-1]. The setting range of "Linear acceleration/deceleration" is 0 ms to 10 ms. Setting of longer than 10 ms will be recognized as 10 ms. (Example) When a command is given from a synchronous encoder, a synchronous operation will start smoothly even if it starts during line operation.  Setting range: 0 to 65535	0 [ms]	<input type="radio"/>	<input type="radio"/>

7. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode											
				C P	C L										
PB04 FFC Feed forward gain		<p>Set the feed forward gain.</p> <p>When the setting is 100%, the droop pulses during operation at constant speed are nearly zero. However, sudden acceleration/deceleration will increase the overshoot. As a guideline, when the feed forward gain setting is 100%, set 1 s or more for the acceleration time constant to the rated speed.</p> <p>Setting range: 0 to 100</p>	0 [%]	<input type="radio"/>	<input type="radio"/>										
PB06 GD2 Load to motor inertia ratio		<p>Set the load to motor inertia ratio.</p> <p>The setting of this parameter will be automatic or manual depending on the setting of [Pr. PA08]. Refer to the following table for details. When the parameter is set to automatic, the value will vary between 0.00 and 100.00.</p> <p>Setting range: 0.00 to 300.00</p> <table border="1" style="margin: 10px auto;"> <thead> <tr> <th>Pr. PA08</th> <th>This parameter</th> </tr> </thead> <tbody> <tr> <td>___ 0 (2 gain adjustment mode 1 (interpolation mode))</td> <td rowspan="2">Automatic setting</td> </tr> <tr> <td>___ 1 (Auto tuning mode 1)</td> </tr> <tr> <td>___ 2 (Auto tuning mode 2)</td> <td rowspan="3">Manual setting</td> </tr> <tr> <td>___ 3 (Manual mode)</td> </tr> <tr> <td>___ 4 (2 gain adjustment mode 2)</td> </tr> </tbody> </table>	Pr. PA08	This parameter	___ 0 (2 gain adjustment mode 1 (interpolation mode))	Automatic setting	___ 1 (Auto tuning mode 1)	___ 2 (Auto tuning mode 2)	Manual setting	___ 3 (Manual mode)	___ 4 (2 gain adjustment mode 2)	7.00 [times]	<input type="radio"/>	<input type="radio"/>	
Pr. PA08	This parameter														
___ 0 (2 gain adjustment mode 1 (interpolation mode))	Automatic setting														
___ 1 (Auto tuning mode 1)															
___ 2 (Auto tuning mode 2)	Manual setting														
___ 3 (Manual mode)															
___ 4 (2 gain adjustment mode 2)															
PB07 PG1 Model loop gain		<p>Set the response gain to the target position.</p> <p>Increasing the setting value will also increase the response level to the position command but will be liable to generate vibration and/or noise.</p> <p>The setting of this parameter will be automatic or manual depending on the setting of [Pr. PA08]. Refer to the following table for details.</p> <p>Setting range: 1.0 to 2000.0</p> <table border="1" style="margin: 10px auto;"> <thead> <tr> <th>Pr. PA08</th> <th>This parameter</th> </tr> </thead> <tbody> <tr> <td>___ 0 (2 gain adjustment mode 1 (interpolation mode))</td> <td>Manual setting</td> </tr> <tr> <td>___ 1 (Auto tuning mode 1)</td> <td rowspan="2">Automatic setting</td> </tr> <tr> <td>___ 2 (Auto tuning mode 2)</td> </tr> <tr> <td>___ 3 (Manual mode)</td> <td rowspan="2">Manual setting</td> </tr> <tr> <td>___ 4 (2 gain adjustment mode 2)</td> </tr> </tbody> </table>	Pr. PA08	This parameter	___ 0 (2 gain adjustment mode 1 (interpolation mode))	Manual setting	___ 1 (Auto tuning mode 1)	Automatic setting	___ 2 (Auto tuning mode 2)	___ 3 (Manual mode)	Manual setting	___ 4 (2 gain adjustment mode 2)	15.0 [rad/s]	<input type="radio"/>	<input type="radio"/>
Pr. PA08	This parameter														
___ 0 (2 gain adjustment mode 1 (interpolation mode))	Manual setting														
___ 1 (Auto tuning mode 1)	Automatic setting														
___ 2 (Auto tuning mode 2)															
___ 3 (Manual mode)	Manual setting														
___ 4 (2 gain adjustment mode 2)															
PB08 PG2 Position loop gain		<p>Set the gain of the position loop.</p> <p>Set this parameter to increase the position response to level load disturbance. Increasing the setting value will also increase the response level to the load disturbance but will be liable to generate vibration and/or noise.</p> <p>The setting of the parameter will be the automatic setting or manual setting depending on the [Pr. PA08] setting. Refer to the following table for details.</p> <p>Setting range: 1.0 to 2000.0</p> <table border="1" style="margin: 10px auto;"> <thead> <tr> <th>Pr. PA08</th> <th>This parameter</th> </tr> </thead> <tbody> <tr> <td>___ 0 (2 gain adjustment mode 1 (interpolation mode))</td> <td rowspan="3">Automatic setting</td> </tr> <tr> <td>___ 1 (Auto tuning mode 1)</td> </tr> <tr> <td>___ 2 (Auto tuning mode 2)</td> </tr> <tr> <td>___ 3 (Manual mode)</td> <td>Manual setting</td> </tr> <tr> <td>___ 4 (2 gain adjustment mode 2)</td> <td>Automatic setting</td> </tr> </tbody> </table>	Pr. PA08	This parameter	___ 0 (2 gain adjustment mode 1 (interpolation mode))	Automatic setting	___ 1 (Auto tuning mode 1)	___ 2 (Auto tuning mode 2)	___ 3 (Manual mode)	Manual setting	___ 4 (2 gain adjustment mode 2)	Automatic setting	37.0 [rad/s]	<input type="radio"/>	<input type="radio"/>
Pr. PA08	This parameter														
___ 0 (2 gain adjustment mode 1 (interpolation mode))	Automatic setting														
___ 1 (Auto tuning mode 1)															
___ 2 (Auto tuning mode 2)															
___ 3 (Manual mode)	Manual setting														
___ 4 (2 gain adjustment mode 2)	Automatic setting														

7. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode	
				C P	C L
PB09 VG2 Speed loop gain		Set the gain of the speed loop. Set this parameter when vibration occurs on machines of low rigidity or with large backlash. Increasing the setting value will also increase the response level but will be liable to generate vibration and/or noise. The setting of the parameter will be automatic or manual depending on the setting of [Pr. PA08]. Refer to the table of [Pr. PB08] for details. Setting range: 20 to 65535	823 [rad/s]	<input type="radio"/>	<input type="radio"/>
PB10 VIC Speed integral compensation		Set the integral time constant of the speed loop. Decreasing the setting value will increase the response level but will be liable to generate vibration and/or noise. The setting of the parameter will be automatic or manual depending on the setting of [Pr. PA08]. Refer to the table of [Pr. PB08] for details. Setting range: 0.1 to 1000.0	33.7 [ms]	<input type="radio"/>	<input type="radio"/>
PB11 VDC Speed differential compensation		Set the differential compensation. To enable the setting value, turn on PC (proportional control). Setting range: 0 to 1000	980	<input type="radio"/>	<input type="radio"/>
PB12 OVA Overshoot amount compensation		Set a viscous friction torque in percentage to the rated torque at servo motor rated speed. When the response level is low, or when the torque is limited, the efficiency of the parameter can be lower. Setting range: 0 to 100	0 [%]	<input type="radio"/>	<input type="radio"/>
PB13 NH1 Machine resonance suppression filter 1		Machine resonance suppression filter 1 Set the notch frequency of the machine resonance suppression filter 1. When "Filter tuning mode selection" is set to "Automatic setting (_ _ _ 1)" in [Pr. PB01], this parameter will be adjusted automatically. When "Filter tuning mode selection" is set to "Manual setting (_ _ _ 2)" in [Pr. PB01], the setting value will be enabled. Setting range: 10 to 4500	4500 [Hz]	<input type="radio"/>	<input type="radio"/>
PB14 NHQ1 Notch shape selection 1		Set forms of the machine resonance suppression filter 1. When "Filter tuning mode selection" is set to "Automatic setting (_ _ _ 1)" in [Pr. PB01], this parameter will be adjusted automatically. Set manually for the manual setting.			
	_ _ _ x	For manufacturer setting	0h	<input type="checkbox"/>	<input type="checkbox"/>
	_ _ x _	Notch depth selection 0: -40 dB 1: -14 dB 2: -8 dB 3: -4 dB	0h	<input type="radio"/>	<input type="radio"/>
	_ x _ _	Notch width selection 0: $\alpha = 2$ 1: $\alpha = 3$ 2: $\alpha = 4$ 3: $\alpha = 5$	0h	<input type="radio"/>	<input type="radio"/>
	x _ _ _	For manufacturer setting	0h	<input type="checkbox"/>	<input type="checkbox"/>
PB15 NH2 Machine resonance suppression filter 2		Set the notch frequency of the machine resonance suppression filter 2. To enable the setting value, select "Enabled (_ _ _ 1)" of "Machine resonance suppression filter 2 selection" in [Pr. PB16]. Setting range: 10 to 4500	4500 [Hz]	<input type="radio"/>	<input type="radio"/>

7. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode																																																																					
				C P	C L																																																																				
PB16 NHQ2 Notch shape selection 2	Set forms of the machine resonance suppression filter 2.																																																																								
	___x	Machine resonance suppression filter 2 selection 0: Disabled 1: Enabled	0h	<input type="radio"/>	<input type="radio"/>																																																																				
	__x_	Notch depth selection 0: -40 dB 1: -14 dB 2: -8 dB 3: -4 dB	0h	<input type="radio"/>	<input type="radio"/>																																																																				
	_x__	Notch width selection 0: $\alpha = 2$ 1: $\alpha = 3$ 2: $\alpha = 4$ 3: $\alpha = 5$	0h	<input type="radio"/>	<input type="radio"/>																																																																				
x___	For manufacturer setting	0h	<input type="checkbox"/>	<input type="checkbox"/>																																																																					
PB17 NHF Shaft resonance suppression filter	Set the shaft resonance suppression filter. This is used to suppress a low-frequency machine vibration. When "Shaft resonance suppression filter selection" is set to "Automatic setting (___0)" in [Pr. PB23], the value will be calculated automatically from the servo motor you use and load to motor inertia ratio. Set manually for "Manual setting (___1)". When "Shaft resonance suppression filter selection" is set to "Disabled (___2)" in [Pr. PB23], the setting value of this parameter will be disabled. When "Machine resonance suppression filter 4 selection" is set to "Enabled (___1)" in [Pr. PB49], the shaft resonance suppression filter is not available.																																																																								
	__x x	Shaft resonance suppression filter setting frequency selection Refer to table 7.5 for settings. Set the value closest to the frequency you need.	00h	<input type="radio"/>	<input type="radio"/>																																																																				
	_x__	Notch depth selection 0: -40 dB 1: -14 dB 2: -8 dB 3: -4 dB	0h	<input type="radio"/>	<input type="radio"/>																																																																				
	x___	For manufacturer setting	0h	<input type="checkbox"/>	<input type="checkbox"/>																																																																				
<p>Table 7.5 Shaft resonance suppression filter setting frequency selection</p> <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th>Setting value</th> <th>Frequency [Hz]</th> <th>Setting value</th> <th>Frequency [Hz]</th> </tr> </thead> <tbody> <tr><td>00</td><td>Disabled</td><td>10</td><td>562</td></tr> <tr><td>01</td><td>Disabled</td><td>11</td><td>529</td></tr> <tr><td>02</td><td>4500</td><td>12</td><td>500</td></tr> <tr><td>03</td><td>3000</td><td>13</td><td>473</td></tr> <tr><td>04</td><td>2250</td><td>14</td><td>450</td></tr> <tr><td>05</td><td>1800</td><td>15</td><td>428</td></tr> <tr><td>06</td><td>1500</td><td>16</td><td>409</td></tr> <tr><td>07</td><td>1285</td><td>17</td><td>391</td></tr> <tr><td>08</td><td>1125</td><td>18</td><td>375</td></tr> <tr><td>09</td><td>1000</td><td>19</td><td>360</td></tr> <tr><td>0A</td><td>900</td><td>1A</td><td>346</td></tr> <tr><td>0B</td><td>818</td><td>1B</td><td>333</td></tr> <tr><td>0C</td><td>750</td><td>1C</td><td>321</td></tr> <tr><td>0D</td><td>692</td><td>1D</td><td>310</td></tr> <tr><td>0E</td><td>642</td><td>1E</td><td>300</td></tr> <tr><td>0F</td><td>600</td><td>1F</td><td>290</td></tr> </tbody> </table>						Setting value	Frequency [Hz]	Setting value	Frequency [Hz]	00	Disabled	10	562	01	Disabled	11	529	02	4500	12	500	03	3000	13	473	04	2250	14	450	05	1800	15	428	06	1500	16	409	07	1285	17	391	08	1125	18	375	09	1000	19	360	0A	900	1A	346	0B	818	1B	333	0C	750	1C	321	0D	692	1D	310	0E	642	1E	300	0F	600	1F	290
Setting value	Frequency [Hz]	Setting value	Frequency [Hz]																																																																						
00	Disabled	10	562																																																																						
01	Disabled	11	529																																																																						
02	4500	12	500																																																																						
03	3000	13	473																																																																						
04	2250	14	450																																																																						
05	1800	15	428																																																																						
06	1500	16	409																																																																						
07	1285	17	391																																																																						
08	1125	18	375																																																																						
09	1000	19	360																																																																						
0A	900	1A	346																																																																						
0B	818	1B	333																																																																						
0C	750	1C	321																																																																						
0D	692	1D	310																																																																						
0E	642	1E	300																																																																						
0F	600	1F	290																																																																						

7. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode				
				C P	C L			
PB18 LPF Low-pass filter setting		Set the low-pass filter. The following shows a relation of a required parameter to this parameter. Setting range: 100 to 18000	3141 [rad/s]	○	○			
		<table border="1"> <thead> <tr> <th>[Pr. PB23]</th> <th>[Pr. PB18]</th> </tr> </thead> <tbody> <tr> <td>__ 0 _ (Initial value)</td> <td>Automatic setting</td> </tr> <tr> <td>__ 1 _</td> <td>Setting value enabled</td> </tr> <tr> <td>__ 2 _</td> <td>Setting value disabled</td> </tr> </tbody> </table>				[Pr. PB23]	[Pr. PB18]	__ 0 _ (Initial value)
[Pr. PB23]	[Pr. PB18]							
__ 0 _ (Initial value)	Automatic setting							
__ 1 _	Setting value enabled							
__ 2 _	Setting value disabled							
PB19 VRF11 Vibration suppression control 1 - Vibration frequency		Set the vibration frequency for vibration suppression control 1 to suppress low-frequency machine vibration. When "Vibration suppression control 1 tuning mode selection" is set to "Automatic setting (__ 1)" in [Pr. PB02], this parameter will be set automatically. Set manually for "Manual setting (__ 2)". For details, refer to section 7.1.5 of "MR-JE-_A Servo Amplifier Instruction Manual". Setting range: 0.1 to 300.0	100.0 [Hz]	○	○			
PB20 VRF12 Vibration suppression control 1 - Resonance frequency		Set the resonance frequency for vibration suppression control 1 to suppress low-frequency machine vibration. When "Vibration suppression control 1 tuning mode selection" is set to "Automatic setting (__ 1)" in [Pr. PB02], this parameter will be set automatically. Set manually for "Manual setting (__ 2)". For details, refer to section 7.1.5 of "MR-JE-_A Servo Amplifier Instruction Manual". Setting range: 0.1 to 300.0	100.0 [Hz]	○	○			
PB21 VRF13 Vibration suppression control 1 - Vibration frequency damping		Set a damping of the vibration frequency for vibration suppression control 1 to suppress low-frequency machine vibration. When "Vibration suppression control 1 tuning mode selection" is set to "Automatic setting (__ 1)" in [Pr. PB02], this parameter will be set automatically. Set manually for "Manual setting (__ 2)". For details, refer to section 7.1.5 of "MR-JE-_A Servo Amplifier Instruction Manual". Setting range: 0.00 to 0.30	0.00	○	○			
PB22 VRF14 Vibration suppression control 1 - Resonance frequency damping		Set a damping of the resonance frequency for vibration suppression control 1 to suppress low-frequency machine vibration. When "Vibration suppression control 1 tuning mode selection" is set to "Automatic setting (__ 1)" in [Pr. PB02], this parameter will be set automatically. Set manually for "Manual setting (__ 2)". For details, refer to section 7.1.5 of "MR-JE-_A Servo Amplifier Instruction Manual". Setting range: 0.00 to 0.30	0.00	○	○			
PB23 VFBF Low-pass filter selection	___ x	Shaft resonance suppression filter selection Select the shaft resonance suppression filter. 0: Automatic setting 1: Manual setting 2: Disabled When you select "Enabled (__ 1)" of "Machine resonance suppression filter 4 selection" in [Pr. PB49], the shaft resonance suppression filter is not available.	0h	○	○			
	__ x _	Low-pass filter selection Select the low-pass filter. 0: Automatic setting 1: Manual setting 2: Disabled	0h	○	○			
	_ x _ _	For manufacturer setting	1h					
	x _ _ _		0h					

7. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode	
				C P	C L
PB24 *MVS Slight vibration suppression control	___x	Slight vibration suppression control selection Select the slight vibration suppression control. 0: Disabled 1: Enabled To enable the slight vibration suppression control, set "Gain adjustment mode selection" to "Manual mode (___3)" in [Pr. PA08].	0h	<input type="radio"/>	<input type="radio"/>
	__x_	For manufacturer setting	0h	<input type="checkbox"/>	<input type="checkbox"/>
	_x__		0h	<input type="checkbox"/>	<input type="checkbox"/>
	x___		0h	<input type="checkbox"/>	<input type="checkbox"/>
PB25 *BOP1 Function selection B-1	___x	For manufacturer setting	0h	<input type="checkbox"/>	<input type="checkbox"/>
	__x_	Position acceleration/deceleration filter type selection Select the position acceleration/deceleration filter type. 0: Primary delay 1: Linear acceleration/deceleration	0h	<input type="radio"/>	<input type="radio"/>
	_x__	For manufacturer setting	0h	<input type="checkbox"/>	<input type="checkbox"/>
	x___		0h	<input type="checkbox"/>	<input type="checkbox"/>
PB26 *CDP Gain switching function	Select the gain switching condition. Set conditions to enable the gain switching values set in [Pr. PB29] to [Pr. PB36] and [Pr. PB56] to [Pr. PB60].				
	___x	Gain switching selection 0: Disabled 1: Input device (gain switching (CDP)) 2: Command frequency 3: Droop pulses 4: Servo motor speed	0h	<input type="radio"/>	<input type="radio"/>
	__x_	Gain switching condition selection 0: Gain after switching is enabled with gain switching condition or more 1: Gain after switching is enabled with gain switching condition or less	0h	<input type="radio"/>	<input type="radio"/>
	_x__	For manufacturer setting	0h	<input type="checkbox"/>	<input type="checkbox"/>
	x___		0h	<input type="checkbox"/>	<input type="checkbox"/>
PB27 CDL Gain switching condition		Set the value of the gain switching (command frequency, droop pulses, or servo motor speed) selected in [Pr. PB26]. The set value unit differs depending on the switching condition item. (Refer to section 7.2.3 of "MR-JE-_A Servo Amplifier Instruction Manual".) Setting range: 0 to 9999	10 [kpulse/s]/ [pulse]/ [r/min]	<input type="radio"/>	<input type="radio"/>
PB28 CDT Gain switching time constant		Set the time constant at which the gains will change in response to the conditions set in [Pr. PB26] and [Pr. PB27]. Setting range: 0 to 100	1 [ms]	<input type="radio"/>	<input type="radio"/>
PB29 GD2B Load to motor inertia ratio after gain switching		Set the load to motor inertia ratio when gain switching is enabled. This parameter is enabled only when "Gain adjustment mode selection" is set to "Manual mode (___3)" in [Pr. PA08]. Setting range: 0.00 to 300.00	7.00 [times]	<input type="radio"/>	<input type="radio"/>

7. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode	
				C P	C L
PB30 PG2B Position loop gain after gain switching		Set the position loop gain for when the gain switching is enabled. When a value less than 1.0 rad/s is set, the value will be the same as that of [Pr. PB08]. This parameter is enabled only when "Gain adjustment mode selection" is set to "Manual mode (___ 3)" in [Pr. PA08]. Setting range: 0.0 to 2000.0	0.0 [rad/s]	<input type="radio"/>	<input type="radio"/>
PB31 VG2B Speed loop gain after gain switching		Set the speed loop gain for when the gain switching is enabled. When a value less than 20 rad/s is set, the value will be the same as that of [Pr. PB09]. This parameter is enabled only when "Gain adjustment mode selection" is set to "Manual mode (___ 3)" in [Pr. PA08]. Setting range: 0 to 65535	0 [rad/s]	<input type="radio"/>	<input type="radio"/>
PB32 VICB Speed integral compensation after gain switching		Set the speed integral compensation for when the gain switching is enabled. When a value less than 0.1 ms is set, the value will be the same as that of [Pr. PB10]. This parameter is enabled only when "Gain adjustment mode selection" is set to "Manual mode (___ 3)" in [Pr. PA08]. Setting range: 0.0 to 5000.0	0.0 [ms]	<input type="radio"/>	<input type="radio"/>
PB33 VRF1B Vibration suppression control 1 - Vibration frequency after gain switching		Set the vibration frequency for vibration suppression control 1 for when the gain switching is enabled. When a value less than 0.1 Hz is set, the value will be the same as that of [Pr. PB19]. This parameter will be enabled only when the following conditions are fulfilled. <ul style="list-style-type: none"> - "Gain adjustment mode selection" is set to "Manual mode (___ 3)" in [Pr. PA08]. - "Vibration suppression control 1 tuning mode selection" is set to "Manual setting (___ 2)" in [Pr. PB02]. - "Gain switching selection" is set to "Input device (gain switching (CDP)) (___ 1)" in [Pr. PB26]. Switching during driving may cause a shock. Be sure to switch them after the servo motor stops. Setting range: 0.0 to 300.0	0.0 [Hz]	<input type="radio"/>	<input type="radio"/>
PB34 VRF2B Vibration suppression control 1 - Resonance frequency after gain switching		Set the resonance frequency for vibration suppression control 1 for when the gain switching is enabled. When a value less than 0.1 Hz is set, the value will be the same as that of [Pr. PB20]. This parameter will be enabled only when the following conditions are fulfilled. <ul style="list-style-type: none"> - "Gain adjustment mode selection" in [Pr. PA08] is "Manual mode (___ 3)". - "Vibration suppression control 1 tuning mode selection" is set to "Manual setting (___ 2)" in [Pr. PB02]. - "Gain switching selection" is set to "Input device (gain switching (CDP)) (___ 1)" in [Pr. PB26]. Switching during driving may cause a shock. Be sure to switch them after the servo motor stops. Setting range: 0.0 to 300.0	0.0 [Hz]	<input type="radio"/>	<input type="radio"/>
PB35 VRF3B Vibration suppression control 1 - Vibration frequency damping after gain switching		Set a damping of the vibration frequency for vibration suppression control 1 when the gain switching is enabled. This parameter will be enabled only when the following conditions are fulfilled. <ul style="list-style-type: none"> - "Gain adjustment mode selection" is set to "Manual mode (___ 3)" in [Pr. PA08]. - "Vibration suppression control 1 tuning mode selection" is set to "Manual setting (___ 2)" in [Pr. PB02]. - "Gain switching selection" is set to "Input device (gain switching (CDP)) (___ 1)" in [Pr. PB26]. Switching during driving may cause a shock. Be sure to switch them after the servo motor stops. Setting range: 0.00 to 0.30	0.00	<input type="radio"/>	<input type="radio"/>

7. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode	
				C P	C L
PB36 VRF4B Vibration suppression control 1 - Resonance frequency damping after gain switching		<p>Set a damping of the resonance frequency for vibration suppression control 1 when the gain switching is enabled.</p> <p>This parameter will be enabled only when the following conditions are fulfilled.</p> <ul style="list-style-type: none"> ▪ "Gain adjustment mode selection" is set to "Manual mode (_ _ _ 3)" in [Pr. PA08]. ▪ "Vibration suppression control 1 tuning mode selection" is set to "Manual setting (_ _ _ 2)" in [Pr. PB02]. ▪ "Gain switching selection" is set to "Input device (gain switching (CDP)) (_ _ _ 1)" in [Pr. PB26]. <p>Switching during driving may cause a shock. Be sure to switch them after the servo motor stops.</p> <p>Setting range: 0.00 to 0.30</p>	0.00	○	○

7. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode																																																																																																																																																																																																							
				C P	C L																																																																																																																																																																																																						
PB45 CNHF Command notch filter	Set the command notch filter.																																																																																																																																																																																																										
	__ x x	Command notch filter setting frequency selection Refer to table 7.6 for the relation of setting values to frequency.	00h	<input type="radio"/>	<input type="radio"/>																																																																																																																																																																																																						
	_ x _ _	Notch depth selection Refer to table 7.7 for details.	0h	<input type="radio"/>	<input type="radio"/>																																																																																																																																																																																																						
	x _ _ _	For manufacturer setting	0h	<input type="checkbox"/>	<input type="checkbox"/>																																																																																																																																																																																																						
Table 7.6 Command notch filter setting frequency selection																																																																																																																																																																																																											
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Setting value</th> <th>Frequency [Hz]</th> <th>Setting value</th> <th>Frequency [Hz]</th> <th>Setting value</th> <th>Frequency [Hz]</th> </tr> </thead> <tbody> <tr><td>00</td><td>Disabled</td><td>20</td><td>70</td><td>40</td><td>17.6</td></tr> <tr><td>01</td><td>2250</td><td>21</td><td>66</td><td>41</td><td>16.5</td></tr> <tr><td>02</td><td>1125</td><td>22</td><td>62</td><td>42</td><td>15.6</td></tr> <tr><td>03</td><td>750</td><td>23</td><td>59</td><td>43</td><td>14.8</td></tr> <tr><td>04</td><td>562</td><td>24</td><td>56</td><td>44</td><td>14.1</td></tr> <tr><td>05</td><td>450</td><td>25</td><td>53</td><td>45</td><td>13.4</td></tr> <tr><td>06</td><td>375</td><td>26</td><td>51</td><td>46</td><td>12.8</td></tr> <tr><td>07</td><td>321</td><td>27</td><td>48</td><td>47</td><td>12.2</td></tr> <tr><td>08</td><td>281</td><td>28</td><td>46</td><td>48</td><td>11.7</td></tr> <tr><td>09</td><td>250</td><td>29</td><td>45</td><td>49</td><td>11.3</td></tr> <tr><td>0A</td><td>225</td><td>2A</td><td>43</td><td>4A</td><td>10.8</td></tr> <tr><td>0B</td><td>204</td><td>2B</td><td>41</td><td>4B</td><td>10.4</td></tr> <tr><td>0C</td><td>187</td><td>2C</td><td>40</td><td>4C</td><td>10</td></tr> <tr><td>0D</td><td>173</td><td>2D</td><td>38</td><td>4D</td><td>9.7</td></tr> <tr><td>0E</td><td>160</td><td>2E</td><td>37</td><td>4E</td><td>9.4</td></tr> <tr><td>0F</td><td>150</td><td>2F</td><td>36</td><td>4F</td><td>9.1</td></tr> <tr><td>10</td><td>140</td><td>30</td><td>35.2</td><td>50</td><td>8.8</td></tr> <tr><td>11</td><td>132</td><td>31</td><td>33.1</td><td>51</td><td>8.3</td></tr> <tr><td>12</td><td>125</td><td>32</td><td>31.3</td><td>52</td><td>7.8</td></tr> <tr><td>13</td><td>118</td><td>33</td><td>29.6</td><td>53</td><td>7.4</td></tr> <tr><td>14</td><td>112</td><td>34</td><td>28.1</td><td>54</td><td>7.0</td></tr> <tr><td>15</td><td>107</td><td>35</td><td>26.8</td><td>55</td><td>6.7</td></tr> <tr><td>16</td><td>102</td><td>36</td><td>25.6</td><td>56</td><td>6.4</td></tr> <tr><td>17</td><td>97</td><td>37</td><td>24.5</td><td>57</td><td>6.1</td></tr> <tr><td>18</td><td>93</td><td>38</td><td>23.4</td><td>58</td><td>5.9</td></tr> <tr><td>19</td><td>90</td><td>39</td><td>22.5</td><td>59</td><td>5.6</td></tr> <tr><td>1A</td><td>86</td><td>3A</td><td>21.6</td><td>5A</td><td>5.4</td></tr> <tr><td>1B</td><td>83</td><td>3B</td><td>20.8</td><td>5B</td><td>5.2</td></tr> <tr><td>1C</td><td>80</td><td>3C</td><td>20.1</td><td>5C</td><td>5.0</td></tr> <tr><td>1D</td><td>77</td><td>3D</td><td>19.4</td><td>5D</td><td>4.9</td></tr> <tr><td>1E</td><td>75</td><td>3E</td><td>18.8</td><td>5E</td><td>4.7</td></tr> <tr><td>1F</td><td>72</td><td>3F</td><td>18.2</td><td>5F</td><td>4.5</td></tr> </tbody> </table>						Setting value	Frequency [Hz]	Setting value	Frequency [Hz]	Setting value	Frequency [Hz]	00	Disabled	20	70	40	17.6	01	2250	21	66	41	16.5	02	1125	22	62	42	15.6	03	750	23	59	43	14.8	04	562	24	56	44	14.1	05	450	25	53	45	13.4	06	375	26	51	46	12.8	07	321	27	48	47	12.2	08	281	28	46	48	11.7	09	250	29	45	49	11.3	0A	225	2A	43	4A	10.8	0B	204	2B	41	4B	10.4	0C	187	2C	40	4C	10	0D	173	2D	38	4D	9.7	0E	160	2E	37	4E	9.4	0F	150	2F	36	4F	9.1	10	140	30	35.2	50	8.8	11	132	31	33.1	51	8.3	12	125	32	31.3	52	7.8	13	118	33	29.6	53	7.4	14	112	34	28.1	54	7.0	15	107	35	26.8	55	6.7	16	102	36	25.6	56	6.4	17	97	37	24.5	57	6.1	18	93	38	23.4	58	5.9	19	90	39	22.5	59	5.6	1A	86	3A	21.6	5A	5.4	1B	83	3B	20.8	5B	5.2	1C	80	3C	20.1	5C	5.0	1D	77	3D	19.4	5D	4.9	1E	75	3E	18.8	5E	4.7	1F	72	3F	18.2	5F	4.5
Setting value	Frequency [Hz]	Setting value	Frequency [Hz]	Setting value	Frequency [Hz]																																																																																																																																																																																																						
00	Disabled	20	70	40	17.6																																																																																																																																																																																																						
01	2250	21	66	41	16.5																																																																																																																																																																																																						
02	1125	22	62	42	15.6																																																																																																																																																																																																						
03	750	23	59	43	14.8																																																																																																																																																																																																						
04	562	24	56	44	14.1																																																																																																																																																																																																						
05	450	25	53	45	13.4																																																																																																																																																																																																						
06	375	26	51	46	12.8																																																																																																																																																																																																						
07	321	27	48	47	12.2																																																																																																																																																																																																						
08	281	28	46	48	11.7																																																																																																																																																																																																						
09	250	29	45	49	11.3																																																																																																																																																																																																						
0A	225	2A	43	4A	10.8																																																																																																																																																																																																						
0B	204	2B	41	4B	10.4																																																																																																																																																																																																						
0C	187	2C	40	4C	10																																																																																																																																																																																																						
0D	173	2D	38	4D	9.7																																																																																																																																																																																																						
0E	160	2E	37	4E	9.4																																																																																																																																																																																																						
0F	150	2F	36	4F	9.1																																																																																																																																																																																																						
10	140	30	35.2	50	8.8																																																																																																																																																																																																						
11	132	31	33.1	51	8.3																																																																																																																																																																																																						
12	125	32	31.3	52	7.8																																																																																																																																																																																																						
13	118	33	29.6	53	7.4																																																																																																																																																																																																						
14	112	34	28.1	54	7.0																																																																																																																																																																																																						
15	107	35	26.8	55	6.7																																																																																																																																																																																																						
16	102	36	25.6	56	6.4																																																																																																																																																																																																						
17	97	37	24.5	57	6.1																																																																																																																																																																																																						
18	93	38	23.4	58	5.9																																																																																																																																																																																																						
19	90	39	22.5	59	5.6																																																																																																																																																																																																						
1A	86	3A	21.6	5A	5.4																																																																																																																																																																																																						
1B	83	3B	20.8	5B	5.2																																																																																																																																																																																																						
1C	80	3C	20.1	5C	5.0																																																																																																																																																																																																						
1D	77	3D	19.4	5D	4.9																																																																																																																																																																																																						
1E	75	3E	18.8	5E	4.7																																																																																																																																																																																																						
1F	72	3F	18.2	5F	4.5																																																																																																																																																																																																						
Table 7.7 Notch depth selection																																																																																																																																																																																																											
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Setting value</th> <th>Depth [dB]</th> <th>Setting value</th> <th>Depth [dB]</th> </tr> </thead> <tbody> <tr><td>0</td><td>-40.0</td><td>8</td><td>-6.0</td></tr> <tr><td>1</td><td>-24.1</td><td>9</td><td>-5.0</td></tr> <tr><td>2</td><td>-18.1</td><td>A</td><td>-4.1</td></tr> <tr><td>3</td><td>-14.5</td><td>B</td><td>-3.3</td></tr> <tr><td>4</td><td>-12.0</td><td>C</td><td>-2.5</td></tr> <tr><td>5</td><td>-10.1</td><td>D</td><td>-1.8</td></tr> <tr><td>6</td><td>-8.5</td><td>E</td><td>-1.2</td></tr> <tr><td>7</td><td>-7.2</td><td>F</td><td>-0.6</td></tr> </tbody> </table>						Setting value	Depth [dB]	Setting value	Depth [dB]	0	-40.0	8	-6.0	1	-24.1	9	-5.0	2	-18.1	A	-4.1	3	-14.5	B	-3.3	4	-12.0	C	-2.5	5	-10.1	D	-1.8	6	-8.5	E	-1.2	7	-7.2	F	-0.6																																																																																																																																																																		
Setting value	Depth [dB]	Setting value	Depth [dB]																																																																																																																																																																																																								
0	-40.0	8	-6.0																																																																																																																																																																																																								
1	-24.1	9	-5.0																																																																																																																																																																																																								
2	-18.1	A	-4.1																																																																																																																																																																																																								
3	-14.5	B	-3.3																																																																																																																																																																																																								
4	-12.0	C	-2.5																																																																																																																																																																																																								
5	-10.1	D	-1.8																																																																																																																																																																																																								
6	-8.5	E	-1.2																																																																																																																																																																																																								
7	-7.2	F	-0.6																																																																																																																																																																																																								

7. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode	
				C P	C L
PB46 NH3 Machine resonance suppression filter 3		Set the notch frequency of the machine resonance suppression filter 3. To enable the setting value, set "Machine resonance suppression filter 3 selection" to "Enabled (___ 1)" in [Pr. PB47]. Setting range: 10 to 4500	4500 [Hz]	<input type="radio"/>	<input type="radio"/>
PB47 NHQ3 Notch shape selection 3		Set forms of the machine resonance suppression filter 3.			
	___ x	Machine resonance suppression filter 3 selection 0: Disabled 1: Enabled	0h	<input type="radio"/>	<input type="radio"/>
	__ x _	Notch depth selection 0: -40 dB 1: -14 dB 2: -8 dB 3: -4 dB	0h	<input type="radio"/>	<input type="radio"/>
	_ x __	Notch width selection 0: $\alpha = 2$ 1: $\alpha = 3$ 2: $\alpha = 4$ 3: $\alpha = 5$	0h	<input type="radio"/>	<input type="radio"/>
	x ___	For manufacturer setting	0h	<input type="radio"/>	<input type="radio"/>
PB48 NH4 Machine resonance suppression filter 4		Set the notch frequency of the machine resonance suppression filter 4. To enable the setting value, set "Machine resonance suppression filter 4 selection" to "Enabled (___ 1)" in [Pr. PB49]. Setting range: 10 to 4500	4500 [Hz]	<input type="radio"/>	<input type="radio"/>
PB49 NHQ4 Notch shape selection 4		Set forms of the machine resonance suppression filter 4.			
	___ x	Machine resonance suppression filter 4 selection 0: Disabled 1: Enabled When "Enabled" is set, [Pr. PB17 Shaft resonance suppression filter] is not available.	0h	<input type="radio"/>	<input type="radio"/>
	__ x _	Notch depth selection 0: -40 dB 1: -14 dB 2: -8 dB 3: -4 dB	0h	<input type="radio"/>	<input type="radio"/>
	_ x __	Notch width selection 0: $\alpha = 2$ 1: $\alpha = 3$ 2: $\alpha = 4$ 3: $\alpha = 5$	0h	<input type="radio"/>	<input type="radio"/>
	x ___	For manufacturer setting	0h	<input type="radio"/>	<input type="radio"/>
PB50 NH5 Machine resonance suppression filter 5		Set the notch frequency of the machine resonance suppression filter 5. To enable the setting value, set "Machine resonance suppression filter 5 selection" to "Enabled (___ 1)" in [Pr. PB51]. Setting range: 10 to 4500	4500 [Hz]	<input type="radio"/>	<input type="radio"/>

7. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode	
				C P	C L
PB51 NHQ5 Notch shape selection 5	___x	Machine resonance suppression filter 5 selection 0: Disabled 1: Enabled	0h	<input type="radio"/>	<input type="radio"/>
	--x_	Notch depth selection 0: -40 dB 1: -14 dB 2: -8 dB 3: -4 dB	0h	<input type="radio"/>	<input type="radio"/>
	_x__	Notch width selection 0: $\alpha = 2$ 1: $\alpha = 3$ 2: $\alpha = 4$ 3: $\alpha = 5$	0h	<input type="radio"/>	<input type="radio"/>
	x___	For manufacturer setting	0h	<input type="radio"/>	<input type="radio"/>
PB52 VRF21 Vibration suppression control 2 - Vibration frequency		Set the vibration frequency for vibration suppression control 2 to suppress low-frequency machine vibration. When "Vibration suppression control 2 tuning mode selection" is set to "Automatic setting (_ _ 1 _)" in [Pr. PB02], this parameter will be set automatically. Set manually for "Manual setting (_ _ 2 _)". To enable the digit, set "Vibration suppression mode selection" to "3 inertia mode (_ _ 1)" in [Pr. PA24]. Setting range: 0.1 to 300.0	100.0 [Hz]	<input type="radio"/>	<input type="radio"/>
PB53 VRF22 Vibration suppression control 2 - Resonance frequency		Set the resonance frequency for vibration suppression control 2 to suppress low-frequency machine vibration. When "Vibration suppression control 2 tuning mode selection" is set to "Automatic setting (_ _ 1 _)" in [Pr. PB02], this parameter will be set automatically. Set manually for "Manual setting (_ _ 2 _)". To enable the digit, set "Vibration suppression mode selection" to "3 inertia mode (_ _ 1)" in [Pr. PA24]. Setting range: 0.1 to 300.0	100.0 [Hz]	<input type="radio"/>	<input type="radio"/>
PB54 VRF23 Vibration suppression control 2 - Vibration frequency damping		Set a damping of the vibration frequency for vibration suppression control 2 to suppress low-frequency machine vibration. When "Vibration suppression control 2 tuning mode selection" is set to "Automatic setting (_ _ 1 _)" in [Pr. PB02], this parameter will be set automatically. Set manually for "Manual setting (_ _ 2 _)". To enable the digit, set "Vibration suppression mode selection" to "3 inertia mode (_ _ 1)" in [Pr. PA24]. Setting range: 0.00 to 0.30	0.00	<input type="radio"/>	<input type="radio"/>
PB55 VRF24 Vibration suppression control 2 - Resonance frequency damping		Set a damping of the resonance frequency for vibration suppression control 2 to suppress low-frequency machine vibration. When "Vibration suppression control 2 tuning mode selection" is set to "Automatic setting (_ _ 1 _)" in [Pr. PB02], this parameter will be set automatically. Set manually for "Manual setting (_ _ 2 _)". To enable the digit, set "Vibration suppression mode selection" to "3 inertia mode (_ _ 1)" in [Pr. PA24]. Setting range: 0.00 to 0.30	0.00	<input type="radio"/>	<input type="radio"/>

7. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode	
				C P	C L
PB56 VRF21B Vibration suppression control 2 - Vibration frequency after gain switching		<p>Set the vibration frequency for vibration suppression control 2 for when the gain switching is enabled. When a value less than 0.1 Hz is set, the value will be the same as that of [Pr. PB52]. This parameter will be enabled only when the following conditions are fulfilled.</p> <ul style="list-style-type: none"> • "Gain adjustment mode selection" is set to "Manual mode (___ 3)" in [Pr. PA08]. • "Vibration suppression mode selection" is set to "3 inertia mode (___ 1)" in [Pr. PA24]. • "Vibration suppression control 2 tuning mode selection" is set to "Manual setting (_ 2 _)" in [Pr. PB02]. • "Gain switching selection" is set to "Input device (gain switching (CDP)) (___ 1)" in [Pr. PB26]. <p>Switching during driving may cause a shock. Be sure to switch them after the servo motor stops.</p> <p>Setting range: 0.0 to 300.0</p>	0.0 [Hz]	<input type="radio"/>	<input type="radio"/>
PB57 VRF22B Vibration suppression control 2 - Resonance frequency after gain switching		<p>Set the resonance frequency for vibration suppression control 2 for when the gain switching is enabled. When a value less than 0.1 Hz is set, the value will be the same as that of [Pr. PB53]. This parameter will be enabled only when the following conditions are fulfilled.</p> <ul style="list-style-type: none"> • "Gain adjustment mode selection" is set to "Manual mode (___ 3)" in [Pr. PA08]. • "Vibration suppression mode selection" is set to "3 inertia mode (___ 1)" in [Pr. PA24]. • "Vibration suppression control 2 tuning mode selection" is set to "Manual setting (_ 2 _)" in [Pr. PB02]. • "Gain switching selection" is set to "Input device (gain switching (CDP)) (___ 1)" in [Pr. PB26]. <p>Switching during driving may cause a shock. Be sure to switch them after the servo motor stops.</p> <p>Setting range: 0.0 to 300.0</p>	0.0 [Hz]	<input type="radio"/>	<input type="radio"/>
PB58 VRF23B Vibration suppression control 2 - Vibration frequency damping after gain switching		<p>Set a damping of the vibration frequency for vibration suppression control 2 when the gain switching is enabled. This parameter will be enabled only when the following conditions are fulfilled.</p> <ul style="list-style-type: none"> • "Gain adjustment mode selection" is set to "Manual mode (___ 3)" in [Pr. PA08]. • "Vibration suppression mode selection" is set to "3 inertia mode (___ 1)" in [Pr. PA24]. • "Vibration suppression control 2 tuning mode selection" is set to "Manual setting (_ 2 _)" in [Pr. PB02]. • "Gain switching selection" is set to "Input device (gain switching (CDP)) (___ 1)" in [Pr. PB26]. <p>Switching during driving may cause a shock. Be sure to switch them after the servo motor stops.</p> <p>Setting range: 0.00 to 0.30</p>	0.00	<input type="radio"/>	<input type="radio"/>
PB59 VRF24B Vibration suppression control 2 - Resonance frequency damping after gain switching		<p>Set a damping of the resonance frequency for vibration suppression control 2 when the gain switching is enabled. This parameter will be enabled only when the following conditions are fulfilled.</p> <ul style="list-style-type: none"> • "Gain adjustment mode selection" is set to "Manual mode (___ 3)" in [Pr. PA08]. • "Vibration suppression mode selection" is set to "3 inertia mode (___ 1)" in [Pr. PA24]. • "Vibration suppression control 2 tuning mode selection" is set to "Manual setting (_ 2 _)" in [Pr. PB02]. • "Gain switching selection" is set to "Input device (gain switching (CDP)) (___ 1)" in [Pr. PB26]. <p>Switching during driving may cause a shock. Be sure to switch them after the servo motor stops.</p> <p>Setting range: 0.00 to 0.30</p>	0.00	<input type="radio"/>	<input type="radio"/>

7. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode	
				C P	C L
PB60 PG1B Model loop gain after gain switching		<p>Set the model loop gain for when the gain switching is enabled.</p> <p>When a value less than 1.0 rad/s is set, the value will be the same as that of [Pr. PB07].</p> <p>This parameter will be enabled only when the following conditions are fulfilled.</p> <ul style="list-style-type: none"> ▪ "Gain adjustment mode selection" is set to "Manual mode (___ 3)" in [Pr. PA08]. ▪ "Gain switching selection" is set to "Input device (gain switching (CDP)) (___ 1)" in [Pr. PB26]. <p>Switching during driving may cause a shock. Be sure to switch them after the servo motor stops.</p> <p>Setting range: 0.0 to 2000.0</p>	0.0 [rad/s]	<input type="radio"/>	<input type="radio"/>

7.2.3 Extension setting parameters ([Pr. PC__])

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode	
				C P	C L
PC01 STA JOG operation acceleration time constant		<p>Set an acceleration time constant for the JOG operation of the program method.</p> <p>Set an acceleration time from 0 r/min to the rated speed.</p> <div style="text-align: center;"> </div> <p>For example for the servo motor of 3000 r/min rated speed, set 3000 (3s) to increase speed from 0 r/min to 1000 r/min in 1 s.</p> <p>Additionally, when 20000 ms or more value is set, it will be clamped to 20000 ms.</p> <p>Setting range: 0 to 50000</p>	0 [ms]	<input type="radio"/>	<input type="radio"/>

7. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode	
				C P	C L
PC02 STB JOG operation deceleration time constant		<p>Set a deceleration time constant for the JOG operation of the program method. Set a deceleration time from the rated speed to 0 r/min. Additionally, when 20000 ms or more value is set, it will be clamped to 20000 ms.</p> <p>Setting range: 0 to 50000</p>	0 [ms]		○
PC03 *STC S-pattern acceleration/d eceleration time constant		<p>This parameter is used to smooth start/stop of the servo motor. Set the time of the arc part for S-pattern acceleration/deceleration. Servo is usually operated with linear acceleration and deceleration; however, smooth start and stop are enabled by setting [Pr. PC03 S-pattern acceleration/deceleration time constants]. When the S-pattern acceleration/deceleration time constants are set, smooth positioning is enabled as shown in the following figure. Note that when it is set, a time period from the start to output of MEND (Travel completion) is longer by the S-pattern acceleration/deceleration time constants.</p> <p>When the STC value is set longer than the constant speed time, the speed may not reach to the command speed. Additionally, when 1000 ms or more value is set, it will be clamped to 1000 ms.</p> <p>Setting range: 0 to 5000</p>	0 [ms]	○	○

























7. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode																																			
				C P	C L																																		
PC14 MOD1 Analog monitor 1 output	-- x x	Analog monitor 1 output selection Select a signal to output to MO1 (Analog monitor 1). Refer to appendix 8.3 of "MR-JE-_A Servo Amplifier Instruction Manual" for detection point of output selection. Refer to table 7.8 or 7.9 for settings.	00h	<input type="radio"/>	<input type="radio"/>																																		
	_ x _ _	For manufacturer setting	0h	<input type="checkbox"/>	<input type="checkbox"/>																																		
	x _ _ _		0h	<input type="checkbox"/>	<input type="checkbox"/>																																		
<p>Table 7.8 Analog monitor setting value</p> <table border="1"> <thead> <tr> <th>Setting value</th> <th>Item</th> </tr> </thead> <tbody> <tr><td>00</td><td>Servo motor speed (± 8 V/max. speed) (Note 1)</td></tr> <tr><td>01</td><td>Torque (± 8 V/max. torque) (Note 3)</td></tr> <tr><td>02</td><td>Servo motor speed (+8 V/max. speed) (Note 1)</td></tr> <tr><td>03</td><td>Torque (+8 V/max. torque) (Note 3)</td></tr> <tr><td>04</td><td>Current command (± 8 V/max. current command)</td></tr> <tr><td>05</td><td>Command pulse frequency (± 10 V/± 4 Mpulses/s)</td></tr> <tr><td>06</td><td>Servo motor-side droop pulses (± 10 V/100 pulses) (Note 2)</td></tr> <tr><td>07</td><td>Servo motor-side droop pulses (± 10 V/1000 pulses) (Note 2)</td></tr> <tr><td>08</td><td>Servo motor-side droop pulses (± 10 V/10000 pulses) (Note 2)</td></tr> <tr><td>09</td><td>Servo motor-side droop pulses (± 10 V/100000 pulses) (Note 2)</td></tr> <tr><td>0A</td><td>Feedback position (± 10 V/1 Mpulses) (Note 2)</td></tr> <tr><td>0B</td><td>Feedback position (± 10 V/10 Mpulses) (Note 2)</td></tr> <tr><td>0C</td><td>Feedback position (± 10 V/100 Mpulses) (Note 2)</td></tr> <tr><td>0D</td><td>Bus voltage (+8 V/400 V)</td></tr> <tr><td>0E</td><td>Speed command 2 (± 8 V/max. speed)</td></tr> <tr><td>17</td><td>Encoder inside temperature (± 10 V/± 128 °C)</td></tr> </tbody> </table> <p>Note 1. The maximum speed of the HF-KN series servo motor is 4500 r/min and that of the HG-KN series is 5000 r/min. Please watch out when using an HG-KN series servo motor as a replacement for the HF-KN series servo motor because HG-KN series outputs 8 V at 5000 r/min.</p> <p>Note 2. Encoder pulse unit</p> <p>Note 3. The value in [Pr. PA11] or [Pr. PA12] whichever is higher is applied for the maximum torque.</p>						Setting value	Item	00	Servo motor speed (± 8 V/max. speed) (Note 1)	01	Torque (± 8 V/max. torque) (Note 3)	02	Servo motor speed (+8 V/max. speed) (Note 1)	03	Torque (+8 V/max. torque) (Note 3)	04	Current command (± 8 V/max. current command)	05	Command pulse frequency (± 10 V/ ± 4 Mpulses/s)	06	Servo motor-side droop pulses (± 10 V/100 pulses) (Note 2)	07	Servo motor-side droop pulses (± 10 V/1000 pulses) (Note 2)	08	Servo motor-side droop pulses (± 10 V/10000 pulses) (Note 2)	09	Servo motor-side droop pulses (± 10 V/100000 pulses) (Note 2)	0A	Feedback position (± 10 V/1 Mpulses) (Note 2)	0B	Feedback position (± 10 V/10 Mpulses) (Note 2)	0C	Feedback position (± 10 V/100 Mpulses) (Note 2)	0D	Bus voltage (+8 V/400 V)	0E	Speed command 2 (± 8 V/max. speed)	17	Encoder inside temperature (± 10 V/ ± 128 °C)
Setting value	Item																																						
00	Servo motor speed (± 8 V/max. speed) (Note 1)																																						
01	Torque (± 8 V/max. torque) (Note 3)																																						
02	Servo motor speed (+8 V/max. speed) (Note 1)																																						
03	Torque (+8 V/max. torque) (Note 3)																																						
04	Current command (± 8 V/max. current command)																																						
05	Command pulse frequency (± 10 V/ ± 4 Mpulses/s)																																						
06	Servo motor-side droop pulses (± 10 V/100 pulses) (Note 2)																																						
07	Servo motor-side droop pulses (± 10 V/1000 pulses) (Note 2)																																						
08	Servo motor-side droop pulses (± 10 V/10000 pulses) (Note 2)																																						
09	Servo motor-side droop pulses (± 10 V/100000 pulses) (Note 2)																																						
0A	Feedback position (± 10 V/1 Mpulses) (Note 2)																																						
0B	Feedback position (± 10 V/10 Mpulses) (Note 2)																																						
0C	Feedback position (± 10 V/100 Mpulses) (Note 2)																																						
0D	Bus voltage (+8 V/400 V)																																						
0E	Speed command 2 (± 8 V/max. speed)																																						
17	Encoder inside temperature (± 10 V/ ± 128 °C)																																						

7. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode	
				C P	C L
PC15 MOD2 Analog monitor 2 output	-- x x	Analog monitor 2 output selection Select a signal to output to MO2 (Analog monitor 2). Refer to appendix 8.3 of "MR-JE-_A Servo Amplifier Instruction Manual" for detection point of output selection. Refer to [Pr. PC14] for settings.	01h	<input type="radio"/>	<input type="radio"/>
	_ x _ _	For manufacturer setting	0h	<input type="checkbox"/>	<input type="checkbox"/>
	x _ _ _		0h	<input type="checkbox"/>	<input type="checkbox"/>
PC16 MBR Electromagne tic brake sequence output	/	Set the delay time from when MBR (Electromagnetic brake interlock) turns off till when the base drive circuit is shut-off. Setting range: 0 to 1000	0 [ms]	<input type="radio"/>	<input type="radio"/>
PC17 ZSP Zero speed	/	Set an output range of ZSP (Zero speed detection). ZSP (Zero speed detection) has hysteresis of 20 r/min. Setting range: 0 to 10000	50 [r/min]	<input type="radio"/>	<input type="radio"/>
PC18 *BPS Alarm history clear	_ _ _ x	Alarm history clear selection This parameter is used to clear the alarm history. 0: Disabled 1: Enabled When "Enabled" is set, the alarm history will be cleared at the next power-on. After the alarm history is cleared, the setting is automatically disabled.	0h	<input type="radio"/>	<input type="radio"/>
	_ _ x _	For manufacturer setting	0h	<input type="checkbox"/>	<input type="checkbox"/>
	_ x _ _		0h	<input type="checkbox"/>	<input type="checkbox"/>
	x _ _ _		0h	<input type="checkbox"/>	<input type="checkbox"/>

7. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode												
				C P	C L											
PC19 *ENRS Encoder output pulse selection	___x	Encoder output pulse phase selection Select an encoder pulse direction. 0: Increasing A-phase 90° in CCW 1: Increasing A-phase 90° in CW <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th rowspan="2">Setting value</th> <th colspan="2">Servo motor rotation direction</th> </tr> <tr> <th>CCW</th> <th>CW</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>A-phase  B-phase </td> <td>A-phase  B-phase </td> </tr> <tr> <td>1</td> <td>A-phase  B-phase </td> <td>A-phase  B-phase </td> </tr> </tbody> </table>	Setting value	Servo motor rotation direction		CCW	CW	0	A-phase  B-phase 	A-phase  B-phase 	1	A-phase  B-phase 	A-phase  B-phase 	0h	<input type="radio"/>	<input type="radio"/>
	Setting value	Servo motor rotation direction														
		CCW	CW													
	0	A-phase  B-phase 	A-phase  B-phase 													
1	A-phase  B-phase 	A-phase  B-phase 														
__x_	Encoder output pulse setting selection 0: Output pulse setting 1: Division ratio setting 2: The same output pulse setting as the command pulse 3: A-phase/B-phase pulse electronic gear setting 5: Command pulse input through output setting When "1" is set, the settings of [Pr. PA16 Encoder output pulses 2] will be disabled. When "2" is set, the settings of [Pr. PA15 Encoder output pulses] and [Pr. PA16 Encoder output pulses 2] will be disabled. When using this setting, do not change the settings in [Pr. PA06] and [Pr. PA07] after the power-on. When "5" is set, the settings of [Pr. PA15 Encoder output pulses] and [Pr. PA16 Encoder output pulses 2] will be disabled. "Encoder output pulse phase selection (___x)" and "Encoder selection for encoder output pulse (x___)" will be also disabled. When [Pr. PA01] is set to other than "Point table method (___6)" and "Program method (___7)", [AL. 37 Parameter error] occurs. When "5" is set, assign PP/PP2 with [Pr. PD44] and NP/NP2 with [Pr. PD46].	0h	<input type="radio"/>	<input type="radio"/>												
_x__	For manufacturer setting	0h	<input type="checkbox"/>	<input type="checkbox"/>												
x___		0h	<input type="checkbox"/>	<input type="checkbox"/>												
PC20 *SNO Station number setting		Specify a station Number of the servo amplifier for RS-422 and USB communication. Always set one station to one axis of the servo amplifier. Setting one station Number to two or more stations will disable a normal communication. Setting range: 0 to 31	0 [Station]	<input type="radio"/>	<input type="radio"/>											

7. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode	
				C P	C L
PC21 *SOP RS-422 communicatio n function selection	Select the details of RS-422 communication function.				
	___x	For manufacturer setting	0h		
	__x__	RS-422 communication baud rate selection 0: 9600 [bps] 1: 19200 [bps] 2: 38400 [bps] 3: 57600 [bps] 4: 115200 [bps] 6: 4800 [bps]	0h	○	○
	_x__	RS-422 communication response delay time selection 0: Disabled 1: Enabled (responding after 800 μs or longer delay time)	0h	○	○
PC22 *COP1 Function selection C-1	___x	For manufacturer setting	0h		
	__x__		2h		
	_x__		0h		
	x___	Encoder cable communication method selection Select how to execute the encoder cable communication method. 0: Two-wire type 1: Four-wire type If the setting is incorrect, [AL. 16 Encoder initial communication error 1] or [AL. 20 Encoder normal communication error 1] occurs.	0h	○	○
PC24 *COP3 Function selection C-3	___x	In-position range unit selection Select a unit of in-position range. 0: Command unit 1: Servo motor encoder pulse unit	0h	○	○
	__x__	For manufacturer setting	0h		
	_x__		0h		
	x___	Error excessive alarm/error excessive warning level unit selection Select units for the error excessive alarm level setting with [Pr. PC43] and for the error excessive warning level setting with [Pr. PC73]. 0: 1 rev unit 1: 0.1 rev unit 2: 0.01 rev unit 3: 0.001 rev unit	0h	○	○
PC26 *COP5 Function selection C-5	___x	[AL. 99 Stroke limit warning] selection Select [AL. 99 Stroke limit warning]. 0: Enabled 1: Disabled	0h	○	○
	__x__	For manufacturer setting	0h		
	_x__		0h		
	x___		0h		

7. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode	
				C P	C L
PC27 *COP6 Function selection C-6	___x	For manufacturer setting	0h		
	__x_		0h		
	_x__	Undervoltage alarm selection Select the alarm and warning that occurs when the bus voltage drops to the undervoltage alarm level. 0: [AL. 102] regardless of servo motor speed 1: [AL. E9.1] occurs when the servo motor speed is 50 r/min or less, and [AL. 10.2] occurs when the servo motor speed is over 50 r/min.	0h	○	○
	x___	For manufacturer setting	0h		
PC30 STA2 Home position return acceleration time constant		This parameter is used when a home position return is executed with the program method. Set the acceleration time constant for the home position return. Set an acceleration time from 0 r/min to the rated speed. Additionally, when a value of 20000 ms or more is set, it will be clamped to 20000 ms. Setting range: 0 to 50000	0 [ms]		○
PC31 STB2 Home position return deceleration time constant		This parameter is used when a home position return is executed with the program method. Set the deceleration time constant at the home position return. Set a deceleration time from the rated speed to 0 r/min. Additionally, when a value of 20000 ms or more is set, it will be clamped to 20000 ms. Setting range: 0 to 50000	0 [ms]		○
PC35 TL2 Internal torque limit 2		Set the parameter on the assumption that the maximum torque is 100.0 %. The parameter is for limiting the torque of the servo motor. No torque is generated when this parameter is set to "0.0". When TL1 (Internal torque limit selection) is turned on, internal torque limits 1 and 2 are compared and the lower value will be enabled. Setting range: 0.0 to 100.0	100.0 [%]	○	○

7. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode	
				C P	C L
PC36 *DMD Status display selection	-- x x	Status display selection at power-on Select a status display shown at power-on. 00: Cumulative feedback pulse 01: Servo motor speed 02: Droop pulses 03: Cumulative command pulses 04: Command pulse frequency 05: Analog speed command voltage (not used for the positioning mode) 06: Analog torque limit voltage 07: Regenerative load ratio 08: Effective load ratio 09: Peak load ratio 0A: Instantaneous torque 0B: Position within one-revolution/virtual position within one-revolution (1 pulse unit) 0C: Position within one-revolution/virtual position within one-revolution (1000 pulses unit) 0D: ABS counter/virtual ABS counter 0E: Load to motor inertia ratio 0F: Bus voltage 10: Encoder inside temperature 11: Settling time 12: Oscillation detection frequency 13: Number of tough drives 14: Unit power consumption (increment of 1 W) 15: Unit power consumption (increment of 1 kW) 16: Unit total power consumption (increment of 1 Wh) 17: Unit total power consumption (increment of 100 kWh) 21: Current position 22: Command position 23: Command remaining distance 24: Point table No./Program No. 25: Step No. 26: Override voltage 27: Override level 28: Cam axis one cycle current value 29: Cam standard position 2A: Cam axis feed current value 2B: Cam No. in execution 2C: Cam stroke amount in execution 2D: Main axis current value 2E: Main axis one cycle current value	00h	<input type="radio"/>	<input type="radio"/>


7. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode							
				C P	C L						
PC36 *DMD Status display selection	_ x _ _	Status display at power-on in corresponding control mode 0: Depends on the control mode <table border="1" style="margin: 10px auto;"> <thead> <tr> <th>Control mode</th> <th>Status display at power-on</th> </tr> </thead> <tbody> <tr> <td>Positioning (point table method)</td> <td>Current position</td> </tr> <tr> <td>Positioning (program method)</td> <td>Current position</td> </tr> </tbody> </table> 1: Depends on the setting in the lower two digits of this parameter	Control mode	Status display at power-on	Positioning (point table method)	Current position	Positioning (program method)	Current position	0h	<input type="radio"/>	<input type="radio"/>
	Control mode	Status display at power-on									
Positioning (point table method)	Current position										
Positioning (program method)	Current position										
	x _ _ _	For manufacturer setting	0h	<input type="checkbox"/>	<input type="checkbox"/>						
PC37 VCO Analog override Offset		Set an offset voltage of VC (Override input). This will be automatic setting by executing VC automatic offset. Setting range: -9999 to 9999	0 [mV]	<input type="radio"/>	<input type="radio"/>						
PC38 TPO Analog torque limit offset		Set the offset voltage of TLA (Analog torque limit). Setting range: -9999 to 9999	0 [mV]	<input type="radio"/>	<input type="radio"/>						
PC39 MO1 Analog monitor 1 offset		Set the offset voltage of MO1 (Analog monitor 1). Setting range: -9999 to 9999	0 [mV]	<input type="radio"/>	<input type="radio"/>						
PC40 MO2 Analog monitor 2 offset		Set the offset voltage of MO2 (Analog monitor 2). Setting range: -9999 to 9999	0 [mV]	<input type="radio"/>	<input type="radio"/>						
PC43 ERZ Error excessive alarm level		Set an error excessive alarm level. You can change the setting unit with "Error excessive alarm/error excessive warning level unit selection" in [Pr. PC24]. However, setting "0" will be 3 rev. Setting over 200 rev will be clamped to 200 rev. Setting range: 0 to 1000	0 [rev]	<input type="radio"/>	<input type="radio"/>						

7. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode	
				C P	C L
PC51 RSBR Forced stop deceleration time constant		<p>Set a deceleration time constant for the forced stop deceleration function. Set the time taken from the rated speed to 0 r/min in a unit of ms.</p> <p>[Precautions]</p> <ul style="list-style-type: none"> - If the servo motor torque is saturated at the maximum torque during a forced stop deceleration because the set time is too short, the time to stop will be longer than the set time constant. - [AL. 50 Overload alarm 1] or [AL. 51 Overload alarm 2] may occur during forced stop deceleration, depending on the set value. - After an alarm that leads to a forced stop deceleration, if an alarm that does not lead to a forced stop deceleration occurs or if the control circuit power supply is cut, dynamic braking will start regardless of the deceleration time constant setting. <p>Setting range: 0 to 20000</p>	100 [ms]	<input type="radio"/>	<input type="radio"/>

7. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode	
				C P	C L
PC68 LPSNL Mark detection range - (lower three digits)		Set the lower limit of the mark detection. Upper and lower are a set. Setting address: 	0 Refer to Function column for unit.	○	○
PC69 LPSNH Mark detection range - (upper three digits)					
PC73 ERW Error excessive warning level		Set an error excessive warning level. To enable the parameter, set "[AL. 9B Error excessive warning] selection" to "Enabled (1 __ _)" in [Pr. PC60]. The setting unit can be changed with "Error excessive alarm/error excessive warning level unit selection" in [Pr. PC24]. Set the level in rev unit. When "0" is set, 1 rev will be applied. Setting over 200 rev will be clamped to 200 rev. When an error reaches the set value, [AL. 9B Error excessive warning] will occur. When the error decreases lower than the set value, the warning will be canceled automatically. The minimum pulse width of the warning signal is 100 [ms]. Set as follows: [Pr. PC73 Error excessive warning level] < [Pr. PC43 Error excessive alarm level] When you set as [Pr. PC73 Error excessive warning level] ≥ [Pr. PC43 Error excessive alarm level], [AL. 52 Error excessive] will occur earlier than the warning. This parameter setting is available with servo amplifiers with software version B4 or later. Setting range: 0 to 1000	0 [rev]	○	○

7. PARAMETERS

7.2.4 I/O setting parameters ([Pr. PD_ _])

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode	
				C P	C L
PD01 *DIA1 Input signal automatic on selection 1	Select input devices to turn on automatically.				
	_ _ _ x (HEX)	_ _ _ x (BIN): For manufacturer setting	0h		
		_ _ x _ (BIN): For manufacturer setting			
		_ x _ _ (BIN): SON (Servo-on)		<input type="radio"/>	<input type="radio"/>
		0: Disabled (Use for an external input signal.) 1: Enabled (automatic on)			
	_ _ x _ (HEX)	x _ _ _ (BIN): For manufacturer setting	0h		
		_ _ _ x (BIN): PC (Proportional control)		<input type="radio"/>	<input type="radio"/>
		0: Disabled (Use for an external input signal.) 1: Enabled (automatic on)			
		_ _ x _ (BIN): TL (External torque limit selection)		<input type="radio"/>	<input type="radio"/>
		0: Disabled (Use for an external input signal.) 1: Enabled (automatic on)			
	_ x _ _ (HEX)	_ x _ _ (BIN): For manufacturer setting	0h		
		_ _ x _ (BIN): For manufacturer setting			
		_ x _ _ (BIN): LSP (Forward rotation stroke end)		<input type="radio"/>	<input type="radio"/>
		0: Disabled (Use for an external input signal.) 1: Enabled (automatic on)			
	x _ _ _ (HEX)	x _ _ _ (BIN): LSN (Reverse rotation stroke end)	0h	<input type="radio"/>	<input type="radio"/>
		0: Disabled (Use for an external input signal.) 1: Enabled (automatic on)			
_ _ _ X (BIN): EM2 (Forced stop 2)/EM1 (Forced stop 1)		<input type="radio"/>		<input type="radio"/>	
0: Disabled (Use for an external input signal.) 1: Enabled (automatic on)					
_ _ x _ (BIN): For manufacturer setting					
_ x _ _ (BIN): For manufacturer setting					
x _ _ _ (BIN): For manufacturer setting					

7. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode																																																												
				C P	C L																																																											
PD01 *DIA1 Input signal automatic on selection 1		<p>Convert the setting value into hexadecimal as follows.</p> <table border="1"> <thead> <tr> <th colspan="2">Input device</th> <th colspan="2">Initial value</th> </tr> <tr> <th colspan="2"></th> <th>BIN</th> <th>HEX</th> </tr> </thead> <tbody> <tr> <td colspan="2">SON (Servo-on)</td> <td>0</td> <td rowspan="4">0</td> </tr> <tr> <td colspan="2"></td> <td>0</td> </tr> <tr> <td colspan="2"></td> <td>0</td> </tr> <tr> <td colspan="2"></td> <td>0</td> </tr> <tr> <td colspan="2">PC (Proportional control)</td> <td>0</td> <td rowspan="4">0</td> </tr> <tr> <td colspan="2">TL (External torque limit selection)</td> <td>0</td> </tr> <tr> <td colspan="2"></td> <td>0</td> </tr> <tr> <td colspan="2"></td> <td>0</td> </tr> <tr> <td colspan="2">LSP (Forward rotation stroke end)</td> <td>0</td> <td rowspan="4">0</td> </tr> <tr> <td colspan="2">LSN (Reverse rotation stroke end)</td> <td>0</td> </tr> <tr> <td colspan="2"></td> <td>0</td> </tr> <tr> <td colspan="2"></td> <td>0</td> </tr> <tr> <td colspan="2">EM2 (Forced stop 2)/EM1 (Forced stop 1)</td> <td>0</td> <td rowspan="4">0</td> </tr> <tr> <td colspan="2"></td> <td>0</td> </tr> <tr> <td colspan="2"></td> <td>0</td> </tr> <tr> <td colspan="2"></td> <td>0</td> </tr> </tbody> </table> <p>BIN 0: Use for an external input signal. BIN 1: Automatic on</p>	Input device		Initial value				BIN	HEX	SON (Servo-on)		0	0			0			0			0	PC (Proportional control)		0	0	TL (External torque limit selection)		0			0			0	LSP (Forward rotation stroke end)		0	0	LSN (Reverse rotation stroke end)		0			0			0	EM2 (Forced stop 2)/EM1 (Forced stop 1)		0	0			0			0			0		
Input device		Initial value																																																														
		BIN	HEX																																																													
SON (Servo-on)		0	0																																																													
		0																																																														
		0																																																														
		0																																																														
PC (Proportional control)		0	0																																																													
TL (External torque limit selection)		0																																																														
		0																																																														
		0																																																														
LSP (Forward rotation stroke end)		0	0																																																													
LSN (Reverse rotation stroke end)		0																																																														
		0																																																														
		0																																																														
EM2 (Forced stop 2)/EM1 (Forced stop 1)		0	0																																																													
		0																																																														
		0																																																														
		0																																																														

7. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode																																																																																																																		
				C P	C L																																																																																																																	
PD04 *D11H Input device selection 1H	Any input device can be assigned to the CN1-15 pin.																																																																																																																					
	__ x x	Not used with the positioning mode.	02h																																																																																																																			
	x x __	Positioning mode - Device selection Refer to table 7.10 for settings.	02h	○	○																																																																																																																	
Table 7.10 Selectable input devices <table border="1" style="margin: auto;"> <thead> <tr> <th rowspan="2">Setting value</th> <th colspan="2">Input device (Note 1)</th> </tr> <tr> <th>CP</th> <th>CL</th> </tr> </thead> <tbody> <tr><td>02</td><td>SON</td><td>SON</td></tr> <tr><td>03</td><td>RES</td><td>RES</td></tr> <tr><td>04</td><td>PC</td><td>PC</td></tr> <tr><td>05</td><td>TL</td><td>TL</td></tr> <tr><td>06</td><td>CR</td><td>CR</td></tr> <tr><td>07</td><td>ST1</td><td>ST1</td></tr> <tr><td>08</td><td>ST2</td><td>ST2</td></tr> <tr><td>09</td><td>TL1</td><td>TL1</td></tr> <tr><td>0A</td><td>LSP</td><td>LSP</td></tr> <tr><td>0B</td><td>LSN</td><td>LSN</td></tr> <tr><td>0D</td><td>CDP</td><td>CDP</td></tr> <tr><td>12</td><td>MSD</td><td>MSD</td></tr> <tr><td>1E</td><td>CLTC (Note 2)</td><td>CLTC (Note 2)</td></tr> <tr><td>1F</td><td>CPCD (Note 2)</td><td>CPCD (Note 2)</td></tr> <tr><td>20</td><td>MD0</td><td>MD0</td></tr> <tr><td>21</td><td>CAMC (Note 2)</td><td>CAMC (Note 2)</td></tr> <tr><td>23</td><td>TCH</td><td style="text-align: center;">\</td></tr> <tr><td>24</td><td>TP0</td><td>TP0</td></tr> <tr><td>25</td><td>TP1</td><td>TP1</td></tr> <tr><td>26</td><td>OVR</td><td>OVR</td></tr> <tr><td>27</td><td>TSTP</td><td>TSTP</td></tr> <tr><td>29</td><td>CI0 (Note 2)</td><td>CI0 (Note 2)</td></tr> <tr><td>2A</td><td>CI1 (Note 2)</td><td>CI1 (Note 2)</td></tr> <tr><td>2B</td><td>DOG</td><td>DOG</td></tr> <tr><td>30</td><td style="text-align: center;">\</td><td>LPS</td></tr> <tr><td>31</td><td>CI2 (Note 2)</td><td>CI2 (Note 2)</td></tr> <tr><td>32</td><td style="text-align: center;">\</td><td style="text-align: center;">\</td></tr> <tr><td>34</td><td style="text-align: center;">\</td><td>PI1</td></tr> <tr><td>35</td><td style="text-align: center;">\</td><td>PI2</td></tr> <tr><td>36</td><td style="text-align: center;">\</td><td>PI3</td></tr> <tr><td>37</td><td>CI3 (Note 2)</td><td>CI3 (Note 2)</td></tr> <tr><td>38</td><td>DI0</td><td>DI0</td></tr> <tr><td>39</td><td>DI1</td><td>DI1</td></tr> <tr><td>3A</td><td>DI2</td><td>DI2</td></tr> <tr><td>3B</td><td>DI3</td><td>DI3</td></tr> <tr><td>3C</td><td>DI4</td><td style="text-align: center;">\</td></tr> </tbody> </table> <p>Note 1. CP: Positioning mode (point table method) CL: Positioning mode (program method) The diagonal lines indicate manufacturer settings. Never change the setting.</p> <p>Note 2. This is available with servo amplifiers with software version B7 or later.</p>						Setting value	Input device (Note 1)		CP	CL	02	SON	SON	03	RES	RES	04	PC	PC	05	TL	TL	06	CR	CR	07	ST1	ST1	08	ST2	ST2	09	TL1	TL1	0A	LSP	LSP	0B	LSN	LSN	0D	CDP	CDP	12	MSD	MSD	1E	CLTC (Note 2)	CLTC (Note 2)	1F	CPCD (Note 2)	CPCD (Note 2)	20	MD0	MD0	21	CAMC (Note 2)	CAMC (Note 2)	23	TCH	\	24	TP0	TP0	25	TP1	TP1	26	OVR	OVR	27	TSTP	TSTP	29	CI0 (Note 2)	CI0 (Note 2)	2A	CI1 (Note 2)	CI1 (Note 2)	2B	DOG	DOG	30	\	LPS	31	CI2 (Note 2)	CI2 (Note 2)	32	\	\	34	\	PI1	35	\	PI2	36	\	PI3	37	CI3 (Note 2)	CI3 (Note 2)	38	DI0	DI0	39	DI1	DI1	3A	DI2	DI2	3B	DI3	DI3	3C	DI4	\
Setting value	Input device (Note 1)																																																																																																																					
	CP	CL																																																																																																																				
02	SON	SON																																																																																																																				
03	RES	RES																																																																																																																				
04	PC	PC																																																																																																																				
05	TL	TL																																																																																																																				
06	CR	CR																																																																																																																				
07	ST1	ST1																																																																																																																				
08	ST2	ST2																																																																																																																				
09	TL1	TL1																																																																																																																				
0A	LSP	LSP																																																																																																																				
0B	LSN	LSN																																																																																																																				
0D	CDP	CDP																																																																																																																				
12	MSD	MSD																																																																																																																				
1E	CLTC (Note 2)	CLTC (Note 2)																																																																																																																				
1F	CPCD (Note 2)	CPCD (Note 2)																																																																																																																				
20	MD0	MD0																																																																																																																				
21	CAMC (Note 2)	CAMC (Note 2)																																																																																																																				
23	TCH	\																																																																																																																				
24	TP0	TP0																																																																																																																				
25	TP1	TP1																																																																																																																				
26	OVR	OVR																																																																																																																				
27	TSTP	TSTP																																																																																																																				
29	CI0 (Note 2)	CI0 (Note 2)																																																																																																																				
2A	CI1 (Note 2)	CI1 (Note 2)																																																																																																																				
2B	DOG	DOG																																																																																																																				
30	\	LPS																																																																																																																				
31	CI2 (Note 2)	CI2 (Note 2)																																																																																																																				
32	\	\																																																																																																																				
34	\	PI1																																																																																																																				
35	\	PI2																																																																																																																				
36	\	PI3																																																																																																																				
37	CI3 (Note 2)	CI3 (Note 2)																																																																																																																				
38	DI0	DI0																																																																																																																				
39	DI1	DI1																																																																																																																				
3A	DI2	DI2																																																																																																																				
3B	DI3	DI3																																																																																																																				
3C	DI4	\																																																																																																																				

7. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode	
				C P	C L
PD12		Any input device can be assigned to the CN1-19 pin.			
*DI5H	__ x x	Not used with the positioning mode.	07h	<input type="checkbox"/>	<input type="checkbox"/>
Input device selection 5H	x x __	Positioning mode - Device selection Refer to table 7.10 in [Pr. PD04] for settings.	38h	<input type="checkbox"/>	<input type="checkbox"/>
PD14		Any input device can be assigned to the CN1-41 pin.			
*DI6H	__ x x	Not used with the positioning mode.	08h	<input type="checkbox"/>	<input type="checkbox"/>
Input device selection 6H	x x __	Positioning mode - Device selection Refer to table 7.10 in [Pr. PD04] for settings.	39h	<input type="checkbox"/>	<input type="checkbox"/>
PD18		Any input device can be assigned to the CN1-43 pin.			
*DI8H	__ x x	Not used with the positioning mode.	00h	<input type="checkbox"/>	<input type="checkbox"/>
Input device selection 8H	x x __	Positioning mode - Device selection Refer to table 7.10 in [Pr. PD04] for settings.	07h	<input type="checkbox"/>	<input type="checkbox"/>
PD20		Any input device can be assigned to the CN1-44 pin.			
*DI9H	__ x x	Not used with the positioning mode.	00h	<input type="checkbox"/>	<input type="checkbox"/>
Input device selection 9H	x x __	Positioning mode - Device selection Refer to table 7.10 in [Pr. PD04] for settings.	08h	<input type="checkbox"/>	<input type="checkbox"/>

7. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode																																																																																																																								
				C P	C L																																																																																																																							
PD24 *DO2 Output device selection 2	__ x x	Device selection Any output device can be assigned to the CN1-23 pin. Refer to table 7.11 for settings.	0Ch	○	○																																																																																																																							
	_ x _ _	For manufacturer setting	0h																																																																																																																									
	x _ _ _		0h																																																																																																																									
Table 7.11 Selectable output devices																																																																																																																												
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">Setting value</th> <th colspan="2">Output device (Note 1)</th> </tr> <tr> <th>CP</th> <th>CL</th> </tr> </thead> <tbody> <tr><td>00</td><td>Always off</td><td>Always off</td></tr> <tr><td>02</td><td>RD</td><td>RD</td></tr> <tr><td>03</td><td>ALM</td><td>ALM</td></tr> <tr><td>04</td><td>INP</td><td>INP</td></tr> <tr><td>05</td><td>MBR</td><td>MBR</td></tr> <tr><td>06</td><td>DB</td><td>DB</td></tr> <tr><td>07</td><td>TLC</td><td>TLC</td></tr> <tr><td>08</td><td>WNG</td><td>WNG</td></tr> <tr><td>09</td><td>Always off</td><td>Always off</td></tr> <tr><td>0A</td><td>SA</td><td>SA</td></tr> <tr><td>0B</td><td>Always off</td><td>Always off</td></tr> <tr><td>0C</td><td>ZSP</td><td>ZSP</td></tr> <tr><td>0D</td><td>MTTR</td><td>MTTR</td></tr> <tr><td>0F</td><td>CDPS</td><td>CDPS</td></tr> <tr><td>10</td><td>Always off</td><td>Always off</td></tr> <tr><td>11</td><td>Always off</td><td>Always off</td></tr> <tr><td>1F</td><td>CPCC (Note 2)</td><td>CPCC (Note 2)</td></tr> <tr><td>23</td><td>CPO</td><td>CPO</td></tr> <tr><td>24</td><td>ZP</td><td>ZP</td></tr> <tr><td>25</td><td>POT</td><td>POT</td></tr> <tr><td>26</td><td>PUS</td><td>PUS</td></tr> <tr><td>27</td><td>MEND</td><td>MEND</td></tr> <tr><td>29</td><td>CLTS (Note 2)</td><td>CLTS (Note 2)</td></tr> <tr><td>2B</td><td>CLTSM (Note 2)</td><td>CLTSM (Note 2)</td></tr> <tr><td>2C</td><td>PED</td><td>PED</td></tr> <tr><td>2D</td><td></td><td>SOUT</td></tr> <tr><td>2E</td><td></td><td>OUT1</td></tr> <tr><td>2F</td><td></td><td>OUT2</td></tr> <tr><td>30</td><td></td><td>OUT3</td></tr> <tr><td>31</td><td>ALMWNG</td><td>ALMWNG</td></tr> <tr><td>32</td><td>Always off</td><td>Always off</td></tr> <tr><td>33</td><td>MSDH</td><td>MSDH</td></tr> <tr><td>34</td><td>MSDL</td><td>MSDL</td></tr> <tr><td>37</td><td>CAMS (Note 2)</td><td>CAMS (Note 2)</td></tr> <tr><td>38</td><td>PT0</td><td></td></tr> <tr><td>39</td><td>PT1</td><td></td></tr> <tr><td>3A</td><td>PT2</td><td></td></tr> <tr><td>3B</td><td>PT3</td><td></td></tr> </tbody> </table>						Setting value	Output device (Note 1)		CP	CL	00	Always off	Always off	02	RD	RD	03	ALM	ALM	04	INP	INP	05	MBR	MBR	06	DB	DB	07	TLC	TLC	08	WNG	WNG	09	Always off	Always off	0A	SA	SA	0B	Always off	Always off	0C	ZSP	ZSP	0D	MTTR	MTTR	0F	CDPS	CDPS	10	Always off	Always off	11	Always off	Always off	1F	CPCC (Note 2)	CPCC (Note 2)	23	CPO	CPO	24	ZP	ZP	25	POT	POT	26	PUS	PUS	27	MEND	MEND	29	CLTS (Note 2)	CLTS (Note 2)	2B	CLTSM (Note 2)	CLTSM (Note 2)	2C	PED	PED	2D		SOUT	2E		OUT1	2F		OUT2	30		OUT3	31	ALMWNG	ALMWNG	32	Always off	Always off	33	MSDH	MSDH	34	MSDL	MSDL	37	CAMS (Note 2)	CAMS (Note 2)	38	PT0		39	PT1		3A	PT2		3B	PT3	
Setting value	Output device (Note 1)																																																																																																																											
	CP	CL																																																																																																																										
00	Always off	Always off																																																																																																																										
02	RD	RD																																																																																																																										
03	ALM	ALM																																																																																																																										
04	INP	INP																																																																																																																										
05	MBR	MBR																																																																																																																										
06	DB	DB																																																																																																																										
07	TLC	TLC																																																																																																																										
08	WNG	WNG																																																																																																																										
09	Always off	Always off																																																																																																																										
0A	SA	SA																																																																																																																										
0B	Always off	Always off																																																																																																																										
0C	ZSP	ZSP																																																																																																																										
0D	MTTR	MTTR																																																																																																																										
0F	CDPS	CDPS																																																																																																																										
10	Always off	Always off																																																																																																																										
11	Always off	Always off																																																																																																																										
1F	CPCC (Note 2)	CPCC (Note 2)																																																																																																																										
23	CPO	CPO																																																																																																																										
24	ZP	ZP																																																																																																																										
25	POT	POT																																																																																																																										
26	PUS	PUS																																																																																																																										
27	MEND	MEND																																																																																																																										
29	CLTS (Note 2)	CLTS (Note 2)																																																																																																																										
2B	CLTSM (Note 2)	CLTSM (Note 2)																																																																																																																										
2C	PED	PED																																																																																																																										
2D		SOUT																																																																																																																										
2E		OUT1																																																																																																																										
2F		OUT2																																																																																																																										
30		OUT3																																																																																																																										
31	ALMWNG	ALMWNG																																																																																																																										
32	Always off	Always off																																																																																																																										
33	MSDH	MSDH																																																																																																																										
34	MSDL	MSDL																																																																																																																										
37	CAMS (Note 2)	CAMS (Note 2)																																																																																																																										
38	PT0																																																																																																																											
39	PT1																																																																																																																											
3A	PT2																																																																																																																											
3B	PT3																																																																																																																											
<p>Note 1. CP: Positioning mode (point table method) CL: Positioning mode (program method) The diagonal lines indicate manufacturer settings. Never change the setting.</p> <p>2. This is available with servo amplifiers with software version B7 or later.</p>																																																																																																																												

7. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode	
				C P	C L
PD25 *DO3 Output device selection 3	__ x x	Device selection Any output device can be assigned to the CN1-24 pin. Refer to table 7.11 in [Pr. PD24] for settings.	04h	<input type="radio"/>	<input type="radio"/>
	_ x _ _	For manufacturer setting	0h	<input type="checkbox"/>	<input type="checkbox"/>
	x _ _ _		0h	<input type="checkbox"/>	<input type="checkbox"/>
PD26 *DO4 Output device selection 4	__ x x	Device selection Any output device can be assigned to the CN1-25 pin. Refer to table 7.11 in [Pr. PD24] for settings.	00h	<input type="radio"/>	<input type="radio"/>
	_ x _ _	For manufacturer setting	0h	<input type="checkbox"/>	<input type="checkbox"/>
	x _ _ _		0h	<input type="checkbox"/>	<input type="checkbox"/>
PD28 *DO6 Output device selection 6	__ x x	Device selection Any output device can be assigned to the CN1-49 pin. Refer to table 7.11 in [Pr. PD24] for settings.	02h	<input type="radio"/>	<input type="radio"/>
	_ x _ _	For manufacturer setting	0h	<input type="checkbox"/>	<input type="checkbox"/>
	x _ _ _		0h	<input type="checkbox"/>	<input type="checkbox"/>
PD29 *DIF Input filter setting	Select a filter for the input signal.				
	___ x	Input signal filter selection If external input signal causes chattering due to noise, etc., input filter is used to suppress it. 0: None 1: 0.888 [ms] 2: 1.777 [ms] 3: 2.666 [ms] 4: 3.555 [ms] 5: 4.444 [ms] 6: 5.333 [ms]	4h	<input type="radio"/>	<input type="radio"/>
	_ _ x _	RES (Reset) dedicated filter selection 0: Disabled 1: Enabled (50 [ms])	0h	<input type="radio"/>	<input type="radio"/>
	_ x _ _	CR (Clear) dedicated filter selection 0: Disabled 1: Enabled (50 [ms])	0h	<input type="radio"/>	<input type="radio"/>
	x _ _ _	For manufacturer setting	0h	<input type="checkbox"/>	<input type="checkbox"/>

7. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode													
				C P	C L												
PD30 *DOP1 Function selection D-1	___x	Stop method selection for LSP (Forward rotation stroke end) off or LSN (Reverse rotation stroke end) off Select a stop method for LSP (Forward rotation stroke end) off or LSN (Reverse rotation stroke end) off. (Refer to section 7.5.)	0h	<input type="radio"/>	<input type="radio"/>												
	<table border="1"> <thead> <tr> <th>Setting value</th> <th>Control mode</th> </tr> <tr> <td></td> <th>CP/CL</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Quick stop (home position erased)</td> </tr> <tr> <td>1</td> <td>Slow stop (home position erased)</td> </tr> <tr> <td>2</td> <td>Slow stop (deceleration to a stop by deceleration time constant)</td> </tr> <tr> <td>3</td> <td>Quick stop (stop by clearing remaining distance)</td> </tr> </tbody> </table>		Setting value	Control mode		CP/CL	0	Quick stop (home position erased)	1	Slow stop (home position erased)	2	Slow stop (deceleration to a stop by deceleration time constant)	3	Quick stop (stop by clearing remaining distance)			
	Setting value	Control mode															
		CP/CL															
0	Quick stop (home position erased)																
1	Slow stop (home position erased)																
2	Slow stop (deceleration to a stop by deceleration time constant)																
3	Quick stop (stop by clearing remaining distance)																
__x_	Base circuit status selection for RES (Reset) on 0: Base circuit shut-off 1: No base circuit shut-off	0h	<input type="radio"/>	<input type="radio"/>													
_x__	Stop method selection at software limit detection Select a stop method selection at software limit detection. (Refer to section 7.6.) 0: Quick stop (home position erased) 1: Slow stop (home position erased) 2: Slow stop (deceleration to a stop by deceleration time constant) 3: Quick stop (stop by clearing remaining distance)	0h	<input type="radio"/>	<input type="radio"/>													
x___	Servo motor thermistor enabled/disabled selection 0: Enabled 1: Disabled For servo motors without thermistor, the setting will be disabled.	0h	<input type="radio"/>	<input type="radio"/>													
PD31 *DOP2 Function selection D-2	___x	For manufacturer setting	0h	<input type="checkbox"/>	<input type="checkbox"/>												
	__x_		0h	<input type="checkbox"/>	<input type="checkbox"/>												
	_x__		0h	<input type="checkbox"/>	<input type="checkbox"/>												
	x___	Mark detection fast input signal filter selection 0: Standard 0.166 [ms] 1: 0.055 [ms] 2: 0.111 [ms] 3: 0.166 [ms] 4: 0.222 [ms] 5: 0.277 [ms] 6: 0.333 [ms] 7: 0.388 [ms] 8: 0.444 [ms] 9 to E: Disabled (Setting this will be the same as "F".) F: Non-filter This digit will be enabled when MSD (Mark detection) is assigned to the CN1-10 pin with [Pr. PD44].	0h	<input type="radio"/>	<input type="radio"/>												
PD32 *DOP3 Function selection D-3	___x	CR (Clear) selection This is used to set CR (Clear). 0: Deletes droop pulses by turning on the device 1: Always deletes droop pulses during the device on 2: Disabled	0h	<input type="radio"/>	<input type="radio"/>												
	__x_	For manufacturer setting	0h	<input type="checkbox"/>	<input type="checkbox"/>												
	_x__		0h	<input type="checkbox"/>	<input type="checkbox"/>												
	x___		0h	<input type="checkbox"/>	<input type="checkbox"/>												


7. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode							
				C P	C L						
PD33 *DOP4 Function selection D-4	___x	For manufacturer setting	0h								
	__x_		0h								
	_x__	Rotation direction selection for enabling torque limit Select a rotation direction which enables the internal torque limit 2 and the external torque limit. 0: Enabled with both CCW and CW 1: Enabled with CCW 2: Enabled with CW	0h	○	○						
	x___	For manufacturer setting	0h								
PD34 *DOP5 Function selection D-5	___x	Alarm code output Select an alarm code output. Alarm codes are outputted to pins CN1-23, CN1-24, and CN1-49. 0: Disabled 1: Enabled For details of the alarm codes, refer to chapter 8.	0h	○	○						
	__x_	Selection of output device at warning occurrence Select ALM (Malfunction) output status for a warning occurrence.	0h	○	○						
	<table border="1"> <thead> <tr> <th>Setting value</th> <th>Device status</th> </tr> </thead> <tbody> <tr> <td>0</td> <td> </td> </tr> <tr> <td>1</td> <td> </td> </tr> </tbody> </table>		Setting value	Device status	0		1				
	Setting value	Device status									
0											
1											
_x__	For manufacturer setting	0h									
x___		0h									

7. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode																													
				C P	C L																												
PD41 *DIA3 Input signal automatic on selection 3	Select input devices to turn on automatically.																																
	___x (HEX)	___x (BIN): MD0 (operation mode selection 1) 0: Disabled (Use for an external input signal.) 1: Enabled (automatic on)	0h	<input type="radio"/>	<input type="radio"/>																												
		__x_ (BIN): MD1 (operation mode selection 2) 0: Disabled (Use for an external input signal.) 1: Enabled (automatic on)		<input type="checkbox"/>	<input type="checkbox"/>																												
		_x__ (BIN): For manufacturer setting		<input type="checkbox"/>	<input type="checkbox"/>																												
		x___ (BIN): For manufacturer setting		<input type="checkbox"/>	<input type="checkbox"/>																												
	__x_ (HEX)	___x (BIN): For manufacturer setting	0h	<input type="checkbox"/>	<input type="checkbox"/>																												
		__x_ (BIN): For manufacturer setting		<input type="checkbox"/>	<input type="checkbox"/>																												
		_x__ (BIN): OVR (Analog override selection) 0: Disabled (Use for an external input signal.) 1: Enabled (automatic on)		<input type="radio"/>	<input type="radio"/>																												
		x___ (BIN): For manufacturer setting		<input type="checkbox"/>	<input type="checkbox"/>																												
	_x__	For manufacturer setting	0h	<input type="checkbox"/>	<input type="checkbox"/>																												
x___		0h	<input type="checkbox"/>	<input type="checkbox"/>																													
Convert the setting value into hexadecimal as follows.																																	
<table border="1" style="margin-left: 20px;"> <thead> <tr> <th rowspan="2">Input device</th> <th colspan="2">Initial value</th> </tr> <tr> <th>BIN</th> <th>HEX</th> </tr> </thead> <tbody> <tr> <td>MD0 (Operation mode selection 1)</td> <td>0</td> <td rowspan="4">0</td> </tr> <tr> <td>MD1 (Operation mode selection 2)</td> <td>0</td> </tr> <tr> <td></td> <td>0</td> </tr> <tr> <td></td> <td>0</td> </tr> </tbody> </table> <table border="1" style="margin-left: 20px;"> <thead> <tr> <th rowspan="2">Input device</th> <th colspan="2">Initial value</th> </tr> <tr> <th>BIN</th> <th>HEX</th> </tr> </thead> <tbody> <tr> <td></td> <td>0</td> <td rowspan="4">0</td> </tr> <tr> <td></td> <td>0</td> </tr> <tr> <td>OVR (Analog override selection)</td> <td>0</td> </tr> <tr> <td></td> <td>0</td> </tr> </tbody> </table> <p style="margin-left: 20px;">BIN 0: Use for an external input signal. BIN 1: Automatic on</p>						Input device	Initial value		BIN	HEX	MD0 (Operation mode selection 1)	0	0	MD1 (Operation mode selection 2)	0		0		0	Input device	Initial value		BIN	HEX		0	0		0	OVR (Analog override selection)	0		0
Input device	Initial value																																
	BIN	HEX																															
MD0 (Operation mode selection 1)	0	0																															
MD1 (Operation mode selection 2)	0																																
	0																																
	0																																
Input device	Initial value																																
	BIN	HEX																															
	0	0																															
	0																																
OVR (Analog override selection)	0																																
	0																																

7. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode																			
				C P	C L																		
PD42 *DIA4 Input signal automatic on selection 4	Select input devices to turn on automatically.																						
	___ x	For manufacturer setting	0h																				
	__ x _		0h																				
	_ x _ _ (HEX)	___ x (BIN): DI0 (Point table No./program No. selection 1) 0: Disabled (Use for an external input signal.) 1: Enabled (automatic on)	0h	○	○																		
		__ x _ (BIN): DI1 (Point table No./Program No. selection 2) 0: Disabled (Use for an external input signal.) 1: Enabled (automatic on)		○	○																		
		_ x _ _ (BIN): DI2 (Point table No./Program No. selection 3) 0: Disabled (Use for an external input signal.) 1: Enabled (automatic on)		○	○																		
		x _ _ _ (BIN): DI3 (Point table No./Program No. selection 4) 0: Disabled (Use for an external input signal.) 1: Enabled (automatic on)		○	○																		
	x _ _ _ For manufacturer setting	0h																					
Convert the setting value into hexadecimal as follows.																							
<table border="1" style="display: inline-table; margin-right: 20px;"> <tr><td>0</td><td></td><td>0</td><td>0</td></tr> </table>  <table border="1" style="display: inline-table;"> <thead> <tr> <th rowspan="2">Input device</th> <th colspan="2">Initial value</th> </tr> <tr> <th>BIN</th> <th>HEX</th> </tr> </thead> <tbody> <tr> <td>DI0 (Point table No./Program No. 1)</td> <td>0</td> <td rowspan="4" style="text-align: center; vertical-align: middle;">0</td> </tr> <tr> <td>DI1 (Point table No./Program No. 2)</td> <td>0</td> </tr> <tr> <td>DI2 (Point table No./Program No. 3)</td> <td>0</td> </tr> <tr> <td>DI3 (Point table No./Program No. 4)</td> <td>0</td> </tr> </tbody> </table>						0		0	0	Input device	Initial value		BIN	HEX	DI0 (Point table No./Program No. 1)	0	0	DI1 (Point table No./Program No. 2)	0	DI2 (Point table No./Program No. 3)	0	DI3 (Point table No./Program No. 4)	0
0		0	0																				
Input device	Initial value																						
	BIN	HEX																					
DI0 (Point table No./Program No. 1)	0	0																					
DI1 (Point table No./Program No. 2)	0																						
DI2 (Point table No./Program No. 3)	0																						
DI3 (Point table No./Program No. 4)	0																						
PD44 *DI11H Input device selection 11H	Any input device can be assigned to the CN1-10 pin and the CN1-37 pin.																						
	__ x x	Not used with the positioning mode.	00h																				
	x x _ _	Positioning mode - Device selection Refer to table 7.10 in [Pr. PD04] for settings. When "00" is set, PP/PP2 (Forward rotation pulse/Manual pulse generator) will be assigned. The CN1-10 pin is available with servo amplifiers with software version B7 or later. The CN1-37 pin is available with servo amplifiers having software version B7 or later, and manufactured in May, 2015 or later.	20h	○	○																		
PD46 *DI12H Input device selection 12H	Any input device can be assigned to the CN1-35 pin and the CN1-38 pin.																						
	__ x x	Not used with the positioning mode.	00h																				
	x x _ _	Positioning mode - Device selection Refer to table 7.10 in [Pr. PD04] for settings. When "00" is set, NP/NP2 (Reverse rotation pulse/Manual pulse generator) will be assigned. The CN1-35 pin is available with servo amplifiers with software version B7 or later. The CN1-38 pin is available with servo amplifiers having software version B7 or later, and manufactured in May, 2015 or later.	2Bh	○	○																		

7. PARAMETERS

7.2.5 Extension setting 2 parameters ([Pr. PE__])

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode	
				C P	C L
PE41 EOP3 Function selection E-3	___x	Robust filter selection 0: Disabled 1: Enabled When "Enabled" is set, the machine resonance suppression filter 5 that is set in [Pr. PB51] is not available.	0h	<input type="radio"/>	<input type="radio"/>
	__x_	For manufacturer setting	0h	<input type="checkbox"/>	<input type="checkbox"/>
	_x__		0h	<input type="checkbox"/>	<input type="checkbox"/>
	x___		0h	<input type="checkbox"/>	<input type="checkbox"/>

7.2.6 Extension setting 3 parameters ([Pr. PF__])

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode	
				C P	C L
PF09 *FOP5 Function selection F-5	___x	Electronic dynamic brake selection 0: Disabled 3: Automatic (enabled only for specified servo motors) Refer to the following table for the specified servo motors.	0h	<input type="radio"/>	<input type="radio"/>
	__x_	For manufacturer setting	0h	<input type="checkbox"/>	<input type="checkbox"/>
	_x__		0h	<input type="checkbox"/>	<input type="checkbox"/>
	x___		0h	<input type="checkbox"/>	<input type="checkbox"/>
PF15 DBT Electronic dynamic brake operating time		Set an operating time for the electronic dynamic brake. Setting range: 0 to 10000	2000 [ms]	<input type="radio"/>	<input type="radio"/>
PF21 DRT Drive recorder switching time setting		Set a drive recorder switching time. When a USB communication is disconnected or a graph function is terminated while using a graph function, the function will be switched to the drive recorder function automatically after the setting time of this parameter. When a value from "1" to "32767" is set, the function will be switched to the drive recorder function after the set time. However, when "0" is set, it will be switched after 600 s. When "-1" is set, the drive recorder function is disabled. Setting range: -1 to 32767	0 [s]	<input type="radio"/>	<input type="radio"/>
PF23 OSCL1 Vibration tough drive - Oscillation detection level		Set a filter readjustment sensitivity of [Pr. PB13 Machine resonance suppression filter 1] and [Pr. PB15 Machine resonance suppression filter 2] while the vibration tough drive is enabled. Note that setting "0" will be 50%. Example: When "50" is set to this parameter, the filter will be readjusted at the time of the oscillation level reaching 50% or more. Setting range: 0 to 100	50 [%]	<input type="radio"/>	<input type="radio"/>

7. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode	
				C P	C L
PF24 *OSCL2 Vibration tough drive function selection	___ x	Oscillation detection alarm selection Select whether to generate an alarm or a warning when an oscillation continues at a filter readjustment sensitivity level of [Pr. PF23]. The setting is always enabled regardless of the vibration tough drive in [Pr. PA20]. 0: [AL. 54 Oscillation detection] will occur at oscillation detection. 1: [AL. F3.1 Oscillation detection warning] will occur at oscillation detection. 2: Oscillation detection function disabled	0h	<input type="radio"/>	<input type="radio"/>
	__ x _	For manufacturer setting	0h	<input type="checkbox"/>	<input type="checkbox"/>
	_ x _ _		0h	<input type="checkbox"/>	<input type="checkbox"/>
	x _ _ _		0h	<input type="checkbox"/>	<input type="checkbox"/>
PF25 CVAT Instantaneous power failure tough drive - Detection time		Set the time until the occurrence of [AL. 10.1 Voltage drop in the power]. When "instantaneous power failure tough drive selection" is set to "Disabled (_ 0 _)" in [Pr. PA20], this parameter is disabled. When "Instantaneous power failure tough drive selection" is set to "Enabled (_ 1 _)" in [Pr. PA20], the power should be off for the setting value of this parameter +1 s or more before turning on the power to enable a parameter whose symbol is preceded by "*". Setting range: 30 to 2000	200 [ms]	<input type="radio"/>	<input type="radio"/>
PF31 FRIC Machine diagnosis function - Friction judgement speed		Set a servo motor speed to divide a friction estimation area into high and low for the friction estimation process of the machine diagnosis. However, setting "0" will be the value half of the rated speed. When your operation pattern is under rated speed, we recommend that you set half value to the maximum speed with this. Setting range: 0 to permissible speed	0 [r/min]	<input type="radio"/>	<input type="radio"/>

7. PARAMETERS

7.2.7 Positioning control parameters ([Pr. PT_ _])

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode	
				C P	C L
PT01 *CTY Command mode selection	___x	Positioning command method selection 0: Absolute value command method 1: Incremental value command method	0h	<input type="radio"/>	<input type="radio"/>
	__x_	For manufacturer setting	0h	<input type="checkbox"/>	<input type="checkbox"/>
	_x__	Position data unit 0: mm 1: inch 2: degree 3: pulse For the simple cam function, set a command unit of the cam axis one cycle input during the cam control. The setting unit is applied to the cam axis one cycle length setting and the cam axis one cycle current value.	0h	<input type="radio"/>	<input type="radio"/>
	x___	For manufacturer setting	0h	<input type="checkbox"/>	<input type="checkbox"/>
PT02 *TOP1 Function selection T-1	___x	Follow-up of SON (Servo-on) off/EM2 (Forced stop 2) off with absolute value command method in incremental system 0: Disabled (Home position is erased at servo-off or EM2 off.) 1: Enabled (Home position is not erased even if servo-off, EM2 off, or alarm occurrence which can be canceled with reset. The operation can be continued.)	0h	<input type="radio"/>	<input type="radio"/>
	__x_	For manufacturer setting	0h	<input type="checkbox"/>	<input type="checkbox"/>
	_x__		0h	<input type="checkbox"/>	<input type="checkbox"/>
	x___	Point table/program writing inhibit 0: Allow 1: Inhibit	0h	<input type="radio"/>	<input type="radio"/>

7. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode	
				C P	C L
PT03 *FTY Feeding function selection	---x	Feed length multiplication [STM] 0: × 1 1: × 10 2: × 100 3: × 1000 This digit will be disabled when [degree] or [pulse] of "Position data unit" is set in [Pr. PT01].	0h	<input type="radio"/>	<input type="radio"/>
	--x-	Manual pulse generator multiplication 0: × 1 1: × 10 2: × 100	0h	<input type="radio"/>	<input type="radio"/>
	_x--	Shortest rotation selection per degree 0: Rotation direction specifying 1: Shortest rotation This parameter setting is available with servo amplifiers with software version B7 or later.	0h	<input type="radio"/>	<input type="radio"/>
	x---	For manufacturer setting	0h	<input type="checkbox"/>	<input type="checkbox"/>
PT04 *ZTY Home position return type	---x	Home position return method 0: Dog type (rear end detection, Z-phase reference)/torque limit changing dog type 1: Count type (front end detection, Z-phase reference) 2: Data set type/torque limit changing data set type 3: Stopper type 4: Home position ignorance (servo-on position as home position) 5: Dog type (rear end detection, rear end reference) 6: Count type (front end detection, front end reference) 7: Dog cradle type 8: Dog type (front end detection, Z-phase reference) 9: Dog type (front end detection, front end reference) A: Dogless type (Z-phase reference)	0h	<input type="radio"/>	<input type="radio"/>
	--x-	Home position return direction 0: Address increasing direction 1: Address decreasing command Setting "2" or more to this digit will be recognized as "1: Address decreasing direction".	1h	<input type="radio"/>	<input type="radio"/>
	_x--	Home position shift distance multiplication Set a multiplication of [Pr. PT07 Home position shift distance]. 0: × 1 1: × 10 2: × 100 3: × 1000 When [degree] of "Position data unit" is set in [Pr. PT01] in the point table method or program method, "0" and "1" can be used. ("2" or more will be recognized as "1".)	0h	<input type="radio"/>	<input type="radio"/>
	x---	For manufacturer setting	0h	<input type="checkbox"/>	<input type="checkbox"/>
PT05 ZRF Home position return speed	<input type="checkbox"/>	Set the servo motor speed for the home position return.. Setting range: 0 to permissible instantaneous speed	100 [r/min]	<input type="radio"/>	<input type="radio"/>
PT06 CRF Creep speed	<input type="checkbox"/>	Set a creep speed after proximity dog at home position return. Setting range: 0 to permissible instantaneous speed	10 [r/min]	<input type="radio"/>	<input type="radio"/>

7. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode	
				C P	C L
PT07 ZST Home position shift distance		Set a shift distance from the Z-phase pulse detection position in the encoder. The unit will be changed to [μm], $10^{-(\text{STM}-4)}$ [inch], 10^{-3} [degree], or [pulse] with the setting of [Pr. PT01]. Refer to the Function column of [Pr. PA10] for the command unit of [pulse]. Additionally, when "Home position shift distance multiplication" is set in [Pr. PT04], it is used with " $\times 10^n$ ". Setting range: 0 to 65535	0 Refer to Function column for unit.	<input type="radio"/>	<input type="radio"/>
PT08 *ZPS Home position return position data		Set the current position when the home position return is complete. The unit will be changed to 10^{STM} [μm], $10^{-(\text{STM}-4)}$ [inch], 10^{-3} [degree], or [pulse] with the setting of [Pr. PT01]. Additionally, when the following parameters are changed, the home position return position data will be changed. Execute the home position return again. - "Position data unit" in [Pr. PT01] - "Feed length multiplication (STM)" in [Pr. PT03] - "Home position return type" in [Pr. PT04] Setting range: -32768 to 32767	0 Refer to Function column for unit.	<input type="radio"/>	<input type="radio"/>
PT09 DCT Travel distance after proximity dog		Set a travel distance after proximity dog at home position return for the count type, dog type rear end reference, count type front end reference, and dog type front end reference. The unit will be changed to 10^{STM} [μm], $10^{-(\text{STM}-4)}$ [inch], 10^{-3} [degree], or [pulse] with the setting of [Pr. PT01]. Setting range: 0 to 65535	0 Refer to Function column for unit.	<input type="radio"/>	<input type="radio"/>
PT10 ZTM Stopper type home position return stopper time		Set a time from a moving part touches the stopper and torques reaches to the torque limit of [Pr. PT11 Stopper type home position return - Torque limit value] to a home position is set for the stopper type home position return. Setting "0" to "4" will be the same as setting "5". Setting range: 0 to 1000	100 [ms]	<input type="radio"/>	<input type="radio"/>
PT11 ZTT Stopper type home position return torque limit value		Set a torque limit value with [%] to the maximum torque at stopper type home position return. Setting "0.0" will be the same as setting "1.0". Setting range: 0 to 1000	15.0 [%]	<input type="radio"/>	<input type="radio"/>
PT12 CRP Rough match output range		Set a range of the command remaining distance which outputs CPO (Rough match). The unit will be changed to 10^{STM} [μm], $10^{-(\text{STM}-4)}$ [inch], 10^{-3} [degree], or [pulse] with the setting of [Pr. PT01]. Refer to the Function column of [Pr. PA10] for the command unit [pulse]. Setting range: 0 to 65535	0 Refer to Function column for unit.	<input type="radio"/>	<input type="radio"/>
PT13 JOG JOG speed		Set a JOG speed. Setting range: 0 to permissible instantaneous speed	100 [r/min]	<input type="radio"/>	<input type="radio"/>

7. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode	
				C P	C L
PT19 *LPPL Position range output address + (lower three digits)		Set an address increasing side of the position range output address. Upper and lower are a set. Set a range which POT (Position range) turns on with [Pr. PT19] to [Pr. PT22]. Setting address: <div style="text-align: center;"> </div>	0 Refer to Function column for unit.	○	○
PT20 *LPPH Position range output address + (upper three digits)					
PT21 *LNPL Position range output address - (lower three digits)		Set an address decreasing side of the position range output address. Upper and lower are a set. Set a range which POT (Position range) turns on with [Pr. PT19] to [Pr. PT22]. Setting address: <div style="text-align: center;"> </div>	0 Refer to Function column for unit.	○	○
PT22 *LNPH Position range output address - (upper three digits)					
PT23 OUT1 OUT1 output setting time		Set an output time for when OUT1 (Program output 1) is turned on with the OUTON command. Setting "0" will keep the on-state. To turn it off, use the OUTOF command. Setting range: 0 to 20000	0 [ms]		○
PT24 OUT2 OUT2 output setting time		Set an output time for when OUT2 (Program output 2) is turned on with the OUTON command. Setting "0" will keep the on-state. To turn it off, use the OUTOF command. Setting range: 0 to 20000	0 [ms]		○

7. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode																				
				C P	C L																			
PT25 OUT3 OUT3 output setting time		Set an output time for when OUT3 (Program output 3) is turned on with the OUTON command. Setting "0" will keep the on-state. To turn it off, use the OUTOF command. Setting range: 0 to 20000	0 [ms]		○																			
PT26 *TOP2 Function selection T-2	---x	Electronic gear fraction clear selection 0: Disabled 1: Enabled Selecting "Enabled" will clear a fraction of the previous command by the electronic gear at start of the automatic operation. Setting "2" or more to this digit will be "Disabled".	0h	○	○																			
	--x_	Current position/command position display selection Select how to display a current position and command position.	0h	○	○																			
	<table border="1"> <thead> <tr> <th rowspan="2">Setting value</th> <th rowspan="2">Displayed data</th> <th rowspan="2">Operation mode</th> <th colspan="2">Status display</th> </tr> <tr> <th>Current position</th> <th>Command position</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Positioning display</td> <td>Auto/Manual</td> <td>Actual current position is displayed as machine home position is 0.</td> <td>Command current position is displayed as machine home position is 0.</td> </tr> <tr> <td rowspan="2">1</td> <td rowspan="2">Roll feed display</td> <td>Automatic</td> <td rowspan="2">Actual current position will be displayed as automatic operation start position is 0.</td> <td>When ST1 (Forward rotation start) or ST2 (Reverse rotation start) is turned on, counting starts from 0 and a command current position to the target position is displayed. When a stop, a point table command position is displayed for the point table method and 0 is always displayed for the program method.</td> </tr> <tr> <td>Manual</td> <td>"0" is always displayed.</td> </tr> </tbody> </table>					Setting value	Displayed data	Operation mode	Status display		Current position	Command position	0	Positioning display	Auto/Manual	Actual current position is displayed as machine home position is 0.	Command current position is displayed as machine home position is 0.	1	Roll feed display	Automatic	Actual current position will be displayed as automatic operation start position is 0.	When ST1 (Forward rotation start) or ST2 (Reverse rotation start) is turned on, counting starts from 0 and a command current position to the target position is displayed. When a stop, a point table command position is displayed for the point table method and 0 is always displayed for the program method.	Manual	"0" is always displayed.
	Setting value	Displayed data	Operation mode	Status display																				
Current position				Command position																				
0	Positioning display	Auto/Manual	Actual current position is displayed as machine home position is 0.	Command current position is displayed as machine home position is 0.																				
1	Roll feed display	Automatic	Actual current position will be displayed as automatic operation start position is 0.	When ST1 (Forward rotation start) or ST2 (Reverse rotation start) is turned on, counting starts from 0 and a command current position to the target position is displayed. When a stop, a point table command position is displayed for the point table method and 0 is always displayed for the program method.																				
		Manual		"0" is always displayed.																				
This digit will be disabled when [degree] of "Position data unit" is set in [Pr. PT01]. Additionally, setting "2" or more will be "positioning display".																								
	x	For manufacturer setting	0h																					
	x_	Mark detection function selection 0: Current position latch function 1: Interrupt positioning function (Note) Note. The interrupt positioning function is available with servo amplifiers with software version B7 or later.	0h	○	○																			

7. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode																									
				C P	C L																								
PT29 *TOP3 Function selection T-3	Set a polarity of DOG, SIG, PI1, PI2, and PI3.																												
	___x (HEX)	___x (BIN): DOG (Proximity dog) polarity selection 0: Dog detection with off 1: Dog detection with on	0h	<input type="radio"/>	<input type="radio"/>																								
		__x_ (BIN): For manufacturer setting		<input type="checkbox"/>	<input type="checkbox"/>																								
		_x__ (BIN): For manufacturer setting		<input type="checkbox"/>	<input type="checkbox"/>																								
		x___ (BIN): Mark detection input polarity Select MSD (Mark detection) input polarity. 0: Normally closed contact 1: Normally open contact		<input type="radio"/>	<input type="radio"/>																								
	__x_ (HEX)	__x_ (BIN): PI1 (Program input 1) polarity selection 0: Positive logic 1: Negative logic	0h	<input type="checkbox"/>	<input type="radio"/>																								
		__x_ (BIN): PI2 (Program input 2) polarity selection 0: Positive logic 1: Negative logic		<input type="checkbox"/>	<input type="radio"/>																								
		_x__ (BIN): PI3 (Program input 3) polarity selection 0: Positive logic 1: Negative logic		<input type="checkbox"/>	<input type="radio"/>																								
		x___ (BIN): For manufacturer setting		<input type="checkbox"/>	<input type="checkbox"/>																								
	_x__	For manufacturer setting	0h	<input type="checkbox"/>	<input type="checkbox"/>																								
x___	For manufacturer setting	0h	<input type="checkbox"/>	<input type="checkbox"/>																									
Convert the setting value into hexadecimal as follows.																													
<table border="1" style="margin-left: 20px;"> <thead> <tr> <th rowspan="2">Setting</th> <th colspan="2">Initial value</th> </tr> <tr> <th>BIN</th> <th>HEX</th> </tr> </thead> <tbody> <tr> <td>DOG (Proximity dog) polarity selection</td> <td>0</td> <td rowspan="3">0</td> </tr> <tr> <td>Mark detection input polarity</td> <td>0</td> </tr> <tr> <td>Mark detection input polarity</td> <td>0</td> </tr> </tbody> </table> <table border="1" style="margin-left: 20px;"> <thead> <tr> <th rowspan="2">Setting</th> <th colspan="2">Initial value</th> </tr> <tr> <th>BIN</th> <th>HEX</th> </tr> </thead> <tbody> <tr> <td>PI1 (Program input 1) polarity selection</td> <td>0</td> <td rowspan="3">0</td> </tr> <tr> <td>PI2 (Program input 2) polarity selection</td> <td>0</td> </tr> <tr> <td>PI3 (Program input 3) polarity selection</td> <td>0</td> </tr> </tbody> </table>						Setting	Initial value		BIN	HEX	DOG (Proximity dog) polarity selection	0	0	Mark detection input polarity	0	Mark detection input polarity	0	Setting	Initial value		BIN	HEX	PI1 (Program input 1) polarity selection	0	0	PI2 (Program input 2) polarity selection	0	PI3 (Program input 3) polarity selection	0
Setting	Initial value																												
	BIN	HEX																											
DOG (Proximity dog) polarity selection	0	0																											
Mark detection input polarity	0																												
Mark detection input polarity	0																												
Setting	Initial value																												
	BIN	HEX																											
PI1 (Program input 1) polarity selection	0	0																											
PI2 (Program input 2) polarity selection	0																												
PI3 (Program input 3) polarity selection	0																												

7. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode	
				C P	C L
PT30 MSTL Mark sensor stop travel distance (lower three digits)		Set a mark sensor stop travel distance. Upper and lower are a set. When MSD (Mark detection) is on, the remaining distance will be changed to the travel distance that is set with this parameter.	0 Refer to Function column for unit.	<input type="radio"/>	<input type="radio"/>
PT31 MSTH Mark sensor stop travel distance (upper three digits)		Setting address: <div style="text-align: center;"> </div> When changing the setting, be sure to set the lower three digits first. Then, set the upper three digits. An incorrect order of the setting will trigger [AL. 37]. Therefore, cycling power may be required after [Pr. PT30] and [Pr. PT31] are all set. The unit will be changed to 10 ^{STM} [μm], 10 ^(STM-4) [inch], 10 ⁻³ [degree], or [pulse] with the setting of [Pr. PT01]. This parameter setting is available with servo amplifiers with software version B7 or later. Setting range: 0 to 999			
PT34 *PDEF Point table/program default		Use this parameter when initializing point tables, programs, and cam data. The point tables, the programs, and the cam data will be the following status by being initialized. Point table: All "0" Program: Erased Cam data: Erased Initialize the point tables and the programs with the following procedures: 1) Set "5001h" to this parameter. 2) Cycle the power of the servo amplifier. After the servo amplifier power is on, the initialization completes in about 20 s. "dEF" will be displayed on the display (five-digit, seven-segment LED) during the initialization. After the initialization, the setting of this parameter will be "0000h" automatically. Initialize the cam data with the following procedures: 1) Set "5010h" to this parameter. 2) Cycle the power of the servo amplifier. After the initialization, the setting of this parameter will be "0000h" automatically. Initialize the point tables, the programs and the cam data with the following procedures: 1) Set "5011h" to this parameter. 2) Cycle the power of the servo amplifier. After the servo amplifier power is on, the initialization completes in about 20 s. "dEF" will be displayed on the display (five-digit, seven-segment LED) during the initialization. After the initialization, the setting of this parameter will be "0000h" automatically.	0000h	<input type="radio"/>	<input type="radio"/>
PT35 *TOP5 Function selection T-5	___x	For manufacturer setting	0h	<input type="checkbox"/>	<input type="checkbox"/>
	__x_		0h	<input type="checkbox"/>	<input type="checkbox"/>
	_x__	Simple cam function selection 0: Disabled 1: Enabled This digit is enabled when the control mode is in the point table method or the program method. Enabling this digit in other control modes will trigger [AL. 37 Parameter error].	0h	<input type="radio"/>	<input type="radio"/>
	x___	For manufacturer setting	0h	<input type="checkbox"/>	<input type="checkbox"/>

7. PARAMETERS


No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode	
				C P	C L
PT41 ORP Home position return inhibit function selection	___x	Home position return inhibit selection 0: Disabled (home position return allowed) 1: Enabled (home position return inhibited) Selecting "1" for this digit will disable the home position return regardless of turning on ST1 in the home position return mode.	0h	○	○
	__x_	For manufacturer setting	0h		
	_x__		0h		
	x___		0h		

7. PARAMETERS

7.3 How to set the electronic gear

(1) Setting [mm], [inch], or [pulse] with "Position data unit" of [Pr. PT01].

Adjust [Pr. PA06] and [Pr. PA07] to match the servo amplifier setting with the travel distance of the machine.




Pt: Servo motor encoder revolution 131072 [pulse/rev]
 ΔS : Travel distance per servo motor revolution [mm/rev]/[inch/rev]/[pulse/rev]
 $CMX/CDV = Pt/\Delta S$

Set the electronic gear within the following range. Setting out of the range will trigger [AL. 37 Parameter error].

Electronic gear setting range
$1/865 < CMX/CDV < 271471$

(2) Setting [degree] with "Position data unit" of [Pr. PT01].

Set the number of gear teeth on machine side to [Pr. PA06] and the number of gear teeth on servo motor side to [Pr. PA07].



Pt: Servo motor encoder encoder revolution 131072 [pulse/rev]


Set the electronic gear within the following range. Setting out of the range will trigger [AL. 37 Parameter error].

- (a) Set values to make numerator and denominator 16384 or lower if the electronic gear (CMX/CDV) is reduced to its lowest terms.
- (b) Set values to make numerator and denominator 16777216 or lower if $(CMX \times Pt)/(CDV \times 360000)$ is reduced to its lowest terms.

The following shows a setting example of the electronic gear.

The number of gear teeth on machine side: 25, and the number of gear teeth on servo motor side: 11

Set [Pr. PA06] = 25 and [Pr. PA07] = 11.




Pt (Servo motor resolution): 131072 pulses/rev
 Z1: Number of gear teeth on servo motor side
 Z2: Number of gear teeth on machine side
 Z1: Z2 = 11:25

7. PARAMETERS

7.4 Software limit


The limit stop with the software limit ([Pr. PT15] to [Pr. PT18]) is the same as the motion of the stroke end. Exceeding a setting range will stop and servo-lock the shaft. This will be enabled at power-on and will be disabled at home position return. Setting a same value to "Software limit +" and "Software limit -" will disable this function. Setting a larger value to "Software limit -" than "Software limit +" will trigger [AL. 37.2 Parameter combination error].



7. PARAMETERS

7.5 Stop method for LSP (Forward rotation stroke end) off or LSN (Reverse rotation stroke end) off

Select a servo motor stop method for when LSP (Forward rotation stroke end) or LSN (Reverse rotation stroke end) is off with the first digit of [Pr. PD30].




Stop method selection for LSP (Forward rotation stroke end) off or LSN (Reverse rotation stroke end) off
 0: Quick stop (home position erased)
 1: Slow stop (home position erased)
 2: Slow stop (deceleration to a stop by deceleration time constant)
 3: Quick stop (stop by clearing remaining distance)

[Pr. PD30] setting	Operation status		Remark
	During rotation at constant speed	During deceleration to a stop	
--- 0 (initial value)			Erases the droop pulses and stops the servo motor. Erases the home position. A difference will be generated between the command position and the current position. Perform a home position return again.
--- 1			Travels for the droop pulses portion and stops the servo motor. Erases the home position. A difference will be generated between the command position and the current position. Perform a home position return again.
--- 2			Decelerates to a stop with the deceleration time constant currently selected with the point table or the program. Continues operation for a delay portion of the S-pattern acceleration/deceleration time constants. Maintains the home position.
--- 3			Travels for the droop pulses portion and stops the servo motor. Continues operation for a delay portion of the S-pattern acceleration/deceleration time constants. Maintains the home position.

7. PARAMETERS

7.6 Stop method at software limit detection

Select a stop method of the servo motor for when a software limit ([Pr. PT15] to [Pr. PT18]) is detected with the setting of the third digit in [Pr. PD30]. The software limit limits a command position controlled in the servo amplifier. Therefore, actual stop position will not reach the set position of the software limit.



- Stop method selection at software limit detection
- 0: Quick stop (home position erased)
 - 1: Slow stop (home position erased)
 - 2: Slow stop (deceleration to a stop by deceleration time constant)
 - 3: Quick stop (stop by clearing remaining distance)

[Pr. PD30] setting	Operation status		Remark
	During rotation at constant speed	During deceleration to a stop	
0 (initial value)			Erases the droop pulses and stops the servo motor. Erases the home position. A difference will be generated between the command position and the current position. Perform a home position return again.
1			Travels for the droop pulses portion and stops the servo motor. Erases the home position. A difference will be generated between the command position and the current position. Perform a home position return again.
2			Decelerates to a stop with the deceleration time constant currently selected with the point table or the program. Continues operation for a delay portion of the S-pattern acceleration/deceleration time constants. Maintains the home position.
3			Travels for the droop pulses portion and stops the servo motor. Continues operation for a delay portion of the S-pattern acceleration/deceleration time constants. Maintains the home position.

8. TROUBLESHOOTING

8. TROUBLESHOOTING

POINT
<ul style="list-style-type: none"> ● Refer to "MELSERVO-JE Servo Amplifier Instruction Manual (Troubleshooting)" for details of alarms and warnings. ● As soon as an alarm occurs, turn SON (Servo-on) off and interrupt the power. ● [AL. 37 Parameter error] and warnings (except [AL. F0 Tough drive warning]) are not recorded in the alarm history.

When an error occurs during operation, the corresponding alarm or warning is displayed. When the alarm occurs, refer to "MELSERVO-JE Servo Amplifier Instruction Manual (Troubleshooting)" to remove the failure. When an alarm occurs, ALM (Malfunction) will turn off. If any warning occurs, refer to section 1.5 and take the appropriate action.

8.1 Explanations of the lists

(1) No./Name/Detail No./Detail name

Indicates the alarm or warning No., name, detail No., and detail name.

(2) Stop method

For the alarms and warnings in which "SD" is written in the stop method column, the servo motor stops with the dynamic brake after forced stop deceleration. For the alarms and warnings in which "DB" or "EDB" is written in the stop method column, the servo motor stops with the dynamic brake without forced stop deceleration.

(3) Alarm deactivation

After the alarm cause has been removed, the alarm can be deactivated in any of the methods marked ○ in the alarm deactivation column. Warnings are automatically canceled after the cause of occurrence is removed. Alarms are deactivated by alarm reset, CPU reset, or power cycling.

Alarm deactivation	Explanation
Alarm reset	<ol style="list-style-type: none"> 1. Turn on RES (Reset) with an input device. 2. Press the "SET" button while the display of the servo amplifier is in the current alarm display mode. 3. Click the "Occurring Alarm Reset" button in the "Alarm Display" window of MR Configurator2.
Cycling the power	Turn off the power, check that the 5-digit, 7-segment LED display is off, and then turn on the power.

(4) Alarm code

Alarm codes are outputted only from the MR-JE-A. To output alarm codes, set [Pr. PD34] to "___1" when using an MR-JE-A. Alarm codes are outputted by turning on/off bit 0 to bit 2. Warnings ([AL. 90] to [AL. F3]) do not have alarm codes. The alarm codes in the following table will be outputted when they occur. The alarm codes will not be outputted in normal condition.

8. TROUBLESHOOTING

8.2 Alarm and warning list

When an error occurs during operation, the corresponding alarm or warning is displayed. If any alarm or warning has occurred, refer to section 8.2 or 8.3 and take the appropriate action. When an alarm occurs, ALM (Malfunction) will turn off.

To output alarm codes, set [Pr. PD34] to "___ 1". Alarm codes are outputted by turning on/off of bit 0 to bit 2. Warnings ([AL. 91] to [AL. F3]) do not have alarm codes. The alarm codes in the following table will be outputted when they occur. The alarm codes will not be outputted in normal condition.

After the alarm cause has been removed, the alarm can be deactivated in any of the methods marked ○ in the alarm deactivation column. Warnings are automatically canceled after the cause of occurrence is removed.

For the alarms and warnings in which "SD" is written in the stop method column, the servo motor stops with the dynamic brake after forced stop deceleration. For the alarms and warnings written "DB" in the stop method column, the servo motor stops with the dynamic brake without forced stop deceleration.

8.3 Alarm list

	No.	Alarm code			Name	Detailed display	Detail name	Stop method (Note 2, 3)	Alarm deactivation		
		CN1 49 (Bit 2)	CN1 23 (Bit 1)	CN1 24 (Bit 0)					Alarm reset (RES)	Press the "SET" button on the current alarm display.	Power off On (Note 4)
Alarm	10	0	1	0	Undervoltage	10.1	Voltage drop in the power	DB	○	○	○
						10.2	Bus voltage drop	SD	○	○	○
	12	0	0	0	Memory error 1 (RAM)	12.1	RAM error 1	DB			○
						12.2	RAM error 2	DB			○
						12.4	RAM error 4	DB			○
						12.5	RAM error 5	DB			○
	13	0	0	0	Clock error	13.1	Clock error 1	DB			○
						13.2	Clock error 2	DB			○
	14	0	0	0	Control process error	14.1	Control process error 1	DB			○
						14.2	Control process error 2	DB			○
						14.3	Control process error 3	DB			○
						14.4	Control process error 4	DB			○
						14.5	Control process error 5	DB			○
						14.6	Control process error 6	DB			○
						14.7	Control process error 7	DB			○
14.8						Control process error 8	DB			○	
14.9						Control process error 9	DB			○	
15	0	0	0	Memory error 2 (EEP-ROM)	15.1	EEP-ROM error at power on	DB			○	
					15.2	EEP-ROM error during operation	DB			○	

8. TROUBLESHOOTING

	No.	Alarm code			Name	Detailed display	Detail name	Stop method (Note 2, 3)	Alarm deactivation		
		CN1 49 (Bit 2)	CN1 23 (Bit 1)	CN1 24 (Bit 0)					Alarm reset (RES)	Press the "SET" button on the current alarm display.	Power off On (Note 4)
Alarm	16	1	1	0	Encoder initial communication error 1	16.1	Encoder initial communication - Receive data error 1	DB			○
						16.2	Encoder initial communication - Receive data error 2	DB			○
						16.3	Encoder initial communication - Receive data error 3	DB			○
						16.5	Encoder initial communication - Transmission data error 1	DB			○
						16.6	Encoder initial communication - Transmission data error 2	DB			○
						16.7	Encoder initial communication - Transmission data error 3	DB			○
						16.A	Encoder initial communication - Process error 1	DB			○
						16.B	Encoder initial communication - Process error 2	DB			○
						16.C	Encoder initial communication - Process error 3	DB			○
						16.D	Encoder initial communication - Process error 4	DB			○
						16.E	Encoder initial communication - Process error 5	DB			○
						16.F	Encoder initial communication - Process error 6	DB			○
	17	0	0	0	Board error	17.1	Board error 1	DB			○
						17.3	Board error 2	DB			○
						17.4	Board error 3	DB			○
	19	0	0	0	Memory error 3 (Flash-ROM)	19.1	Flash-ROM error 1	DB			○
						19.2	Flash-ROM error 2	DB			○
	1A	1	1	0	Servo motor combination error	1A.1	Servo motor combination error	DB			○
	1E	1	1	0	Encoder initial communication error 2	1E.1	Encoder malfunction	DB			○
	1F	1	1	0	Encoder initial communication error 3	1F.1	Incompatible encoder	DB			○
	20	1	1	0	Encoder normal communication error 1	20.1	Encoder normal communication - Receive data error 1	EDB			○
						20.2	Encoder normal communication - Receive data error 2	EDB			○
						20.3	Encoder normal communication - Receive data error 3	EDB			○
						20.5	Encoder normal communication - Transmission data error 1	EDB			○
						20.6	Encoder normal communication - Transmission data error 2	EDB			○
						20.7	Encoder normal communication - Transmission data error 3	EDB			○
						20.9	Encoder normal communication - Receive data error 4	EDB			○
						20.A	Encoder normal communication - Receive data error 5	EDB			○
	21	1	1	0	Encoder normal communication error 2	21.1	Encoder data error 1	EDB			○
						21.2	Encoder data update error	EDB			○
						21.3	Encoder data waveform error	EDB			○
						21.5	Encoder hardware error 1	EDB			○
						21.6	Encoder hardware error 2	EDB			○
	24	1	0	0	Main circuit error	24.1	Ground fault detected at hardware detection circuit	DB			○
						24.2	Ground fault detected by software detection function	DB	○	○	○

8. TROUBLESHOOTING

	No.	Alarm code			Name	Detailed display	Detail name	Stop method (Note 2, 3)	Alarm deactivation		
		CN1 49 (Bit 2)	CN1 23 (Bit 1)	CN1 24 (Bit 0)					Alarm reset (RES)	Press the "SET" button on the current alarm display.	Power off On (Note 4)
Alarm	30	0	0	1	Regenerative error (Note 1)	30.1	Regeneration heat error	DB	○ (Note 1)	○ (Note 1)	○ (Note 1)
						30.2	Regeneration signal error	DB	○ (Note 1)	○ (Note 1)	○ (Note 1)
						30.3	Regeneration feedback signal error	DB	○ (Note 1)	○ (Note 1)	○ (Note 1)
	31	1	0	1	Overspeed	31.1	Abnormal motor speed	SD	○	○	○
	32	1	0	0	Overcurrent	32.1	Overcurrent detected at hardware detection circuit (during operation)	DB	/	/	○
						32.2	Overcurrent detected at software detection function (during operation)	DB	○	○	○
						32.3	Overcurrent detected at hardware detection circuit (during a stop)	DB	/	/	○
						32.4	Overcurrent detected at software detection function (during a stop)	DB	○	○	○
	33	0	0	1	Overvoltage	33.1	Main circuit voltage error	EDB	○	○	○
	35	1	0	1	Command frequency error	35.1	Command frequency error	SD	○	○	○
	37	0	0	0	Parameter error	37.1	Parameter setting range error	DB	/	/	○
						37.2	Parameter combination error	DB	/	/	○
						37.3	Point table setting error	DB	/	/	○
	39	0	0	0	Program error	39.1	Program error	DB	/	/	○
						39.2	Command argument external error	DB	/	/	○
						39.3	Register No. error	DB	/	/	○
						39.4	Non-correspondence command error	DB	/	/	○
	3A	0	0	0	Inrush current suppression circuit error	3A.1	Inrush current suppression circuit error	EDB	/	/	○
	3E	0	0	0	Operation mode error	3E.6	Operation mode switch error	DB	/	/	○
	45	0	1	1	Main circuit device overheat (Note 1)	45.1	Main circuit device overheat error	SD	○ (Note 1)	○ (Note 1)	○ (Note 1)
	46	0	1	1	Servo motor overheat (Note 1)	46.1	Abnormal temperature of servo motor 1	SD	○ (Note 1)	○ (Note 1)	○ (Note 1)
						46.5	Abnormal temperature of servo motor 3	DB	○ (Note 1)	○ (Note 1)	○ (Note 1)
						46.6	Abnormal temperature of servo motor 4	DB	○ (Note 1)	○ (Note 1)	○ (Note 1)
47	0	1	1	Cooling fan error	47.2	Cooling fan speed reduction error	SD	/	/	○	
50	0	1	1	Overload 1 (Note 1)	50.1	Thermal overload error 1 during operation	SD	○ (Note 1)	○ (Note 1)	○ (Note 1)	
					50.2	Thermal overload error 2 during operation	SD	○ (Note 1)	○ (Note 1)	○ (Note 1)	
					50.3	Thermal overload error 4 during operation	SD	○ (Note 1)	○ (Note 1)	○ (Note 1)	
					50.4	Thermal overload error 1 during a stop	SD	○ (Note 1)	○ (Note 1)	○ (Note 1)	
					50.5	Thermal overload error 2 during a stop	SD	○ (Note 1)	○ (Note 1)	○ (Note 1)	
					50.6	Thermal overload error 4 during a stop	SD	○ (Note 1)	○ (Note 1)	○ (Note 1)	
51	0	1	1	Overload 2 (Note 1)	51.1	Thermal overload error 3 during operation	DB	○ (Note 1)	○ (Note 1)	○ (Note 1)	
					51.2	Thermal overload error 3 during a stop	DB	○ (Note 1)	○ (Note 1)	○ (Note 1)	

8. TROUBLESHOOTING

	No.	Alarm code			Name	Detailed display	Detail name	Stop method (Note 2, 3)	Alarm deactivation		
		CN1 49 (Bit 2)	CN1 23 (Bit 1)	CN1 24 (Bit 0)					Alarm reset (RES)	Press the "SET" button on the current alarm display.	Power off On (Note 4)
Alarm	52	1	0	1	Error excessive	52.1	Excess droop pulse 1	SD	○	○	○
						52.3	Excess droop pulse 2	SD	○	○	○
						52.4	Error excessive during 0 torque limit	SD	○	○	○
						52.5	Excess droop pulse 3	EDB	○	○	○
	54	0	1	1	Oscillation detection	54.1	Oscillation detection error	EDB	○	○	○
	56	1	1	0	Forced stop error	56.2	Over speed during forced stop	EDB	○	○	○
						56.3	Estimated distance over during forced stop	EDB	○	○	○
	61	1	0	1	Operation error	61.1	Point table setting error	DB	○	○	○
	61	1	0	1	Operation error	61.1	Point table setting error	DB	○	○	○
	8A	0	0	0	USB communication time-out error/Serial communication time-out error	8A.1	USB communication time-out error/Serial communication time-out error	SD	○	○	○
	8E	0	0	0	USB communication error/Serial communication error	8E.1	USB communication receive error/Serial communication receive error	SD	○	○	○
						8E.2	USB communication checksum error/Serial communication checksum error	SD	○	○	○
						8E.3	USB communication character error/Serial communication character error	SD	○	○	○
						8E.4	USB communication command error/Serial communication command error	SD	○	○	○
						8E.5	USB communication data number error/Serial communication data number error	SD	○	○	○
8888				Watchdog	8888_	Watchdog	SD			○	

Note 1. Leave for about 30 minutes of cooling time after removing the cause of occurrence.

2. The following shows three stop methods of DB, EDB, and SD.

DB: Dynamic brake stop (For a servo amplifier without the dynamic brake, the servo motor coasts.)

EDB: Electronic dynamic brake stop (available with specified servo motors)

Refer to the following table for the specified servo motors. DB is applied as the stop method for other than the specified servo motor.

For MR-JE_A, setting [Pr. PF09] to "(_ _ _ 3)" enables the electronic dynamic brake.

Series	Servo motor
HG-KN	HG-KN053/HG-KN13/HG-KN23/HG-KN43
HG-SN	HG-SN52

SD: Forced stop deceleration

3. This is applicable when [Pr. PA04] is set to the initial value. The stop method of SD can be changed to DB using [Pr. PA04].

4. To cancel the alarm, turn off the power and check that the 5-digit, 7-segment LED display is off, and then turn on the power.

8. TROUBLESHOOTING

8.4 Warning list

	No.	Name	Detailed display	Detail name	Stop method (Note 2, 3)
Warning	90	Home position return incomplete warning	90.1	Home position return incomplete	
			90.2	Home position return abnormal termination	
			90.5	Z-phase unpassed	
	91	Servo amplifier overheat warning (Note 1)	91.1	Main circuit device overheat warning	
	97	Program operation disabled warning	97.1	Program operation disabled warning	
	98	Software limit warning	98.1	Forward rotation-side software stroke limit reached	
			98.2	Reverse rotation-side software stroke limit reached	
	99	Stroke limit warning	99.1	Forward rotation stroke end off	(Note 4)
			99.2	Reverse rotation stroke end off	(Note 4)
	E0	Excessive regeneration warning (Note 1)	E0.1	Excessive regeneration warning	
	E1	Overload warning 1 (Note 1)	E1.1	Thermal overload warning 1 during operation	
			E1.2	Thermal overload warning 2 during operation	
			E1.3	Thermal overload warning 3 during operation	
			E1.4	Thermal overload warning 4 during operation	
			E1.5	Thermal overload warning 1 during a stop	
			E1.6	Thermal overload warning 2 during a stop	
			E1.7	Thermal overload warning 3 during a stop	
	E1.8	Thermal overload warning 4 during a stop			
	E6	Servo forced stop warning	E6.1	Forced stop warning	SD
	E8	Cooling fan speed reduction warning	E8.1	Decreased cooling fan speed warning	
	E9	Main circuit off warning	E9.1	Servo-on signal on during main circuit off	DB
			E9.2	Bus voltage drop during low speed operation	DB
	EC	Overload warning 2 (Note 1)	EC.1	Overload warning 2	
	ED	Output watt excess warning	ED.1	Output watt excess warning	
	F0	Tough drive warning	F0.1	Instantaneous power failure tough drive warning	
			F0.3	Vibration tough drive warning	
	F2	Drive recorder - Miswriting warning	F2.1	Drive recorder - Area writing time-out warning	
			F2.2	Drive recorder - Data miswriting warning	
	F3	Oscillation detection warning	F3.1	Oscillation detection warning	
	F5	Simple cam function - Cam data miswriting warning	F5.1	Cam data - Area writing time-out warning	
F5.2			Cam data - Area miswriting warning		
F5.3			Cam data checksum error		
F6	Simple cam function - Cam control warning	F6.1	Cam axis one cycle current value restoration failed		
		F6.2	Cam axis feed current value restoration failed		
		F6.3	Cam unregistered error		
		F6.4	Cam control data setting range error		
		F6.5	Cam No. external error		
F6.6	Cam control inactive				

- Note
1. Leave for about 30 minutes of cooling time after removing the cause of occurrence.
 2. The following shows two stop methods of DB and SD.
 - DB: Stop with dynamic brake
 - SD: Forced stop deceleration
 3. This is applicable when [Pr. PA04] is set to the initial value. The stop method of SD can be changed to DB using [Pr. PA04].
 4. Quick stop or slow stop can be selected using [Pr. PD30].

9. OPTIONS AND PERIPHERAL EQUIPMENT

9. OPTIONS AND PERIPHERAL EQUIPMENT



WARNING

● Before connecting any option or peripheral equipment, turn off the power and wait for 15 minutes or more until the charge lamp turns off. Then, confirm that the voltage between P+ and N- is safe with a voltage tester and others. Otherwise, an electric shock may occur. In addition, when confirming whether the charge lamp is off or not, always confirm it from the front of the servo amplifier.



CAUTION

● Use the specified peripheral equipment and options to prevent a malfunction or a fire.

For the details of the following items, refer to chapter/section (of "MR-JE-_A Servo Amplifier Instruction Manual") indicated in the table.

Item	Detailed explanation
	MR-JE-_A
Cable/connector sets	Section 11.1
Regenerative option	Section 11.2
Junction terminal block MR-TB50	Section 11.3
MR Configurator2	Section 11.4
Selection example of wires	Section 11.5
Molded-case circuit breakers, fuses, magnetic contactors	Section 11.6
Power factor improving AC reactor	Section 11.7
Relay (recommended)	Section 11.8
Noise reduction techniques	Section 11.9
Earth-leakage current breaker	Section 11.10
EMC filter (recommended)	Section 11.11

9. OPTIONS AND PERIPHERAL EQUIPMENT

9.1 MR-HDP01 manual pulse generator


POINT
<ul style="list-style-type: none"> ● When using an MR-HDP01, set [Pr. PA13 Command pulse input form] to "_ 2 _ 2" or "_ 3 _ 2". ● Configure MR-HDP01 with sink interface.

You can operate servo motors by using MR-HDP01 manual pulse generator. A multiplication to pulse signals which MR-HDP01 generates with external input signals can be changed with TP0 (Manual pulse generator multiplication 1) and TP1 (Manual pulse generator multiplication 2).

(1) Specifications

Item	Specifications	
Power supply	Voltage	4.5 V DC to 13.2 V DC
	Consumption current	60 mA or less
Interface	Maximum output current: 20 mA for open collector output	
Pulse signal form	A-phase/B-phase, 2 signals of 90° phase difference	
Pulse resolution	100 pulses/rev	
Maximum speed	Instantaneous maximum: 600 r/min, normal: 200 r/min	
Temperature range for operation	-10 °C to 60 °C	
Temperature range for storage	-30 °C to 80 °C	


(2) Connection example



- Note 1. To assign PP and NP, set [Pr. PD44] and [Pr. PD46] to "0 0 _ _".
 Note 2. To use this as an input device, assign to specified pin of the CN1 connector with [Pr. PD04] to [Pr. PD22].

9. OPTIONS AND PERIPHERAL EQUIPMENT


(3) Terminal assignment



Signal name	Description
+5 to 12 V	Power supply input
0 V	Common for power and signal
A	A-phase output pulse
B	B-phase output pulse


(4) Mounting

[Unit: mm]



(5) Dimensions

[Unit: mm]



10. COMMUNICATION FUNCTION (MITSUBISHI GENERAL-PURPOSE AC SERVO PROTOCOL)

10. COMMUNICATION FUNCTION (MITSUBISHI GENERAL-PURPOSE AC SERVO PROTOCOL)

For the details of the following items, refer to chapter/section (of "MR-JE-_A Servo Amplifier Instruction Manual") indicated in the table.

Item	Detailed explanation
	MR-JE-_A
Structure	Section 12.1
Communication specifications	Section 12.2
Protocol	Section 12.3
Data processing	Section 12.5.1
Status display	Section 12.5.2
Parameter	Section 12.5.3
Prohibiting/canceling I/O devices (DIO)	Section 12.5.6
Alarm history	Section 12.5.10
Current alarm	Section 12.5.11
Software version	Section 12.5.12

POINT

- Creating and reading programs are not available with Mitsubishi general-purpose AC servo protocol (RS-422 communication). Use MR Configurator2.

10.1 Command and data No. list

POINT

- Even if a command or data No. is the same between different model servo amplifiers, its description may differ.
- The symbols in the control mode column mean as follows:
 - CP: Positioning mode (point table method)
 - CL: Positioning mode (program method)

10. COMMUNICATION FUNCTION (MITSUBISHI GENERAL-PURPOSE AC SERVO PROTOCOL)

10.1.1 Reading command

(1) Status display (command [0] [1])

Command	Data No.	Description	Status display	Control mode		Frame length
				C P	C L	
[0] [1]	[0] [0]	Status display symbol and unit	Cumulative feedback pulses	○	○	16
	[0] [1]		Servo motor speed	○	○	
	[0] [2]		Droop pulses Servo motor-side droop pulses	○	○	
	[0] [3]		Cumulative command pulses			
	[0] [4]		Command pulse frequency			
	[0] [5]		Analog speed command voltage Analog speed limit voltage			
	[0] [6]		Analog torque limit voltage Analog torque command voltage			
	[0] [7]		Regenerative load ratio	○	○	
	[0] [8]		Effective load ratio	○	○	
	[0] [9]		Peak load ratio	○	○	
	[0] [A]		Instantaneous torque	○	○	
	[0] [B]		Position within one-revolution	○	○	
	[0] [C]		ABS counter	○	○	
	[0] [D]		Load to motor inertia ratio	○	○	
	[0] [E]		Bus voltage	○	○	
	[2] [0]		Encoder inside temperature	○	○	
	[2] [1]		Settling time	○	○	
	[2] [2]		Oscillation detection frequency	○	○	
	[2] [3]		Number of tough drive operations	○	○	
	[2] [8]		Unit power consumption	○	○	
	[2] [9]		Unit total power consumption	○	○	
	[2] [A]		Current position	○	○	
	[2] [B]		Command position	○	○	
	[2] [C]		Command remaining distance	○	○	
	[2] [D]		Point table No./Program No.	○	○	

10. COMMUNICATION FUNCTION (MITSUBISHI GENERAL-PURPOSE AC SERVO PROTOCOL)

Command	Data No.	Description	Status display	Control mode		Frame length
				C P	C L	
[0] [1]	[2] [E]	Status display symbol and unit	Step No.	○	○	16
	[2] [F]		Analog override voltage	○	○	
	[3] [0]		Override level	○	○	
	[3] [3]		Cam axis one cycle current value	○	○	
	[3] [4]		Cam standard position	○	○	
	[3] [5]		Cam axis feed current value	○	○	
	[3] [6]		Cam No. in execution	○	○	
	[3] [7]		Cam stroke amount in execution	○	○	
	[3] [8]		Main axis current value	○	○	
	[3] [9]		Main axis one cycle current value	○	○	
[8] [0]	Status display data value and processing information	Cumulative feedback pulses	○	○	12	
[8] [1]		Servo motor speed	○	○		
[8] [2]		Droop pulses	○	○		
[8] [3]		Cumulative command pulses	○	○		
[8] [4]		Command pulse frequency	○	○		
[8] [5]		Analog speed command voltage	○	○		
[8] [6]		Analog speed limit voltage	○	○		
[8] [7]		Analog torque limit voltage	○	○		
[8] [8]		Analog torque command voltage	○	○		
[8] [9]		Regenerative load ratio	○	○		
[8] [A]		Effective load ratio	○	○		
[8] [B]		Peak load ratio	○	○		
[8] [C]		Instantaneous torque	○	○		
[8] [D]		Position within one-revolution	○	○		
[8] [E]		ABS counter	○	○		
[A] [0]		Load to motor inertia ratio	○	○		
[A] [1]		Bus voltage	○	○		
[A] [2]		Encoder inside temperature	○	○		
[A] [3]		Settling time	○	○		
[A] [4]		Oscillation detection frequency	○	○		
[A] [5]		Number of tough drive operations	○	○		
[A] [6]		Unit power consumption	○	○		
[A] [7]		Unit total power consumption	○	○		
[A] [8]		Current position	○	○		
[A] [9]		Command position	○	○		
[A] [A]		Command remaining distance	○	○		
[A] [B]		Command remaining distance	○	○		
[A] [C]		Command remaining distance	○	○		
[A] [D]		Point table No./Program No.	○	○		
[A] [E]		Step No.	○	○		
[A] [F]	Analog override voltage	○	○			
[B] [0]	Override level	○	○			
[B] [3]	Cam axis one cycle current value	○	○			
[B] [4]	Cam standard position	○	○			
[B] [5]	Cam axis feed current value	○	○			
[B] [6]	Cam No. in execution	○	○			
[B] [7]	Cam stroke amount in execution	○	○			
[B] [8]	Main axis current value	○	○			
[B] [9]	Main axis one cycle current value	○	○			

10. COMMUNICATION FUNCTION (MITSUBISHI GENERAL-PURPOSE AC SERVO PROTOCOL)

(2) Parameter (command [0] [4], [1] [5], [1] [6], [1] [7], [0] [8], and [0] [9])

Command	Data No.	Description	Control mode		Frame length
			C P	C L	
[0] [4]	[0] [1]	<p>Parameter group reading</p> <p>0000: Basic setting parameters ([Pr. PA__]) 0001: Gain/filter parameters ([Pr. PB__]) 0002: Extension setting parameters ([Pr. PC__]) 0003: I/O setting parameters ([Pr. PD__]) 0004: Extension setting 2 parameters ([Pr. PE__]) 0005: Extension setting 3 parameters ([Pr. PF__]) 000C: Positioning control parameters ([Pr. PT__])</p> <p>Reads the parameter group specified with the command [8] [5] + data No. [0] [0]. Therefore, be sure to specify the parameter group with the command [8] [5] + data No. [0] [0] before reading the current values.</p>	○	○	4
[1] [5]	[0] [1] to [F] [F]	<p>Current value of each parameter</p> <p>Reads the current values of the parameters in the parameter group specified with the command [8] [5] + data No. [0] [0]. Therefore, be sure to specify the parameter group with the command [8] [5] + data No. [0] [0] before reading the current values.</p> <p>The data No. (hexadecimal) value which is converted to decimal corresponds to the parameter No.</p>	○	○	12
[1] [6]	[0] [1] to [F] [F]	<p>Upper limit value of each parameter setting range</p> <p>Reads the permissible upper limit values of the parameters in the parameter group specified with the command [8] [5] + data No. [0] [0]. Therefore, be sure to specify the parameter group with the command [8] [5] + data No. [0] [0] before reading the upper limit values.</p> <p>The data No. (hexadecimal) value which is converted to decimal corresponds to the parameter No.</p>	○	○	
[1] [7]	[0] [1] to [F] [F]	<p>Lower limit value of each parameter setting range</p> <p>Reads the permissible lower limit values of the parameters in the parameter group specified with the command [8] [5] + data No. [0] [0]. Therefore, be sure to specify the parameter group with the command [8] [5] + data No. [0] [0] before reading the lower limit values.</p> <p>The data No. (hexadecimal) value which is converted to decimal corresponds to the parameter No.</p>	○	○	
[0] [8]	[0] [1] to [F] [F]	<p>Each parameter symbol</p> <p>Reads the symbols of the parameters in the parameter group specified with the command [8] [5] + data No. [0] [0]. Therefore, be sure to specify the parameter group with the command [8] [5] + data No. [0] [0] before reading the symbol.</p> <p>The data No. (hexadecimal) value which is converted to decimal corresponds to the parameter No.</p>	○	○	
[0] [9]	[0] [1] to [F] [F]	<p>Writing enable/disable of parameters</p> <p>Reads writing enable/disable of the parameters in the parameter group specified with the command [8] [5] + data No. [0] [0]. Therefore, be sure to specify the parameter group with the command [8] [5] + data No. [0] [0] before reading the writing enable/disable.</p> <p>0000: Writing enabled 0001: Writing disabled</p>	○	○	4

10. COMMUNICATION FUNCTION (MITSUBISHI GENERAL-PURPOSE AC SERVO PROTOCOL)

(3) External I/O signals (command [1] [2])

Command	Data No.	Description	Control mode		Frame length
			C P	C L	
[1] [2]	[0] [0] to [0] [2]	Input device status	○	○	8
	[4] [0]	External input pin status	○	○	
	[6] [0] to [6] [2]	Status of input device turned on by communication	○	○	
	[8] [0] to [8] [3]	Output device status	○	○	
	[C] [0]	External output pin status	○	○	

(4) Current position latch display (command [1] [A])

Command	Data No.	Description	Control mode		Frame length
			C P	C L	
[1] [A]	[0] [0]	MSD (Mark detection) rising latch data (data part)	○	○	8
	[0] [1]	MSD (Mark detection) falling latch data (data part)	○	○	
	[0] [2]	MSD (Mark detection) rising latch data (data part + additional information)	○	○	12
	[0] [3]	MSD (Mark detection) falling latch data (data part + additional information)	○	○	

10. COMMUNICATION FUNCTION (MITSUBISHI GENERAL-PURPOSE AC SERVO PROTOCOL)

(5) Alarm history (command [3] [3])

Command	Data No.	Description	Alarm occurrence sequence	Control mode		Frame length
				C P	C L	
[3] [3]	[1] [0]	Alarm No. in alarm history	Most recent alarm	○	○	4
	[1] [1]		One alarm ago	○	○	
	[1] [2]		Two alarms ago	○	○	
	[1] [3]		Three alarms ago	○	○	
	[1] [4]		Four alarms ago	○	○	
	[1] [5]		Five alarms ago	○	○	
	[1] [6]		Six alarms ago	○	○	
	[1] [7]		Seven alarms ago	○	○	
	[1] [8]		Eight alarms ago	○	○	
	[1] [9]		Nine alarms ago	○	○	
	[1] [A]		Ten alarms ago	○	○	
	[1] [B]		Eleven alarms ago	○	○	
	[1] [C]		Twelve alarms ago	○	○	
	[1] [D]		Thirteen alarms ago	○	○	
	[1] [E]		Fourteen alarms ago	○	○	
	[1] [F]	Fifteen alarms ago	○	○		
	[2] [0]	Alarm occurrence time in alarm history	Most recent alarm	○	○	8
	[2] [1]		One alarm ago	○	○	
	[2] [2]		Two alarms ago	○	○	
	[2] [3]		Three alarms ago	○	○	
	[2] [4]		Four alarms ago	○	○	
	[2] [5]		Five alarms ago	○	○	
	[2] [6]		Six alarms ago	○	○	
	[2] [7]		Seven alarms ago	○	○	
	[2] [8]		Eight alarms ago	○	○	
	[2] [9]		Nine alarms ago	○	○	
	[2] [A]		Ten alarms ago	○	○	
	[2] [B]		Eleven alarms ago	○	○	
	[2] [C]		Twelve alarms ago	○	○	
	[2] [D]		Thirteen alarms ago	○	○	
	[2] [E]		Fourteen alarms ago	○	○	
	[2] [F]	Fifteen alarms ago	○	○		

(6) Current alarm (command [0] [2])

Command	Data No.	Description	Control mode		Frame length
			C P	C L	
[0] [2]	[0] [0]	Current alarm No.	○	○	4

10. COMMUNICATION FUNCTION (MITSUBISHI GENERAL-PURPOSE AC SERVO PROTOCOL)

(7) Status display at alarm occurrence (command [3] [5])

Command	Data No.	Description	Status display	Control mode		Frame length
				C P	C L	
[3] [5]	[0] [0]	Status display symbol and unit	Cumulative feedback pulses	○	○	16
	[0] [1]		Servo motor speed	○	○	
	[0] [2]		Droop pulses	○	○	
	[0] [3]		Cumulative command pulses	○	○	
	[0] [4]		Command pulse frequency	○	○	
	[0] [5]		Analog speed command voltage	○	○	
			Analog speed limit voltage	○	○	
	[0] [6]		Analog torque limit voltage	○	○	
			Analog torque command voltage	○	○	
	[0] [7]		Regenerative load ratio	○	○	
	[0] [8]		Effective load ratio	○	○	
	[0] [9]		Peak load ratio	○	○	
	[0] [A]		Instantaneous torque	○	○	
	[0] [B]		Position within one-revolution	○	○	
	[0] [C]		ABS counter	○	○	
	[0] [D]		Load to motor inertia ratio	○	○	
	[0] [E]		Bus voltage	○	○	
	[2] [0]		Encoder inside temperature	○	○	
	[2] [1]		Settling time	○	○	
	[2] [2]		Oscillation detection frequency	○	○	
	[2] [3]		Number of tough drive operations	○	○	
	[2] [8]		Unit power consumption	○	○	
	[2] [9]		Unit total power consumption	○	○	
	[2] [A]		Current position	○	○	
	[2] [B]		Command position	○	○	
	[2] [C]		Command remaining distance	○	○	
	[2] [D]		Point table No./Program No.	○	○	
	[2] [E]		Step No.	○	○	
	[2] [F]		Analog override voltage	○	○	
	[3] [0]		Override level	○	○	
	[3] [3]		Cam axis one cycle current value	○	○	
	[3] [4]		Cam standard position	○	○	
	[3] [5]		Cam axis feed current value	○	○	
	[3] [6]		Cam No. in execution	○	○	
	[3] [7]		Cam stroke amount in execution	○	○	
	[3] [8]		Main axis current value	○	○	
	[3] [9]		Main axis one cycle current value	○	○	

10. COMMUNICATION FUNCTION (MITSUBISHI GENERAL-PURPOSE AC SERVO PROTOCOL)

Command	Data No.	Description	Status display	Control mode		Frame length
				C P	C L	
[3] [5]	[8] [0]	Status display data value and processing information	Cumulative feedback pulses	○	○	12
	[8] [1]		Servo motor speed	○	○	
	[8] [2]		Droop pulses	○	○	
	[8] [3]		Cumulative command pulses	○	○	
	[8] [4]		Command pulse frequency	○	○	
	[8] [5]		Analog speed command voltage	○	○	
			Analog speed limit voltage	○	○	
	[8] [6]		Analog torque limit voltage	○	○	
			Analog torque command voltage	○	○	
	[8] [7]		Regenerative load ratio	○	○	
	[8] [8]		Effective load ratio	○	○	
	[8] [9]		Peak load ratio	○	○	
	[8] [A]		Instantaneous torque	○	○	
	[8] [B]		Position within one-revolution	○	○	
	[8] [C]		ABS counter	○	○	
	[8] [D]		Load to motor inertia ratio	○	○	
	[8] [E]		Bus voltage	○	○	
	[A] [0]		Encoder inside temperature	○	○	
	[A] [1]		Settling time	○	○	
	[A] [2]		Oscillation detection frequency	○	○	
	[A] [3]		Number of tough drive operations	○	○	
	[A] [8]		Unit power consumption	○	○	
	[A] [9]		Unit total power consumption	○	○	
	[A] [A]		Current position	○	○	
	[A] [B]		Command position	○	○	
	[A] [C]		Command remaining distance	○	○	
	[A] [D]		Point table No./Program No.	○	○	
	[A] [E]		Step No.	○	○	
	[A] [F]		Analog override voltage	○	○	
	[B] [0]		Override level	○	○	
	[B] [3]		Cam axis one cycle current value	○	○	
	[B] [4]		Cam standard position	○	○	
	[B] [5]		Cam axis feed current value	○	○	
	[B] [6]		Cam No. in execution	○	○	
[B] [7]	Cam stroke amount in execution	○	○			
[B] [8]	Main axis current value	○	○			
[B] [9]	Main axis one cycle current value	○	○			

10. COMMUNICATION FUNCTION (MITSUBISHI GENERAL-PURPOSE AC SERVO PROTOCOL)

(8) Point table setting data (command [4] [0], [4] [5], [5] [0], [5] [4], [5] [8], [6] [0], [6] [4])

Command	Data No.	Description	Control mode		Frame length
			C P	C L	
[4] [0]	[0] [1] to [1] [F]	Reading position data of each point table The data No. (hexadecimal) value which is converted to decimal corresponds to the point table No.	○	○	8
[4] [5]	[0] [1] to [1] [F]	Reading M code of each point table This command will be available in the future. The data No. (hexadecimal) value which is converted to decimal corresponds to the point table No.	○	○	
[5] [0]	[0] [1] to [1] [F]	Reading speed data of each point table The data No. (hexadecimal) value which is converted to decimal corresponds to the point table No.	○	○	
[5] [4]	[0] [1] to [1] [F]	Reading acceleration time constant of each point table The data No. (hexadecimal) value which is converted to decimal corresponds to the point table No.	○	○	
[5] [8]	[0] [1] to [1] [F]	Reading deceleration time constant of each point table The data No. (hexadecimal) value which is converted to decimal corresponds to the point table No.	○	○	
[6] [0]	[0] [1] to [1] [F]	Reading dwell of each point table The data No. (hexadecimal) value which is converted to decimal corresponds to the point table No.	○	○	
[6] [4]	[0] [1] to [1] [F]	Reading sub function of each point table The data No. (hexadecimal) value which is converted to decimal corresponds to the point table No.	○	○	

(9) Position data unit/Current position latch data (command [6] [C])

Command	Data No.	Description	Control mode		Frame length
			C P	C L	
[6] [C]	[0] [0]	Reading position data unit ___ x 0: mm, 1: inch, 2: pulse, 3: degree __ x _0: Enabled, 1: Disabled	○	○	4
	[0] [1]	Reading current position latch data Reads data latched at rising edge of LPS signal using LPOS command in the program operation.	○	○	12

(10) General purpose register (Rx) value (command [6] [D])

Command	Data No.	Description	Control mode		Frame length
			C P	C L	
[6] [D]	[0] [1]	Reading general purpose register (R1) value	○	○	8
	[0] [2]	Reading general purpose register (R2) value	○	○	
	[0] [3]	Reading general purpose register (R3) value	○	○	
	[0] [4]	Reading general purpose register (R4) value	○	○	

10. COMMUNICATION FUNCTION (MITSUBISHI GENERAL-PURPOSE AC SERVO PROTOCOL)

(11) General purpose register (Dx) value (command [6] [E])

Command	Data No.	Description	Control mode		Frame length
			C P	C L	
[6] [E]	[0] [1]	Reading general purpose register (D1) value	○	○	8
	[0] [2]	Reading general purpose register (D2) value	○	○	
	[0] [3]	Reading general purpose register (D3) value	○	○	
	[0] [4]	Reading general purpose register (D4) value	○	○	

(12) Number of general purpose register (command [6] [F])

Command	Data No.	Description	Control mode		Frame length
			C P	C L	
[6] [F]	[0] [0]	Reading the number of general purpose register (Rx)	○	○	8
	[0] [1]	Reading the number of general purpose register (Dx)	○	○	

(13) Others (command [0] [0], [0] [2])

Command	Data No.	Description	Control mode		Frame length
			C P	C L	
[0] [0]	[1] [2]	Reading test operation mode 0000: Normal mode (not test operation mode) 0001: JOG operation 0002: Positioning operation 0004: Output signal (DO) forced output 0005: Single-step feed operation	○	○	4
	[1] [D]	Reading EEP-ROM stored data type 0000: Initial state 0001: Point table method 0002: Program method	○	○	
	[1] [E]	Reading control mode 0006: Positioning mode (point table method) 0007: Positioning mode (program method)	○	○	
[0] [2]	[9] [0]	Servo motor-side pulse unit absolute position	○	○	8
	[9] [1]	Command unit absolute position	○	○	
	[7] [0]	Software version	○	○	16

10. COMMUNICATION FUNCTION (MITSUBISHI GENERAL-PURPOSE AC SERVO PROTOCOL)

10.1.2 Writing commands

(1) Status display (command [8] [1])

Command	Data No.	Description	Setting range	Control mode		Frame length
				C P	C L	
[8] [1]	[0] [0]	Deleting status display data	1EA5	○	○	4

(2) Parameter (command [9] [4], [8] [5])

Command	Data No.	Description	Setting range	Control mode		Frame length
				C P	C L	
[9] [4]	[0] [1] to [F] [F]	Writing each parameter Writes the values of the parameters in the parameter group specified with the command [8] [5] + data No. [0] [0]. Therefore, be sure to specify the parameter group with the command [8] [5] + data No. [0] [0] before writing the values. The data No. (hexadecimal) value which is converted to decimal corresponds to the parameter No.	Varies depending on the parameter	○	○	12
[8] [5]	[0] [0]	Writing parameter group 0000: Basic setting parameters ([Pr. PA__]) 0001: Gain/filter parameters ([Pr. PB__]) 0002: Extension setting parameters ([Pr. PC__]) 0003: I/O setting parameters ([Pr. PD__]) 0004: Extension setting 2 parameters ([Pr. PE__]) 0005: Extension setting 3 parameters ([Pr. PF__]) 000C: Positioning control parameters ([Pr. PT__])	0000 to 000C	○	○	4

(3) External I/O signals (command [9] [2])

Command	Data No.	Description	Setting range	Control mode		Frame length
				C P	C L	
[9] [2]	[6] [0] to [6] [2]	Communication input device signal	Refer to section 10.2.2.	○	○	8

(4) Alarm history (command [8] [2])

Command	Data No.	Description	Setting range	Control mode		Frame length
				C P	C L	
[8] [2]	[2] [0]	Clearing alarm history	1EA5	○	○	4

(5) Current alarm (command [8] [2])

Command	Data No.	Description	Setting range	Control mode		Frame length
				C P	C L	
[8] [2]	[0] [0]	Clearing alarm	1EA5	○	○	4

10. COMMUNICATION FUNCTION (MITSUBISHI GENERAL-PURPOSE AC SERVO PROTOCOL)

(6) I/O device prohibition (command [9] [0])

Command	Data No.	Description	Setting range	Control mode		Frame length
				C P	C L	
[9] [0]	[0] [0]	Turns off the input devices except EM2, LSP and LSN, external analog input signals, and pulse train inputs, independently of the external on/off status.	1EA5	○	○	4
	[0] [3]	Prohibits all output devices (DO).	1EA5	○	○	
	[1] [0]	Cancels the prohibition of the input devices except EM2, LSP and LSN, external analog input signals and pulse train inputs.	1EA5	○	○	
	[1] [3]	Cancels the prohibition of the output device.	1EA5	○	○	

(7) Operation mode selection (command [8] [B])

Command	Data No.	Description	Setting range	Control mode		Frame length
				C P	C L	
[8] [B]	[0] [0]	Selecting test operation mode 0000: Test operation mode cancel 0001: JOG operation 0002: Positioning operation 0004: Output signal (DO) forced output 0005: Single-step feed operation	0000 to 0002, 0004, 0005	○	○	4

10. COMMUNICATION FUNCTION (MITSUBISHI GENERAL-PURPOSE AC SERVO PROTOCOL)

(8) Test operation mode data (command [9] [2], [A] [0])

Command	Data No.	Description	Setting range	Control mode		Frame length			
				C P	C L				
[9] [2]	[0] [0] to [0] [2]	Input signal for test operation	Refer to section 14.5.7 of "MR-JE-_A Servo Amplifier Instruction Manual".	○	○	8			
	[A] [0]	Forced output of signal pin	Refer to section 14.5.9 of "MR-JE-_A Servo Amplifier Instruction Manual".	○	○				
[A] [0]	[1] [0]	Writes the servo motor speed in the test operation mode (JOG operation and positioning operation).	0000 to 7FFF	○	○	4			
	[1] [1]	Writes the acceleration/deceleration time constant in the test operation mode (JOG operation and positioning operation).	00000000 to 7FFFFFFF	○	○	8			
	[2] [0]	Set the travel distance of the test operation mode (positioning operation).	00000000 to 7FFFFFFF	○	○	4			
	[2] [1]	Select the positioning direction of the test operation (positioning operation). <div style="text-align: center; margin: 10px 0;"> <table border="1" style="display: inline-table; border-collapse: collapse;"> <tr> <td style="padding: 2px 5px;">0</td> <td style="padding: 2px 5px;"> </td> <td style="padding: 2px 5px;">0</td> <td style="padding: 2px 5px;"> </td> </tr> </table> <p style="margin-left: 40px;"> 0: Forward rotation direction 1: Reverse rotation direction 0: Command pulse unit 1: Encoder pulse unit </p> </div>	0		0			0000 to 0101	○
	0		0						
	[4] [0]	This is a start command of the test operation (positioning operation).	1EA5	○	○				
[4] [1]	Use this to make a temporary stop during test operation (positioning operation). "□" in the data indicates a blank. STOP: Temporary stop GO□□: Restart for remaining distance CLR□: Remaining distance clear	STOP GO□□ CLR□	○	○					

10. COMMUNICATION FUNCTION (MITSUBISHI GENERAL-PURPOSE AC SERVO PROTOCOL)

(9) Point table setting data (command [C] [0], [C] [2], [C] [6], [C] [7], [C] [8], [C] [A], [C] [B])

Command	Data No.	Description	Setting range	Control mode		Frame length
				C P	C L	
[C] [0]	[0] [1] to [1] [F]	Writing position data of each point table The data No. (hexadecimal) value which is converted to decimal corresponds to the point table No.	-999999 to 999999	○	/	8
[C] [2]	[0] [1] to [1] [F]	Writing M code of each point table This command will be available in the future. The data No. (hexadecimal) value which is converted to decimal corresponds to the point table No.	0 to 99	○	/	
[C] [6]	[0] [1] to [1] [F]	Writing speed data of each point table The data No. (hexadecimal) value which is converted to decimal corresponds to the point table No.	0 to permissible speed	○	/	
[C] [7]	[0] [1] to [1] [F]	Writing acceleration time constant of each point table The data No. (hexadecimal) value which is converted to decimal corresponds to the point table No.	0 to 20000	○	/	
[C] [8]	[0] [1] to [1] [F]	Writing deceleration time constant of each point table The data No. (hexadecimal) value which is converted to decimal corresponds to the point table No.	0 to 20000	○	/	
[C] [A]	[0] [1] to [1] [F]	Writing dwell of each point table The data No. (hexadecimal) value which is converted to decimal corresponds to the point table No.	0 to 20000	○	/	
[C] [B]	[0] [1] to [1] [F]	Writing sub function of each point table The data No. (hexadecimal) value which is converted to decimal corresponds to the point table No.	0 to 3, 8 to 11	○	/	

(10) General purpose register (Rx) value (command [B] [9])

Command	Data No.	Description	Setting range	Control mode		Frame length
				C P	C L	
[B] [9]	[0] [1]	Writing general purpose register (R1) value	Varies depending on the commands (Refer to section 5.2.2.)	/	○	8
	[0] [2]	Writing general purpose register (R2) value		/	○	
	[0] [3]	Writing general purpose register (R3) value		/	○	
	[0] [4]	Writing general purpose register (R4) value		/	○	

(11) General purpose register (Dx) value (command [B] [A])

Command	Data No.	Description	Setting range	Control mode		Frame length
				C P	C L	
[B] [A]	[0] [1]	Writing general purpose register (D1) value	Varies depending on the commands (Refer to section 5.2.2.)	/	○	8
	[0] [2]	Writing general purpose register (D2) value		/	○	
	[0] [3]	Writing general purpose register (D3) value		/	○	
	[0] [4]	Writing general purpose register (D4) value		/	○	

10. COMMUNICATION FUNCTION (MITSUBISHI GENERAL-PURPOSE AC SERVO PROTOCOL)

10.2 Detailed explanations of commands

10.2.1 External I/O signal status (DIO diagnosis)

(1) Reading input device status

The current input device status can be read.


(a) Transmission

Transmit command [1] [2] + data No. [0] [0] to [0] [2].

Command	Data No.
[1] [2]	[0] [0] to [0] [2]

(b) Return

The slave station returns the status of the input devices.



Bit	Symbol		
	Data No. [0] [0]	Data No. [0] [1]	Data No. [0] [2]
0	SON		MD0
1	LSP		MD1
2	LSN		
3	TL		TCH
4	TL1		TP0
5	PC		TP1
6	RES		OVR
7	CR		
8	SP1		
9	SP2		DOG
10	SP3		
11	ST1/RS2		
12	ST2/RS1		
13	CMX1		
14	CMX2		
15	LOP		
16		MSD	LPS
17		PI1	
18	EM2/EM1	PI2	
19		PI3	
20	STAB2	CAMC	OV0
21		CI0	OV1
22		CI1	OV2
23		CI2	OV3
24	TSTP	CI3	DI0
25		CLTC	DI1
26		CPCD	DI2
27	CDP		DI3
28			DI4
29			
30			
31			

10. COMMUNICATION FUNCTION (MITSUBISHI GENERAL-PURPOSE AC SERVO PROTOCOL)

(2) Reading external input pin status

Reads the on/off statuses of the external input pins.


(a) Transmission

Transmit command [1] [2] + data No. [4] [0].

Command	Data No.
[1] [2]	[4] [0]

(b) Return

The on/off statuses of the input pins are returned.



1: On
0: Off

Command of each bit is transmitted to the master station as hexadecimal data.

Bit	CN1 connector pin	Bit	CN1 connector pin
0	43	16	
1	44	17	
2	42	18	
3	15	19	
4	19	20	
5	41	21	
6	10 (Note)	22	
7	35 (Note)	23	
8		24	
9		25	
10		26	
11		27	
12		28	
13		29	
14		30	
15		31	

Note. When the pulse train input is selected with [Pr. PD44] or [Pr. PD46], this bit will be always "0" (off).

10. COMMUNICATION FUNCTION (MITSUBISHI GENERAL-PURPOSE AC SERVO PROTOCOL)

(3) Reading the status of input devices switched on with communication

Reads the on/off statuses of the input devices switched on with communication.


(a) Transmission

Transmit command [1] [2] + data No. [6] [0] to [6] [2].

Command	Data No.
[1] [2]	[6] [0] to [6] [2]

(b) Return

The slave station returns the status of the input devices.



Command of each bit is transmitted to the master station as hexadecimal data.

Bit	Symbol		
	Data No. [6] [0]	Data No. [6] [1]	Data No. [6] [2]
0	SON		MD0
1	LSP		MD1
2	LSN		
3	TL		TCH
4	TL1		TP0
5	PC		TP1
6	RES		OVR
7	CR		
8	SP1		
9	SP2		DOG
10	SP3		
11	ST1/RS2		
12	ST2/RS1		
13	CMX1		
14	CMX2		
15	LOP		
16		MSD	LPS
17		PI1	
18	EM2/EM1	PI2	
19		PI3	
20	STAB2	CAMC	OV0
21		CI0	OV1
22		CI1	OV2
23		CI2	OV3
24	TSTP	CI3	DI0
25		CLTC	DI1
26		CPCD	DI2
27	CDP		DI3
28			DI4
29			
30			
31			

10. COMMUNICATION FUNCTION (MITSUBISHI GENERAL-PURPOSE AC SERVO PROTOCOL)

(4) Reading external output pin status

Reads the on/off statuses of the external output pins.


(a) Transmission

Transmit command [1] [2] + data No. [C] [0].

Command	Data No.
[1] [2]	[C] [0]

(b) Return

The slave station returns the status of the output devices.



1: On
0: Off

Command of each bit is transmitted to the master station as hexadecimal data.

Bit	CN1 connector pin	Bit	CN1 connector pin
0	49	16	
1	24	17	
2	23	18	
3		19	
4		20	
5	48	21	
6	33	22	
7		23	
8		24	
9		25	
10		26	
11		27	
12		28	
13		29	
14		30	
15		31	

10. COMMUNICATION FUNCTION (MITSUBISHI GENERAL-PURPOSE AC SERVO PROTOCOL)

(5) Reading output device status

Reads the on/off statuses of the output devices.


(a) Transmission

Transmit command [1] [2] + data No. [8] [0] to [8] [3].

Command	Data No.
[1] [2]	[8] [0] to [8] [3]

(b) Return

The slave station returns the status of the input/output devices.



Command of each bit is transmitted to the master station as hexadecimal data.

Bit	Symbol			
	Data No. [8] [0]	Data No. [8] [1]	Data No. [8] [2]	Data No. [8] [3]
0	RD			MCD00
1	SA			MCD01
2	ZSP			MCD02
3	TLC		CPO	MCD03
4	VLC		ZP	MCD10
5	INP		POT	MCD11
6			PUS	MCD12
7	WNG		MEND	MCD13
8	ALM			
9	OP			
10	MBR			
11				
12	ALCD0		PED	
13	ALCD1			
14	ALCD2			
15				
16				
17			ALMWNG	
18				
19		MSDH		
20		MSDL		
21		SOUT		
22		OUT1		
23		OUT2		
24		OUT3	PT0 (Note)	
25	CDPS	CAMS	PT1 (Note)	
26		CLTS	PT2 (Note)	
27		CLTSM	PT3 (Note)	
28		CPCC	PT4 (Note)	
29				
30				
31	MTTR			

Note. For MR-JE-_A servo amplifiers, up to four points of DO are available; therefore, PT0 to PT4 cannot be outputted simultaneously.

10. COMMUNICATION FUNCTION (MITSUBISHI GENERAL-PURPOSE AC SERVO PROTOCOL)


10.2.2 Input device on/off

POINT	<p>● The on/off status of all devices in the servo amplifier are the status of the data received at last. Therefore, when there is a device which must be kept on, transmit data which turns the device on every time.</p>
--------------	--

Each input device can be switched on/off. However, when the device to be switched off is in the external input signal, also switch off the input signal.

Transmit command [9] [2] + data No. [6] [0] to [6] [2].

Command	Data No.	Setting data
[9] [2]	[6] [0] to [6] [2]	See below.



Bit	Symbol		
	Data No. [6] [0]	Data No. [6] [1]	Data No. [6] [2]
0	SON		MD0
1	LSP		MD1
2	LSN		
3	TL		TCH
4	TL1		TP0
5	PC		TP1
6	RES		OVR
7	CR		
8	SP1		
9	SP2		DOG
10	SP3		
11	ST1/RS2		
12	ST2/RS1		
13	CMX1		
14	CMX2		
15	LOP		
16		MSD	LPS
17		PI1	
18	EM2/EM1	PI2	
19		PI3	
20	STAB2	CAMC	OV0
21		CI0	OV1
22		CI1	OV2
23		CI2	OV3
24	TSTP	CI3	DI0
25		CLTC	DI1
26		CPCD	DI2
27	CDP		DI3
28			DI4
29			
30			
31			


10. COMMUNICATION FUNCTION (MITSUBISHI GENERAL-PURPOSE AC SERVO PROTOCOL)

10.2.3 Input device on/off (for test operation)

Each input devices can be turned on/off for test operation. However, when the device to be switched off is in the external input signal, also switch off the input signal.

Transmit command [9] [2] + data No. [0] [0] to [0] [2].

Command	Data No.	Setting data
[9] [2]	[0] [0] to [0] [2]	See below.



Command of each bit is transmitted to the master station as hexadecimal data.

Bit	Symbol		
	Data No. [0] [0]	Data No. [0] [1]	Data No. [0] [2]
0	SON		MD0
1	LSP		MD1
2	LSN		
3	TL		TCH
4	TL1		TP0
5	PC		TP1
6	RES		OVR
7	CR		
8	SP1		
9	SP2		DOG
10	SP3		
11	ST1/RS2		
12	ST2/RS1		
13	CMX1		
14	CMX2		
15	LOP		
16		MSD	LPS
17		PI1	
18	EM2/EM1	PI2	
19		PI3	
20	STAB2	CAMC	OV0
21		CI0	OV1
22		CI1	OV2
23		CI2	OV3
24	TSTP	CI3	DI0
25		CLTC	DI1
26		CPCD	DI2
27	CDP		DI3
28			DI4
29			
30			
31			

10. COMMUNICATION FUNCTION (MITSUBISHI GENERAL-PURPOSE AC SERVO PROTOCOL)

10.2.4 Test operation mode

POINT
<ul style="list-style-type: none"> ● The test operation mode is for checking an operation. Do not use it for an actual operation. ● If communication stops for 0.5 s or longer during the test operation, the servo motor decelerates to a stop, resulting in servo-lock. To prevent this, keep the communication all the time by checking the status display, etc. ● The test operation mode can be started even in operation. In this case, switching to the test operation mode will shut off the base circuit to coast the servo motor.

(1) How to prepare and cancel the test operation mode

(a) Preparation of the test operation mode

Set the test operation mode type with the following procedure.

1) Setting of test operation mode

Transmit the command [8] [B] + data No. [0] [0] + data to set the test operation mode.

Command	Data No.	Transmission data	Setting test operation mode
[8] [B]	[0] [0]	0004	Output signal (DO) forced output (Note)
		0005	Single-step feed

Note. Refer to section 10.2.5 for the output signal (DO) forced output.

2) Check of test operation mode

Read the test operation mode set for the slave station, and check that it is set correctly.

a) Transmission

Transmit command [0] [0] + data No. [1] [2].

Command	Data No.
[0] [0]	[1] [2]

b) Return

The slave station returns the preset operation mode.

0	0	0	□
---	---	---	---

└ Reading test operation mode
 0: Normal mode (not test operation mode)
 1: JOG operation
 2: Positioning operation
 3: Motor-less operation
 4: Output signal (DO) forced output
 5: Single-step feed

(b) Cancel of test operation mode


To stop the test operation mode, transmit the command [8] [B] + data No. [0] [0] + data. Turn off the servo amplifier before switching the operation mode from the test to the normal.

Command	Data No.	Transmission data	Setting test operation mode
[8] [B]	[0] [0]	0000	Test operation mode cancel

10. COMMUNICATION FUNCTION (MITSUBISHI GENERAL-PURPOSE AC SERVO PROTOCOL)

(2) Single-step feed

Set each value of target point tables for the single-step feed before executing single-step feed. Transmit command and data No. to execute single-step feed.



Note 1. Start it after checking ZP (Home position return completion). See the 4 bit of the read data with the command [1] [2] and data No. [8] [2].

Note 2. A point table No. in hexadecimal will be entered to "__".

10. COMMUNICATION FUNCTION (MITSUBISHI GENERAL-PURPOSE AC SERVO PROTOCOL)

10.2.5 Output signal pin on/off (output signal (DO) forced output)

In the test operation mode, the output signal pins can be turned on/off regardless of the servo status. Disable the external input signals in advance with command [9] [0].

(1) Selecting the output signal (DO) forced output of the test operation mode

Transmit command + [8] [B] + data No. [0] [0] + data "0004" to select the output signal (DO) forced output.


0	0	0	4
---	---	---	---

Setting test operation mode
4: Output signal (DO) forced output

(2) External output signal on/off

Transmit the following communication commands.

Command	Data No.	Setting data
[9] [2]	[A] [0]	See below.



1: On
0: Off

Command of each bit is transmitted to the master station as hexadecimal data.

Bit	CN1 connector pin	Bit	CN1 connector pin
0	49	16	
1	24	17	
2	23	18	
3		19	
4		20	
5	48	21	
6	33	22	
7		23	
8		24	
9		25	
10		26	
11		27	
12		28	
13		29	
14		30	
15		31	

(3) Output signal (DO) forced output

To stop the output signal (DO) forced output, transmit command [8] [B] + data No. [0] [0] + data. Turn off the servo amplifier before switching the operation mode from the test to the normal.

Command	Data No.	Transmission data	Setting test operation mode
[8] [B]	[0] [0]	0000	Test operation mode cancel

10. COMMUNICATION FUNCTION (MITSUBISHI GENERAL-PURPOSE AC SERVO PROTOCOL)

10.2.6 Point table

(1) Reading data

(a) Position data


Reads position data of point tables.

1) Transmission

Transmits the command [4] [0] + the data No. [0] [1] to [1] [F] corresponding to the point tables to read. Refer to section 10.1.1.

2) Return

The slave station returns the position data of point table requested.



(b) Speed data


Reads speed data of point tables.

1) Transmission

Transmits the command [5] [0] + the data No. [0] [1] to [1] [F] corresponding to the point tables to read. Refer to section 10.1.1.

2) Return

The slave station returns the speed data of point table requested.



10. COMMUNICATION FUNCTION (MITSUBISHI GENERAL-PURPOSE AC SERVO PROTOCOL)

(c) Acceleration time constant


Reads acceleration time constant of point tables.

1) Transmission

Transmits the command [5] [4] + the data No. [0] [1] to [1] [F] corresponding to the point tables to read. Refer to section 10.1.1.

2) Return

The slave station returns the acceleration time constant of point table requested.



(d) Deceleration time constant


Reads deceleration time constant of point tables.

1) Transmission

Transmits the command [5] [8] + the data No. [0] [1] to [1] [F] corresponding to the point tables to read. Refer to section 10.1.1.

2) Return

The slave station returns the deceleration time constant of point table requested.



10. COMMUNICATION FUNCTION (MITSUBISHI GENERAL-PURPOSE AC SERVO PROTOCOL)

(e) Dwell


Reads dwell of point tables.

1) Transmission

Transmits the command [6] [0] + the data No. [0] [1] to [1] [F] corresponding to the point tables to read. Refer to section 10.1.1.

2) Return

The slave station returns the dwell of point table requested.



(f) Sub function


Reads sub function of point tables.

1) Transmission

Transmits the command [6] [4] + the data No. [0] [1] to [1] [F] corresponding to the point tables to read. Refer to section 10.1.1.

2) Return

The slave station returns the sub function of point table requested.



10. COMMUNICATION FUNCTION (MITSUBISHI GENERAL-PURPOSE AC SERVO PROTOCOL)

(g) M code

Reads M code of point tables.


M code will be available in the future.

1) Transmission

Transmits the command [4] [5] + the data No. [0] [1] to [1] [F] corresponding to the point tables to read. Refer to section 10.1.1.

2) Return

The slave station returns the M code of point table requested.



10. COMMUNICATION FUNCTION (MITSUBISHI GENERAL-PURPOSE AC SERVO PROTOCOL)

(2) Writing data

⚠ CAUTION


● If setting values need to be changed with a high frequency (i.e. once or more per hour), write the setting values to the RAM, not to the EEP-ROM. The EEP-ROM has a limitation in the number of write times, and exceeding this limitation causes the servo amplifier to malfunction. Note that the number of write times to the EEP-ROM is limited to approximately 100,000.

(a) Position data

Writes position data of point tables.

Transmits the command [C] [0] + the data No. [0] [1] to [1] [F] corresponding to the point tables to write. Refer to section 10.1.1.

Command	Data No.	Data
[C] [0]	[0] [1] to [1] [F]	Refer to the following:



Data is transferred in hexadecimal.

Decimal point position

0: No decimal point

1: First least significant digit (not used normally)

2: Second least significant digit

3: Third least significant digit

4: Forth least significant digit

5: Fifth least significant digit

6: Sixth least significant digit

Select the same decimal point position as the set feed length multiplication (STM) in [Pr. PT03].
If a different decimal point position is set, slave stations will not receive data.

Writing mode

0: Writing to EEP-ROM/RAM

1: Writing to RAM

When changing the position data frequently using communication, set "1" to the write mode to change only the RAM data in the servo amplifier.

When changing data once or more within an hour, do not write it to the EEP-ROM.


10. COMMUNICATION FUNCTION (MITSUBISHI GENERAL-PURPOSE AC SERVO PROTOCOL)

(b) Speed data

Writes speed data of point tables.

Transmits the command [C] [6] + the data No. [0] [1] to [1] [F] corresponding to the point tables to write. Refer to section 10.1.1.

Command	Data No.	Data
[C] [6]	[0] [1] to [1] [F]	Refer to the following:



Writing mode
 0: Writing to EEP-ROM/RAM
 1: Writing to RAM

When changing the speed data frequently using communication, set "1" to the write mode to change only the RAM data in the servo amplifier.


When changing data once or more within an hour, do not write it to the EEP-ROM.

(c) Acceleration time constant

Writes acceleration time constant of point tables.

Transmits the command [C] [7] + the data No. [0] [1] to [1] [F] corresponding to the point tables to write. Refer to section 10.1.1.

Command	Data No.	Data
[C] [7]	[0] [1] to [1] [F]	Refer to the following:



Writing mode
 0: Writing to EEP-ROM/RAM
 1: Writing to RAM

When changing the acceleration time constant frequently using communication, set "1" to the write mode to change only the RAM data in the servo amplifier.

When changing data once or more within an hour, do not write it to the EEP-ROM.


10. COMMUNICATION FUNCTION (MITSUBISHI GENERAL-PURPOSE AC SERVO PROTOCOL)

(d) Deceleration time constant

Writes deceleration time constant of point tables.

Transmits the command [C] [8] + the data No. [0] [1] to [1] [F] corresponding to the point tables to write. Refer to section 10.1.1.

Command	Data No.	Data
[C] [8]	[0] [1] to [1] [F]	Refer to the following:



Writing mode
 0: Writing to EEP-ROM/RAM
 1: Writing to RAM

When changing the deceleration time constant frequently using communication, set "1" to the write mode to change only the RAM data in the servo amplifier.


When changing data once or more within an hour, do not write it to the EEP-ROM.

(e) Dwell

Writes dwell of point tables.

Transmits the command [C] [A] + the data No. [0] [1] to [1] [F] corresponding to the point tables to write. Refer to section 10.1.1.

Command	Data No.	Data
[C] [A]	[0] [1] to [1] [F]	Refer to the following:



Writing mode
 0: Writing to EEP-ROM/RAM
 1: Writing to RAM

When changing the dwell frequently using communication, set "1" to the write mode to change only the RAM data in the servo amplifier.

When changing data once or more within an hour, do not write it to the EEP-ROM.


10. COMMUNICATION FUNCTION (MITSUBISHI GENERAL-PURPOSE AC SERVO PROTOCOL)

(f) Sub function

Writes sub function of point tables.

Transmits the command [C] [B] + the data No. [0] [1] to [1] [F] corresponding to the point tables to write. Refer to section 10.1.1.

Command	Data No.	Data
[C] [B]	[0] [1] to [1] [F]	Refer to the following:



Writing mode
 0: Writing to EEP-ROM/RAM
 1: Writing to RAM

When changing the sub function frequently using communication, set "1" to the write mode to change only the RAM data in the servo amplifier.

When changing data once or more within an hour, do not write it to the EEP-ROM.


(g) M code

Writes M code of point tables.

M code will be available in the future.

Transmits the command [C] [2] + the data No. [0] [1] to [1] [F] corresponding to the point tables to write. Refer to section 10.1.1.

Command	Data No.	Data
[C] [2]	[0] [1] to [1] [F]	Refer to the following:



Writing mode
 0: Writing to EEP-ROM/RAM
 1: Writing to RAM

When changing the M code frequently using communication, set "1" to the write mode to change only the RAM data in the servo amplifier.

When changing data once or more within an hour, do not write it to the EEP-ROM.

REVISIONS

*The manual number is given on the bottom left of the back cover.

Print Data	*Manual Number	Revision
May. 2015	SH(NA)030150-A	First edition

This manual confers no industrial property rights or any rights of any other kind, nor does it confer any patent licenses. Mitsubishi Electric Corporation cannot be held responsible for any problems involving industrial property rights which may occur as a result of using the contents noted in this manual.

Country/Region	Sales office	Tel/Fax
USA	MITSUBISHI ELECTRIC AUTOMATION, INC. 500 Corporate Woods Parkway, Vernon Hills, IL 60061, U.S.A.	Tel : +1-847-478-2100 Fax : +1-847-478-2253
Mexico	MITSUBISHI ELECTRIC AUTOMATION, INC. Mexico Branch Mariano Escobedo #69, Col. Zona Industrial, Tlalnepantla Edo, C.P.54030, Mexico	Tel : +52-55-3067-7500 Fax : -
Brazil	MITSUBISHI ELECTRIC DO BRASIL COMÉRCIO E SERVIÇOS LTDA. Rua Jussara, 1750- Bloco B Anexo, Jardim Santa Cecilia, CÉP 06465-070, Barueri - SP, Brasil	Tel : +55-11-4689-3000 Fax : +55-11-4689-3016
Germany	MITSUBISHI ELECTRIC EUROPE B.V. German Branch Gothaer Strasse 8, D-40880 Ratingen, Germany	Tel : +49-2102-486-0 Fax : +49-2102-486-1120
UK	MITSUBISHI ELECTRIC EUROPE B.V. UK Branch Travellers Lane, Hatfield, Hertfordshire, AL10 8XB, U.K.	Tel : +44-1707-28-8780 Fax : +44-1707-27-8695
Italy	MITSUBISHI ELECTRIC EUROPE B.V. Italian Branch Centro Direzionale Colleoni - Palazzo Sirio Viale Colleoni 7, 20864 Agrate Brianza (Milano) Italy	Tel : +39-039-60531 Fax : +39-039-6053-312
Spain	MITSUBISHI ELECTRIC EUROPE, B.V. Spanish Branch Carretera de Rubí, 76-80-Apdo. 420, 08173 Sant Cugat del Vallés (Barcelona), Spain	Tel : +34-935-65-3131 Fax : +34-935-89-1579
France	MITSUBISHI ELECTRIC EUROPE B.V. French Branch 25, Boulevard des Bouvets, F-92741 Nanterre Cedex, France	Tel : +33-1-55-68-55-68 Fax : +33-1-55-68-57-57
Czech Republic	MITSUBISHI ELECTRIC EUROPE B.V. Czech Branch Avenir Business Park, Radlicka 751/113e, 158 00 Praha5, Czech Republic	Tel : +420-251-551-470 Fax : +420-251-551-471
Poland	MITSUBISHI ELECTRIC EUROPE B.V. Polish Branch Krakowska 50, 32-083 Balice, Poland	Tel : +48-12-630-47-00 Fax : +48-12-630-47-01
Russia	MITSUBISHI ELECTRIC EUROPE B.V. Russian Branch St. Petersburg office Piskarevsky pr. 2, bld 2, lit "Sch", BC "Benua", office 720; RU-195027 St. Petersburg, Russia	Tel : +7-812-633-3497 Fax : +7-812-633-3499
Sweden	MITSUBISHI ELECTRIC EUROPE B.V. (Scandinavia) Fjellievägen 8, SE-22736 Lund, Sweden	Tel : +46-8-625-10-00 Fax : +46-46-39-70-18
Turkey	MITSUBISHI ELECTRIC TURKEY A.Ş Ümraniye Branch Şerifali Mahallesi Nutuk Sokak No:5, TR-34775 Ümraniye, İstanbul, Turkey	Tel : +90-216-526-3990 Fax : +90-216-526-3995
UAE	MITSUBISHI ELECTRIC EUROPE B.V. Dubai Branch Dubai Silicon Oasis, P.O.BOX 341241, Dubai, U.A.E.	Tel : +971-4-3724716 Fax : +971-4-3724721
South Africa	ADROIT TECHNOLOGIES 20 Waterford Office Park, 189 Witkoppen Road, Fourways, Johannesburg, South Africa	Tel : +27-11-658-8100 Fax : +27-11-658-8101
China	MITSUBISHI ELECTRIC AUTOMATION (CHINA) LTD. No.1386 Hongqiao Road, Mitsubishi Electric Automation Center, Shanghai, China	Tel : +86-21-2322-3030 Fax : +86-21-2322-3000
Taiwan	SETSUYO ENTERPRISE CO., LTD. 6F, No.105, Wugong 3rd Road, Wugu District, New Taipei City 24889, Taiwan, R.O.C.	Tel : +886-2-2299-2499 Fax : +886-2-2299-2509
Korea	MITSUBISHI ELECTRIC AUTOMATION KOREA CO., LTD. 7F-9F, Gangseo Hangang Xi-tower A, 401, Yangcheon-ro, Gangseo-Gu, Seoul 157-801, Korea	Tel : +82-2-3660-9510 Fax : +82-2-3664-8372/8335
Singapore	MITSUBISHI ELECTRIC ASIA PTE. LTD. 307, Alexandra Road, Mitsubishi Electric Building, Singapore 159943	Tel : +65-6473-2308 Fax : +65-6476-7439
Thailand	MITSUBISHI ELECTRIC FACTORY AUTOMATION (THAILAND) CO., LTD. 12th Floor, SV.City Building, Office Tower 1, No. 896/19 and 20 Rama 3 Road, Kwaeng Bangpongpan, Khet Yannawa, Bangkok 10120, Thailand	Tel : +66-2682-6522 to 6531 Fax : +66-2682-6020
Indonesia	PT. MITSUBISHI ELECTRIC INDONESIA Gedung Jaya 11th Floor, JL. MH. Thamrin No.12, Jakarta Pusat 10340, Indonesia	Tel : +62-21-3192-6461 Fax : +62-21-3192-3942
Vietnam	MITSUBISHI ELECTRIC VIETNAM COMPANY LIMITED Unit 01-04, 10th Floor, Vincom Center, 72 Le Thanh Ton Street, District 1, Ho Chi Minh City, Vietnam	Tel : +84-8-3910-5945 Fax : +84-8-3910-5947
India	MITSUBISHI ELECTRIC INDIA PVT. LTD. Pune Branch Emerald House, EL -3, J Block, M.I.D.C Bhosari, Pune - 411026, Maharashtra, India	Tel : +91-20-2710-2000 Fax : +91-20-2710-2100
Australia	MITSUBISHI ELECTRIC AUSTRALIA PTY. LTD. 348 Victoria Road, P.O. Box 11, Rydalmere, N.S.W 2116, Australia	Tel : +61-2-9684-7777 Fax : +61-2-9684-7245

MELSERVO is a trademark or registered trademark of Mitsubishi Electric Corporation in Japan and/or other countries.
Microsoft, Windows, Internet Explorer, and Windows Vista are registered trademarks or trademarks of Microsoft Corporation in the United States, Japan, and/or other countries.
Intel, Pentium, and Celeron are trademarks of Intel Corporation in the United States and/or other countries.
All other product names and company names are trademarks or registered trademarks of their respective companies.

Warranty

1. Warranty period and coverage

We will repair any failure or defect hereinafter referred to as "failure" in our FA equipment hereinafter referred to as the "Product" arisen during warranty period at no charge due to causes for which we are responsible through the distributor from which you purchased the Product or our service provider. However, we will charge the actual cost of dispatching our engineer for an on-site repair work on request by customer in Japan or overseas countries. We are not responsible for any on-site readjustment and/or trial run that may be required after a defective unit are repaired or replaced.

[Term]

The term of warranty for Product is twelve (12) months after your purchase or delivery of the Product to a place designated by you or eighteen (18) months from the date of manufacture whichever comes first ("Warranty Period"). Warranty period for repaired Product cannot exceed beyond the original warranty period before any repair work.

[Limitations]

- (1) You are requested to conduct an initial failure diagnosis by yourself, as a general rule.
It can also be carried out by us or our service company upon your request and the actual cost will be charged. However, it will not be charged if we are responsible for the cause of the failure.
- (2) This limited warranty applies only when the condition, method, environment, etc. of use are in compliance with the terms and conditions and instructions that are set forth in the instruction manual and user manual for the Product and the caution label affixed to the Product.
- (3) Even during the term of warranty, the repair cost will be charged on you in the following cases;
 - (i) a failure caused by your improper storing or handling, carelessness or negligence, etc., and a failure caused by your hardware or software problem
 - (ii) a failure caused by any alteration, etc. to the Product made on your side without our approval
 - (iii) a failure which may be regarded as avoidable, if your equipment in which the Product is incorporated is equipped with a safety device required by applicable laws and has any function or structure considered to be indispensable according to a common sense in the industry
 - (iv) a failure which may be regarded as avoidable if consumable parts designated in the instruction manual, etc. are duly maintained and replaced
 - (v) any replacement of consumable parts (battery, fan, smoothing capacitor, etc.)
 - (vi) a failure caused by external factors such as inevitable accidents, including without limitation fire and abnormal fluctuation of voltage, and acts of God, including without limitation earthquake, lightning and natural disasters
 - (vii) a failure generated by an unforeseeable cause with a scientific technology that was not available at the time of the shipment of the Product from our company
 - (viii) any other failures which we are not responsible for or which you acknowledge we are not responsible for

2. Term of warranty after the stop of production

- (1) We may accept the repair at charge for another seven (7) years after the production of the product is discontinued. The announcement of the stop of production for each model can be seen in our Sales and Service, etc.
- (2) Please note that the Product (including its spare parts) cannot be ordered after its stop of production.

3. Service in overseas countries

Our regional FA Center in overseas countries will accept the repair work of the Product. However, the terms and conditions of the repair work may differ depending on each FA Center. Please ask your local FA center for details.

4. Exclusion of responsibility for compensation against loss of opportunity, secondary loss, etc.

Whether under or after the term of warranty, we assume no responsibility for any damages arisen from causes for which we are not responsible, any losses of opportunity and/or profit incurred by you due to a failure of the Product, any damages, secondary damages or compensation for accidents arisen under a specific circumstance that are foreseen or unforeseen by our company, any damages to products other than the Product, and also compensation for any replacement work, readjustment, start-up test run of local machines and the Product and any other operations conducted by you.

5. Change of Product specifications

Specifications listed in our catalogs, manuals or technical documents may be changed without notice.

6. Application and use of the Product

- (1) For the use of our General-Purpose AC Servo, its applications should be those that may not result in a serious damage even if any failure or malfunction occurs in General-Purpose AC Servo, and a backup or fail-safe function should operate on an external system to General-Purpose AC Servo when any failure or malfunction occurs.
- (2) Our General-Purpose AC Servo is designed and manufactured as a general purpose product for use at general industries. Therefore, applications substantially influential on the public interest for such as atomic power plants and other power plants of electric power companies, and also which require a special quality assurance system, including applications for railway companies and government or public offices are not recommended, and we assume no responsibility for any failure caused by these applications when used
In addition, applications which may be substantially influential to human lives or properties for such as airlines, medical treatments, railway service, incineration and fuel systems, man-operated material handling equipment, entertainment machines, safety machines, etc. are not recommended, and we assume no responsibility for any failure caused by these applications when used. We will review the acceptability of the abovementioned applications, if you agree not to require a specific quality for a specific application. Please contact us for consultation.

MODEL	MR-JE-A INSTRUCTIONMANUAL(ITIGIME)
MODEL CODE	1CW707

MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE : TOKYO BLDG MARUNOUCHI TOKYO 100-8310