

MITSUBISHI

QA65B/QA68B

Extension Base Unit

User's Manual

Thank you for buying the Mitsubishi general-purpose programmable controller MELSEC-Q Series

Prior to use, please read both this manual and detailed manual thoroughly and familiarize yourself with the product.

MELSEC-Q
Mitsubishi Programmable
Controller

MODEL	QA65B-U-E
MODEL CODE	13JR26
IB(NA)-0800158-D(1004)MEE	

● CONDITIONS OF USE FOR THE PRODUCT ●

- (1) Mitsubishi programmable controller ("the PRODUCT") shall be used in conditions;
- i) where any problem, fault or failure occurring in the PRODUCT, if any, shall not lead to any major or serious accident; and
 - ii) where the backup and fail-safe function are systematically or automatically provided outside of the PRODUCT for the case of any problem, fault or failure occurring in the PRODUCT.

- (2) The PRODUCT has been designed and manufactured for the purpose of being used in general industries.

MITSUBISHI SHALL HAVE NO RESPONSIBILITY OR LIABILITY (INCLUDING, BUT NOT LIMITED TO ANY AND ALL RESPONSIBILITY OR LIABILITY BASED ON CONTRACT, WARRANTY, TORT, PRODUCT LIABILITY) FOR ANY INJURY OR DEATH TO PERSONS OR LOSS OR DAMAGE TO PROPERTY CAUSED BY the PRODUCT THAT ARE OPERATED OR USED IN APPLICATION NOT INTENDED OR EXCLUDED BY INSTRUCTIONS, PRECAUTIONS, OR WARNING CONTAINED IN MITSUBISHI'S USER, INSTRUCTION AND/OR SAFETY MANUALS, TECHNICAL BULLETINS AND GUIDELINES FOR the PRODUCT.

("Prohibited Application")

Prohibited Applications include, but not limited to, the use of the PRODUCT in;

- Nuclear Power Plants and any other power plants operated by Power companies, and/or any other cases in which the public could be affected if any problem or fault occurs in the PRODUCT.
- Railway companies or Public service purposes, and/or any other cases in which establishment of a special quality assurance system is required by the Purchaser or End User.
- Aircraft or Aerospace, Medical applications, Train equipment, transport equipment such as Elevator and Escalator, Incineration and Fuel devices, Vehicles, Manned transportation, Equipment for Recreation and Amusement, and Safety devices, handling of Nuclear or Hazardous Materials or Chemicals, Mining and Drilling, and/or other applications where there is a significant risk of injury to the public or property.

Notwithstanding the above, restrictions Mitsubishi may in its sole discretion, authorize use of the PRODUCT in one or more of the Prohibited Applications, provided that the usage of the PRODUCT is limited only for the specific applications agreed to by Mitsubishi and provided further that no special quality assurance or fail-safe, redundant or other safety features which exceed the general specifications of the PRODUCTS are required. For details, please contact the Mitsubishi representative in your region.

1. Overview

1.1 Overview

This User's Manual describes the specifications, configuration devices, names and settings of each part, and mounting and installation of the QA65B extension base unit, QA68B extension base unit (hereinafter, QA6□B).

Refer to the QCPU User's Manual(Hardware Design, Maintenance and Inspection) SH-080483ENG enclosed with the main base unit for the matters not described in this manual, such as the QA6□B safety precautions and general specifications.

1.2 Supplied parts

The parts enclosed with this module are listed below.

Product	Type	Quantity
Extension base unit	QA6□B	1
I/O number seal	-	1
This manual	-	1

2. System Configuration

2.1 System configuration

The system configuration and precautions for using the QA6□B extension base unit are described in this section.


(1) Extension base unit connection order

When using the Q5□B/Q6□B, QA1S6□B and QA6□B together, connect from the unit closest to the main base unit in the order of Q5□B/Q6□B, QA1S6□B and QA6□B.

(2) Setting order of the expansion stage numbers for expansion base units

Expansion base units require the setting of the expansion stage numbers (1 to 7) using the stage setting connector.

Assign the expansion stage numbers starting from 1 to 7 to the expansion base units counting from the one which is connected to the main base unit.



2.2 List of configuration devices

The following shows the applicable types for configurations of the QA6□B.

Module	Type				Remarks
Power module	A61P, A68P,	A61PN, A61PEU,	A62P, A62PEU	A63P,	
Input module	AX10, AX21, AX40, AX42-S1, AX71, AX81-S1, AX82	AX11, AX21EU, AX41, AX50-S1, AX80, AX81-S2,	AX11EU, AX31, AX41-S1, AX60-S1, AX80E, AX81-S3,	AX20, AX31-S1, AX42, AX70, AX81, AX81B,	
Output module	AY10, AY11E, AY13E, AY23, AY42, AY42-S4, AY60, AY71, AY82EP	AY10A, AY11AEU, AY13EU, AY40, AY42-S1, AY50, AY60S, AY72,	AY11, AY11EEU, AY15EU, AY40A, AY42-S2, AY51, AY60E, AY80,	AY11A, AY13, AY22, AY41, AY42-S3, AY51-S1, AY70, AY81,	
I/O module	A42XY,	AH42			
High-speed counter module	AD61,	AD61S1			*1
Analog-digital conversion module	A68AD,	A68AD-S2,	A68ADN,	A616AD	
Digital-analog conversion module	A62DA, A616DAV,	A62DA-S1, A616DAI	A68DAV,	A68DAI-S1,	
Temperature-digital conversion module	A68RD3, A616TD, A60MXT,	A68RD3N, A60MX, A60MXTN	A68RD4, A60MXR,	A68RD4N, A60MXRN,	
Interrupt module	AI61,	AI61-S1			*2
Positioning module	AD70, AD71S2,	AD70D, AD71S7,	AD71, AD72	AD71S1,	
	AD75P1-S3, AD75M1,	AD75P2-S3, AD75M2,	AD75P3-S3, AD75M3		*1
MELSECNET/MINI-S3 master module	AJ71PT32-S3, AJ71T32-S3				*1

Module	Type	Remarks
Intelligent communication module	AD51, AD51E, AD51H, AD51-S3, AD51E-S3, AD51H-S3	*2
PC fault detection module	AS91	
MELSEC-I/OLINK module	AJ51T64	
B/NET module	AJ71B62-S3	
Blanking module	AG60	
Dummy module	AG62	
A-A1S conversion adapter	A1ADP-XY, A1ADP-SP	*3

*1: The dedicated commands used in the QnA and A Series program cannot be used with the Q mode CPU.

Replace these with FROM/TO commands.

*2: There is a limit to the number of mountable modules.

Module	Type	number of mountable
Intelligent communication module	AD51, AD51E, AD51-S3, AD51E-S3, AD51H, AD51H-S3	6 *4
Interrupt module	AI61, AI61-S1	1 *5

*3: For units to be installed, refer to the A-A1S conversion adapter manual.

*4: In combined use of the QA1S6□B and QA6□B, up to 6 intelligent communication modules can be installed.

*5: Only one interrupt module is valid which can be chosen from QI60, A1SI61, AI61 or AI61-S1.

3. Specifications

3.1 Specifications

The QA6□B performance specifications are given below.


Item	Type	QA65B	QA68B
Number of I/O modules connected		5	8
Applicable modules		A series module	
5VDC internal current consumption (A)		0.117	0.117
Weight (kg)		1.60	2.00

4.Names and setting of parts

The names of and settings for each QA6□B part are explained in this section.

4.1 Names of parts


The names of each QA6□B part are explained below.



No.	Name	Usage
1)	Expansion cable connector	A connector for signal transmission with the basic base module or the other expansion base module. Connects the expansion cable. Do not remove the supplied connector cover.
2)	Base cover	PCB surface protection cover.
3)	Stage number setting connector	A used to set the stage numbers of the expansion base modules. Refer to section 4.2 for the setting procedure.
4)	Module connector	Connector for mounting power supply unit, input/output unit and special function module. Mount the dustproof connector cover, blank cover unit (AG60) or dummy unit (AG62) on the connector in the spare spaces with module connected.
5)	Module fixing hole	Cut out to accept projection and hook at rear of modules.
6)	Screw hole for fastening modules	A screw hole used for fastening a module to the base. (M4 screw)
7)	Base module installation hole	A hole used for mounting the base module to a panel such as a control panel.

4.2 Setting the expansion stage numbers

The method of setting the QA6□B stages is explained below.



Stage number setting for expansion base modules

	Stage number setting						
	1th stage	2th stage	3th stage	4th stage	5th stage	6th stage	7th stage
Position of connector pin in stage number setting connector							

Point
(1) To set the stage number setting connector, select the appropriate number from 1 through 7 in ascending order according to the number of expansion modules.
(2) Do not assign the same stage number to several modules or skip any stage numbers. Otherwise, improper I/O operation results.
(3) The expansion stage number is factory-set to 1.

5. Loading and Installation

5.1 Module Installation

This section describes the precautions to handle the CPU, I/O, special function, power supply, and base module.



- (1) Do not drop or apply a strong impact to the module housing, memory card, terminal block connectors, and pin connectors.
- (2) Do not remove the PC board of the modules from housing. Otherwise, malfunctions may result.
- (3) When using the expansion base module QA6□B, be sure to install the power supply module.
Although the module may work without the power supply module under light load, stable operation is not guaranteed.
- (4) Limit the tightening torque for the module installation screws and terminal block screws within the following range:

Location of screw	Tightening torque range
I/O module terminal block installation screw (M3)	36 to 48N•cm
A series module installation screw (M4)	78 to 118N•cm
I/O module terminal screw (M4)	
Power supply module terminal screw (M4)	98 to 137N•cm

- (5) When using the expansion cable, do not bind it with or place it close to the main circuit (high-voltage, large-current) lines.

5.2 Precautions for installing base unit

(1) Unit installation position




*1:

When link module is not used	50mm or more
When using $\phi 4.5\text{mm}$ optical fiber cable	100mm or more
When using a coaxial cable	
When using $\phi 8.5\text{mm}$ optical fiber cable	130mm or more


*2: 20mm or more when connecting extension cable without removing adjacent modules.

(2) Module installing position


(a) Install the PC in the following position to ensure ventilation for heat radiation.



(b) Do not install the PC in the following positions.



Vertical position



Horizontal position



(3) Install the base module on a flat surface.

When the base module is installed on an uneven surface, the PC board may be strained, resulting in malfunction.

(4) Do not install the PC close to a vibration source such as a large electromagnetic contactor or no-fuse breaker. Install the PC to the separate panel or isolate it as far as possible.

(5) Provide the following distances between the PC and devices (contactor or relay) to avoid the influence of radiation noise or heat.

- Device installed in front of the PC: 100mm or more
- Device installed on either side of the PC: 50mm or more



5.3 Installation and removal of modules

This section explains the installation and removal procedures of the power supply module, CPU module, I/O module, special function module, etc to and from the base unit.


(1) Installation of module

Insert the two module fixing projections (two) into the module fixing hole (B) in the base unit.


Load the module into the base unit by pushing it in the direction of arrow.

Check if the hook of module is securely inserted in the module fixing hole (A) in the base unit.

Completed



Module mounting screw
(M4(0.16)×0.7(0.03)×12(0.47))



Points

- (1) To fix the module, be sure to insert the module fixing projection into the module fixing hole (B). If the module is forcibly fixed without insertion, the pins in the module connector may be bent or damaged.
- (2) When the base unit is used at locations where there are especially large vibration and/or shock, screw the module to the base.


(2) Removal of module

Hold the module with both hands and push the hook latch at the top of module.

While pushing the hook latch, pull the module toward you.

Lift upwards and remove the module fixing projections from the module fixing hole (B).

Completed




Points

To remove the module, be sure to disengage the hook from the module fixing hole (A) and then remove the module fixing projections from the module fixing hole (B). If the module is forcibly removed, the hook or module fixing projections will be damaged.


Appendices

Appendices 1 External Dimension Diagram

The external dimensions of the QA6□B are shown below.



The external dimensions of the QA68B



The external dimensions of the QA65B

Warranty

Mitsubishi will not be held liable for damage caused by factors found not to be the cause of Mitsubishi; machine damage or lost profits caused by faults in the Mitsubishi products; damage, secondary damage, accident compensation caused by special factors unpredictable by Mitsubishi; damages to products other than Mitsubishi products; and to other duties.

Country/Region	Sales office/Tel	Country/Region	Sales office/Tel
U.S.A	Mitsubishi Electric Automation Inc. 500 Corporate Woods Parkway Vernon Hills, IL 60061, U.S.A. Tel : +1-847-478-2100	Hong Kong	Mitsubishi Electric Automation (Hong Kong) Ltd. 10th Floor, Manulife Tower, 169 Electric Road, North Point, Hong Kong Tel : +852-2887-8870
Brazil	MELCO-TEC Rep. Com.e Assessoria Tecnica Ltda. Rua Correia Dias, 184, Edificio Paraiso Trade Center-8 andar Paraiso, Sao Paulo, SP Brazil Tel : +55-11-5908-8331	China	Mitsubishi Electric Automation (Shanghai) Ltd. 4/F Zhi Fu Plazz, No.80 Xin Chang Road, Shanghai 200003, China Tel : +86-21-6120-0808
Germany	Mitsubishi Electric Europe B.V. German Branch Gothaer Strasse 8 D-40880 Ratingen, GERMANY Tel : +49-2102-486-0	Taiwan	Setsuyo Enterprise Co., Ltd. 6F No.105 Wu-Kung 3rd.Rd, Wu-Ku Hsiang, Taipei Hsine, Taiwan Tel : +886-2-2299-2499
U.K	Mitsubishi Electric Europe B.V. UK Branch Travellers Lane, Hatfield, Hertfordshire., AL10 8XB, U.K. Tel : +44-1707-276100	Korea	Mitsubishi Electric Automation Korea Co., Ltd. 1480-6, Gayang-dong, Gangseo-ku Seoul 157-200, Korea Tel : +82-2-3660-9552
Italy	Mitsubishi Electric Europe B.V. Italian Branch Centro Dir. Colleoni, Pal. Perseo-Ingr.2 Via Paracelso 12, I-20041 Agrate Brianza., Milano, Italy Tel : +39-039-60531	Singapore	Mitsubishi Electric Asia Pte, Ltd. 307 Alexandra Road #05-01/02, Mitsubishi Electric Building, Singapore 159943 Tel : +65-6470-2460
Spain	Mitsubishi Electric Europe B.V. Spanish Branch Carretera de Rubi 76-80, E-08190 Sant Cugat del Valles, Barcelona, Spain Tel : +34-93-565-3131	Thailand	Mitsubishi Electric Automation (Thailand) Co., Ltd. Bang-Chan Industrial Estate No.111 Moo 4, Serithai Rd, T.Kannayao, A.Kannayao, Bangkok 10230 Thailand Tel : +66-2-517-1326
France	Mitsubishi Electric Europe B.V. French Branch 25, Boulevard des Bouvets, F-92741 Nanterre Cedex, France TEL: +33-1-5568-5568	Indonesia	P.T. Autoteknindo Sumber Makmur Muara Karang Selatan, Block A/Utara No.1 Kav. No.11 Kawasan Industri Pergudangan Jakarta - Utara 14440, P.O.Box 5045 Jakarta, 11050 Indonesia Tel : +62-21-6630833
South Africa	Circuit Breaker Industries Ltd. Private Bag 2016, ZA-1600 Isando, South Africa Tel : +27-11-928-2000	India	Messung Systems Pvt, Ltd. Electronic Sadan NO:III Unit No15, M.I.D.C Bhosari, Pune-411026, India Tel : +91-20-2712-3130
		Australia	Mitsubishi Electric Australia Pty. Ltd. 348 Victoria Road, Rydalmere, N.S.W 2116, Australia Tel : +61-2-9684-7777

MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE : TOKYO BUILDING, 2-7-3 MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN
NAGOYA WORKS : 1-14, YADA-MINAMI 5-CHOME, HIGASHI-KU, NAGOYA, JAPAN

When exported from Japan, this manual does not require application to the Ministry of Economy, Trade and Industry for service transaction permission.

Specifications subject to change without notice.