



PROGRAMMABLE CONTROLLERS  
MELSEC-F

## FX3GC SERIES PROGRAMMABLE CONTROLLERS

### HARDWARE MANUAL

|               |             |
|---------------|-------------|
| Manual Number | JY997D45201 |
| Revision      | C           |
| Date          | April 2015  |

This manual describes the part names, dimensions, mounting, cabling and specifications for the product. This manual is extracted from FX3GC Series User's Manual - Hardware Edition. Refer to FX3GC Series User's Manual - Hardware Edition for more details. Before use, read this manual and manuals of relevant products fully to acquire proficiency in the handling and operating the product. Make sure to learn all the product information, safety information, and precautions.

And, store this manual in a safe place so that you can take it out and read it whenever necessary. Always forward it to the end user.

Registration

The company name and the product name to be described in this manual are the registered trademarks or trademarks of each company.

Effective April 2015

Specifications are subject to change without notice.

© 2012 Mitsubishi Electric Corporation

## Safety Precaution (Read these precautions before use.)

This manual classifies the safety precautions into two categories:

**⚠ WARNING** and **⚠ CAUTION**.

|                  |   |
|------------------|---|
| <b>⚠ WARNING</b> | Indicates that incorrect handling may cause hazardous conditions, resulting in death or severe injury.                              |
| <b>⚠ CAUTION</b> | Indicates that incorrect handling may cause hazardous conditions, resulting in medium or slight personal injury or physical damage. |

Depending on the circumstances, procedures indicated by **⚠ CAUTION** may also cause severe injury.

It is important to follow all precautions for personal safety.

|  |                  |
|--|------------------|
| <b>STARTUP AND MAINTENANCE PRECAUTIONS</b>   | <b>⚠ WARNING</b> |
| <ul style="list-style-type: none"><li>Do not touch any terminal while the PLC's power is on. Doing so may cause electric shock or malfunctions.</li><li>Before cleaning or retightening terminals, cut off all phases of the power supply externally. Failure to do so may cause electric shock.</li></ul> |                  |

JY997D45201C

1

|  |                  |
|--|------------------|
| <b>STARTUP AND MAINTENANCE PRECAUTIONS</b>   | <b>⚠ WARNING</b> |
| <ul style="list-style-type: none"><li>Use the battery for memory backup correctly in conformance to FX3GC Series User's Manual - Hardware Edition.<ul style="list-style-type: none"><li>Use the battery only for the specified purpose.</li><li>Connect the battery correctly.</li><li>Do not charge, disassemble, heat, put in fire, short-circuit, connect reversely, weld, swallow or burn the battery, or apply excessive forces (vibration, impact, drop, etc.) to the battery.</li><li>Do not store or use the battery at high temperatures or expose to direct sunlight.</li><li>Do not expose to water, bring near fire or touch liquid leakage or other contents directly.</li><li>Incorrect handling of the battery may cause heat excessive generation, bursting, ignition, liquid leakage or deformation, and lead to injury, fire or failures and malfunctions of facilities and other equipment.</li></ul></li><li>Before modifying or disrupting the program in operation or running the PLC, carefully read through this manual and the associated manuals and ensure the safety of the operation. An operation error may damage the machinery or cause accidents.</li></ul> |                  |

|  |                  |
|--|------------------|
| <b>STARTUP AND MAINTENANCE PRECAUTIONS</b>   | <b>⚠ CAUTION</b> |
| <ul style="list-style-type: none"><li>Do not disassemble or modify the PLC. Doing so may cause fire, equipment failures, or malfunctions. For repair, contact your local Mitsubishi Electric representative.</li><li>Turn off the power to the PLC before connecting or disconnecting any extension cable. Failure to do so may cause equipment failures or malfunctions.</li><li>Turn off the power to the PLC before attaching or detaching the following devices. Failure to do so may cause equipment failures or malfunctions.<ul style="list-style-type: none"><li>Peripheral devices, extension units/blocks, special adapters, FX Series terminal blocks, extension power supply unit, connector conversion adapter and battery.</li></ul></li></ul> |                  |

|  |                  |
|--|------------------|
| <b>DISPOSAL PRECAUTIONS</b>  | <b>⚠ CAUTION</b> |
| <ul style="list-style-type: none"><li>Please contact a certified electronic waste disposal company for the environmentally safe recycling and disposal of your device. When disposing of batteries, separate them from other waste according to local regulations. (For details of the Battery Directive in EU countries, refer to FX3GC Series User's Manual - Hardware Edition.)</li></ul> |                  |

|   |                  |
|---|------------------|
| <b>TRANSPORTATION AND STORAGE PRECAUTIONS</b>   | <b>⚠ CAUTION</b> |
| <ul style="list-style-type: none"><li>When transporting the FX3GC Series PLC incorporating the optional battery, turn on the PLC before shipment, confirm that the battery mode is set using a parameter and the ALM LED is OFF, and check the battery life. If the PLC is transported with the ALM LED on or the battery exhausted, the battery-backed data may be unstable during transportation.</li><li>The PLC is a precision instrument. During transportation, avoid impacts larger than those specified in Section 2.1. Failure to do so may cause failures in the PLC. After transportation, verify the operations of the PLC.</li><li>When transporting lithium batteries, follow required transportation regulations. (For details of the regulated products, refer to FX3GC Series User's Manual - Hardware Edition.)</li></ul> |                  |

2

## Certification of UL, cUL standards

Please consult with Mitsubishi Electric for information on UL, cUL standard practices and the corresponding types of equipment.

## Compliance with EC directive(CE Marking )

This document does not guarantee that a mechanical system including this product will comply with the following standards. Compliance to EMC directive and LVD directive of the entire mechanical system should be checked by the user / manufacturer. For more details please contact the local Mitsubishi Electric sales site.

## Requirement for Compliance with EMC directive

The following products have shown compliance through direct testing (of the identified standards below) and design analysis (through the creation of a technical construction file) to the European Directive for Electromagnetic Compatibility (2004/108/EC) when used as directed by the appropriate documentation.

### Attention

- This product is designed for use in industrial applications.

### Note

- Authorized Representative in the European Community:  
Mitsubishi Electric Europe B.V.  
Gothaer Str. 8, 40880 Ratingen, Germany

**Type :** Programmable Controller (Open Type Equipment)  
**Models :** MELSEC FX3GC series, FX3U(C) series and FX2NC series manufactured

|                         |   |  |
|-------------------------|---|--|
| from June 1st, 2005     | FX3U-232ADP<br>FX3U-4AD-ADP<br>FX3U-4AD-PT-ADP            | FX3U-485ADP<br>FX3U-4DA-ADP<br>FX3U-4AD-TC-ADP                               |
| from April 1st, 2007    | FX3U-232ADP-MB  | FX3U-485ADP-MB   |
| from October 1st, 2007  | FX3UC-1PS-5V<br>FX2NC-★EX<br>FX2NC-★EX-DS<br>FX2NC-16EX-T | FX2NC-★EYT<br>FX2NC-★EYT-DSS<br>Where ★★ indicates:16,32<br>FX2NC-16EX-T-DSS |
| from December 1st, 2007 | FX3U-4AD-PTW-ADP<br>FX3U-4AD-PNK-ADP                      |  |
| from June 1st, 2009     | FX3U-3A-ADP   |  |
| from January 1st, 2012  | FX3GC-32MT/D  | FX3GC-32MT/DSS   |

| Standard   | Remark  |
|--|---|
| EN61131-2:2007<br>Programmable controllers<br>- Equipment requirements and tests | Compliance with all relevant aspects of the standard.<br>EMI <ul style="list-style-type: none"><li>Radiated Emission</li><li>Conducted Emission</li></ul> EMS <ul style="list-style-type: none"><li>Radiated electromagnetic field</li><li>Fast transient burst</li><li>Electrostatic discharge</li><li>High-energy surge</li><li>Voltage drops and interruptions</li><li>Conducted RF</li><li>Power frequency magnetic field</li></ul> |

**Models :** MELSEC FX2NC series manufactured

|                        |  |   |
|------------------------|--|---|
| from March 1st, 1999   | FX2NC-★EX-DS<br>Where ★★ indicates:16,32 | FX2NC-★EYT-DSS                              |
| from August 1st, 1999  | FX2NC-16EX-T-DS                          | FX2NC-16EYR-T-DSS                           |
| from October 1st, 2007 | FX2NC-★EX<br>Where ★★ indicates:16,32    | FX2NC-★EYT<br>FX2NC-16EX-T<br>FX2NC-16EYR-T |

| Standard  | Remark  |
|---|---|
| EN61000-6-4:2007<br>Generic emission standard Industrial environment<br>EN50081-2:1993<br>Electromagnetic compatibility | Compliance with all relevant aspects of the standard. <ul style="list-style-type: none"><li>Emission-Enclosure port</li><li>Emission-Low voltage AC mains port</li><li>Emission-Telecommunications/network port</li></ul>   |
| EN61000-6-2:2005<br>- Generic immunity standard Industrial environment  | Compliance with all relevant aspects of the standard. <ul style="list-style-type: none"><li>Radio-frequency electromagnetic field. Amplitude modulated</li><li>Fast transients</li><li>Electrostatic discharge</li><li>Surges</li><li>Voltage dips</li><li>Voltage interruptions</li><li>Radio-frequency common mode</li><li>Power-frequency magnetic field</li></ul> |

**Models : MELSEC FX2N series manufactured**

from July 1st, 1997 FX2N-16EX-ES/UL FX2N-16EYR-ES/UL  
FX2N-16EYT-ESS/UL  
from August 1st, 2005 FX2N-8ER-ES/UL FX2N-8EX-ES/UL  
FX2N-8EYR-ES/UL FX2N-8EYT-ESS/UL  
from September 1st, 2010 FX2N-8EYR-S-ES/UL

For the products above, PLCs manufactured before March 31st, 2002 are compliant with EN50081-2 (EN61000-6-4) and EN50082-2  
from April 1st, 2002 to April 30th, 2006 are compliant with EN50081-2 (EN61000-6-4) and EN61131-2:1994+A11:1996+A12:2000  
after May 1st, 2006 are compliant with EN61131-2:2007

| Standard  | Remark   |
|---|--|
| EN61000-6-4:2007<br>Generic emission standard Industrial environment<br>EN50081-2:1993<br>Electromagnetic compatibility | Compliance with all relevant aspects of the standard.<br><ul style="list-style-type: none"> <li>Emission-Enclosure port</li> <li>Emission-Low voltage AC mains port</li> <li>Emission-Telecommunications/network port</li> </ul>   |
| EN50082-2:1995<br>Electromagnetic compatibility<br>- Generic immunity standard Industrial environment                   | Compliance with all relevant aspects of the standard.<br><ul style="list-style-type: none"> <li>RF immunity</li> <li>Fast Transients</li> <li>ESD</li> <li>Conducted</li> <li>Power magnetic fields</li> </ul>   |
| EN61131-2:1994<br>/A11:1996<br>/A12:2000<br>Programmable controllers<br>- Equipment requirements and tests              | Compliance with all relevant aspects of the standard.<br><ul style="list-style-type: none"> <li>Radiated electromagnetic field</li> <li>Fast transient burst</li> <li>Electrostatic discharge</li> <li>Damped oscillatory wave</li> </ul>  |
| EN61131-2:2007<br>Programmable controllers<br>- Equipment requirements and tests  | Compliance with all relevant aspects of the standard.<br>EMI<br><ul style="list-style-type: none"> <li>Radiated Emission</li> <li>Conducted Emission</li> </ul> EMS<br><ul style="list-style-type: none"> <li>Radiated electromagnetic field</li> <li>Fast transient burst</li> <li>Electrostatic discharge</li> <li>High-energy surge</li> <li>Voltage drops and interruptions</li> <li>Conducted RF</li> <li>Power frequency magnetic field</li> </ul> |

**Requirement for Compliance with LVD directive**

The following products have shown compliance through direct testing (of the identified standards below) and design analysis (through the creation of a technical construction file) to the European Directive for Low Voltage (2006/95/EC) when used as directed by the appropriate documentation.

**Models : MELSEC FX2NC series manufactured**

from August 1st, 1999 FX2NC-16EYR-T-DS  
from October 1st, 2007 FX2NC-16EYR-T

| Standard  | Remark  |
|---|---|
| IEC1010-1:1990<br>/A1:1992<br>BSEN61010-1:1993 *<br>Safety requirements for electrical equipment for measurement, control, and laboratory use<br>- General requirements | The equipment has been assessed as a component for fitting in a suitable enclosure which meets the requirements of IEC1010-1:1990+A1:1992 |

\* Compliance to BSEN61010-1 is claimed through virtue of direct compliance to IEC1010-1 and Amendment 1.

**Models : MELSEC FX2N series manufactured**

from July 1st, 1997 FX2N-16EYR-ES/UL  
from August 1st, 2005 FX2N-8ER-ES/UL FX2N-8EYR-ES/UL  
from September 1st, 2010 FX2N-8EYR-S-ES/UL

For the products above, PLCs manufactured before March 31st, 2002 are compliant with IEC1010-1  
from April 1st, 2002 to April 30th, 2006 are compliant with EN61131-2:1994+A11:1996+A12:2000  
after May 1st, 2006 are compliant with EN61131-2:2007

| Standard  | Remark   |
|---|--|
| IEC1010-1:1990<br>/A1:1992<br>Safety requirements for electrical equipment for measurement, control, and laboratory use<br>- General requirements | The equipment has been assessed as a component for fitting in a suitable enclosure which meets the requirements of IEC1010-1:1990+A1:1992                  |
| EN61131-2:1994:2007<br>/A12:2000<br>/A11:1996<br>Programmable controllers<br>- Equipment requirements and tests                                   | The equipment has been assessed as a component for fitting in a suitable enclosure which meets the requirements of EN61131-2:1994+A11:1996+A12:2000; :2007 |

**Caution for compliance with EC Directive****Installation in Enclosure**

Programmable logic controllers are open-type devices that must be installed and used within conductive control boxes. Please use the FX3GC Series programmable logic controllers while installed in conductive shielded control boxes. Please secure the control box lid to the control box (for conduction). Installation within a control box greatly affects the safety of the system and aids in shielding noise from the programmable logic controller.

**Caution for Analog Products in use**

The analog products have been found to be compliant to the European standards in the aforesaid manual and directive. However, for the very best performance from what are in fact delicate measuring and controlled output device Mitsubishi Electric would like to make the following points;

As analog devices are sensitive by nature, their use should be considered carefully. For users of proprietary cables (integral with sensors or actuators), these users should follow the manufacturers' installation requirements.

Mitsubishi Electric recommends that shielded cables be used. If no other EMC protection is provided, then users may experience temporary loss of accuracy between +10%/-10% in very heavy industrial areas.

However, Mitsubishi Electric suggests that when adequate EMC precautions are followed with general good EMC practice for the users complete control system.

- Sensitive analog cables should not be laid next to or bound with high voltage cabling. Where possible, users should run analog cables separately.
- Good cable shielding should be used. When grounding the shield - ensure that no loops are accidentally created.
- When reading analog values, EMC induced errors can be smoothed out by averaging the readings. This can be achieved either through functions on the analog products or through the user's program in the FX3GC Series PLC main unit.

**Associated manuals**

FX3GC Series PLC (main unit) comes with this document (hardware manual).

For a detailed explanation of the FX3GC Series hardware and information on instructions for PLC programming and special function block, refer to the relevant documents.

| Manual name  | Manual No.                           | Description  |
|--|--------------------------------------|--|
| FX3GC Series<br>User's Manual<br>- Hardware Edition  | JY997D45401<br>MODEL CODE:<br>09R533 | Explains the FX3GC Series PLC specifications for I/O, wiring, installation, and maintenance.     |
| FX3S/FX3G/FX3GC/<br>FX3U/FX3UC Series<br>Programming<br>Manual<br>- Basic & Applied<br>Instruction Edition | JY997D16601<br>MODEL CODE:<br>09R517 | Describes PLC programming for basic/applied instructions STL/SFC programming and system devices. |
| MELSEC-Q/L/F<br>Structured<br>Programming<br>Manual<br>(Fundamentals)                                      | SH-080782<br>MODEL CODE:<br>13JW06   | Programming methods, specifications, functions, etc. required to create structured programs.     |
| FXCPU Structured<br>Programming<br>Manual<br>[Device & Common]   | JY997D26001<br>MODEL CODE:<br>09R925 | Devices, parameters, etc. provided in structured projects of GX Works2.                          |
| FXCPU Structured<br>Programming<br>Manual<br>[Basic & Applied<br>Instruction]                              | JY997D34701<br>MODEL CODE:<br>09R926 | Sequence instructions provided in structured projects of GX Works2.                              |
| FXCPU Structured<br>Programming<br>Manual<br>[Application<br>Functions]                                    | JY997D34801<br>MODEL CODE:<br>09R927 | Application functions provided in structured projects of GX Works2.                              |

| Manual name  | Manual No.                           | Description  |
|--|--------------------------------------|--|
| FX Series User's<br>Manual - Data<br>Communication<br>Edition                              | JY997D16901<br>MODEL CODE:<br>09R715 | Explains N:N Network, parallel link, computer link, non-protocol communication by RS instructions/FX2N-232IF.        |
| FX3S/FX3G/FX3GC/<br>FX3U/FX3UC Series<br>User's Manual<br>- Analog Control<br>Edition      | JY997D16701<br>MODEL CODE:<br>09R619 | Describes specifications for analog control and programming methods for the FX3S/FX3G/FX3GC/FX3U/FX3UC Series PLC.   |
| FX3S/FX3G/FX3GC/<br>FX3U/FX3UC Series<br>User's Manual<br>- Positioning Control<br>Edition | JY997D16801<br>MODEL CODE:<br>09R620 | Explains the positioning control specifications of the FX3S/FX3G/FX3GC/FX3U/FX3UC Series and programming procedures. |


**How to obtain manuals**

For the necessary product manuals or documents, consult with the Mitsubishi Electric dealer from where you purchase your product.

**Incorporated Items**

Check if the following product and items are included in the package:

|   |  | Included Items |                  |
|---|--|----------------|------------------|
| ■ Main units  |  |                |                  |
| FX3GC-32MT/D  | Product  |                | 1 unit           |
|   | FX2NC-100MPCB<br>[1m (3' 3"), three wire]      |                | 1 cable          |
|   | FX2NC-100BPCB<br>[1m (3' 3"), two wire]        |                | 1 cable          |
|   | Manuals [Japanese version,<br>English version] |                | 1 manual<br>each |
| FX3GC-32MT/DSS  | Product  |                | 1 unit           |
|   | FX2NC-100MPCB<br>[1m (3' 3"), three wire]      |                | 1 cable          |
|   | Manuals [Japanese version,<br>English version] |                | 1 manual<br>each |
|   | ■ Input / output extension blocks              |                |                  |
| FX2NC-□□EX<br>FX2NC-16EX-T  | Product  |                | 1 unit           |
|   | FX2NC-10BPCB1<br>[0.1m (3.93"), double-ended]  |                | 1 cable          |
| FX2NC-□□EX-DS<br>FX2NC-16EX-T-DS<br>FX2NC-□□EYT<br>FX2NC-□□EYT-DSS<br>FX2NC-16EYR-T<br>FX2NC-16EYR-T-DS | Product  |                | 1 unit           |



## 2.3 Procedures for installing to and detaching from DIN rail

The products can be installed on a DIN46277 rail [35 mm (1.38" wide)].


This section explains the installations of the main units.

For the input/output extension blocks and special adapters, refer to the following manual.


→ FX3GC Series User's Manual - Hardware Edition.

### 2.3.1 Installation

- 1) Turn the power supply OFF.
- 2) Push the DIN rail mounting hooks ① of all connected units/blocks as shown in the figure below ①.




- 4) While pressing the main unit onto the DIN rail, lock the DIN rail mounting hooks as shown in the figure below ③.



### 2.3.2 Removal methods

- 1) Turn the power supply OFF.
- 2) Disconnect all connected cables including the power cable and I/O cable.
- 3) Insert a flathead screwdriver to the DIN rail mounting hook (①) in the figure on the right.
- 4) Lever the screwdriver slightly toward direction ②, to pull out the DIN rail mounting hooks, allowing them to come off the DIN rail.
- 5) Remove the main unit from the DIN rail (③ in the figure on the right).
- 6) Push the DIN rail mounting hooks as shown in the figure on the right ④.




## 2.4 Connection of power supply connector

Use the dedicated built-in power connector to supply power to the main unit.


The power should be supplied to the main unit, FX2NC Series I/O extension blocks and FX2NC/FX3UC Series special function blocks. Some (FX2NC-□□EX(-T)) of FX2NC Series I/O extension blocks require power cable types "B" and "C" shown on the below, while others (FX2NC-□□EX(-T)-DS) do not require them. For details, refer to FX3GC Series User's Manual - Hardware Edition.

When connecting two or more extension blocks which require power cables "B" and "C" shown on the right, perform crossover wiring between the extension blocks using two (upper and lower) power connectors.



### Removal of the power cable

- 1) Turn the power supply OFF.
- 2) Pinch the power cable connector "a" and disconnect it in the direction of the arrow (see figure on the right).



Power Cable types "A" and "B" are supplied with the main unit, while type "C" is supplied with the FX2NC-□□EX and FX2NC-16EX-T.

| Type | Application   | Model          | Length       | Cable supplied with          |
|------|---|----------------|--------------|------------------------------|
| "A"  | Power cable for main unit   | FX2NC-100MP CB | 1m (3' 3")   | FX3GC-32MT/D, FX3GC-32MT/DSS |
| "B"  | Input power cable for FX2NC series input extension blocks           | FX2NC-100BP CB | 1m (3' 3")   | FX3GC-32MT/D                 |
| "C"  | Input power crossover cable for FX2NC series input extension blocks | FX2NC-10BPC B1 | 0.1m (3.93") | FX2NC-□□EX, FX2NC-16EX-T     |


The crossover cable (type "C") can skip up to 4 16-point output blocks to connect units.

If more blocks should be skipped to supply power to an input block, use cable type "B".

## 2.5 Connection to input/output connector

The input/output connectors of the main units conform to MIL-C-83503.

→ Refer to Chapter 4 for the I/O connector pin arrangement.



- 1) **Compliant connectors (commercially available connectors)**  
Use a 20-pin (1-key) socket connector conforming to MIL-C-83503.  
Confirm in advance that the connectors do not interfere with other parts including connector covers.

### 2) Input/output cables (available from Mitsubishi)

Input/output cables with attached connectors are available.

| Model names     | Length       | Description   | Shape  |
|-----------------|--------------|---|--|
| FX-16E-500CAB-S | 5m (16'4")   | General-purpose input/output cable  | <ul style="list-style-type: none"> <li>Single wire (Wire color: red)</li> <li>PLC side: A 20-pin connector</li> </ul>  |
| FX-16E-150CAB   | 1.5m (4'11") | Cables for connecting the FX Series terminal block with input/output connectors. For terminal block connection, refer to FX3GC Series User's Manual - Hardware Edition. | <ul style="list-style-type: none"> <li>Flat cables (with tube)</li> <li>A 20-pin connector at both ends</li> </ul>   |
| FX-16E-300CAB   | 3m (9'10")   |   |  |
| FX-16E-500CAB   | 5m (16'4")   |   |  |
| FX-16E-150CAB-R | 1.5m (4'11") |   |  |
| FX-16E-300CAB-R | 3m (9'10")   | Cables for connecting the A Series Model A6TBXY36 connector/terminal block conversion unit and input/output connector type  | <ul style="list-style-type: none"> <li>Round multicore cables</li> <li>A 20-pin connector at both ends</li> </ul>  |
| FX-16E-500CAB-R | 5m (16'4")   |   |  |
| FX-A32E-150CAB  | 1.5m (4'11") | Cables for connecting the A Series Model A6TBXY36 connector/terminal block conversion unit and input/output connector type  | <ul style="list-style-type: none"> <li>Flat cables (with tube)</li> <li>PLC side: Two 20-pin connectors in 16-point units.</li> <li>Terminal block side: A dedicated connector</li> <li>One common terminal covers 32 input/output terminals.</li> </ul> |
| FX-A32E-300CAB  | 3m (9'10")   |   |  |
| FX-A32E-500CAB  | 5m (16'4")   |   |  |

## 3) Connectors for user-made input/output cables (available from Mitsubishi)

Users should provide electric wires and a pressure bonding tool.

| Model name and composition of input/output connector |  | Applicable electric wire (UL-1061 are recommended) and tool |   |  |
|--|--|---|---|--|
| Our model name                                       | Details of part (made by DDK Ltd.)                                 | Electric wire size  | Pressure bonding tool (made by DDK Ltd.)        |  |
| FX2C-I/O-CON for flat cable                          | 10-piece set<br>Solderless connector FRC2-A020-30S                 | AWG28 (0.1mm <sup>2</sup> )<br>1.27 pitch, 20-core          | 357J-4674D: Main body<br>357J-4664N: Attachment |  |
| FX2C-I/O-CON-S for bulk wire                         | 5-piece set<br>Housing HU-200S2-001<br>Solderless contact HU-411S  | AWG22 (0.3mm <sup>2</sup> )                                 | 357J-5538                                       |  |
| FX2C-I/O-CON-SA for bulk wire                        | 5-piece set<br>Housing HU-200S2-001<br>Solderless contact HU-411SA | AWG20 (0.5mm <sup>2</sup> )                                 | 357J-13963                                      |  |

## 4) Certified connectors (commercially available connectors)

Connectors made by DDK Ltd. shown in item 3).



## 2.6 Connection to input/output terminal block

### 2.6.1 Cable

1) Applicable cable

| Type        | Wire size  |
|-------------|--|
| Single wire | 0.3mm <sup>2</sup> to 0.5mm <sup>2</sup> (AWG22 to 20) |
| Double wire | 0.3mm <sup>2</sup> (AWG22)×2                           |

2) Termination

Strip the coating of strand wire and twist the cable core before connecting it, or strip the coating of single wire before connecting it. An alternative connection is to use a ferrule with insulating sleeve.


<Reference>

| Manufacturer    | Model      | Caulking tool   |
|-----------------|------------|---|
| Phoenix Contact | AI 0.5-8WH | CRIMPFOX 6 <sup>*1</sup><br>(or CRIMPFOX 6T-F <sup>*2</sup> ) |

<sup>\*1</sup> Old model name: CRIMPFOX ZA 3

<sup>\*2</sup> Old model name: CRIMPFOX UD 6

- Stranded wire/solid wire
- Bar terminal with insulating sleeve



When using a stick terminal with an insulating sleeve, choose a wire with proper cable sheath referring to the above outside dimensions, otherwise the wire cannot be inserted easily.

### 2.6.2 Tightening Torque


Tighten the terminals to a torque of 0.22 to 0.25 N·m.

Do not tighten terminal screws with a torque outside the above-mentioned range.

Failure to do so may cause equipment failures or malfunctions.

#### Tool

To tighten terminals, use a purchased small-sized screwdriver whose head is straight and is not widened as shown in the right figure.



#### Note:

If the diameter of screwdriver grip is too small, tightening torque will not be able to be achieved. To achieve the appropriate tightening torque shown in the table above, use the following screwdriver or an appropriate replacement (grip diameter approximately 25 mm (0.98 inch)).

<Reference>

| Manufacturer    | Model       |
|-----------------|-------------|
| Phoenix Contact | SZS 0.4×2.5 |

## 3. Power supply/input/output specifications and examples of external wiring

### DESIGN PRECAUTIONS



- Make sure to have the following safety circuits outside of the PLC to ensure safe system operation even during external power supply problems or PLC failure. Otherwise, malfunctions may cause serious accidents.
  - Most importantly, have the following: an emergency stop circuit, a protection circuit, an interlock circuit for opposite movements (such as normal vs. reverse rotation), and an interlock circuit (to prevent damage to the equipment at the upper and lower positioning limits).
  - Note that when the PLC CPU detects an error, such as a watchdog timer error, during self-diagnosis, all outputs are turned off. Also, when an error that cannot be detected by the PLC CPU occurs in an input/output control block, output control may be disabled. External circuits and mechanisms should be designed to ensure safe machinery operation in such a case.
  - Note that when an error occurs in a relay, triac or transistor output device, the output could be held either on or off. For output signals that may lead to serious accidents, external circuits and mechanisms should be designed to ensure safe machinery operation in such a case.

### DESIGN PRECAUTIONS



- Do not bundle the control line together with or lay it close to the main circuit or power line. As a guideline, lay the control line at least 100mm (3.94 inch) or more away from the main circuit or power line. Noise may cause malfunctions.
- Install module so that excessive force will not be applied to the built-in programming port, power connectors, I/O connectors, communication connectors, or communication cables. Failure to do so may result in wire damage/breakage or PLC failure.

#### Notes

- Simultaneously turn on and off the power supplies of the main unit and extension devices.
- Even if the power supply causes an instantaneous power failure for 5 ms or less, the PLC can continue to operate.
- If a long-time power failure or an abnormal voltage drop occurs, the PLC stops, and output is turned off. When the power supply is restored, it will automatically restart (when the RUN input is on).

### WIRING PRECAUTIONS



- Make sure to cut off all phases of the power supply externally before attempting installation or wiring work. Failure to do so may cause electric shock or damage to the product.

### WIRING PRECAUTIONS



- Connect the DC power supply wiring to the dedicated terminals described in this manual. If an AC power supply is connected to a DC input/output terminal or DC power supply terminal, the PLC will burn out.
- Do not wire vacant terminals externally. Doing so may damage the product.
- Perform class D grounding (grounding resistance: 100Ω or less) to the grounding terminal on the main unit. Do not use common grounding with heavy electrical systems (refer to section 3.2).
- When drilling screw holes or wiring, make sure cutting or wire debris does not enter the ventilation slits. Failure to do so may cause fire, equipment failures or malfunctions.
- Make sure to properly wire to the terminal block (European type) in accordance with the following precautions. Failure to do so may cause electric shock, equipment failures, a short-circuit, wire breakage, malfunctions, or damage to the product.
  - The disposal size of the cable end should follow the dimensions described in the manual.
  - Tightening torque should follow the specifications in the manual. Twist the end of strand wire and make sure that there are no loose wires.
  - Do not solder-plate the electric wire ends.
  - Do not connect more than the specified number of wires or electric wires of unspecified size.
  - Affix the electric wires so that neither the terminal block nor the connected parts are directly stressed.

#### Notes

- Input/output wiring 50 to 100m (164'1" to 328'1") long will cause almost no problems of noise, but, generally, the wiring length should be less than 20m (65'7") to ensure the safety.
- Extension cables are easily affected by noise. Lay the cables at a distance of at least 30 to 50mm (1.19" to 1.97") away from the PLC output and other power lines.

### 3.1 Power supply specifications and example of external wiring

→ For more details, refer to FX3GC Series User's Manual - Hardware Edition.

#### 3.1.1 Power supply specifications

The specifications for the power supply of the main unit are shown in the following table.

| Item                                       | Specification   |
|--|---|
| Supply voltage                             | 24V DC +20% -15%  |
| Allowable instantaneous power failure time | Operation can be continued upon occurrence of an instantaneous power failure for 5ms or less. |
| Power fuse                                 | 125V 3.15A  |
| Rush current                               | 30A max. 0.5ms/24V DC   |
| Power consumption <sup>*1</sup>            | 8W  |
| 5V DC built-in power supply <sup>*2</sup>  | 400mA   |

<sup>\*1</sup> Input/output extension blocks and special function blocks are not contained in power consumption. For power consumption of the FX2NC input/output extension blocks, refer to the following table.

| Model names        | Power consumption |
|--------------------|-------------------|
| FX2NC-16EX-T(-DS)  | 2.2W              |
| FX2NC-16EX(-DS)    | 2.2W              |
| FX2NC-32EX(-DS)    | 4.2W              |
| FX2NC-16EYR-T(-DS) | 2.2W              |
| FX2NC-16EYT(-DSS)  | 0.35W             |
| FX2NC-32EYT(-DSS)  | 0.7W              |

→ Refer to the FX3GC Series User's Manual - Hardware Edition.

→ For the power consumed by the special function blocks, refer to the appropriate manuals.

<sup>\*2</sup> Cannot be used to supply power to an external destination. This power is supplied to input/output extension blocks, special function blocks and special adapters only.

#### 3.1.2 Example of external wiring (power type)


Supply 24V DC power to the main unit and FX2NC-□□EX(-T) using the dedicated connector.

→ For the details of wiring work, refer to Section 2.4

→ For the power supply wiring of the FX2NC input extension blocks, refer to the Subsection 3.3.3

Use a 24V DC +20% -15% DC power supply. The allowable range of the 24V DC power supply may be narrower when special function blocks are connected.

→ For more details, refer to the FX3GC Series User's Manual - Hardware Edition




<sup>\*1</sup> A UL Listed or Recognized fuse rated not higher than 3.47A must be used with FX3GC.

### 3.2 Grounding

Ground the PLC as stated below.

- Perform class D grounding. (Grounding resistance: 100 Ω or less)
- Ground the PLC independently if possible. If it cannot be grounded independently, ground it jointly as shown below.



- Position the grounding point as close to the PLC as possible to decrease the length of the ground wire.

### 3.3 Input specifications and external wiring

→ For more details, refer to FX3GC Series User's Manual  
- Hardware Edition.

#### 3.3.1 Input specifications


| Item                          |  |              | Specification  |
|-------------------------------|--|--------------|--|
| Number of input points        | FX3GC-32MT/D(SS)<br>FX2NC-16EX(-DS)<br>FX2NC-16EX-T(-DS) |              | 16 points  |
|                               | FX2NC-32EX(-DS)  |              | 32 points  |
|                               |  |              |  |
| Input connecting type         | FX3GC-32MT/D(SS)<br>FX2NC-□□EX(-DS)                      |              | Connector  |
|                               | FX2NC-16EX-T(-DS)  |              | Terminal block   |
| Input form                    | FX3GC-32MT/D<br>FX2NC-□□EX<br>FX2NC-16EX-T               |              | Sink   |
|                               | FX3GC-32MT/DSS<br>FX2NC-□□EX-DS<br>FX2NC-16EX-T-DS       |              | Sink/Source  |
| Input signal voltage          |  |              | 24V DC +20% -15%   |
| Input impedance               | Main unit  | X000 to X007 | 3.3kΩ  |
|                               |  | X010 to X017 | 4.3kΩ  |
|                               | Input/output extension block                             |              | 4.3kΩ  |
| Input signal current          | Main unit  | X000 to X007 | 7mA/24V DC   |
|                               |  | X010 to X017 | 5mA/24V DC   |
|                               | Input/output extension block                             |              | 5mA/24V DC   |
| ON input sensitivity current  | Main unit  | X000 to X007 | 4.5mA or more  |
|                               |  | X010 to X017 | 3.5mA or more  |
| OFF input sensitivity current | Main unit  | X000 to X007 | 4.5mA or more  |
|                               |  | X010 to X017 | 3.5mA or more  |
| OFF input sensitivity current |  |              | 1.5mA or less  |
| Input response time           |  |              | Approx. 10ms   |
| Input signal form             | FX3GC-32MT/D<br>FX2NC-□□EX<br>FX2NC-16EX-T               |              | No-voltage contact input<br>NPN open collector transistor  |
|                               | FX3GC-32MT/DSS<br>FX2NC-□□EX-DS<br>FX2NC-16EX-T-DS       |              | <ul style="list-style-type: none"> <li>Sink input:<br/>No-voltage contact input<br/>NPN open collector transistor</li> <li>Source input:<br/>No-voltage contact input<br/>PNP open collector transistor</li> </ul> |
| Input circuit insulation      |  |              | Photocoupler insulation  |
| Input operation display       |  |              | LED on panel lights when photocoupler is driven.   |

#### 3.3.2 Handling of input terminal

- FX3GC-32MT/D, FX2NC-□□EX(-T)**  
Inputs turn ON when the input terminal and COM terminal are electrically connected with a no-voltage contact or NPN open collector transistor.
- FX3GC-32MT/DSS, FX2NC-□□EX(-T)-DS**
  - Sink input**  
Inputs turn ON when the 24V DC ⊕ terminal and COM△ terminal or COM terminal are connected, and the input terminal and 24V DC ⊖ terminal are electrically connected with a no-voltage contact or NPN open collector transistor.
  - Source input**  
Inputs turn ON when the 24V DC ⊖ terminal and COM△ terminal or COM terminal are connected, and the input terminal and 24V DC ⊕ terminal are electrically connected with a no-voltage contact or PNP open collector transistor. Where △ indicates 0 to 2

#### 3.3.3 Example of input wiring

##### 1. Examples of input wiring (FX3GC-32MT/D)




\*1 A UL Listed or Recognized fuse rated not higher than 3.47A must be used with FX3GC.

\*2 The grounding resistance should be 100Ω or less.

\*3 Use a fuse suitable for the system.

#### 2. Examples of sink input wiring (FX3GC-32MT/DSS)




\*1 A UL Listed or Recognized fuse rated not higher than 3.47A must be used with FX3GC.

\*2 The grounding resistance should be 100Ω or less.

\*3 Use a fuse suitable for the system.

##### 3. Examples of source input wiring (FX3GC-32MT/DSS)



\*1 A UL Listed or Recognized fuse rated not higher than 3.47A must be used with FX3GC.

\*2 The grounding resistance should be 100Ω or less.

\*3 Use a fuse suitable for the system.

### 3.4 Transistor output specifications and example of external wiring

→ For more details, refer to FX3GC Series User's Manual  
- Hardware Edition.

#### 3.4.1 Transistor output specifications

| Item                         |                                       |                                 |              | Specification<br>(Transistor)                    |  |
|------------------------------|---------------------------------------|---------------------------------|--------------|--|--|
| Number of output points      | FX3GC-32MT/D(SS)<br>FX2NC-16EYT(-DSS) |                                 |              | 16 points  |  |
|                              | FX2NC-32EYT(-DSS)                     |                                 |              | 32 points  |  |
| Output connecting type       |                                       |                                 |              | Connector  |  |
| Output form                  | FX3GC-32MT/D<br>FX2NC-□□EYT           |                                 |              | Transistor (Sink)                                |  |
|                              | FX3GC-32MT/DSS<br>FX2NC-□□EYT-DSS     |                                 |              | Transistor (Source)                              |  |
| External power supply        |                                       |                                 |              | 5 to 30V DC                                      |  |
| Max. load                    | Resistance load                       | Main unit                       | Y000, Y001   | 0.3A/point                                       | Make sure that the total load current of 8 resistance load points is 0.8A*1 or less. |
|                              |                                       |                                 | Y002 to Y017 | 0.1A/point                                       |  |
|                              |                                       | FX2NC-□□EYT (-DSS)              |              | 0.1A/point                                       | Make sure that the total load current of 8 resistance load points is 0.8A or less.   |
|                              | Inductive load                        | Main unit                       | Y000, Y001   | 7.2W/point (24V DC)                              | Make sure that the total load of 16 inductive load points is 38.4W/24V DC or less.   |
|                              |                                       |                                 | Y002 to Y017 | 2.4W/point (24V DC)                              |  |
|                              |                                       | FX2NC-□□EYT (-DSS)              |              | 2.4W/point (24V DC)                              |  |
| Open circuit leakage current |                                       |                                 |              | 0.1mA or less/30V DC                             |  |
| ON voltage                   |                                       |                                 |              | 1.5V or less                                     |  |
| Response time                | OFF→ON                                | Main unit                       | Y000, Y001   | 5μs or less/10mA or more (5 to 24V DC)           |  |
|                              |                                       |                                 | Y002 to Y017 | 0.2ms or less/100mA (at 24V DC)                  |  |
|                              |                                       | FX2NC-□□EYT (-DSS)              |              | 0.2ms or less/100mA (at 24V DC)                  |  |
|                              | ON→OFF                                | Main unit                       | Y000, Y001   | 5μs or less/10mA or more (5 to 24V DC)           |  |
|                              |                                       |                                 | Y002 to Y017 | 0.2ms or less/100mA (at 24V DC)                  |  |
| FX2NC-□□EYT (-DSS)           |                                       | 0.2ms or less/100mA (at 24V DC) |              |  |  |
| Output circuit insulation    |                                       |                                 |              | Photocoupler insulation                          |  |
| Output operation display     |                                       |                                 |              | LED on panel lights when photocoupler is driven. |  |

\*1 When the two COM1(+V0) terminals are connected outside the PLC, resistance load is 1.6A or less.

### 3.4.2 Handling of transistor output circuit

#### Output terminal:

The main unit and FX2NC input/output extension block have 16 transistor output points per common.

Two COM★ or +V△ terminals connected to each other inside the PLC are provided for outputs.

Connect two COM★ or +V△ terminals outside the PLC so that the load applied to each COM★ or +V△ terminal is smaller.

Where ★ indicates:1 to 3


Where △ indicates:0 to 2

#### Output current:


The ON voltage of the output transistor is approx. 1.5V. When driving a semiconductor element, carefully check the input voltage characteristics of the applied element.

### 3.4.3 External Wiring of Transistor Output

#### 1. External wiring of sink output type



#### 2. External wiring of source output type



### 3.5 Relay output specifications and example of external wiring

→ For more details, refer to FX3GC Series User's Manual - Hardware Edition.

#### 3.5.1 Relay output specifications

| Item                         |  | Specification (Relay)  |
|------------------------------|--|--|
| Number of output points      | FX2NC-16EYR-T(-DS)   | 16 points  |
| Output connecting type       | Terminal block   |  |
| External power supply        | 30V DC or less or 240V AC or less (250V AC or less when the unit does not comply with CE, UL or cUL standards) |  |
| Max. load                    | Resistance load  | 2A /point<br>When using one COM□ terminal, make sure that the total load current of 8 resistance load points is 4 A or less.<br>When connecting two COM□ terminals outside the PLC, make sure that the total load current of 8 resistance load points is 8A or less. |
|                              | Inductive load   | 80VA<br>→ For the product life of relay contacts, refer to the FX3GC Series User's Manual - Hardware Edition.  |
| Min. load                    | 5V DC, 2mA (reference value)   |  |
| Open circuit leakage current | -  |  |
| Response time                | OFF→ON   | 10ms or less   |
|                              | ON→OFF   | 10ms or less   |
| Circuit insulation           | Mechanical insulation  |  |
| Display of output operation  | LED lights when power is applied to relay coil.  |  |

#### 3.5.2 Handling of relay output circuit

##### Output terminal:


Main units, FX2NC input/output extension blocks have 8 relay output points per common.

Two COM★ terminals connected to each other inside the FX2NC-16EYR-T(-DS) are provided for outputs.

Connect two COM★ terminals outside the PLC so that the load applied to each COM★ terminal is smaller.


Where ★ indicates:1 or 2

#### 3.5.3 Example of relay output wiring



### 3.6 Cautions in input and output wiring

→ For more details, refer to FX3GC Series User's Manual - Hardware Edition.



#### 3.6.1 Instructions for connecting input devices

- In the case of no-voltage contact  
The input current of this PLC is 5 to 7mA/24V DC. Use input devices applicable to this minute current. If no-voltage contacts (switches) for large current are used, contact failure may occur.
- In the case of input device with built-in series diode  
The voltage drop of the series diode should be approx. 4V or less. When lead switches with a series LED are used, up to two switches can be connected in series. Also make sure that the input current is over the input-sensing level while the switches are ON.
- In the case of input device with built-in parallel resistance  
Use a device with a parallel resistance of 15kΩ or more. When the resistance is less than 15kΩ, connect a bleeder resistance.
- In the case of 2-wire proximity switch  
Use a two-wire proximity switch whose leakage current is 1.5mA or less when the switch is off. When the current is 1.5mA or more, connect a bleeder resistance.

#### 3.6.2 Cautions on transistor output wiring

- Protection circuit for load short-circuits  
A short-circuit at a load connected to an output terminal could cause burnout at the output element or the PCB. To prevent this, a protection fuse should be inserted at the output. Use a load power supply capacity that is at least 2 times larger than the total rated fuse capacity.
- Contact protection circuit for inductive loads  
When an inductive load is connected, connect a diode (for commutation) in parallel with the load as necessary. The diode (for commutation) must comply with the following specifications.
 

|                 |                                   |
|-----------------|-----------------------------------|
| Reverse voltage | 5 to 10 times of the load voltage |
| Forward current | Load current or more              |
- Interlock  
Loads, such as contactors for normal and reverse rotations, that must not be turned on simultaneously should have an interlock in the PLC program and an external interlock.

### 3.6.3 Cautions on relay output wiring

- Protection circuit for load short-circuiting  
When a load connected to the output terminal short-circuits, the printed circuit board may be burnt out. Fit a protective fuse on the output circuit.
- Protection circuit of contact when inductive load is used  
An internal protection circuit for the relays is not provided for the relay output circuit in this product. It is recommended to use inductive loads with built-in protection circuits. When using loads without built-in protection circuits, insert an external contact protection circuit, etc. to reduce noise and extend the product life.
  - DC circuit  
Connect a diode in parallel with the load. Use a diode (for commutation) having the following specifications.
 

|                 |                                |
|-----------------|--------------------------------|
| Reverse voltage | 5 to 10 times the load voltage |
| Forward current | Load current or more           |
  - AC circuit  
Connect the surge absorber (combined CR components such as a surge killer and spark killer, etc.) parallel to the load. Select the rated voltage of the surge absorber suitable to the output used. Refer to the table below for other specifications.
 

|                        |                     |
|------------------------|---------------------|
| Electrostatic capacity | Approx. 0.1μF       |
| Resistance value       | Approx. 100 to 200Ω |
- Interlock  
Loads, such as contactors for normal and reverse rotations, that must not be turned on simultaneously should have an interlock in the PLC program and an external interlock.
- Common mode  
Use output contacts of the PLC in the common mode.


## 4. Terminal layouts

### 4.1 Main units

#### 4.1.1 FX3GC-32MT/D

The I/O wiring is different in the FX3GC-32MT/DSS. Refer to Sections 3.3 and 3.4 for the details.


FX3GC-32MT/D



#### 4.1.2 FX3GC-32MT/DSS

The I/O wiring is different in the FX3GC-32MT/D. Refer to Sections 3.3 and 3.4 for the details.


FX3GC-32MT/DSS




## 4.2 FX2NC input/output extension blocks

### 4.2.1 FX2NC-□□EX(-DS)


FX2NC-16EX




FX2NC-32EX



FX2NC-16EX-DS




FX2NC-32EX-DS




### 4.2.2 FX2NC-□□EYT(-DSS)


FX2NC-16EYT




FX2NC-32EYT



FX2NC-16EYT-DSS




FX2NC-32EYT-DSS




## 4.2.3 FX2NC-16EX-T(-DS), FX2NC-16EYR-T(-DS)

FX2NC-16EX-T(-DS)



FX2NC-16EYR-T(-DS)



This manual confers no industrial property rights or any rights of any other kind, nor does it confer any patent licenses. Mitsubishi Electric Corporation cannot be held responsible for any problems involving industrial property rights which may occur as a result of using the contents noted in this manual.

### Warranty

Mitsubishi will not be held liable for damage caused by factors found not to be the cause of Mitsubishi; opportunity loss or lost profits caused by faults in the Mitsubishi products; damage, secondary damage, accident compensation caused by special factors unpredictable by Mitsubishi; damages to products other than Mitsubishi products; and to other duties.



### For safe use

- This product has been manufactured as a general-purpose part for general industries, and has not been designed or manufactured to be incorporated in a device or system used in purposes related to human life.
- Before using the product for special purposes such as nuclear power, electric power, aerospace, medicine or passenger movement vehicles, consult with Mitsubishi Electric.
- This product has been manufactured under strict quality control. However when installing the product where major accidents or losses could occur if the product fails, install appropriate backup or failsafe functions in the system.

**MITSUBISHI ELECTRIC CORPORATION**

HEAD OFFICE : TOKYO BUILDING, 2-7-3 MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN