

CL1X4-D1S2 CC-Link/LT Remote I/O Module

Please read this manual thoroughly before starting to use the product and handle the product properly.

User's Manual

MODEL	CL1X4-D1S2
MANUAL Number	JY997D10801G
Date	April 2015

●SAFETY PRECAUTIONS●


(Read these precautions before using)

Please read this manual carefully and pay special attention to safely in order to handle this product properly. Also pay careful attention to safely and handle the module properly. These precautions apply only to Mitsubishi equipment. Refer to the user's manual of the CPU module to use for a description of the PLC system safety precautions.

These ●SAFETY PRECAUTIONS● classify the safety precautions into two categories: "WARNING" and "CAUTION".



Procedures which may lead to a dangerous condition and cause death or serious injury if not carried out properly.



Procedures which may lead to a dangerous condition and cause superficial to medium injury, or physical damage only, if not carried out properly.

Depending on circumstances, procedures indicated by **CAUTION** may also be linked to serious results. In any case, it is important to follow the directions for usage. Store this manual in a safe place so that you can take it out and read it whenever necessary. Always forward it to the end user.

[DESIGN PRECAUTIONS]

WARNING

- Configure an interlock circuit in a sequence program so that the system operates on the safety side using the communication status information in the event the data link falls into a communication problem. Otherwise, erroneous output and malfunction may result in accidents.
- Remote input and output can not be switched ON or OFF when a problem occurs in the remote I/O modules. Therefore build an external monitoring circuit that will monitor any input signals that could cause a serious accident.

CAUTION

- Do not have control cables and connection cables bundled with or placed near by the main circuit and/or power cables. Wire those cables at least 100mm(3.94 inch) away from the main circuit and/or power cables. It may cause malfunction due to noise interference.
- Use the module and the connection cable without applying any force on them. Otherwise, such cables may be broken or fail.

[INSTALLATION PRECAUTIONS]

CAUTION

- Use the module in an environment that meets the general specifications contained in this manual. Using this module in an environment outside the range of the general specifications could result in electric shock, fire, erroneous operation, and damage to or deterioration of the product.
- Do not directly touch the module's conductive parts. Doing so could cause malfunction or trouble in the module.
- Tighten the module securely using DIN rail or installation screws within the specified torque range. If the screws are too loose, the module may drop from its installation position, short circuit, or malfunction. If the screws are too tight, the screws may be damaged, which may cause the module to drop from its installation position or short circuit.
- Install the module on a flat surface. If the mounting surface has concave and/or convex, an excessive force may be applied on the module, and nonconformity may be caused.

[WIRING PRECAUTIONS]

WARNING

- Perform installation and wiring after disconnecting the power supply at all phases externally. If the power is not disconnected at all phases an electric shock or product damage may result.

CAUTION

- Perform correct wiring for the module according to the product's rated voltage and terminal arrangement. Connecting to a power supply different from rating or miss-wiring may cause fire, product failure or malfunction.
- Fix I/O terminal block securing screws securely within the regulated torque. Loose I/O terminal block securing screws may cause fire and/or malfunction. If the I/O terminal block securing screws are too tight, it may cause short circuit, equipment failures, or erroneous operation due to damage of the screws.
- Make sure foreign objects do not get inside the module, such as dirt and wire chips. It may cause fire, product failure or malfunction.
- Attach a warning label (hazard symbol 417-IEC-5036) concerning the electric shock to the location.

[STARTING AND MAINTENANCE PRECAUTIONS]

WARNING

- Do not touch the terminals when the power is ON. It may cause an electric shock or malfunction.
- Perform cleaning the module or retightening of terminal screws after turning OFF the all external power supply for sure. Failure to do so may cause failure or malfunction of the modules

CAUTION

- Do not disassemble or modify the module. Doing so may cause failure, malfunction, injury, or fire.
- The module case is made of resin; do not drop it or subject it to strong shock. A module damage may result.
- Make sure to switch all phases of the external power supply OFF before installing or removing the module to/from the panel. Failure to do so may cause failure or malfunction of the modules.

[DISPOSAL PRECAUTIONS]

CAUTION

- When disposing of this product, treat it as industrial waste.

[TRANSPORTATION AND MAINTENANCE PRECAUTIONS]

CAUTION

- During transportation avoid the impact which exceeds a regulated value as the module is a precision instrument. Doing so could cause trouble in the module.
- It is necessary to check the operation of module after transportation, in case of any impact damage. Otherwise, causes the damage of the machine and the accident.

●Note Concerning the CE Marking●

This note does not guarantee that an entire mechanical module produced in accordance with the contents of the notification comply with the following standards. Compliance to EMC standards of the entire mechanical module should be checked by the user / manufacturer.

Attention

- This product is designed for use in industrial applications.

Note

- Authorized Representative in the European Community:
Mitsubishi Electric Europe B.V.
Gothaer Str. 8, 40880 Ratingen, Germany

Standards with which this product complies

Type : Programmable Controller (Open Type Equipment) Remote I/O module

Models : Products manufactured:

from February 1st, 2004 to April 30th, 2006 are compliant with

EN61000-6-4 and EN61131-2:1994+A11:1996+A12:2000

after May 1st, 2006 are compliant with EN61131-2:2007

Electromagnetic Compatibility Standards (EMC)	Remark
EN61000-6-4:2001 Electromagnetic compatibility -Generic standards - Emission standard for Industrial environment	Compliance with all relevant aspects of the standard. (Radiated Emissions and Mains Terminal Voltage Emissions)
EN61131-2:1994/A11:1996/A12:2000 Programmable controllers -Equipment requirements and tests	Compliance with all relevant aspects of the standard. (RF Immunity, Fast transients, ESD and Damped oscillatory wave)

Electromagnetic Compatibility Standards (EMC)	Remark
EN61131-2: 2007 Programmable controllers -Equipment requirements and tests	Compliance with all relevant aspects of the standard. (Radiated Emissions, Conducted Emissions, Radiated electromagnetic field, Fast transient burst, Electrostatic discharge, High-energy surge, Voltage drops and interruptions, Conducted RF and Power frequency magnetic field)

For more details please contact the local Mitsubishi Electric sales site.

- Notes for compliance to EMC regulation.

It is necessary to install the CL1 series module in a shielded metal control panel.

- Use this product in Zone A^{*1} as defined in EN61131-2.

^{*1} Zone defined in EN61131-2

Separation defined in EN61131-2 for EMC LVD regulation decided depending on condition in industrial setting.

Zone C = Factory mains which is isolated from public mains by dedicated transformers.

Zone B = Dedicated power distribution which is protected by secondary surge protection. (300V or less in the rated voltage is assumed.)


Zone A = Local power distribution which is isolated from dedicated power distribution by AC/DC converters, isolation transformers, etc. (120V or less in the rated voltage is assumed.)

1. Outline of Product

This product is a spring clamp terminal block type input module connected to CC-Link/LT.

This product has four input points (24V DC).

2. Name and Setting of Each Part and Terminal Arrangement



Clamping torque range of terminal block securing screws 0.425 to 0.575 N·m

Name	Description
PW	ON while the power is supplied.
L RUN	ON while normal operation is executed.
L ERR.	ON: When a communication error or DIP switch setting error occurred Flickering at a constant interval: When the setting of the DIP switch was changed while the power was supplied (even while the LED is flickering, the operation continues. The new setting becomes valid when the power is turned OFF once, then ON again.) Flickering at an intermittent interval: When a terminal resistor is not attached or when the module or a connection cable is affected by noise

Name	Description																								
Input operation indicator LED	ON while the input is ON. Extinguished while the input is OFF. <div><div>0123</div><div>○ ○ ○ ○</div><div>Input operation indicator</div></div>																								
Interface	Connector for CC-Link/LT communication line/module power supply (24G/DB/DA/+24V)																								
Terminal block for I/O interface	spring clamp terminal block for connecting input signals and I/O power supply																								
DIP switch *	<p>Set the 10's digit of the station No. using "STATION NO. 10", "STATION NO. 20" and "STATION NO. 40". Set the 1's digit of the station No. using "STATION NO. 1", "STATION NO. 2", "STATION NO. 4" and "STATION NO. 8". Factory default = All bits are OFF. Make sure to set the station No. in the range from 1 to 64. If any station No. outside the range from 1 to 64 is set, it is regarded as an error and the L ERR. LED lights.</p> <p>Example: When setting the station No. to "32", set the DIP switch as follows.</p> <table><tr><th>Station No.</th><th>10's digit</th><th colspan="6">1's digit</th></tr><tr><td></td><td>40</td><td>20</td><td>10</td><td>8</td><td>4</td><td>2</td><td>1</td></tr><tr><td>32</td><td>OFF</td><td>ON</td><td>ON</td><td>OFF</td><td>OFF</td><td>ON</td><td>OFF</td></tr></table> <p>0.5ms Sets the response speed. 1.5ms ON : 0.5 ms (fast response type) OFF : 1.5 ms (standard type)</p>	Station No.	10's digit	1's digit							40	20	10	8	4	2	1	32	OFF	ON	ON	OFF	OFF	ON	OFF
Station No.	10's digit	1's digit																							
	40	20	10	8	4	2	1																		
32	OFF	ON	ON	OFF	OFF	ON	OFF																		

* Set up using a slotted screwdriver with a tip width of 0.9 mm or less.

3. Installation

The CL1X4-D1S2 can be installed to DIN rail or directly installed using mounting screws.


Each installation procedure is described below.

3.1 Installation to DIN rail

When installing the module, align the upper DIN rail installation groove on the module with the DIN rail 1), and press the module on to the DIN rail 2). When removing the module, pull the hook downward for installation to DIN rail 3), then remove the module 4).

DIN rail mounting screw pitch

When installing the module to the DIN rail, tighten the mounting screws at the pitch of 200mm(7.87") or less.



Applicable DIN rail	TH35-7.5Fe and TH35-7.5Al Width:35mm
---------------------	---

3.2 Direct installation

Screw-tighten the module by attaching M4 screws to the upper and lower mounting holes (two holes in all) provided in the module.

Install the module so that the clearance of 1 to 2mm (0.04" to 0.08") is assured for each module.

Applicable screw	M4 × 0.7mm(0.03") × 16mm(0.63") or more (Tightening torque range: 0.78 to 1.08 N·m)
------------------	--

4. Wiring

4.1 Wiring operation of cable

1) Installation of cable

Insert the tool for spring clamp terminal block in the tool insertion entrance of CL1X4-D1S2 (square hole) up to the interior surely. Insert the electric wire in the electric wire insertion entrance (round hole) with the tool for spring clamp terminal block inserted, and pull out the tool.

MITSUBISHI
ELECTRIC

Side
A

Side
B

JAPANESE

ENGLISH

CL1X4-D1S2

CC-Link/LT Remote I/O Module

Please read this manual thoroughly before starting to use the product and handle the product properly.

User's Manual

MODEL	CL1X4-D1S2
MANUAL Number	JY997D10801G
Date	April 2015

●SAFETY PRECAUTIONS●

(Read these precautions before using)

Please read this manual carefully and pay special attention to safety in order to handle this product properly. Also pay careful attention to safely and handle the module properly.

These precautions apply only to Mitsubishi equipment. Refer to the user's manual of the CPU module to use for a description of the PLC system safety precautions.

These ●SAFETY PRECAUTIONS● classify the safety precautions into two categories: "WARNING" and "CAUTION".

<div><div><div></div><div>WARNING</div></div></div>	Procedures which may lead to a dangerous condition and cause death or serious injury if not carried out properly.
<div><div><div></div><div>CAUTION</div></div></div>	Procedures which may lead to a dangerous condition and cause superficial to medium injury, or physical damage only, if not carried out properly.

Depending on circumstances, procedures indicated by **CAUTION** may also be linked to serious results.

In any case, it is important to follow the directions for usage.

Store this manual in a safe place so that you can take it out and read it whenever necessary. Always forward it to the end user.

DESIGN PRECAUTIONS

<div><div><div></div><div>WARNING</div></div></div>	<ul style="list-style-type: none">Configure an interlock circuit in a sequence program so that the system operates on the safety side using the communication status information in the event the data link falls into a communication problem.Otherwise, erroneous output and malfunction may result in accidents.Remote input and output can not be switched ON or OFF when a problem occurs in the remote I/O modules. Therefore build an external monitoring circuit that will monitor any input signals that could cause a serious accident.
---	---

<div><div><div></div><div>CAUTION</div></div></div>	<ul style="list-style-type: none">Do not have control cables and connection cables bundled with or placed near by the main circuit and/or power cables. Wire those cables at least 100mm(3.94 inch) away from the main circuit and/or power cables. It may cause malfunction due to noise interference.Use the module and the connection cable without applying any force on them.Otherwise, such cables may be broken or fail.
---	---

INSTALLATION PRECAUTIONS

<div><div><div></div><div>CAUTION</div></div></div>	<ul style="list-style-type: none">Use the module in an environment that meets the general specifications contained in this manual. Using this module in an environment outside the range of the general specification could result in electric shock, fire, erroneous operation, and damage to or deterioration of the product.Do not directly touch the module's conductive parts. Doing so could cause malfunction or trouble in the module.Tighten the module securely using DIN rail or installation screws within the specified torque range.If the screws are too loose, the module may drop from its installation position, short circuit, or malfunction. If the screws are too tight, the screws may be damaged, which may cause the module to drop from its installation position or short circuit.Install the module on a flat surface.If the mounting surface has concave and/or convex, an excessive force may be applied on the module, and nonconformity may be caused.
---	---

WIRING PRECAUTIONS

<div><div><div></div><div>WARNING</div></div></div>	<ul style="list-style-type: none">Perform installation and wiring after disconnecting the power supply at all phases externally. If the power is not disconnected at all phases an electric shock or product damage may result.
<div><div><div></div><div>CAUTION</div></div></div>	<ul style="list-style-type: none">Perform correct wiring for the module according to the product's rated voltage and terminal arrangement. Connecting to a power supply different from rating or miss-wiring may cause fire, product failure or malfunction.Fix I/O terminal block securing screws securely within the regulated torque. Loose I/O terminal block securing screws may cause fire and/or malfunction. If the I/O terminal block securing screws are too tight, it may cause short circuit, equipment failures, or erroneous operation due to damage of the screws.Make sure foreign objects do not get inside the module, such as dirt and wire chips. It may cause fire, product failure or malfunction.Attach a warning label (hazard symbol 417-IEC-5036) concerning the electric shock to the location.

STARTING AND MAINTENANCE PRECAUTIONS

<div><div><div></div><div>WARNING</div></div></div>	<ul style="list-style-type: none">Do not touch the terminals when the power is ON. It may cause an electric shock or malfunction.Perform cleaning the module or retightening of terminal screws after turning OFF the all external power supply for sure. Failure to do so may cause failure or malfunction of the modules
---	---

<div><div><div></div><div>CAUTION</div></div></div>	<ul style="list-style-type: none">Do not disassemble or modify the module. Doing so may cause failure, malfunction, injury, or fire.The module case is made of resin; do not drop it or subject it to strong shock. A module damage may result.Make sure to switch all phases of the external power supply OFF before installing or removing the module to/from the panel. Failure to do so may cause failure or malfunction of the modules.
---	--

DISPOSAL PRECAUTIONS

<div><div><div></div><div>CAUTION</div></div></div>	<ul style="list-style-type: none">When disposing of this product, treat it as industrial waste.
---	---

TRANSPORTATION AND MAINTENANCE PRECAUTIONS

<div><div><div></div><div>CAUTION</div></div></div>	<ul style="list-style-type: none">During transportation avoid the impact which exceeds a regulated value as the module is a precision instrument. Doing so could cause trouble in the module.It is necessary to check the operation of module after transportation, in case of any impact damage.Otherwise, causes the damage of the machine and the accident.
---	--

●Note Concerning the CE Marking●

This note does not guarantee that an entire mechanical module produced in accordance with the contents of the notification comply with the following standards: Compliance to EMC standards of the entire mechanical module should be checked by the user / manufacturer.

Attention

This product is designed for use in industrial applications.

Note

- Authorized Representative in the European Community:
Mitsubishi Electric Europe B.V.
Gothaer Str. 8, 40880 Ratingen, Germany

Standards with which this product complies

Type : Programmable Controller (Open Type Equipment) Remote I/O module

Models : Products manufactured from February 1st, 2004 to April 30th, 2006 are compliant with EN61000-6-4 and EN61131-2:1994+A11:1996+A12:2000 after May 1st, 2006 are compliant with EN61131-2:2007

Electromagnetic Compatibility Standards (EMC)	Remark
EN61000-6-4:2001 Electromagnetic compatibility -Generic standards - Emission standard for Industrial environment	Compliance with all relevant aspects of the standard. (Radiated Emissions and Mains Terminal Voltage Emissions)
EN61131-2:1994/A11:1996/A12:2000 Programmable controllers -Equipment requirements and tests	Compliance with all relevant aspects of the standard. (RF Immunity, Fast transients, ESD and Damped oscillatory wave)

Electromagnetic Compatibility Standards (EMC)	Remark
EN61131-2: 2007 Programmable controllers -Equipment requirements and tests	Compliance with all relevant aspects of the standard. (Radiated Emissions, Conducted Emissions, Radiated electromagnetic field, Fast transient burst, Electrostatic discharge, High-energy surge, Voltage drops and interruptions, Conducted RF and Power frequency magnetic field)

For more details please contact the local Mitsubishi Electric sales site.

- Notes for compliance to EMC regulation.

It is necessary to install the CL1 series module in a shielded metal control panel.

- Use this product in Zone A*1 as defined in EN61131-2.

*1 Zone defined in EN61131-2

Separation defined in EN61131-2 for EMC LVD regulation decided depending on condition in industrial setting.

Zone C = Factory mains which is isolated from public mains by dedicated transformers.

Zone B = Dedicated power distribution which is protected by secondary surge protection. (300V or less in the rated voltage is assumed.)

Zone A = Local power distribution which is isolated from dedicated power distribution by AC/DC converters, isolation transformers, etc. (120V or less in the rated voltage is assumed.)

1. Outline of Product

This product is a spring clamp terminal block type input module connected to CC-Link/LT.

This product has four input points (24V DC).

2. Name and Setting of Each Part and Terminal Arrangement

Clamping torque range of terminal block securing screws | 0.425 to 0.575 N•m

Name	Description
PW	ON while the power is supplied.
L RUN	ON while normal operation is executed.
Status indicator LED	ON: When a communication error or DIP switch setting error occurred Fllickering at a constant interval: When the setting of the DIP switch was changed while the power was supplied (even while the LED is flickering, the operation continues. The new setting becomes valid when the power is turned OFF once, then ON again.) Fllickering at a intermittent interval: When a terminal resistor is not attached or when the module or a connection cable is affected by noise

Name	Description
Input operation indicator LED	ON while the input is ON. Extinguished while the input is OFF.
Interface	Connector for CC-Link/LT communication line/module power supply (24G/DB/DA+24V)
Terminal block for I/O interface	spring clamp terminal block for connecting input signals and I/O power supply
DIP switch *	Set the 10's digit of the station No. using "STATION NO. 10", "STATION NO. 20" and "STATION NO. 40". Set the 1's digit of the station No. using "STATION NO. 1", "STATION NO. 2", "STATION NO. 4" and "STATION NO. 8". Factory default = All bits are OFF. Make sure to set the station No. in the range from 1 to 64. If any station No. outside the range from 1 to 64 is set, it is regarded as an error and the L ERR. LED lights. Example: When setting the station No. to "32", set the DIP switch as follows. Station No. 40 20 10 8 4 2 1 32 OFF ON ON OFF OFF ON OFF Sets the response speed. ON : 0.5 ms (fast response type) OFF : 1.5 ms (standard type)

* Set up using a slotted screwdriver with a tip width of 0.9 mm or less.

3. Installation

The CL1X4-D1S2 can be installed to DIN rail or directly installed using mounting screws.

Each installation procedure is described below.

3.1 Installation to DIN rail

When installing the module, align the upper DIN rail installation groove on the module with the DIN rail 1), and press the module on to the DIN rail 2). When removing the module, pull the hook downward for installation to DIN rail 3), then remove the module 4).

DIN rail mounting screw pitch

When installing the module to the DIN rail, tighten the mounting screws at the pitch of 200mm(7.87") or less.

Applicable DIN rail	TH35-7.5Fe and TH35-7.5Al Width: 35mm
---------------------	--

3.2 Direct installation

Screw-tighten the module by attaching M4 screws to the upper and lower mounting holes (two holes in all) provided in the module.

Install the module so that the clearance of 1 to 2mm (0.04" to 0.08") is assured for each module.

Applicable screw	M4 × 0.7mm(0.03") × 16mm(0.63") or more (Tightening torque range: 0.78 to 1.08 N-m)
------------------	--

4. Wiring

4.1 Wiring operation of cable

1) Installation of cable

Insert the tool for spring clamp terminal block in the tool insertion entrance of CL1X4-D1S2 (square hole) up to the interior surely.

Insert the electric wire in the electric wire insertion entrance (round hole) with the tool for spring clamp terminal block inserted, and pull out the tool.

Confirm the light pull of the electric wire after the tool is pulled out, and clamping surely.

*1 When the electric wire flaking off length is too long, an electric shock or short-circuited between the adjoining terminals may result. It is likely not to come in contact surely when the electric wire flaking off length is too short.

2) Detaching of cable

Insert the tool for spring clamp terminal block in the tool insertion entrance of the detached terminal number (square hole) up to the interior surely, and pull out the electric wire.

3) Acceptable electric wire

Item	Specification
Size of acceptable electric wire	0.3 to 1.5 mm ² (AWG22 to 16)
Electric wire flaking off length	8(0.32") to 11(0.43") mm

4.2 External wiring

The input terminals of the CL1X4-D1S2 can be wired as positive common or negative common depending on the used sensor.

Positive common

Negative common

4.3 Connection to sensor

Positive common (NPN)

- When using a two-wire type sensor
- When using a three-wire type sensor

- When using a three-wire type sensor (when using the power supply for sensor other than 24V DC)

Negative common (PNP)

- When using a two-wire type sensor
- When using a three-wire type sensor

- When using a three-wire type sensor (when using the power supply for sensor other than 24V DC)

Replace * in the figure with the used input No.

Notes:

*1 Bleeder resistor

When connecting a two-wire type sensor or input equipment containing a parallel resistor, select a sensor or equipment whose leakage current is 1.7mA or less.

If the leakage current is more than 1.7mA, connect a bleeder resistor obtained in the following calculation formula.

Circuit image

The power capacity W of the bleeder resistor R is as follows:

$$W = \frac{(\text{Input voltage})^2}{R}$$

- Please set the response speed (DIP switch) according to the ON or OFF time of the input signal.
- When setting 1.5 ms:
Set both the ON and OFF time of the input signal to 1.5 ms or more.
- When setting 0.5 ms:
Set both the ON and OFF time of the input signal to 0.5 ms or more.

5. Specifications

5.1 General specifications

Item	Specification
Ambient working temperature	0 to 55°C (32 to 131°F)
Ambient storage temperature	-25 to 75°C (-13 to 167°F)
Ambient operating humidity	5 to 95%RH: Dew condensation shall not be considered.
Ambient storage humidity	5 to 95%RH: Dew condensation shall not be considered.
Vibration resistance (*1)	When intermittent vibration is present Frequency Acceleration Half amplitude 10 to 57Hz — 0.075mm 57 to 150Hz 9.8m/s ² — When continuous vibration is present Frequency Acceleration Half amplitude 10 to 57Hz — 0.035mm 57 to 150Hz 4.9m/s ² — 10 times in each of X, Y and Z directions (for 80 min)
Impact resistance (*1)	147 m/s ² , 3 times in each of X, Y and Z directions
Operating atmosphere	Corrosive gas shall not be present.

5.2 Input specifications

Item	Specification
Input method	DC input (External power supply of the input part)
Number of inputs	4 points
Isolation method	Isolation with photocoupler
Rated input voltage	24V DC
Rated input current	Approx. 4 mA
Operating voltage range	20.4 to 28.8V DC (24V DC -15% to +20%) Ripple ratio: Within 5%
Max. simultaneous ON input points	100% (at 24V DC)
ON voltage/ON current	19 V or more/3 mA or more
OFF voltage/OFF current	11 V or less/1.7 mA or less
Input resistance	5.6 kΩ
Response time	OFF→ON 0.5ms/1.5 ms or less (at 24V DC) Selected by DIP switch (default value = OFF/1.5ms). ON→OFF 0.5ms/1.5 ms or less (at 24V DC) Selected by DIP switch (default value = OFF/1.5ms).
Common wiring method	4 points/1 common (2 points) (terminal block two-wire type)

5.3 Performance specifications

Item	Specification
Voltage	20.4 to 28.8V DC (24V DC -15% to +20%) Ripple ratio: Within 5%
Current consumption	40mA (when all points are ON)
Initial current	70mA
Max. allowable momentary power failure period	PS1:1ms
Number of stations occupied	4-, 8- or 16-point mode: 1 station
Noise durability	500Vp-p Noise width: 1μs Cycle: 25 to 60 Hz (by noise simulator)
Withstand voltage	500V AC for 1 min between primary area (external DC terminal) and secondary area (internal circuit)
Isolation resistance	10 MΩ or more between primary area (external DC terminal) and secondary area (internal circuit) by 500V DC megger
Protection class	IP2X
I/O part connection method	Connection with spring clamp terminal block
Module installation method	DIN rail installation, mounted by screws of type M4 × 0.7mm(0.03") × 16mm(0.63") or larger Can be installed in six directions
Mass (weight)	0.06 kg (0.13 lbs)

6. Outside Dimensions

This manual confers no industrial property rights or any rights of any other kind, nor does it confer any patent licenses. Mitsubishi Electric Corporation cannot be held responsible for any problems involving industrial property rights which may occur as a result of using the contents noted in this manual.

Warranty

Mitsubishi will not be held liable for damage caused by factors found not to be the cause of Mitsubishi; machine damage or lost profits caused by faults in the Mitsubishi products; damage, secondary damage, accident compensation caused by special factors unpredictable by Mitsubishi; damages to products other than Mitsubishi products; and to other duties.

For safe use

- This product has been manufactured as a general-purpose part for general industries, and has not been designed or manufactured to be incorporated in a device or system used in purposes related to human life.
- Before using the product for special purposes such as nuclear power, electric power, aerospace, medicine or passenger movement vehicles, consult with Mitsubishi.
- This product has been manufactured under strict quality control. However when installing the product where major accidents or losses could occur if the product fails, install appropriate backup or failsafe functions in the system.

Country/Region	Sales office/Tel	Country/Region	Sales office/Tel
USA	Mitsubishi Electric Automation Inc. 500 Corporate Woods Parkway, Vernon Hills, IL 60061, USA Tel : +1-847-478-2100 MELCO-TEC Representacao Comercial e Assessoria Tecnica Ltda. Av. Paulista, 1430, 07A, Bela Vista, Sao Paulo CEP: 01311-200-SP Brazil Tel : +55-11-3145-2200	South Africa	CB-Electric Private Bag 2016, ZA-1600 Isando, South Africa Tel : +27-11-977-0770
Brazil	Mitsubishi Electric Europe B.V. German Branch Gothaer Strasse 8, D-40880 Ratingen, Germany Tel : +49-2102-486-0 Mitsubishi Electric Europe B.V. UK Branch Travellers Lane, Hatfield, Hertfordshire, AL10 9XB, UK Tel : +44-1470-27-6100 Mitsubishi Electric Europe B.V. Italian Branch Viale Colleoni 7-20884 Agrate Brianza (Milano), Italy Tel : +39-0362-60531	China	Mitsubishi Electric Automation (China) Ltd. No. 1386 Hongqiao Road, Mitsubishi Electric Automation Center, Changning District, Shanghai, China Tel : +86-21-2322-3030
Germany	Mitsubishi Electric Europe B.V. Spanish Branch Carretera de Ruiz 78-80 AC-420, E-08190 Sant Cugat del Valles (Barcelona), Spain Tel : +34-93-565-3131 Mitsubishi Electric Europe B.V. French Branch 25, Boulevard des Bouvets, F-92741 Nanterre Cedex, France Tel : +33-1-6568-5569	Taiwan	Saitoku Enterprise Co., Ltd. 6F, No. 105, Wugong 3rd Road, Wugu District, New Taipei City 24889, Taiwan, R.O.C. Tel : +886-2-2259-2469
UK	Mitsubishi Electric Europe B.V. Polish Branch ul. Krakowska 65, 20-080 Balon, Poland Tel : +48-12-630-47-00	Korea	Mitsubishi Electric Automation Korea Co., Ltd. 3F, 148-6, Gyeong-Dong, Gangseo-Gu, Seoul, 157-200, Korea Tel : +82-2-3660-9530
Italy	Mitsubishi Electric Europe B.V. Russian Branch Branch St Petersburg office Piskarevsky pr. 2, bld 2, lt "Sch", BC "Benua", office 720, 195027, St. Petersburg, Russia Tel : +7-812-633-3497	Singapore	Mitsubishi Electric Asia Pte. Ltd. Industrial Division 307, Alexandra Road, Mitsubishi Electric Building, Singapore, 159943 Tel : +65-6470-2308
Spain	Mitsubishi Electric Europe B.V. Thai Branch Bang-Chan Industrial Estate No.111 Soi Santhai 54, T.Kannayao, A.Kannayao, Bangkok 10230 Thailand Tel : +66-2506-3238	Thailand	Mitsubishi Electric Automation (Thailand) Co., Ltd. Bang-Chan Industrial Estate No.111 Soi Santhai 54, T.Kannayao, A.Kannayao, Bangkok 10230 Thailand Tel : +66-2506-3238
France	Mitsubishi Electric Europe B.V. Indonesian Branch P. T. Autokindo Sumbat Makmur Muara Karang Selatan, Block A / Utara No.1 Kar. No. 11, Kawasan Industri Pondokanyar, Jakarta-Utara 14440, P.O. Box 5045, Indonesia Tel : +62-21-663-0833	India	Mitsubishi Electric India Pvt. Ltd. 2nd Floor, Tower A & B, Cyber Greens, DLF Cyber City, DLF Phase-III, Gurgaon-122002 Tel : +91-1244-63-0300
Czech Republic	Mitsubishi Electric Europe B.V. Australian Branch 34B Victoria Road PO BOX11, Rydalmere, N.S.W.2116, Australia Tel : +61-2-9684-7777	Australia	Mitsubishi Electric Automation Pty. Ltd. 34B Victoria Road PO BOX11, Rydalmere, N.S.W.2116, Australia Tel : +61-2-9684-7777

MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE : TOKYO BUILDING, 2-7-3 MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN

When exported from Japan, this manual does not require application to the Ministry of Economy, Trade and Industry for service transaction permission.

Specifications subject to change without notice.