# **MITSUBISHI** AJ65BT-64AD **Analog-Digital Converter Module**

## **User's Manual**

(Hardware)

Thank you for buying the Mitsubishi general-purpose programmable controller MELSEC-A Series

Prior to use, please read both this manual and detailed manual thoroughly and familiarize yourself with the product.



MODEL	AJ65BT-64AD-U-H-E
MODEL	
CODE	13J892
IB(NA	.)- 66748-I(1112)MEE

91996 MITSUBISHI ELECTRIC CORPORATION

### SAFETY PRECAUTIONS

(Read these precautions before using this product.)

Before using this product, please read this manual and the relevant manuals carefully and pay full attention to safety to handle the product correctly. These precautions apply only to Mitsubishi equipment. Refer to the CPU module user's manual for a description of the programmable controller system safety precautions. In this manual, the safety precautions are classified into two levels: "\_\text{\text{NARNING}} " and "\_\_CAUTION".



Indicates that incorrect handling may cause hazardous conditions, resulting in death or severe injury. Indicates that incorrect handling may cause hazardous conditions, resulting in minor or moderate injury or property

Under some circumstances, failure to observe the precautions given under " 1 CAUTION" may lead to serious consequences. Make sure that the end users read this manual and then keep the manual in a safe place for future reference

### [Design Precautions]

### **↑** WARNING

• In the case of a communication failure in the network, data in the master module are held. Check the communication status information (SB, SW) and configure an

interlock circuit in the sequence program to ensure that the entire system will operate safely

### **∴** CAUTION

Do not install the control lines or communication cables together with the main circuit lines or power cables Keep a distance of 100mm (3.94 inches) or more between them.

Failure to do so may result in malfunction due to noise

#### [Installation Precautions]

### **↑** CAUTION

- Use the programmable controller in an environment that meets the general specifications in this manual Failure to do so may result in electric shock, fire, malfunction, or damage to or deterioration of the product.
- For protection of the switches, do not remove the cushioning material before
- Do not directly touch any conductive part of the module. Doing so can cause malfunction or failure of the module.
- Securely fix the module with a DIN rail or mounting screws. Tighten the screws within the specified torque range.

Undertightening can cause drop of the screw, short circuit or malfunction. Overtightening can damage the screw and/or module, resulting in drop, short

#### [Wiring Precautions]

### **↑** CAUTION

- Shut off the external power supply for the system in all phases before wiring. Failure to do so may result in damage to the product.
- Ground the FG terminals to the protective ground conductor dedicated to the programmable controller.
- Failure to do so may result in malfunction.
- Check the rated voltage and terminal layout before wiring to the module, and connect the cables correctly.
- Connecting a power supply with a different voltage rating or incorrect wiring may
- Use applicable solderless terminals and tighten them within the specified torque
- If any spade solderless terminal is used, it may be disconnected when the terminal screw comes loose, resulting in failure
- Tighten the terminal screw within the specified torque range. Undertightening can cause short circuit or malfunction. Overtightening can damage the screw and/or module, resulting in drop, short circuit, or malfunction.
- Prevent foreign matter such as dust or wire chips from entering the module. Such foreign matter can cause a fire, failure, or malfunction.
- Do not install the control lines or communication cables together with the main circuit lines or power cables. Failure to do so may result in malfunction due to
- Place the cables in a duct or clamp them.
- If not, dangling cable may swing or inadvertently be pulled, resulting in damage to the module or cables or malfunction due to poor contact.
- When disconnecting the cable from the module, do not pull the cable by the cable part. Loosen the screws of connector before disconnecting the cable. Failure to do so may result in damage to the module or cable or malfunction due to poor contact.

#### [Startup and Maintenance Precautions]

### **⚠CAUTION**

- Do not touch any terminal while power is on. Doing so may cause malfunction.
- Do not change the setting jumper while power is on. Doing so may cause failure or malfunction.
- Shut off the external power supply for the system in all phases before cleaning the module or retightening the terminal screws. Failure to do so may cause the module to fail or malfunction.
- Do not disassemble or modify the modules.
- Doing so may cause failure, malfunction, injury, or a fire.
- Do not drop or apply strong shock to the module. Doing so may damage the module.
- Shut off the external power supply for the system in all phases before mounting or removing the module to or from the panel. Failure to do so may cause the module to fail or malfunction.
- After the first use of the product, do not mount/remove the terminal block to/from
- the module more than 50 times (IEC 61131-2 compliant). Before handling the module, touch a grounded metal object to discharge the
- static electricity from the human body. Failure to do so may cause the module to fail or malfunction.

### [Disposal Precautions]

### **↑** CAUTION

. When disposing of this product, treat it as an industrial waste.

#### ●安全注章事项●

#### (使用之前请条必阅读)

在使用本产品之前,应仔细阅读本手册以及本手册中所介绍的相关手册,同时在充分注意安全的前 提下正确操作。

本注意事项仅记载与本产品有关的内容。关于可编程控制器系统方面的安全注意事项,请参阅CPU模

块的用户手册。 在"安全注意事项"中,安全注意事项被分为"\_\_\_\_\_\_警告"和 "\_\_\_\_\_注意"两个等级。

ĺ	⚠警告	表示错误操作可能造成危险后果,导致死亡或重伤事故。
Ì	⚠注意	表示错误操作可能造成危险后果,导致中度伤害、轻伤或财产损失。

此外,根据情况不同,即使标注为"\_\_\_\_\_注意"的事项也有可能会引发严重后果。 这两个等级的注意事项记载的均为重要内容, 请务必遵守。

请妥善保管本手册以备需要时取阅,并将本手册交给最终用户。

#### 【设计注意事项】

#### ▲警告

●数据链接出现通信异常时,将保持主站模块的数据。应使用通信状态信息,在顺控程序上配置互锁电路 以保证系统能安全运行

### ⚠注 意

●请勿将控制线及通信电缆与主电路及动力线等捆扎在一起或相互靠得太近。 应相距大约100mm以上距离。因为噪声有可能导致误动作。

#### 【安装注意事项】

#### ⚠注 意

- 应在详细手册记载的一般规格环境下使用模块。如果在一般规格范围以外的环境中使用模块,可能导致他 电、火灾、误动作、产品损坏或性能劣化。● 为保护开关,在安装前请勿拆除缓冲材料。
- 勿直接触碰模块的导电部分。否则可能导致模块误动作、故障

● 模块应通过DIN与轨或者签案螺栓切实地加以固定, 安装螺栓应在规定的扭矩范围内切实地扭紧。如果螺栓拧得过抡, 有可能导致掉落、短路或误动作。如果螺栓拧得过紧, 有可能造成螺栓及模块破损从而导致掉落、短路或误动作。

#### 【配线注意事项】

#### ⚠注 意

- ●在配线作业等时,必须将系统使用的外部供应电源全部断开后再进行操作。如果未全部断开,有可能导致
- 产品损坏。 ●必須将下端子与可编程控制器的专用接触线连接。否则有可能导致误动作。 ●进行模块配线作业时,应在确认产品的额定电压及端子排列的基础上正确进行操作。如果连接了与额定值 不符的电源或配线错误,可能导致火火或故阵。 应使用台龙的压装端子,并按规定扭矩拧紧。如果使用Y型压装端子,端子螺栓松动时可能导致脱落或故
- 应在规定的扭矩范围内拧紧端子螺栓。如果端子螺栓拧得讨松,有可能导致短路或误动作。如果端子螺栓

- ●应在规定的扭矩范围内打紧端了螺栓。如果骗了螺栓行得过松、有可能导致點路或误动作。如果骗了螺栓 扩得过紧,有可能造成螺栓及模块破损从而导致增杂、股路或误动作。
   ●应注意防止切屑及配线头等异物掉入模块内。否则有可能导致火灾、故障或误动作。
   ·请勿将控制线及通信电缆与主电路及动力线等漏扎在一起或相互靠得太近。因为噪声有可能导致误动作。
   ·与模块相连接的电线及电缆必须收入套管中,或者用夹具进行同定处理。如果未将电缆收入套管或用夹具进行同定处理,可能由于电缆的层动及移动、不经意的拉拽等造成模块及电缆破损、电缆接触不良而导致
- ●在拆卸与模块相连接的电缆时,请勿用手拉扯电缆部分。请在松开与模块连接的部分的螺栓后再拆卸电缆。如果在与模块连接的状态下拉扯电缆,可能导致模块及电缆破损,电缆接触不良而导致误动作。

#### 【启动/维护注意事项】

### ⚠注 意

- 在通电状态下诺勿触摸端子。否则可能导致误动作。 ●在通电状态下诺勿更改设置针脚。否则可能导致故障、误动作。 ●在语电状或重新紧固端子螺栓时,必须将系统使用的外部供应电源全部断开后再进行操作。如果未全部 断开,有可能导致模块或酸或误动作。 ●诸勿新解或改造模块。否则可能导致故障。误动作、人身伤害或火灾。 ●诸勿新解或改造模块。否则可能导致故障。

- ●请勿使模块掉落或受到强烈撞击。否则可能导致模块破损。●在控制盘内拆装模块时,必须将系统使用的外部供应电源全部断开后再进行操作。如果未全部断开,有可
- 能可求於"以降以於明"。 产品投入使用后,端子排的拆装次数不应超过50次。(根据IEC61131-2规范) 在触碰模块之前,必须先触碰已接地的金属等,释放掉人体等所携带的静电。如果不释放掉静电,有可能 导致模块故障或误动作。

### 【报废处理注意事项】

#### ⚠注 意

#### CONDITIONS OF USE FOR THE PRODUCT

(1) Mitsubishi programmable controller ("the PRODUCT") shall be used in conditions; i) where any problem, fault or failure occurring in the PRODUCT, if any, shall not lead to any major or serious accident; and

ii) where the backup and fail-safe function are systematically or automatically provided outside of the PRODUCT for the case of any problem, fault or failure occurring in the PRODUCT.

(2) The PRODUCT has been designed and manufactured for the purpose of being used in general industries

MITSUBISHI SHALL HAVE NO RESPONSIBILITY OR LIABILITY (INCLUDING, BUT NOT LIMITED TO ANY AND ALL RESPONSIBILITY OR LIABILITY BASED ON CONTRACT, WARRANTY, TORT, PRODUCT LIABILITY) FOR ANY INJURY OR DEATH TO PERSONS OR LOSS OR DAMAGE TO PROPERTY CAUSED BY the PRODUCT THAT ARE OPERATED OR USED IN APPLICATION NOT INTENDED OR EXCLUDED BY INSTRUCTIONS, PRECAUTIONS, OR WARNING CONTAINED IN MITSUBISHI'S USER, INSTRUCTION AND/OR SAFETY MANUALS, TECHNICAL BUILLETINS AND GUIDELINES FOR the PRODUCT ("Prohibited Application")

Prohibited Applications include, but not limited to, the use of the PRODUCT in;

- Nuclear Power Plants and any other power plants operated by Power companies, and/or any other cases in which the public could be affected if any problem or fault occurs in the PRODUCT.
- Railway companies or Public service purposes, and/or any other cases in which establishment of a special quality assurance system is required by the Purchaser or
- Aircraft or Aerospace, Medical applications, Train equipment, transport equipment such as Elevator and Escalator, Incineration and Fuel devices, Vehicles, Manned transportation, Equipment for Recreation and Amusement, and Safety devices, handling of Nuclear or Hazardous Materials or Chemicals, Mining and Drilling, and/or other applications where there is a significant risk of injury to the public or property

Notwithstanding the above, restrictions Mitsubishi may in its sole discretion, authorize use of the PRODUCT in one or more of the Prohibited Applications, provided that the usage of the PRODUCT is limited only for the specific applications agreed to by Mitsubishi and provided further that no special quality assurance or fail-safe, redundant or other safety features which exceed the general specifications of the PRODUCTs are required. For details, please contact the Mitsubishi representative in your region.

### **About Manuals**

The following manuals are also related to this product.

In necessary, order them by quoting the details in the tables below.

#### Detailed Manual

Manual Name	Manual No. (Type code)
AJ65BT-64AD Analog-Digital Converter Module User's Manual	SH-3614 (13J893)

### Related Manuals

Manual Name	Manual No. (Type code)
CC-Link System Master/Local Module Type AJ61BT11/A1SJ61BT11 User's Manual	IB-66721 (13J872)
CC-Link System Master/Local Module Type AJ61QBT11/A1SJ61QBT11 User's Manual	IB-66722 (13J873)
CC-Link System Master/Local Module User's Manual	SH-080394E (13JR64)
MELSEC-L CC-Link System Master/Local Module User's Manual	SH-080895ENG (13JZ41)

#### COMPLIANCE WITH EMC AND LOW VOLTAGE DIRECTIVES

(1) Method of ensuring compliance

To ensure that Mitsubishi programmable controllers maintain EMC and Low Voltage Directives when incorporated into other machinery or equipment, certain measures may be necessary. Please refer to one of the following

· User's manual for the CPU module or head module used

Safety Guidelines

(This manual is included with the CPU module, base unit, or head module.) The CE mark on the side of the programmable controller indicates

compliance with EMC and Low Voltage Directives (2) Additional measures

To ensure that this product maintains EMC and Low Voltage Directives, please refer to one of the manuals listed under (1).

### 1. Overview

This user's manual describes the specification, name of each part and wiring for the AJ65BT-64AD analog-digital converter module (abbreviated as AJ65BT-64AD from here on), used as a CC-Link system remote device station.

After unpacking, confirm if the following item is included.

Item name	Numbers of item
AJ65BT-64AD main module	1

### 2. Performance Specifications

#### Performance Specifications

The AJ65BT-64AD performance specification is described below Refer to CPU module User's Manual to be used for general specification of

ltem	Specification				
Analog input	Voltage: -10 to 0 to 10V DC (input resistance $1M\Omega$ ) Selected by the Current: -20 to 0 to 20mA DC (input resistance $250\Omega$ ) input terminal				
Digital output	16-bit encoded binary (data area 12bits)				
I/O characteristics *1	Analog input value	Digital output value			
	-10 to 10V or -20 to 20mA 0 to 10V or 0 to 20mA 0 to 5V or 0 to 20mA 1 to 5V or 4 to 20mA	0 to 4000 or -2000 to 2000 0 to 4000 or -2000 to 2000 0 to 4000 or -2000 to 2000 0 to 4000 or -2000 to 2000			
Maximum resolution	-10 to 10V or -20 to 20mA 0 to 10V or 0 to 20mA 0 to 5V or 0 to 20mA 1 to 5V or 4 to 20mA	5mV or 20μΑ 2.5mV or 10μΑ 1.25mV or 5μΑ 1mV or 4μΑ			
Total precision *2	±1%	(±40)			
Maximum conversion speed	1 ms/c	hannel			
Absolute maximum input	Voltage ±15 V,	current ±30mA <sup>*3</sup>			
Analog input points	4 channels/module				
Insulation method	Photo-coupler insulation between power supply/communication and analog input (not insulated between channels)				
CC-Link station type	Remote device station				
Number of occupied stations	2 stations				
Connection terminal	27-point terminal block				
External power supply	24VDC (18 to 30VDC)				
Supported cable size	0.75 to 2.00mm <sup>2</sup>				
Module mounting screws	M4 x 0.7 mm x 16mm or more (M4 x 0.028 inch x 0.63 inch) Can be installed with DIN rail.				
Supported DIN rail	TH35-7.5Fe, TH35-7.5Al, TH35-15Fe (conforming to JIS C 2812)				
Supported solderless terminal	RAV 1.25-3.5, RAV 2-3.5				
Internal consumption current	0.12 A (at 24VDC)				
Noise durability	By a noise simulator with the following specification: Noise voltage at 500Vp-p, Noise width at 1µs, Noise frequency at 25 to 60Hz				
Dielectric withstand voltage	Between power supply/communication system batch and analog input batch:500VAC, 1minute				
Insulation resistor	Between power supply/communication system batch and analog input batch:500VDC, more than 10MΩ on insulation resistance tester.				
Weight	0.35 (0.7	7) kg(lb.)			


- \*1 Gain is set to 10V/20mA and the offset is set to 0V/4mA (setting pin A) at the time of
- However, when using for current, change the set pin B, and the RYn1 (voltage/current selection) must be turned on.
- \*2 This is the accuracy in respect to the maximum digital output value (+4000). The same value (+4000) applies for the current input and voltage input.
- \*3 Current value indicates value of instant input current that does not break module inner

Point	
The range	for the analog input for conversion is as follows:
Volta	ge : -10 to 0 to 10V
Curre	ent : -20 to 0 to 20mA

## 3. Name of Each Part and their settings

### 3.1 Name of Each Part

The name of each part and their settings in the AJ65BT-64AD are shown




No.	Name and appearance	Description		
1)	Station number setting switch	1)×10	the range 1 to 64.	
2)	Transmission baud rate setting	Setting number	Transmission baud rate	
	switch	0	156kbps (factory default)	
		1	625kbps	
		2	2.5Mbps	
		3	5Mbps	
		4	10Mbps	
		Other than 0 to 4	Unusable. (The L ERR. LED turns on, and results in a communication error.)	

	Name and	1			
No.	appearance	Description			
3)	Channel	Selects the channel (1 to 4) to perform the offset and gain			
	selection switch	adjustment. When a value other than 1 to 4 is selected, no processing is performed. (factory default: 1)			
4)	OFFSET switch			the test mode, the analog input	
		value at that tin	me is stored in th	e AJ65BT-64AD as an offset value.	
5)	GAIN switch			the test mode, the analog input	
- 0)	DECETit-b			e AJ65BT-64AD as a gain value.	
6)	RESET switch			als, remote register, and operation AJ65BT-64AD. By turning this switch	
				ta processing request flag turns on.	
7)	Operation status	LED Name		Description	
	display LED	PW LED	ON : Power s		
			OFF : Power s		
		RUN LED	Normal mode	ON : Normal operation.	
				Flashing : Read/write data error occurred.	
				OFF : 24VDC power supply	
				shutoff or watchdog	
				timer error occurred.	
			Test mode	ON : Offset switch or gain switch is ON.	
				OFF: Offset switch or gain switch is OFF.	
		L RUN LED ON : Normal communic			
		00   50		nication cutoff (time expiration error)	
		SD LED RD LED	ON during data ON during data		
		L ERR. LED		a receive : Communication data error	
		L ERR. LED		: Communication data error : Communication data error	
				: Normal communication	
8)	Terminal module	1 3 5 DA DG +22	7 9 11 11 CH1 V+ 0	3 15 17 19 21 23 25 27 CH2 CH3 CH4 TOM V+ GOM I+ SLD I+ SLD FG1	
				14 16 18 20 22 24 26 CH2 CH3	
		DB SLD (FG) TEST TEST I+ SLD I+ V+ COM V+ COM AG		SLD I+ V+ COM V+ COM AG	
		Test mode setting terminal: By short-circuiting between the terminals, the test mode is started.  Set the analog input range.			
9)	Analog input			mindio, are test mode is started.	
.,	range setting pin	I	Voltage	Current	
		Α	0 to 10V	(0 to 20mA)*	
	C A B	В	1 to 5V	4 to 20mA	
		С	-10 to 10V	-20 to 20mA	
		D	0 to 5V	0 to 20mA	
		(Factory defau			
			* When u	sing in the range 0 to 20mA, use D.	

#### 3.2 Offset/Gain Setting

When changing the I/O conversion characteristics, follow the procedure below.



Remark

- The offset value and gain value are as follows.

  (a) The offset value is the analog input value (voltage or current) which a
- minimum digital output value.

  (b) The gain value is the analog input value (voltage or current) which a maximum digital output value.

### 4. Loading and Installation

The following is explanations of the handling precautions and installation environment which is common to modules when handling AJ65BT-64AD from unpacking to installation.

For the details of loading and installation of the module, refer to User's Manual of programmable controller CPU module to be used.

#### 4.1 Handing Precautions

The precautions when handling the AJ65BT-64AD are described below:

(1) Because the case of the module is mad of resin, be careful not to drop it or expose it to strong impact.

(2) Perform the tightening of the module mounting screws in the following range.

Screw position	Tightening torque range	
Module mounting screw (M4 screw)	0.78 to 1.18N•m	
Terminal block terminal screw (M3.5 screw)	0.59 to 0.88N•m	
Terminal block mounting screw (M4 screw)	0.78 to 1.18N•m	

#### 4.2 Installation Environment

Do not install the A series programmable controller in the following environments.


- (1) Where the ambient temperature exceeds the 0 to 55°C range.
- Where the ambient humidity exceeds the 10 to 90 % RH range. Where condensation is produced by sudden temperature changes.
- Where corrosive or combustible gas is present. (5) Where dust, iron powder and other conductive powder, oil mist, salt, or organic solvents are prevalent.
- In direct sunlight.
- Where a strong electric or magnetic field is generated.
- Where vibration and shock may be applied directly to the module.

### Data Link Cable Wiring

The wiring of the CC-Link dedicated cable which connects the AJ65BT-64AD and the master module is described.

#### 5.1 CC-Link dedicated cable connections

The CC-Link dedicated cable connections between the AJ65BT-64AD and master module are as follows:



### Wiring

The precautions and module connection example for wiring are described.


#### 6.1 Wiring Precautions

To obtain maximum performance from the functions of AJ65BT-64AD and improve the system reliability, an external wiring with high durability against noise is required.

- The precautions when performing external wiring are as follows:

  (1) Use separate cables for the AC and AJ65BT-64AD external input signals, in order not to be affected by the AC side surge or conductivity.
- (2) Do not bundle or place with load carrying wires other than the main circuit line, hight voltage line, or programmable controller. Noises, surges, or
- (3) Place a one-point grounding on the programmable controller side for the shielded line or shielded cable. However, depending on the external noise conditions, it may be better have a grounding externally

#### 6.2 Module Connection Example




- Use a two-core twisted shield line for the power cable.
- Indicates the AJ65BT-64AD input resistor.
- For the current input, be sure to connect the (V+) and (I+) terminals.
- When noise or ripple occurs with the external cable, connect a condenser with about 0.1 to 0.47μF25WV between the terminal V and COM.

Always perform grounding for FG1. When there is a lot of noise, it may be

If the grounding wiring (grounding yes/no) is changed after the offset and gain are set, perform the setting of the offset/gain values again.

### 7. External Dimension Diagram



Mitsubishi will not be held liable for damage caused by factors found not to be the cause of Mitsubishi; machine damage or lost profits caused by faults in the Mitsubishi products; damage, secondary damage, accident compensation caused by special factors unpredictable by Mitsubishi; damages to products other than Mitsubishi products; and to other duties.

Country/Region Sales office/Tel			Country/Region Sales office/Tel		
	U.S.A	Mitsubishi Electric Automation Inc. 500 Corporate Woods Parkway Vernon Hills, IL 60061, U.S.A. Tel: +1-847-478-2100	China	Mitsubishi Electric Automation (China) Ltd. 4/F Zhi Fu Plazz, No.80 Xin Chang Road Shanghai 200003, China Tel: +86-21-6120-0808	
	Brazil	MELCO-TEC Rep. Com.e Assessoria Tecnica Ltda. Rua Correia Dias, 184, Edificio Paraiso Trade Center-8 andar Paraiso, Sao Paulo, SP Brazil Tel: +55-11-5908-8331	Taiwan	Setsuyo Enterprise Co., Ltd. 6F No.105 Wu-Kung 3rd.Rd, Wu-Ku Hsiang, Taipei Hsine, Taiwan Tel : +886-2-2299-2499	
	Germany	Mitsubishi Electric Europe B.V. German Branch Gothaer Strasse 8 D-40880 Ratingen, GERMANY Tel: +49-2102-486-0	Korea	Mitsubishi Electric Automation Korea Co., Ltd. 1480-6, Gayang-dong, Gangseo-ku Seoul 157-200, Korea Tel: +82-2-3660-9552	
	U.K	Mitsubishi Electric Europe B.V. UK Branch Travellers Lane, Hatfield, Hertfordshire., AL10 8XB, U.K. Tel: +44-1707-276100	Singapore	Mitsubishi Electric Asia Pte, Ltd. 307 Alexandra Road #05-01/02, Mitsubishi Electric Building, Singapore 159943 Tel: +65-6470-2480	
	Italy	Mitsubishi Electric Europe B.V. Italian Branch Centro Dir, Colleoni, Pal. Perseo-Ingr.2 Via Paracelso 12, I-20041 Agrate Brianza., Milano, Italy Tel: +39-039-60531	Thai <b>l</b> and	Mitsubishi Electric Automation (Thailand) Co., Ltd. Bang-Chan Industrial Estate No.111 Moo 4, Serithai Rd, T.Kannayao, A.Kannayao, Bangkok 10230 Thailand Tel: +66-2-517-1326	
	Spain	Mitsubishi Electric Europe B.V. Spanish Branch Carretera de Rubi 76-80, E-08190 Sant Cugat del Valles, Barcelona, Spain Tel: +34-93-565-3131	Indonesia	P.T. Autoteknindo Sumber Makmur Muara Karang Selatan, Block A/Utara No.1 Kav. No.11 Kawasan Industri Pergudangan Jakarta - Utara 14440, P.O.Box 5045 Jakarta, 11050 Indonesia Tel: +62-21-6630833	
	France	Mitsubishi Electric Europe B.V. French Branch 25, Boulevard des Bouvets, F-92741 Nanterre Cedex, France Tel : +33-1-5568-5568	India	Messung Systems Pvt, Ltd. Electronic Sadan NO:III Unit No15, M.I.D.C Bhosari, Pune-411026, India Tel: +91-20-2712-3130	
	South Africa	Circuit Breaker Industries Ltd. Private Bag 2016, ZA-1600 Isando, South Africa Tel: +27-11-928-2000	Australia	Mitsubishi Electric Australia Pty. Ltd. 348 Victoria Road, Rydalmere, N.S.W 2116, Australia Tel: +61-2-9684-7777	

#### AMITSUBISHI ELECTRIC CORPORATION

When exported from Japan, this manual does not require application to the Ministry of Economy, Trade and Industry for service transaction permission.

Specifications subject to change without notice.