

CPU Module Logging Configuration Tool/ GX LogViewer


Installation Instructions

Before Using the Product

Please read this document before use. Keep the document in a safe place for future reference.
Make sure that the end users read the document.

For the precautions on using, refer to the following manuals.

 QnUDVCP/LCPU User's Manual (Data Logging Function) [SH-080893ENG]

 MELSEC iQ-R CPU Module User's Manual (Application) [SH-081264ENG]

 GX LogViewer Version 1 Operating Manual [SH-080915ENG]

Notice

- Reprinting or reproducing the part or all of the contents of this document in any form for any purpose without the permission of Mitsubishi Electric Corporation is strictly forbidden.
- Although we have made the utmost effort to follow the revisions of the software and hardware, in some cases, unsynchronized matter may occur.
- The information in this document may be subject to change without notice.

Operating Environment

Item	Contents	
Personal computer	A personal computer on which Windows® operates	
CPU	Intel® Core™2 Duo Processor 2GHz or more	
Required memory	Windows® 7, Windows® 8, Windows® 8.1 (64-bit edition)	Recommended 2GB or more
	Windows® 7, Windows® 8, Windows® 8.1 (32-bit edition)	Recommended 1GB or more
	Windows Vista®	
	Windows® XP	
Available hard disk capacity	512MB or more	
Monitor	Resolution 1024 x 768 pixels or higher	
OS (English version)	Microsoft® Windows® 8.1 Operating System Microsoft® Windows® 8.1 Pro Operating System Microsoft® Windows® 8.1 Enterprise Operating System Microsoft® Windows® 8 Operating System Microsoft® Windows® 8 Pro Operating System Microsoft® Windows® 8 Enterprise Operating System Microsoft® Windows® 7 Starter Operating System Microsoft® Windows® 7 Home Premium Operating System Microsoft® Windows® 7 Professional Operating System Microsoft® Windows® 7 Ultimate Operating System Microsoft® Windows® 7 Enterprise Operating System Microsoft® Windows Vista® Home Basic Operating System ^{*1} Microsoft® Windows Vista® Home Premium Operating System ^{*1} Microsoft® Windows Vista® Business Operating System ^{*1} Microsoft® Windows Vista® Ultimate Operating System ^{*1} Microsoft® Windows Vista® Enterprise Operating System ^{*1} Microsoft® Windows® XP Professional Operating System SP2 or later ^{*1} Microsoft® Windows® XP Home Edition Operating System SP2 or later ^{*1}	

*1 64-bit version is not supported.

- For Windows® 8 and Windows® 8.1, if .NET Framework 3.5 (including .NET 2.0 and 3.0) or .NET Framework 4.5 (including .NET 4.0) is invalid, it needs to be valid.
- For Windows® 7, if .NET Framework 3.5 (including .NET 2.0 and 3.0) is invalid, it needs to be valid.
- When connecting to an RCPU on Windows® Vista, use Service Pack 1 or later.
- When connecting to an RCPU on Windows® XP, use Service Pack 3 or later.
- The following functions cannot be used. This product may not perform properly, when these functions are used.
 - Activating the application with Windows® compatible mode.
 - Simplified user switch-over
 - Remote desktop
 - Large font size (Advanced setting of Display Properties)
 - DPI setting other than 100% (set the size of text and illustration other than [smaller-100%])
 - Windows XP Mode
 - Windows Touch or Touch
 - Modern UI
 - Client Hyper-V
- Use the product as a user having a privilege higher than 'Standard user' or 'Administrator' for Windows Vista®, Windows® 7, Windows® 8, and Windows® 8.1.
- If the Windows firewall setting is enabled, the "Find Module function" and "Direct connection function" may not operate correctly. Disable the Windows firewall setting.
- The screens of this product may not perform properly when multi-display is set on Display Properties.
- The operations on the screen of this product may not be executed properly when the screen resolution is changed while the product is being activated.

Installation

■ Confirm before installation

- Log on to the personal computer as a user having the "Administrator" privilege (Administrator authority).
- Close all the applications running under Microsoft® Windows® Operating System before installation. If the product is installed while other applications are running, it may not operate normally.

1. Unzip the compressed folder.
2. Double-click 'setup.exe' in the unzipped folder to start installation.
3. Select or enter the necessary information by following the on-screen instructions.

Uninstallation


Uninstall CPU Module Logging Configuration Tool/GX LogViewer from the control panel of Windows®.

Installation of USB driver

In order to communicate with a programmable controller CPU via USB, a USB driver needs to be installed.

For a USB driver installation procedure, refer to the following manuals.

 QnUDVCP/LCPU User's Manual (Data Logging Function) [SH-080893ENG]

 MELSEC iQ-R CPU Module User's Manual (Application) [SH-081264ENG]

 GX LogViewer Version 1 Operating Manual [SH-080915ENG]

Software version and operating systems

The operating systems described in the table below are supported by the corresponding software version of CPU Module Logging Configuration Tool Version 1 (English Version).

Software version	Operating system
1.06G or later	Operating system in Simplified Chinese is supported.
1.07H or later	*32-bit Windows® 7* operating system is supported.
1.08J or later	Operating system in Korean is supported.
1.15R or later	Operating system in Traditional Chinese (Taiwan) is supported.
1.18U or later	*64-bit Windows® 7* operating system is supported.
1.32J or later	*32-bit Windows® 8* and *64-bit Windows® 8* operating systems are supported.
1.35M or later	*Windows® 8.1* operating system is supported.

The operating systems described in the table below are supported by the corresponding software version of GX LogViewer Version 1 (English Version).

Software version	Operating system
1.04E or later	Operating system in Simplified Chinese is supported.
1.05F or later	*32-bit Windows® 7* operating system is supported.
1.07H or later	Operating system in Korean is supported.
1.08J or later	Operating system in Traditional Chinese (Taiwan) is supported.
1.10L or later	*64-bit Windows® 7* operating system is supported.
1.32J or later	*32-bit Windows® 8* and *64-bit Windows® 8* operating systems are supported.
1.35M or later	*Windows® 8.1* operating system is supported.

Microsoft, Windows, and Windows Vista are either registered trademarks or trademarks of Microsoft Corporation in the United States, Japan, and other countries.

Intel is a trademark of Intel Corporation in the United States and other countries.

All other company names and product names used in this document are either trademarks or registered trademarks of their respective companies.