

## Before Using the Product

Before using the product, please read this manual. Make sure that the end users read this manual and then keep the manual in a safe place for future reference.

This product is a cover for an AD75CK cable clamp. The MELSEC iQ-R series system using an AD75CK cable clamp will be compliant with ship classification standards by attaching this cover.

### ■ Relevant manuals

Before using the product, please read the Safety Guidelines included with the base unit used, especially the following sections.

- SAFETY PRECAUTIONS
- CONDITIONS OF USE FOR THE PRODUCT
- EMC AND LOW VOLTAGE DIRECTIVES
- WARRANTY

### ■ Manuels correspondants

Avant d'utiliser ce produit, prière de lire les "Safety Guidelines" (directive de sécurité) fournies avec l'unité de base, en particulier dans les sections suivantes.

- PRÉCAUTIONS DE SÉCURITÉ
- CONDITIONS D'UTILISATION DE PRODUIT
- DIRECTIVES CEM ET BASSE TENSION
- GARANTIE

### ■ Packing list

Check that the following items are included in the package of the product.

Item	Quantity
Ship classification compliant cable clamp cover	4
Before Using the Product (this manual)	1

### ■ Operating ambient temperature


Use the product within the range of 0 to 55°C.

### ■ Température ambiante de fonctionnement


Ce produit doit être utilisé entre 0 et 55 °C.

### ■ Handling precautions

- To attach/remove a cover to/from an AD75CK cable clamp, keep a distance of 20mm or more between the cable clamp and the walls. (A distance of 10mm or more is required between the cover and the walls.)




- Wire the ground terminal with the AD75CK cable clamp and cables parallel so that the cable clamp cover is mounted.
- Wire the cables so that they do not sag by their own weight and damage the cable clamp cover.



Cable clamp cover

- Wire the cables so that the braided shield part of cables fixed by the AD75CK cable clamp is brought within the cable clamp cover.




Braided shield

### ■ Attachment/removal procedure

(a) Attaching a cover


Mount a cover to an AD75CK cable clamp in the direction of the arrow, and push it until it clicks.



(b) Removing a cover


① Pull the hook of the cover outward with your fingers.

② Pull the cover forward.



### ■ External dimensions

- When attached to an AD75CK cable clamp



(Unit: mm)

### ■ Information and services

For further information and services, please consult your local Mitsubishi representative.